

NPort 5400 Series

Quick Installation Guide

Version 7.4, July 2021

Technical Support Contact Information
www.moxa.com/support

MOXA[®]

© 2021 Moxa Inc. All rights reserved.

P/N: 1802054000317



Overview

Welcome to Moxa's NPort 5400 Series, a 4 port communication device that allows you to control RS-232 (for the NPort 5410), RS-422/485 (for the NPort 5430/5430I) or RS-232/422/485 (for the NPort 5450/5450I) serial devices over a TCP/IP based Ethernet. Besides, the NPort 5450-T and NPort 5450I-T are designed to use in wide temperature environment.

The NPort 5400 Series is a Moxa Green Product. Moxa's Green Products satisfy the RoHS directive of the European Parliament, and accordingly, do not contain cadmium and cadmium compounds, hexavalent chromium compounds, lead and lead compounds, mercury and mercury compounds, PBBs (polybrominated biphenyls), or PBDEs (polybrominated diphenyl ethers).

NOTE This equipment is intended to be used in a restricted area location.

Package Checklist

Before installing the NPort 5400, verify that the package contains the following items:

- 1 NPort 5400 4-port Serial Device Server
- Power adapter (Not included for the NPort 5450-T and 5450I-T)
- Power jack to 3-pin terminal block adapter
- Wall mount kit; including 6 screws (FTSx6 M3x4mm)
- Quick Installation Guide
- Warranty card

Optional Accessories

- DK-35A for 35 mm DIN-rail; including four screws (M3x8mm). It is not applicable to DNV.

NOTE Notify your sales representative if any of the above items is missing or damaged.

NOTE The equipment is intended to be supplied by an external power source (UL listed / IEC 60950-1 / IEC 62368-1), which output complies to ES1, PS2/LPS, output rating 12 to 48 VDC, 550 mA min., ambient temperature of 40 °C, 55 °C, or 75 °C min. (40 °C or 55 °C for the NPort 5410, NPort 5430, NPort 5450, NPort 5430I, and NPort 5450I; 75°C for the NPort 5450-T, and NPort 5450I-T). Moxa has power adapters with a wide temperature range (-40 to 75°C, -40 to 167°F), the PWR-12150-(plug type)-SB-T Series, for your reference.

NOTE Two supplies (a DC jack and terminal block) are provided, and they do not connect to the power at the same time.

NOTE If you are using a Class I adapter, the power cord needs to be connected to a socket-outlet with an earthing connection.

Hardware Introduction




ATTENTION

Before you connect the NPort 5400 to the DC power inputs, make sure the DC power source voltage is stable.


- The wiring of the input terminal block shall be installed by a skilled person.
- Wire type: Cu
- Only use 28 to 18 AWG wire size, torque value of 0.5 N·m.
- One individual conductor in a clamping point.

As shown in the following figures, the NPort 5410 has 4 Male DB9 ports, for the RS-232 interface, the NPort 5430/5430I has 4 5-pin terminal blocks, for the RS-422/485 interface, and the NPort 5450/5450I has 4 Male DB9 ports, for the RS-232/422/485 interface.


NPort 5410/5450/5450I



NPort 5430 / 5430I



NPort 5450-T / 5450I-T



Reset Button—Press the Reset button continuously for 5 sec to load factory defaults: Use a pointed object, such as a straightened paper clip

or toothpick, to press the reset button. This will cause the Ready LED to blink on and off. The factory defaults will be loaded once the Ready LED stops blinking (after about 5 seconds). At this point, you should release the reset button.

LED Indicators—the NPort 5400’s top panel contains six LED indicators, as described in the following table.

LED Name	LED Color	LED Function
Ready	Red	Steady on: Power is on and the NPort is booting up. Blinking: Indicates an IP conflict, or DHCP or BOOTP server did not respond properly.
	Green	Steady on: Power is on and the NPort is functioning normally. Blinking: The NPort has been located by the NPort Administrator’s Location function
	Off	Power is off, or power error condition exists.
Ethernet	Orange	10 Mbps Ethernet connection.
	Green	100 Mbps Ethernet connection.
	Off	Ethernet cable is disconnected, or has a short.
P1, P2, P3, P4	Orange	Serial port is receiving data.
	Green	Serial port is transmitting data.
	Off	No data is being transmitted or received through the serial port.

LCM Display Panel (not support in -T model)—When the NPort 5400 unit is powered up, you will see a display similar to:

N	P	5	4	1	0	_	6	1	4	0	5			
1	9	2	.	1	6	8	.	1	2	7	.	2	5	4

This is where NP5410_61405 is the server’s name, and 192.168.127.254 is the server’s IP address.

LCM Panel Operation (not support in -T model)—There are four buttons on the NPort 5400’s top panel used to operate the server’s LCM panel. Going from left to right, the buttons are:

Button	Action
MENU	Activates the main menu, or returns to a lower level.
^	Scrolls up through a list of items shown on the LCM panel’s second line.
~	Scrolls down through a list of items shown on the LCM panel’s second line.
SEL	Selects the option listed on the LCM panel’s second line.

Detailed LCM Panel Operating instructions can be found on the CD-ROM in the “NPort 5400 Series User’s Manual.”

Hardware Installation Procedure

STEP 1: After removing the NPort 5400 from the box, the first thing you should do is attach the power adaptor.

STEP 2: Connect the NPort 5400 to a network. Use a standard straight-through Ethernet cable to connect to a Hub or Switch. When setting up or testing the NPort 5400, you might find it convenient to connect

directly to your computer's Ethernet port. In this case, use a cross-over Ethernet cable.

STEP 3: Connect the NPort 5400's serial port to a serial device.


STEP 4: Placement Options

Wall or Cabinet Mounting

The NPort 5400 comes with two metal attachment plates for attaching the NPort 5400 to a wall or the inside of a cabinet. First, use two screws per bracket to attach the brackets to the rear of the NPort5400. Next, use two

screws per bracket to attach the NPort 5400 to a wall or cabinet.

The heads of the screws should be less than 6.0 mm in diameter, and the shafts should be less than 3.5 mm in diameter, as shown by the figure at the right.



DIN-Rail Mounting

DIN-rail attachments can be purchased separately to attach the product to a DIN-rail. When snapping the attachments to the DIN-rail, make sure that the stiff metal springs are at the top.




WARNING


The danger of an explosion is a high possibility if the battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.

NOTE The battery replacement must be handled by authorized personnel only. The warranty is voided if the product is disassembled, modified, or repaired in any way by any persons that are unauthorized to do so by Moxa Inc.

Wall Mount




DIN-Rail



Pull High/Low Resistors Setting for the RS-485

Port (applicable to the NPort 5450 model only)

DIP switches on the bottom of the NPort 5450 are used to set the pull high/low resistor values for each serial port.



Pull High/Low Resistors for the RS-485 Port

SW	1	2	3
	Pull High	Pull Low	Terminator
ON	1KΩ	1KΩ	120Ω
OFF	150KΩ	150KΩ	-

Software Installation Information

For the NPort's configuration, the default IP address of the NPort is:
LAN: Static IP = 192.168.127.254; netmask = 255.255.255.0

You may log in with the default account and password (account: **admin**; password: **moxa**) to change any settings to meet your network topology (e.g., IP address) or serial device (e.g., serial parameters). If you would like to apply the Real COM mode to your application, you will need to install the NPort's driver on your desktop. You may also refer to Moxa support website


<https://www.moxa.com/support/> for the user's manual, driver, the Device Search Utility (DSU), and more.

NOTE For the NPort with DB Male serial ports, you may refer to the DB9 Male Ports pin assignment section to loop back pin 2 and pin 3 for the RS-232 interface to carry out a self test on the device.

Pin Assignments and Cable Wiring

DB9 Male Port Pinouts

Pin assignments apply to the NPort 5410 (RS-232 only), 5450, and 5450I.




DB9 Male	Pin	RS-232	RS-422/ 4-wire RS-485	2-wire RS-485
	1	DCD	TxD-(A)	-
	2	RxD	TxD+(B)	-
	3	TxD	RxD+(B)	Data+(B)
	4	DTR	RxD-(A)	Data-(A)
	5	GND	GND	GND
	6	DSR	-	-
	7	RTS	-	-
	8	CTS	-	-


9	-	-	-
---	---	---	---

DB9 Wiring-NPort 5410/5450/5450I

DB9 Female to DB9 Male




DB9 Female to DB25 Male



Terminal Block Wiring- NPort 5430/5430I

Serial Device Signals NPort 5430/5430I



Environmental Specifications

Power requirements	
Input Voltage	12 to 48 VDC
Power Consumption:	
NPort 5410/5450/5450-T	365 mA max. @ 12 V
NPort 5430	320 mA max. @ 12 V
NPort 5430I	430 mA max. @ 12 V
NPort 5450I/5450I-T	550 mA max. @ 12 V

Operating temp.	
Standard Models	0 to 55°C (32 to 131°F)
Wide Temp. Models	-40 to 75°C (-40 to 167°F)
Operating humidity	5 to 95% RH
Dimensions (W×D×H)	158 × 33 × 103 mm 6.22 × 1.3 × 4.06 in
Serial line protection	Surge: Power: 1 kV; Signal: 1 kV; 2 KV isolation protection (the NPort 5430I/5450I models)
Magnetic isolation	1.5 KV for Ethernet
Power line protection	Level 3 Burst (EFT), EN 61000-4-4 Level 3 Surge, EN 61000-4-5
Regulatory approvals	FCC Part 15B Class A (5430/5430I), Class B (5410/5450/5450I), CE Class A, UL, DNV (for DC input only), LVD, EN 60601-1-2 Class B, EN 55011 (the NPort 5410/5450/5450I models only)