

# Moxa Industrial Secure Router CLI Command Set User's Manual

---

First Edition, June 2014

[www.moxa.com/product](http://www.moxa.com/product)

**MOXA**<sup>®</sup>

© 2014 Moxa Inc. All rights reserved.

# Moxa Industrial Secure Router CLI Command Set User's Manual

The software described in this manual is furnished under a license agreement and may be used only in accordance with the terms of that agreement.

## Copyright Notice

© 2014 Moxa Inc. All rights reserved.

## Trademarks

The MOXA logo is a registered trademark of Moxa Inc.  
All other trademarks or registered marks in this manual belong to their respective manufacturers.

## Disclaimer

Information in this document is subject to change without notice and does not represent a commitment on the part of Moxa.

Moxa provides this document as is, without warranty of any kind, either expressed or implied, including, but not limited to, its particular purpose. Moxa reserves the right to make improvements and/or changes to this manual, or to the products and/or the programs described in this manual, at any time.

Information provided in this manual is intended to be accurate and reliable. However, Moxa assumes no responsibility for its use, or for any infringements on the rights of third parties that may result from its use.

This product might include unintentional technical or typographical errors. Changes are periodically made to the information herein to correct such errors, and these changes are incorporated into new editions of the publication.

## Technical Support Contact Information

[www.moxa.com/support](http://www.moxa.com/support)

### Moxa Americas

Toll-free: 1-888-669-2872  
Tel: +1-714-528-6777  
Fax: +1-714-528-6778

### Moxa Europe

Tel: +49-89-3 70 03 99-0  
Fax: +49-89-3 70 03 99-99

### Moxa India

Tel: +91-80-4172-9088  
Fax: +91-80-4132-1045

### Moxa China (Shanghai office)

Toll-free: 800-820-5036  
Tel: +86-21-5258-9955  
Fax: +86-21-5258-5505

### Moxa Asia-Pacific

Tel: +886-2-8919-1230  
Fax: +886-2-8919-1231

# Table of Contents

<b>1. System Functions</b> .....	<b>1-1</b>
Command Modes.....	1-2
Command Sets.....	1-3
Restart and Reload Factory Default.....	1-3
System Information.....	1-4
User Account.....	1-7
Date and Time.....	1-8
Syslog and Warning.....	1-11
System Files.....	1-17
Security.....	1-18
Diagnostics.....	1-20
Network Services.....	1-23
<b>2. Interface and Routing Functions</b> .....	<b>2-1</b>
Command Modes.....	2-2
Command Sets.....	2-3
Interfaces.....	2-3
Routing.....	2-3
Multicast Routing.....	2-5
<b>3. NAT, VPN, and Firewall Functions</b> .....	<b>3-1</b>
Command Modes.....	3-2
Command Sets.....	3-3
<b>4. Layer 2 Functions</b> .....	<b>4-1</b>
Command Modes.....	4-2
Command Sets.....	4-3
Port.....	4-3
Port Mirror.....	4-6
show port monitor.....	4-6
Redundant Protocols.....	4-7
RSTP.....	4-8
Turbo Ring V2.....	4-13
Virtual LAN.....	4-18
Multicast.....	4-22
QoS and Rate Control.....	4-27
MAC Address Table.....	4-33

# System Functions

---

This chapter describes the commands of the system functions for Moxa industrial secure routers.

The following topics are covered in this chapter:

▣ **Command Modes**

▣ **Command Sets**

- Restart and Reload Factory Default
- System Information
- User Account
- Date and Time
- Syslog and Warning
- System Files
- Security
- Diagnostics
- Network Services

# Command Modes

Refer to the following tables for the command mode descriptions.

Mode	Access Method	Prompt	Exit Method	About This Mode
User EXEC	Begin a session with your router.	Router>	Enter logout or quit.	Use this mode to <ul style="list-style-type: none"><li>• Change terminal settings.</li><li>• Perform basic tests.</li><li>• Display system information.</li></ul>
Privileged EXEC	While in user EXEC mode, enter the enabled command.	Router#	Enter disable to exit.	Use this mode to verify commands that you have entered. Use a password to protect access to this mode.
Global configuration	While in privileged EXEC mode, enter the configure command.	router(config)#	To exit to privileged EXEC mode, enter exit or end, or press Ctrl-Z.	Use this mode to configure parameters that apply to the entire router.

# Command Sets

## Restart and Reload Factory Default

### reload

Use the **reload** privileged command on the router to restart Moxa Router. Use the **reload factory-default** privileged command to restore the router configuration to the factory default values.

#### Command

#### **reload [factory-default]**

Syntax	reload	Halt and perform a cold restart
Description	factory-default	Halt and perform a cold restart with factory default
Defaults	N/A	
Command Modes	Privileged EXEC	
Usage Guidelines	N/A	
Examples	<pre> router# reload factory-default      - Halt and perform a cold restart with factory default router# reload                      - Halt and perform a cold restart router# reload factory-default router# reload     Proceed with reload ? [Y/n] router# reload factory-default     Proceed with reload to factory default? [Y/n] </pre>	
Error messages	N/A	
Related commands	N/A	

## System Information

### hostname

To specify or modify the host name for the network server, use the **hostname** global configuration command. To return to the default, use the **no** form of this command.

#### Commands

**hostname** name

**no hostname**

Syntax Description	hostname	Set system's network name (maximum 30 characters)
	name	Router name string
Defaults	Name is the default router name with the serial number	
Command Modes	Global configuration	
Usage Guidelines	Maximum string tokens are 5. Maximum router name length is 40 characters.	
Examples	<pre>router(config)# hostname MOXA Ethernet Router EDR-810 router(config)# exit router# show system System Information   System Name           : MOXA Ethernet Router EDR-810   System Location       : Router Location   System Description    : MOXA EDR-810   Maintainer Information :   MAC Address           : 00:90:E8:1D:24:36   System Uptime        : 0d0h36m57s</pre>	
Error messages	Length of router hostname is too long	
Related commands	show system	

## snmp-server contact

To set the system contact string, use the **snmp-server contact** global configuration command. To remove the contact string, use the **no** form of this command.

### Commands

**snmp-server contact text**

**no snmp-server contact**

Syntax Description	snmp-server contact	Configure router maintainer contact information
	text	Maintainer contact information
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	"text" parameter can be set as string separated by space. Maximum string tokens are 5. Maximum length of router maintainer contact info is 40.	
Examples	<pre>router(config)# snmp-server contact     &lt;STRING:token1&gt;      - Maintainer contact information router(config)# no snmp-server contact</pre>	
Error messages	Length of maintainer info is too long	
Related commands	show snmp	

## snmp-server description

To set the system description string, use the **snmp-server description** global configuration command. To remove the description string, use the **no** form of this command.

### Commands

**snmp-server description text**

**no snmp-server description**

Syntax Description	snmp-server description	Configure router's system description
	text	Description string
Defaults	The default description is the model name.	
Command Modes	Global configuration	
Usage Guidelines	"text" parameter can be set as string separated by space. Maximum string tokens are 5. Maximum length of router maintainer contact info is 40.	
Examples	<pre>router(config)# snmp-server description MOXA PT Series router(config)# exit router# show system System Information   System Name       : Managed Redundant Router 09458   System Location   : Xindian No. 135 6F Taiwan   System Description : MOXA PT Series   Maintainer Information : 8860289191230   MAC Address       : 00:90:E8:1D:24:36   System Uptime     : 0d0h6m46s</pre>	



Error messages	Length of system description is too long
Related commands	show snmp

## snmp-server location

To set the system location string, use the **snmp-server location** global configuration command. To remove the location string, use the **no** form of this command.

### Commands

**snmp-server location** text

**no snmp-server location**

Syntax Description	snmp-server location	Configure router's system location
	text	Location string
Defaults	The default text is Router Location	
Command Modes	Global configuration	
Usage Guidelines	<p>"text" parameter can be set as string separated by space.</p> <p>Maximum string tokens are 5.</p> <p>Maximum length of router location is 80.</p>	
Examples	<pre>router(config)# snmp-server location &lt;STRING:token1&gt;      - Location string token 1 router(config)# no snmp-server location</pre>	
Error messages	Length of location is too long	
Related commands	show snmp	

## show system

Use **show system** command to display system identification settings.

### Command

**show system**

Syntax Description	show	Show running system information
	system	System hardware and software status
Defaults		
Command Modes	Privileged EXEC/ User EXEC	
Usage Guidelines	N/A	
Examples	<pre>router# show system System Information   System Name           : Managed Redundant Router 09458   System Location       : Xidian No. 135 6F Taiwan   System Description    : MOXA PT Series   Maintainer Information : 8860289191230</pre>	

	MAC Address : 00:90:E8:1D:24:36 System Uptime : 0d0h6m46s
Error messages	N/A
Related commands	snmp-server description snmp-server contact snmp-server location

## User Account

### username

Use the **username** global configuration command on the router to set the username and password of the local login user. Use the **no** form of this command to clear the password setting of the specified user.

#### Commands

**username { admin | user } password string**

**no username { admin | user } password**

Syntax Description	username	Configuration for login account authentication
	admin	Configure for account "admin"
	user	Configure for account "user"
	password	Specify the password
	string	Password string
Defaults	There is no password for each user	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	router(config)# username admin password moxa1234 router(config)# username user password moxa5678	
Error messages	N/A	
Related commands	show users	

### show users

Use the **show users** user EXEC command to display the username/password configuration.

#### Command

**show users**

Commands	users	Display login user settings
Defaults	N/A	
Command Modes	Privileged EXEC/ User EXEC	
Usage	N/A	

Guidelines	
Examples	router# show users Login account information: Name Password ----- admin user
Error messages	N/A
Related commands	username

## Date and Time

### clock set

Use the **clock set** global configuration command on the router to set the current router time.

#### Command

**clock set** hh:mm:ss month day year

Syntax Description	clock	Configure time-of-day clock
	set	Adjust the clock
	hh:mm:ss	hh:mm:ss
	month	1 ~ 12
	day	1 ~ 31
	year	2000 ~ 2037
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	router(config)# clock set 11:11:11 1 1 2010	
Error messages	Illegal parameters!	
Related commands	show clock	

### clock summer-time

Use the **clock summer-time** global configuration command on the router to enable the day light saving time offset and set the applied duration. Use the **no** form of this command to disable it.

#### Commands

**clock summer-time start-date** month week day hour

**clock summer-time end-date** month week day hour

**clock summer-time offset** offset-hour

Syntax Description	clock	Configure time-of-day clock
	summer-time	Configure Summer time parameter
	start-date	The date when summer time offset start

	end-date	The date when summer time offset end
	month	From 'Jan', 'January' or '1' to 'Dec', 'December', or '12'
	week	From '1st' or '1' to 'Last' or '6'
	day	From 'Sun', 'Sunday' or '1' to 'Sat', 'Saturday' or '7'
	hour	0 ~ 23
	offset	Summer time offset
	offset-hour	1 ~ 12
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	When configuring the summer time offset, the start-date and end-date must be configured correctly first.	
Examples	router(config)# clock timezon gm -4	
Error messages	Invalid parameter	
	Month must be configured as 'Jan', 'January' or a numerical '1'.	
	Week must be configured as '1st', '2nd', '3rd', '4th', '5th' or 'Last'	
	Day must be configured as 'Sun', 'Sunday' or a numerical '1'.	
	Hour must be in the range from 0 to 23.	
	Please input the correct start/end date of the summer time first!	
Related commands	show clock	

## clock timezone

Use the **clock timezone** global configuration command on the router to set the current time zone.

### Command

**clock timezone gm** offset-hour

Syntax Description	clock	Configure time-of-day clock
	timezone	Time zone hour shifting
	gm	Greenwich Mean Time
	offset-hour	-12 ~ 12
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	router(config)# clock timezon gm -4	
Error messages	Hour offset is out of range	
Related commands	show clock	

## ntp remote-server

Use the **ntp remote-server** global configuration command to enable the NTP or SNTP client function and configure the remote NTP server. Use the **no** form of this command to return to the default value.

### Commands

**ntp remote-server** server-addr-1 [server-addr-2] [**simple**]

**no ntp remote-server**

Syntax Description	ntp	Configure Network Time Protocol
	remote-server	Configure NTP/SNTP server for time query
	simple	Configure Simple Network Time Protocol instead of Network Time Protocol
	server-addr-1	IP address or DNS name
	server-addr-2	IP address or DNS name
Defaults	The default configuration contains one time server "time.nist.gov".	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	router(config)# ntp remote-server 192.168.127.1 time.stdtime.gov.tw	
Error messages	N/A	
Related commands	show clock	

## ntp server

Use the **ntp server** global configuration command to enable the router as an NTP server. Use the **no** form of this command to return to disable it.

### Commands

**ntp server**

**no ntp server**

Syntax Description	ntp	Configure Network Time Protocol
	server	Enable NTP server
Defaults	Default is disabled	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	router(config)# ntp server	
Error messages	N/A	
Related commands	show clock	

## show clock

Use the **show clock** user EXEC command to display the time-related setting.

### Command

#### show clock

Syntax Description	clock	Display the system clock
Defaults	N/A	
Command Modes	Privileged EXEC/ User EXEC	
Usage Guidelines	N/A	
Examples	<pre>router# show clock  Current Time      : Fri Jan 01 08:38:28 2010 Daylight Saving   Start Date     :   End Date       :   Offset         : Time Zone        : GMT-4:00 Time Server      : Query Period     : 600 sec NTP/SNTP Server  : Disabled</pre>	
Error messages	N/A	
Related commands	<pre>clock set clock summer-time clock timezone ntp refresh-time ntp remote-server ntp server</pre>	

## Syslog and Warning

### warning-notification system-event

Use **warning-notification system-event** global configuration commands to enable the system warning events trigger to email, relay, syslog or trap. Use the **no** form of this command to disable it.

### Commands

```
warning-notification system-event { cold-start | warm-start | config-changed | pwr1-trans-on |
pwr2-trans-on | pwr1-trans-off | pwr2-trans-off | auth-fail | password-changed | tacacs-auth-fail
| radius-auth-fail | topology-changed | coupling-changed | master-changed | rstp-admin-changed
| rstp-topology-changed | turbo-ring-break | di1-trans-on|di1-trans-off } { action action-index |
severity severity-level | active}
```

```
no warning-notification system-event { cold-start | warm-start | config-changed | pwr1-trans-on
| pwr2-trans-on | pwr1-trans-off | pwr2-trans-off | auth-fail | password-changed |
tacacs-auth-fail | radius-auth-fail | topology-changed | coupling-changed | master-changed |
rstp-admin-changed | rstp-topology-changed | turbo-ring-break | di1-trans-on|di1-trans-off }
active}
```

Syntax Description	warning-notification	Enable/disable warning notification with related events
	system-event	Configure system event warning
	cold-start	Enable/disable system cold start event
	warm-start	Enable/disable system warm start event
	config-changed	Enable/disable system configuration change event
	pwr1-trans-on	Enable/disable power 1 on event
	pwr2-trans-on	Enable/disable power 2 on event
	pwr1-trans-off	Enable/disable power 1 off event
	pwr2-trans-off	Enable/disable power 2 off event
	auth-fail	Enable/disable authentication failure event
	password-changed	Enable/disable password change event
	tacacs-auth-fail	Enable/disable TACACS+ authentication failure event
	radius-auth-fail	Enable/disable RADIUS authentication failure event
	topology-changed	Enable/disable topology change event
	coupling-changed	Enable/disable coupling change event
	master-changed	Enable/disable Turbo Ring v2 master change event
	rstp-admin-changed	Enable/disable RSTP root change event
	rstp-topology-changed	Enable/disable RSTP RSTP topology change event
	turbo-ring-break	Enable/disable Turbo Ring v2 break event
	di1-trans-on	Enable/disable DI on event
	di1-trans-off	Enable/disable DI off event
	action	Configure actions of events
	action-index	SNMP Trap, email, Syslog, or Relay 1
	severity	Configure event severity
severity-level	Emergency(0), Alert(1), Critical(2), Error(3), Warning(4), Notice(5), Information(6), Debug(7)	
active	Activate event waring	
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	action-index as follow, Trap only(1), Email only(2), Trap+Email(3), Syslog only(4), Trap+Syslog(5), Email+Syslog(6), Trap+Email+Syslog(7), Relay1 only(8), Trap+Relay1(9), Email+Relay1(10), Trap+Email+Relay1(11), Syslog+Relay1(12), Trap+Syslog+Relay1(13), Email+Syslog+Relay1(14), Trap+Email+Syslog+Relay1(15), Relay2 only(16), Trap+Relay2(17), Email+Relay2(18), Trap+Email+Relay2(19), Syslog+Relay2(20), Trap+Syslog+Relay2(21), Email+Syslog+Relay2(22), Trap+Email+Syslog+Relay2(23), Relay1+Relay2(24), Trap+Relay1+Relay2(25), Syslog+Relay1+Realy2(28), Email+Syslog+Relay1+Relay2(30), Trap+Email+Syslog+Relay1+Relay2(31), None(0) severity-level as follow, Emergency(0), Alert(1), Critical(2), Error(3), Warning(4), Notice(5), Information(6), Debug(7)	
Examples	N/A	

Error messages	N/A
Related commands	N/A

## warning-notification port-event

Use the **warning-notification port-event** interface configuration commands to enable the port warning event trigger to email, relay, syslog or trap. Use the **no** form of this command to disable it.

### Commands

**warning-notification port-event { event { link-on | link-off | traffic-overload rx-threshold duration} | action action-index [severity severity-level | active]}**

**no warning-notification port-event { event { link-on | link-off | traffic-overload} | active}**

Syntax Description	warning-notification	Enable/disable warning notification with related events
	port-event	Configure port event warning
	event	Configure events
	link-on	Enable/disable port link on event
	link-off	Enable/disable port link off event
	traffic-overload	Enable/disable port traffic overload event
	rx-threshold	Enable/disable port RX threshold event
	duration	Enable/disable port duration event
	action	Configure actions for port events
	action-index	SNMP Trap, email, Syslog, or Relay 1
	severity	Configure severity of port events
	severity-level	Emergency(0), Alert(1), Critical(2), Error(3), Warning(4), Notice(5), Information(6), Debug(7)
	active	Activate event warning
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	action-index as follow, Trap only(1), Email only(2), Trap+Email(3), Syslog only(4), Trap+Syslog(5), Email+Syslog(6), Trap+Email+Syslog(7), Relay1 only(8), Trap+Relay1(9), Email+Relay1(10), Trap+Email+Relay1(11), Syslog+Relay1(12), Trap+Syslog+Relay1(13), Email+Syslog+Relay1(14), Trap+Email+Syslog+Relay1(15), Relay2 only(16), Trap+Relay2(17), Email+Relay2(18), Trap+Email+Relay2(19), Syslog+Relay2(20), Trap+Syslog+Relay2(21), Email+Syslog+Relay2(22), Trap+Email+Syslog+Relay2(23), Relay1+Relay2(24), Trap+Relay1+Relay2(25), Syslog+Relay1+Relay2(28), Email+Syslog+Relay1+Relay2(30), Trap+Email+Syslog+Relay1+Relay2(31), None(0) severity-level as follow, Emergency(0), Alert(1), Critical(2), Error(3), Warning(4), Notice(5), Information(6), Debug(7)	
Examples		
Error messages	N/A	



Related commands	
------------------	--

## show relay-warning

Use the **show relay-warning** command to display the settings of the relay warning.

### Commands

**show relay-warning config**

**show relay-warning status**

Syntax Description	show	Show running system information																																																																																								
	relay-warning	Display relay warning configuration																																																																																								
	config	Relay warning configuration																																																																																								
	status	Current relay warning list																																																																																								
Defaults	N/A																																																																																									
Command Modes	Privileged EXEC / User EXEC																																																																																									
Usage Guidelines	N/A																																																																																									
Examples	<pre> router# show relay-warning config System Events Setting   Override Relay Warning Settings      : Disable   Power Input 1 failure(On-&gt;Off)      : Disable   Power Input 2 failure(On-&gt;Off)      : Disable   Turbo Ring Break                     : Disable --More-- Port Events Setting </pre> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Port</th> <th style="text-align: left;">Link</th> <th style="text-align: left;">Traffic Overload</th> <th style="text-align: left;">RX Threshold(%)</th> <th style="text-align: left;">Traffic Duration(s)</th> </tr> </thead> <tbody> <tr><td>1-1</td><td>Ignore</td><td>Disable</td><td>1</td><td>1</td></tr> <tr><td>1-2</td><td>Ignore</td><td>Disable</td><td>1</td><td>1</td></tr> <tr><td>1-3</td><td>Ignore</td><td>Disable</td><td>1</td><td>1</td></tr> <tr><td>1-4</td><td>Ignore</td><td>Disable</td><td>1</td><td>1</td></tr> <tr><td>1-5</td><td>Ignore</td><td>Disable</td><td>1</td><td>1</td></tr> <tr><td>1-6</td><td>Ignore</td><td>Disable</td><td>1</td><td>1</td></tr> <tr><td>1-7</td><td>Ignore</td><td>Disable</td><td>1</td><td>1</td></tr> <tr><td>1-8</td><td>Ignore</td><td>Disable</td><td>1</td><td>1</td></tr> <tr><td>3-1</td><td>Ignore</td><td>Disable</td><td>1</td><td>1</td></tr> <tr><td>3-2</td><td>Ignore</td><td>Disable</td><td>1</td><td>1</td></tr> <tr><td>3-3</td><td>Ignore</td><td>Disable</td><td>1</td><td>1</td></tr> <tr><td>3-4</td><td>Ignore</td><td>Disable</td><td>1</td><td>1</td></tr> <tr><td>3-5</td><td>Ignore</td><td>Disable</td><td>1</td><td>1</td></tr> <tr><td>3-6</td><td>Ignore</td><td>Disable</td><td>1</td><td>1</td></tr> <tr><td>3-7</td><td>Ignore</td><td>Disable</td><td>1</td><td>1</td></tr> <tr><td>3-8</td><td>Ignore</td><td>Disable</td><td>1</td><td>1</td></tr> </tbody> </table> <pre> router# </pre>					Port	Link	Traffic Overload	RX Threshold(%)	Traffic Duration(s)	1-1	Ignore	Disable	1	1	1-2	Ignore	Disable	1	1	1-3	Ignore	Disable	1	1	1-4	Ignore	Disable	1	1	1-5	Ignore	Disable	1	1	1-6	Ignore	Disable	1	1	1-7	Ignore	Disable	1	1	1-8	Ignore	Disable	1	1	3-1	Ignore	Disable	1	1	3-2	Ignore	Disable	1	1	3-3	Ignore	Disable	1	1	3-4	Ignore	Disable	1	1	3-5	Ignore	Disable	1	1	3-6	Ignore	Disable	1	1	3-7	Ignore	Disable	1	1	3-8	Ignore	Disable	1	1
Port	Link	Traffic Overload	RX Threshold(%)	Traffic Duration(s)																																																																																						
1-1	Ignore	Disable	1	1																																																																																						
1-2	Ignore	Disable	1	1																																																																																						
1-3	Ignore	Disable	1	1																																																																																						
1-4	Ignore	Disable	1	1																																																																																						
1-5	Ignore	Disable	1	1																																																																																						
1-6	Ignore	Disable	1	1																																																																																						
1-7	Ignore	Disable	1	1																																																																																						
1-8	Ignore	Disable	1	1																																																																																						
3-1	Ignore	Disable	1	1																																																																																						
3-2	Ignore	Disable	1	1																																																																																						
3-3	Ignore	Disable	1	1																																																																																						
3-4	Ignore	Disable	1	1																																																																																						
3-5	Ignore	Disable	1	1																																																																																						
3-6	Ignore	Disable	1	1																																																																																						
3-7	Ignore	Disable	1	1																																																																																						
3-8	Ignore	Disable	1	1																																																																																						
Error messages	N/A																																																																																									
Related commands	N/A																																																																																									

## show email-warning config

Use the **show email-warning config** command to display the settings of the email warning.

**Command**

**show email-warning config**

Syntax Description	show	Show running system information																																																																																													
	email-warning	Display Email warning configuration																																																																																													
	config	Email warning configuration																																																																																													
Defaults	N/A																																																																																														
Command Modes	Privileged EXEC /User EXEC																																																																																														
Usage Guidelines	N/A																																																																																														
Examples	<pre> router# show email-warning config Mail Server and Email Setup SMTP Server IP/Name  : SMTP Port           : 25 Account Name        : Account Password    :  1st email address : 2nd email address : 3rd email address : 4th email address :  System Events Cold Start          : Disable Warm Start          : Disable Conf. Changed       : Disable Power On-&gt;Off       : Disable Power Off-&gt;On       : Disable Auth. Failure       : Disable Topology Changed    : Disable  --More-- Port Events Setting </pre> <table border="1"> <thead> <tr> <th>Port</th> <th>Link ON</th> <th>Link OFF</th> <th>Traffic Overload</th> <th>RX Threshold(%)</th> <th>Traffic Duration(s)</th> </tr> </thead> <tbody> <tr><td>1-1</td><td>Disable</td><td>Disable</td><td>Disable</td><td>0</td><td>1</td></tr> <tr><td>1-2</td><td>Disable</td><td>Disable</td><td>Disable</td><td>0</td><td>1</td></tr> <tr><td>1-3</td><td>Disable</td><td>Disable</td><td>Disable</td><td>0</td><td>1</td></tr> <tr><td>1-4</td><td>Disable</td><td>Disable</td><td>Disable</td><td>0</td><td>1</td></tr> <tr><td>1-5</td><td>Disable</td><td>Disable</td><td>Disable</td><td>0</td><td>1</td></tr> <tr><td>1-6</td><td>Disable</td><td>Disable</td><td>Disable</td><td>0</td><td>1</td></tr> <tr><td>1-7</td><td>Disable</td><td>Disable</td><td>Disable</td><td>0</td><td>1</td></tr> <tr><td>1-8</td><td>Disable</td><td>Disable</td><td>Disable</td><td>0</td><td>1</td></tr> <tr><td>3-1</td><td>Disable</td><td>Disable</td><td>Disable</td><td>0</td><td>1</td></tr> <tr><td>3-2</td><td>Disable</td><td>Disable</td><td>Disable</td><td>0</td><td>1</td></tr> <tr><td>3-3</td><td>Disable</td><td>Disable</td><td>Disable</td><td>0</td><td>1</td></tr> <tr><td>3-4</td><td>Disable</td><td>Disable</td><td>Disable</td><td>0</td><td>1</td></tr> <tr><td>3-5</td><td>Disable</td><td>Disable</td><td>Disable</td><td>0</td><td>1</td></tr> <tr><td>3-6</td><td>Disable</td><td>Disable</td><td>Disable</td><td>0</td><td>1</td></tr> </tbody> </table>					Port	Link ON	Link OFF	Traffic Overload	RX Threshold(%)	Traffic Duration(s)	1-1	Disable	Disable	Disable	0	1	1-2	Disable	Disable	Disable	0	1	1-3	Disable	Disable	Disable	0	1	1-4	Disable	Disable	Disable	0	1	1-5	Disable	Disable	Disable	0	1	1-6	Disable	Disable	Disable	0	1	1-7	Disable	Disable	Disable	0	1	1-8	Disable	Disable	Disable	0	1	3-1	Disable	Disable	Disable	0	1	3-2	Disable	Disable	Disable	0	1	3-3	Disable	Disable	Disable	0	1	3-4	Disable	Disable	Disable	0	1	3-5	Disable	Disable	Disable	0	1	3-6	Disable	Disable	Disable	0	1
Port	Link ON	Link OFF	Traffic Overload	RX Threshold(%)	Traffic Duration(s)																																																																																										
1-1	Disable	Disable	Disable	0	1																																																																																										
1-2	Disable	Disable	Disable	0	1																																																																																										
1-3	Disable	Disable	Disable	0	1																																																																																										
1-4	Disable	Disable	Disable	0	1																																																																																										
1-5	Disable	Disable	Disable	0	1																																																																																										
1-6	Disable	Disable	Disable	0	1																																																																																										
1-7	Disable	Disable	Disable	0	1																																																																																										
1-8	Disable	Disable	Disable	0	1																																																																																										
3-1	Disable	Disable	Disable	0	1																																																																																										
3-2	Disable	Disable	Disable	0	1																																																																																										
3-3	Disable	Disable	Disable	0	1																																																																																										
3-4	Disable	Disable	Disable	0	1																																																																																										
3-5	Disable	Disable	Disable	0	1																																																																																										
3-6	Disable	Disable	Disable	0	1																																																																																										

	3-7      Disable    Disable    Disable    0            1 3-8      Disable    Disable    Disable    0            1 router#
Error messages	N/A
Related commands	email-warning event email-warning account email-warning server email-warning mail-address

## show logging

Use the **show logging** user EXEC command to display the setting of the IP filter feature.

### Command

#### show logging [event-log]

Syntax Description	logging	Display syslog information
	event-log	Display system event logs
Defaults	N/A	
Command Modes	Privileged EXEC/ User EXEC	
Usage Guidelines	N/A	
Examples	<pre>router# show logging Syslog server #1: Syslog server #2: 192.168.1.2, port: 514 Syslog server #3: 192.168.1.3, port: 514  router# show logging event-log Idx Boot      Time or Uptime                Log -----  1  337 2037/06/23, 20:46:08    192.168.127.1 admin Auth. ok  2  337 2037/06/23, 20:52:47    Authentication fail  3  338 2037/06/23, 21:51:59    Port 1-1(Trk1) link on  4  338 2037/06/23, 21:51:59    Port 1-2 link on  5  338 2037/06/23, 21:51:59    Port 1-5 link on  6  338 2037/06/23, 21:52:03    Port 1-5 link off  7  338 2037/06/23, 21:52:03    Warm start by Firmware Upgrade  8  338 2037/06/23, 21:52:04    Port 1-5 link on  9  338 2037/06/23, 22:03:43    192.168.127.1 admin Auth. ok 10  338 2037/06/23, 22:04:04    192.168.127.1 admin Auth. ok 11  338 2037/06/24, 00:02:47    Port 1-5 link off 12  338 2037/06/24, 00:02:48    Port 1-5 link on</pre>	
Error messages	N/A	
Related commands	logging	

## System Files

### copy

Use the **copy** privileged command on the router to copy an image or configuration file from a remote server to the Flash memory or copy the running configuration, startup configuration or event log to the remote server through TFTP.

#### Commands

**copy tftp device-firmware**

**copy tftp running-config**

**copy {running-config|event-log|startup-config} tftp [tftp-address]**

Syntax	copy	Copy from one file to another
Description	tftp	Remote server through TFTP
	device-firmware	System firmware
	running-config	Current running configuration of system
	startup-config	System startup configuration
	event-log	Event log file
	tftp-address	TFTP address. Ex. tftp://192.168.127.1/abc.txt
	Defaults	N/A
Command Modes	Privileged EXEC	
Usage Guidelines	N/A	
Examples	<pre>router# copy tftp   device-firmware      - System firmware   running-config       - Current running configuration of system router# copy tftp running-config Address or name of remote host [192.168.127.1]? 192.168.127.95 Source file name ? cli.ini Save import config to flash ? [Y/n] Saving configuration ...Success</pre>	
Error messages	Input error	
	Invalid TFTP Server IP/Name !!!	
	TFTP Configuration File Download Fail	
	Invalid Config Files Path and Name !!!	
	Invalid Firmware Files Path and Name !!!	
	TFTP Firmware Download Fail !!!	
	TFTP Configuration File Upload Fail !!!	
Related commands	N/A	

## Security

### ip http-server

Use the **ip http-server** global configuration commands on the router to enable the HTTP/HTTPS service. Use the **no** form of this command to disable the HTTP/HTTPS service.

#### Commands

**ip http-server**

**ip http-server secure**

**no ip http-sever**

Syntax Description	ip	Global IP configuration subcommands
	http-server	Enable HTTP/HTTPS web service
	secure	HTTPS support only
Defaults	HTTP service is enabled.	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	<pre>router(config)# ip http-server   auto-logout           - Web auto-logout timer   secure                 - HTTPS support only router(config)# ip http-server secure router(config)# ip http-server router(config)# no ip http-server</pre>	
Error messages	N/A	
Related commands	show ip http-server	

### trusted-access

Use the **trusted-access** command to enable the trusted IP list for access.

#### Commands

**trusted-access** [ip-address netmask]

**no trusted-access** [ip-address netmask]

Syntax Description	trusted-access	Enable the trusted IP list for access
	ip-address	IP address
	netmask	IP netmask
Defaults	The feature is disabled by default.	
Command Modes	VLAN configuration as management VLAN	
Usage Guidelines	This feature will take effect when the "trusted-access" command is executed.	
Examples	router(config)# interface mgmt	

	<pre>router(config-vlan)# trusted-access 10.10.10.10 255.255.255.0 &lt;IPV4ADDR:ipaddr&gt;          - IP address &lt;IPV4ADDR:netmask&gt;         - IP netmask router (config-vlan)# trusted-access</pre>
Error messages	IP or netmask invalid
	Access ip list full
Related commands	show interface mgmt trusted-access

## show interfaces trusted -access

Use the **show interfaces trusted-access** user EXEC command to display the settings of the accessible IP list.

### Command

#### **show interfaces trusted-access**

Syntax Description	show	Show running system information
	interfaces	Interface status and configuration
	trusted-access	Display trusted access IP list
Defaults	N/A	
Command Modes	Privileged EXEC / User EXEC	
Usage Guidelines	N/A	
Examples	<pre>router# show interfaces trusted-access Trusted Access IP List: Enable Index   IP / netmask 1       192.168.127.253 / 255.255.255.0</pre>	
Error messages	N/A	
Related commands	trusted-access	

## Diagnostics

### ping

Use the **ping** user EXEC command on the router to detect if the remote host is still alive.

#### Command

**ping** ip-address

Syntax	ping	Send echo messages
Description	ip-address	Ex. 192.168.127.1
Defaults	N/A	
Command Modes	Privileged	
Usage Guidelines	N/A	
Examples	router# ping 192.168.127.1 PING 192.168.127.1, Send/Recv/Lost = 4/4/0	
Error messages	N/A	
Related commands	N/A	

### Ildp enable

Use the **Ildp enable** global configuration command to enable LLDP. To stop LLDP, use the **no** form of this command.

#### Commands

**Ildp run**

**no Ildp run**

Syntax Description	Ildp	Configure LLDP parameters
	run	Start up
Defaults	LLDP is enabled in factory default.	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	router(config)# Ildp enable router(config)# no Ildp enable	
Error messages	N/A	
Related commands	show Ildp	

## Ildp timer

Use **Ildp timer** global configuration command to configure the transmission frequency of LLDP messages. To reset the timer to default, use the **no** form of this command.

### Commands

**Ildp timer** transFreq

**no Ildp timer**

Syntax Description	Ildp	Configure LLDP parameters
	timer	Transmission frequency of LLDP updates
	transFreq	5 ~ 32768 seconds
Defaults	Transmission frequency of LLDP updates is 30 seconds.	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	<pre>router(config)# Ildp timer &lt;UINT:transFreq&gt; - 5 ~ 32768 seconds router(config)# Ildp timer 4 % LLDP transmit frequency should be between 5 ~ 32768 router(config)# Ildp timer 50</pre>	
Error messages	LLDP transmit frequency should be between 5 ~ 32768	
Related commands	show Ildp	

## show Ildp

Use the **show Ildp** command to display the LLDP settings and the LLDP neighbor information.

### Commands

**show Ildp**

**show Ildp entry**

Syntax Description	show	Show running system information
	Ildp	Display LLDP information
	entry	LLDP entries
Defaults	N/A	
Command Modes	Privileged EXEC / User EXEC	
Usage Guidelines	N/A	
Examples	<pre>router# show Ildp LLDP Enable           : Enable Message Transmit Interval : 30 seconds  router# show Ildp entry Port      : 23 Neighbor ID       : 00:90:e8:0a:0a:0a Neighbor Port    : 3</pre>	



	<pre> Neighbor Port Descript : 100TX,RJ45. Neighbor System       : Managed Redundant Router 00000 Port                  : 19 Neighbor ID           : 00:90:e8:0a:0a:0a Neighbor Port         : 2 Neighbor Port Descript : 100TX,RJ45. Neighbor System       : Managed Redundant Router 00000 Port                  : 24 Neighbor ID           : 00:90:e8:0a:0a:0a Neighbor Port         : 1 Neighbor Port Descript : 100TX,RJ45. Neighbor System       : Managed Redundant Router 00000                     </pre>
<p>Error messages</p>	<p>N/A</p>
<p>Related commands</p>	<pre> lldp timer lldp run                     </pre>

## Network Services

### snmp-server version

To enable/disable the SNMP server and configure the SNMP version, use the **snmp-server version** global configuration command.

#### Command

**snmp-server version [v1-v2c-v3 | v1-v2c | v3]**

Syntax Description	snmp-server	Enable SNMP server
	version	SNMP version setting
	v1-v2c-v3	Version 1, 2C and 3 support
	v1-v2c	Version 1 and 2C support
	v3	Only version 3 support
Defaults	Default version is v1-v2c	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	<pre>router(config)# snmp-server version v1-v2c-v3          - Version 1, 2C and 3 support v1-v2c             - Version 1 and 2C support v3                 - Only version 3 support</pre>	
Error messages	N/A	
Related commands	show snmp	

### snmp-server community

To set up the community access string to permit access to the Simple Network Management Protocol (SNMP), use the **snmp-server community** global configuration command.

#### Command

**snmp-server community text mode**

Syntax Description	snmp-server	Configure SNMP server
	community	SNMP community setting
	text	SNMP community string
	mode	ro   rw
Defaults	Public community is ro Private community is rw	
Command Modes	Global configuration	
Usage Guidelines	Specifies read-only access. Authorized management stations are only able to retrieve MIB objects. Specifies read-write access. Authorized management stations are able to both retrieve and modify MIB objects	
Examples	router(config)# snmp-server community public ro	

Error messages	SNMP community mode must be ( ro rw )!!
	The longest snmp community string length is 30!!
Related commands	show snmp

## snmp-server user

In the SNMPv3 application, to configure a user's authentication type and password, use the **snmp-server user** global configuration command.

### Command

**snmp-server user** username **auth** auth-type password

Syntax Description	snmp-server	Configure SNMP server
	user	SNMP user setting
	username	SNMP user name
	auth	Specifies which authentication level should be used
	auth-type	no-auth   md5   sha
	password	Password (maximum 30 characters)
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	username is only allowed to be set as "admin" or "user" auth-type is only allowed to be set as "no-auth", "md5" or "sha"	
Examples	router(config)# snmp-server user admin auth md5 moxacli	
Error messages	SNMP user must be ( admin   user )!!	
	SNMP authtype must be ( no-auth   md5   sha )!!	
	Admin/User Password must be at least 8 bytes !!!	
	Admin/User Data Encryption must be at least 8 bytes !!!	
Related commands	show snmp	

## snmp-server trap-mode

To enable all Simple Network Management Protocol (SNMP) notifications (traps or informs) available on your system, use the **snmp-server trap-mode** global configuration command. To disable all available SNMP notifications, use **no** form of this command

### Commands

**snmp-server trap-mode trap**

**snmp-server trap-mode inform [retry times timeout seconds]**

**no snmp-server trap-mode**

Syntax Description	snmp-server	Configure the SNMP server
	trap-mode	SNMP Trap/Inform mode setting
	trap	SNMP Trap
	inform	SNMP Inform

	retry	Inform retries times
	times	1 ~ 99
	timeout	Timeout timer
	seconds	1 ~ 300 seconds
Defaults	The default mode is "trap"	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	router(config)# snmp-server trap-mode trap router(config)# snmp-server trap-mode inform retry 3 timeout 10 router(config)# no snmp-server trap-mode	
Error messages	Invalid inform retries value!!!	
	Invalid inform timeout value!!!	
Related commands	show snmp	

## Service dhcp

To enable the DHCP service, use the **service dhcp dhcp-mode** global configuration command. To disable the DHCP service, use **no** form of this command

### Commands

**service dhcp**

**service dhcp auto-assign**

**no service dhcp**

Syntax Description	service dhcp	Enable DHCP server service
	auto-assign	Enable DHCP server mode as IP-port binding
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	router(config)# service dhcp router(config)# service dhcp auto-assign	
Error messages	N/A	
Related commands	N/A	

## Dynamic DNS

To enable the DDNS service, use the **ip ddns service [DDNS server]** global configuration command. To configure DDNS service, use **ip ddns [username | password | domain]** to disable DHCP service, use the **no** form of this command.

### Commands

**ip ddns service**

**ip ddns service [DDNS server]****ip ddns service [username | password | domain]**

Syntax Description	ip addns service	Configure SNMP server
	username	Configure login username for DDNS service
	password	Configure login password for DDNS service
	domain	Configure domain name for DDNS service
	DDNS server	Select DDNS service [freedns   3322   dyndns   no-ip]
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	<pre>router(config)# ip ddns service {freedns   3322   DynDns   NO-IP} router(config)# ip ddns username user-name router(config)# ip ddns password password router(config)# ip ddns domain domain-name router(config)# no ip ddns</pre>	
Error messages		
Related commands	router# show ip ddns	

# Interface and Routing Functions

---

This chapter describes the interface and routing functions of the Ethernet switches.

The following topics are covered in this chapter:

▣ **Command Modes**

▣ **Command Sets**

- Interfaces
- Routing
- Multicast Routing

## Command Modes

Refer to the following table for the command mode descriptions.

Mode	Access Method	Prompt	Exit Method	About This Mode
User EXEC	Begin a session with your router.	Router>	Enter logout or quit.	Use this mode to <ul style="list-style-type: none"><li>• Change terminal settings.</li><li>• Perform basic tests.</li><li>• Display system information.</li></ul>
Privileged EXEC	While in user EXEC mode, enter the enable command.	Router#	Enter disable to exit.	Use this mode to verify commands that you have entered. Use a password to protect access to this mode.
Global configuration	While in privileged EXEC mode, enter the configure command.	Router(config)#	To exit to privileged EXEC mode, enter exit or end, or press Ctrl-Z.	Use this mode to configure parameters that apply to the entire router.

# Command Sets

## Interfaces

Category	Commands
Interface Configuration	router(config)# interface wan wanID router(config)# interface lan router(config-if)# mode {disable   enable   backup (for Wan2)} router(config-if)# dmz (for Wan2) router(config-if)# no dmz (for Wan2)
DNS Server	router(config-if)# name-server ip-address1 [ip-address2] [ip-address3] (for WAN) router(config-if)# no name-server (for WAN)
LAN IP Setting	router(config-if)# ip address static ip-address subnet-mask router(config-if)# no ip address
Display settings	router# show interface wan wanID router# show interface lan router# show interface bridge
WAN IP Setting	router(config-if)# type {static ip-address subnet-mask [gateway]   dhcp   pppoe host-name user-name password}
PPTP Dialup	router(config-if)# pptp ip-address user-name password router(config-if)# no pptp

## Routing

### Unicast Route

Category	Commands
Display settings	router# show ip route router# show ip route static
Static route settings	router(config)# ip route static name ip-address netmask next-hop [distance] router(config)# no ip route static name router(config)# ip route static name {enable   disable}

### RIP

Category	Commands
Enable/Disable Enter RIP mode	router(config)# ip route rip router(config)# no ip route rip
Add interface to RIP	router(config-RIP)# network {wan1   wan2   lan} router(config-RIP)# no network {wan1   wan2   lan}
Version settings	router(config-RIP)# version {1   2}
Redistribute Static Routing	router(config-RIP)# redistribute static router(config-RIP)# no redistribute static
Display settings	router# show ip route rip



## VRRP

Category	Commands
VRRP Global Settings	<pre>router(config)# vrrp enable router(config)# no vrrp enable</pre>
VRRP Interface Settings	<p>Note: These settings are in interface configuration mode</p> <pre>router(config-if)# vrrp enable router(config-if)# no vrrp enable router(config-if)# vrrp virtual-ip ip-address router(config-if)# vrrp vrid virtual-router-ID router(config-if)# vrrp priority priority router(config-if)# vrrp preemption router(config-if)# no vrrp preemption router(config-if)# vrrp track-interface {lan   wan1   wan2} router(config-if)# no vrrp track-interface {lan   wan1   wan2}</pre>
Display settings	<pre>router# show vrrp</pre>

## Traffic Prioritization

Category	Commands
Enable/Disable Priority settings	<pre>router(config)# traffic priority interface {wan1   wan2   lan} router(config-traffic-priority)# max-bw kbps router(config-traffic-priority)# default-priority {0   1   2   3} router(config-traffic-priority)# priority {0   1   2   3} max-bw kbps min-bw kbps router(config)# no traffic priority interface {wan1   wan2   lan}</pre>
Create/Enter policy configuration mode	<p>Default: enable</p> <pre>router(config)# traffic policy {outgoing   incoming} index</pre>
Policy settings	<p>Default: The default value of priority is 0. The default value of mode is IP. The default values of protocol, IP, port and interface are all. The policy enables by default.</p> <pre>router(config-traffic-policy)# priority {0   1   2   3} router(config-traffic-policy)# mode {IP   MAC} router(config-traffic-policy)# protocol {all   tcp   udp   icmp} router(config-traffic-policy)# src-ip all router(config-traffic-policy)# src-ip single ip-address router(config-traffic-policy)# src-ip range ip-address1 ip-address2 router(config-traffic-policy)# dst-ip all router(config-traffic-policy)# dst-ip single ip-address router(config-traffic-policy)# dst-ip range ip-address1 ip-address2 router(config-traffic-policy)# src-port all router(config-traffic-policy)# src-port single port router(config-traffic-policy)# src-port range port1 port2 router(config-traffic-policy)# dst-port all router(config-traffic-policy)# dst-port single port router(config-traffic-policy)# dst-port range port1 port2 router(config-traffic-policy)# src-mac mac-address router(config-traffic-policy)# interface {all   wan1   wan2   lan}</pre>
Enable/Disable/Delete policy	<pre>router(config)# traffic policy {outgoing   incoming} index {enable   disable} router(config)# no traffic policy {outgoing   incoming} index</pre>

Display settings	router# show traffic priority router# show traffic policy {outgoing   incoming}
------------------	--

## Multicast Routing

### Global Configuration

Use the **ip multicast-routing** command to enable/disable the multicast routing function, and **display** to show the multicast routing forwarding table.

Category	Commands
Multicast routing mode	router(config)#ip multicast-routing { static   dvmrp   pim-sm } router(config)#no ip multicast-routing
Display	router(config)#show ip mroute kernel

### Static Multicast Route

Category	Commands
Enable/disable	router(config)#ip multicast-routing static router(config)#no ip multicast-routing
Static Multicast routes add/delete	router(config)#ip mroute group MCADDR src IPADDR in IFNAME out IFNAME-LIST MCADDR: Multicast group address IPADDR: Multicast source IP address IFNAME: Inbound interface name IFNAME-LIST: Outbound interface list router(config)#no ip mroute group MCADDR src IPADDR
Display settings	router(config)#show ip mroute mode mode: dvmrp   static   pimsm

### DVMRP

Category	Commands
Enable/disable	router(config)#ip multicast-routing dvmrp router(config)#no ip multicast-routing
Enable/disable DVMRP by interface	Use this command to enable/disable DVMRP interface by interface. Go into interface category for the settings first. router(config)#interface IFNAME IFNAME: Interface name router(config-if)#ip dvmrp router(config-if)#no ip dvmrp
Display DVMRP information in the interface	router# show ip dvmrp router# show ip dvmrp route router# show ip dvmrp neighbor

## NAT, VPN, and Firewall Functions

---

This chapter describes the commands for the NAT, VPN, and firewall function.

The following topics are covered in this chapter:

- ❑ **Command Modes**
- ❑ **Command Sets**

## Command Modes

Refer to the following table for the command modes.

Mode	Access Method	Prompt	Exit Method	About This Mode
User EXEC	Begin a session with your router.	Router>	Enter logout or quit.	Use this mode to <ul style="list-style-type: none"><li>• Change terminal settings.</li><li>• Perform basic tests.</li><li>• Display system information.</li></ul>
Privileged EXEC	While in user EXEC mode, enter the enable command.	Router#	Enter disable to exit.	Use this mode to verify commands that you have entered. Use a password to protect access to this mode.
Global configuration	While in privileged EXEC mode, enter the configure command.	Router(config)#	To exit to privileged EXEC mode, enter exit or end, or press Ctrl-Z.	Use this mode to configure parameters that apply to the entire router.

# Command Sets

## Setting Check

Category	Commands
Enable/Disable	router(config)# settingcheck firewall router(config)# no settingcheck firewall router(config)# settingcheck nat router(config)# no settingcheck nat router(config)# settingcheck access-ip router(config)# no settingcheck access-ip router(config)# settingcheck I2-filter router(config)# no settingcheck I2-filter
Manual setting	router(config)# settingcheck timer seconds
Display settings	router# show settingcheck

## NAT

Category	Commands
Display settings	router# show ip nat
Rule settings	Default: The new rule is appended to the last rule if the index field of command is not set, and it enables by default.  1-1: router(config)# ip nat static inside lan ip-address outside wan wanID ip-address [index] N-1: router(config)# ip nat dynamic inside lan ip-address1 ip-address2 outside wan {wanID   auto} [index] Port Forwarding: router(config)# ip nat static {all   tcp   udp} inside lan ip-address port outside wan wanID port [index]
Enable/Disable/Delete rules	router(config)# ip nat index {enable   disable} router(config)# no ip nat index

## Policy Setting

Category	Commands
Display settings	router# show firewall
Create/Enter policy configuration mode	Default: enable router(config)# firewall index
Policy settings	Default: The default value of the action is "accept". The default value of the mode is IP. The default values of the protocol, IP, port and interface are all. The policy is enabled by default.  router(config-firewall)# action {accept   drop} router(config-firewall)# mode {IP   MAC} router(config-firewall)# protocol {all   tcp   udp   icmp} router(config-firewall)# src-ip all

	<pre>router(config-firewall)# src-ip single ip-address router(config-firewall)# src-ip range ip-address1 ip-address2 router(config-firewall)# dst-ip all router(config-firewall)# dst-ip single ip-address router(config-firewall)# dst-ip range ip-address1 ip-address2 router(config-firewall)# src-port all router(config-firewall)# src-port single port router(config-firewall)# src-port range port1 port2 router(config-firewall)# dst-port all router(config-firewall)# dst-port single port router(config-firewall)# dst-port range port1 port2 router(config-firewall)# src-mac mac-address router(config-firewall)# interface {all   lan   wan1   wan2} {all   lan   wan1   wan2}</pre>
Enable/Disable/Delete policy	<pre>router(config)# firewall index [enable   disable] router(config)# no firewall index</pre>

## DoS Defense

Category	Commands
Enable/Disable	<pre>router(config)# dos {null-scan   xmas-scan   nmap-xmas-scan   syn/fin-scan   fin-scan   nmap-id-scan   syn/rst-scan} router(config)# dos {icmp-death   syn-flood   arp-flood} [pkts] router(config)# no dos {null-scan   xmas-scan   nmap-xmas-scan   syn/fin-scan   fin-scan   nmap-id-scan   syn/rst-scan   icmp-death   syn-flood   arp-flood }</pre>
Display settings	<pre>router# show dos</pre>

## Modbus Filtering

Category	Commands
Display settings	<pre>router# show modbus-filter</pre>
Create/Enter policy configuration mode	<pre>Default: enable router(config)# modbus-filter index</pre>
Policy settings	<pre>Default: The default value of action is accept. The default values of protocol, IP, interface, address and function code are all. The policy enables by default.  router(config-modbus-filter)# action {accept   drop} router(config-modbus-filter)# protocol {all   tcp   udp} router(config-modbus-filter)# src-ip all router(config-modbus-filter)# src-ip single ip-address router(config-modbus-filter)# src-ip range ip-address1 ipaddress2 router(config-modbus-filter)# dst-ip all router(config-modbus-filter)# dst-ip single ip-address router(config-modbus-filter)# dst-ip range ip-address1 ipaddress2 router(config-modbus-filter)# function func-code router(config-modbus-filter)# uid uid router(config-modbus-filter)# address all router(config-modbus-filter)# address single address router(config-modbus-filter)# address range address1 address2 router(config-modbus-filter)# interface {all   lan   wan1   wan2} {all   lan   wan1   wan2}</pre>

Enable/Disable/Delete policy	router(config)# modbus-filter index [enable   disable] router(config)# no modbus-filter index
Enable/Disable/Delete policy	router(config)# l2-filter index [enable   disable] router(config)# no l2-filter index

## IPSec

Category	Commands
Display settings	router# show ipsec router# show ipsec name
Global setting	router(config)# ipsec all-connect router(config)# no ipsec all-connect router(config)# ipsec nat-t router(config)# no ipsec nat-t
Create connection /Tunnel setting	<p>Quick Setting: The type, remote-gateway, network must be set in tunnel setting, and the auth-mode should be set to pre-shared key mode in phase1 setting, all other commands are the default values, then it can work as a standard-strength IPSec connection. IPSec Name must begin with an alphabet, and it cannot contain a space.</p> <p>Default: l2tp: disable interface: wan1 mode: wait The connection is disabled by default.</p> <pre> router(config)# ipsec name router(config-ipsec)# l2tp router(config-ipsec)# no l2tp router(config-ipsec)# remote-gateway ip-address router(config-ipsec)# interface wan wanID router(config-ipsec)# startup-mode {start   wait} router(config-ipsec)# local-network ip-address netmask [ID] router(config-ipsec)# remote-network ip-address netmask [ID] </pre>
Phase1 setting	<p>Default: ike-mode: main auth-mode: pre-shared key encryption: 3des hash: sha1 group: 2 negotiation-time: 0 (forever) life-time: 1 hour rekey-time: 9 mins rekey-fuzz-percent: 100%</p> <pre> router(config-ipsec)# phase1 router(config-ipsec-phase1)# ike-mode {main   aggressive} router(config-ipsec-phase1)# auth-mode {psk key   x509 local.crt remote.crt} router(config-ipsec-phase1)# encryption {des   3des   aes128   aes192   aes256} router(config-ipsec-phase1)# hash {any   md5   sha1   sha256} router(config-ipsec-phase1)# dh-group {768   1024   1536   2048} router(config-ipsec-phase1)# negotiation-time times </pre>

	<pre>router(config-ipsec-phase1)# life-time hours router(config-ipsec-phase1)# rekey-time minutes router(config-ipsec-phase1)# rekey-fuzz-percent percentage</pre>
Phase2 setting	<pre>Default: perfect-forward-secrecy: disable encryption: 3des hash: sha1 life-time: 480 mins  router(config-ipsec)# phase2 router(config-ipsec-phase2)# pfs router(config-ipsec-phase2)# no pfs router(config-ipsec-phase2)# encryption {des   3des   aes128   aes192   aes256   no} router(config-ipsec-phase2)# hash {any   md5   sha1   sha256} router(config-ipsec-phase2)# life-time minutes</pre>
Dead Peer Detection	<pre>Default: action: hold delay: 30 sec timeout: 120 sec  router(config-ipsec)# dpd-action {hold   restart   clear   disable} router(config-ipsec)# dpd-delay seconds router(config-ipsec)# dpd-timeout seconds</pre>
Enable/Disable/Delete connections	<pre>router(config)# ipsec name [enable   disable] router(config)# no ipsec name</pre>

## L2TP

Category	Commands
Display settings	<pre>router# show l2tp</pre>
L2TP setting	<pre>router(config)# l2tp interface wan wanID local-ip ip-address offer-ip ip-address1 ip-address2 router(config)# l2tp user name password password re-password router(config)# no l2tp interface wan wanID</pre>



# Layer 2 Functions

---

This chapter describes the commands for the Layer 2 functions.

The following topics are covered in this chapter:

▣ **Command Modes**

▣ **Command Sets**

- Port
- Port Mirror
- show port monitor
- Redundant Protocols
- RSTP
- Turbo Ring V2
- Virtual LAN
- Multicast
- QoS and Rate Control
- MAC Address Table

## Command Modes

Refer to the following table for the command modes.

Mode	Access Method	Prompt	Exit Method	About This Mode
User EXEC	Begin a session with your router.	Router>	Enter logout or quit.	Use this mode to <ul style="list-style-type: none"><li>• Change terminal settings.</li><li>• Perform basic tests.</li><li>• Display system information.</li></ul>
Privileged EXEC	While in user EXEC mode, enter the enable command.	Router#	Enter disable to exit.	Use this mode to verify commands that you have entered. Use a password to protect access to this mode.
Global configuration	While in privileged EXEC mode, enter the configure command.	Router(config)#	To exit to privileged EXEC mode, enter exit or end, or press Ctrl-Z.	Use this mode to configure parameters that apply to the entire router.

# Command Sets

## Port

### shutdown

To disable an interface, use the **shutdown** interface configuration command. To restart a disabled interface, use the **no** form of this command.

#### Commands

**shutdown**

**no shutdown**

Syntax	shutdown	Shutdown the selected interface
Description		
Defaults	None	
Command Modes	Interface configuration	
Usage Guidelines	N/A	
Examples	router(config-if)# shutdown router(config-if)# no shutdown	
Error messages	Cannot configure on trunk member port 1/1!	
Related commands	show interfaces ethernet show interfaces trunk	

### name

Use the **name** interface configuration command to configure the interface name. To remove the configuration, use the **no** form of this command.

#### Commands

**name**

**no name**

Syntax	name	Port name
Description		
Defaults	None	
Command Modes	Interface configuration	
Usage Guidelines		
Examples	router(config)# interface ethernet 1/1 router(config-if)# name interface1_port1 router(config-if)# no name	
Error messages	The length of port name must between 1 and 63! Cannot configure on trunk member port 1/1	
Related commands	show interfaces ethernet show interfaces trunk	

## speed-duplex

Use the **speed-duplex** interface configuration command to specify the speed of the interface and its duplex mode. Use the **no** form of this command to return the interface to its default value.

### Commands

**speed-duplex { 10M-Full | 10M-Half | 100M-Full | 100M-Half | 1G-Full | Auto }**

**no speed-duplex**

Syntax	speed-duplex	Configure speed and duplex operation
Description	10M-Full	Speed 10M-full
	10M-Half	Speed 10M-Half
	100M-Full	Speed 100M-Full
	100M-Half	Speed 100M-Half
	1G-Full	Speed 1G-Full
	Auto	Speed Auto
Defaults	The default is Auto	
Command Modes	Interface configuration	
Usage Guidelines		
Examples	router(config)# interface ethernet 1/1 router(config-if)# speed-duplex 100M-Full	
Error messages	Fiber port can not be set speed-duplex!!!	
	This port can not be set to 1G!!!	
	Parameter does not be defined!!!	
	Cannot configure on trunk member port 1/1	
	This setting cannot be applied on trunk port!	
Related commands	show interfaces ethernet	

## flowcontrol

To set the method of data flow control between the terminals or other devices, use the **flowcontrol** interface configuration command. Use the **no** form of this command to disable flow control

### Commands

**flowcontrol**

**no flowcontrol**

Syntax	flowcontrol	Configure flowcontrol
Description		
Defaults	The default is disable	
Command Modes	Interface configuration	
Usage Guidelines	N/A	
Examples	router(config)# interface ethernet 1/1 router(config-if)# flowcontrol router(config-if)# no router(config-if)# flowcontrol	

Error messages	Fiber port can not be set flow control!!
	Force speed can not be set flow control!!
	Cannot configure on trunk member port 1/1!
	This setting cannot be applied on trunk port!
Related commands	show interfaces ethernet

## show interfaces ethernet

To check the status of the interfaces, use the **show interfaces ethernet** command.

### Command

**show interfaces ethernet [ module/port [config] ]**

Commands	interfaces	Interface status and configuration				
	ethernet	IEEE 802.3/IEEE 802.3z				
	module/port	Port ID or list. Ex. 1/1,2,3,2/1-3,5,...				
	config	Show interface module/port settings				
Defaults						
Command Modes	Privileged EXEC/ User EXEC					
Usage Guidelines	<pre>router# show interfaces ethernet Port Link      Description          Speed    FDX Flow Ctrl MDI/MDIX ----- 1-1 Down       100TX,RJ45.         --       --             -- 1-2 Down       100TX,RJ45.         --       --             -- 1-3 Down       100TX,RJ45.         --       --             -- 1-4 Down       100TX,RJ45.         --       --             -- 1-5 Up         100TX,RJ45.         100M-Full Off        MDI 1-6 Down       100TX,RJ45.         --       --             -- 1-7 Down       100TX,RJ45.         --       --             -- 1-8 Down       100TX,RJ45.         --       --             --  router# show interfaces ethernet 1/1-3 config Port Enable Description          Speed    FDX Flow Ctrl MDI/MDIX ----- 1-1 Yes   100FX,SC,Single,40.  100M-Full Disable   Auto 1-2 Yes   100FX,SC,Single,40.  100M-Full Disable   Auto 1-3 Yes   100TX,RJ45.          Auto     Disable   Auto</pre>					
Examples	N/A					
Error messages	N/A					
Related commands	N/A					

## Port Mirror

### monitor

Use **monitor** global configuration commands to enable the monitoring of data transmitted/received by a specific port. Use no form of this command to disable the monitoring.

#### Commands

**monitor source interface** mod\_port [direction]

**no monitor source interface**

**monitor destination interface** mod\_port

**no monitor destination interface**

Syntax Description	monitor	Configure Port mirror
	source	Monitored port
	interface	Port
	destination	Mirror port
	modPort	Port ID. Ex. 1/3, Trk2,...
	direction	tx   rx   both
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	Traffic send/receive by a source port (Monitored port) will be mirrored to the destination port (Mirror port)	
Examples	<pre>router(config)# monitor source interface 3/1 both Warning !!! Mirror Port don't set ! router(config)# monitor destination interface   &lt;STRING:mirrorPort&gt; - Port ID. Ex. 1/3, 2/1,... router(config)# monitor destination interface 3/1,2 % Invalid format router(config)# monitor destination interface 3/1 % Monitored Port is the same with Mirror Port !!! router(config)# monitor destination interface 3/2 router(config)# monitor source interface 1/1-2</pre>	
Error messages	Monitored Port is the same with Mirror Port !!!	
	Invalid parameter	
	Warning !!! Mirror Port don't set !	
	Warning !!! Monitored Port don't set !	
Related commands	show port monitor	

### show port monitor

Use the **show port monitor** EXEC command to display the setting of the port mirror.

#### Command

**show port monitor**

Syntax Description	show	Show running system information
	port	Display Port configuration
	monitor	Display Port mirror configuration
Defaults	N/A	
Command Modes	Privileged EXEC / User EXEC	
Usage Guidelines	N/A	
Examples	<pre>router# show port monitor Port Being Monitored          Direction  Mirror Port ----- 1-1 1-2                       both       3-2 router#</pre>	
Error messages	N/A	
Related commands	monitor	

## Redundant Protocols

### redundancy

Use the **redundancy** global configuration command on the switch to enter the redundancy configuration mode.

#### **Command**

#### **redundancy**

Syntax Description	redundancy	Enter redundancy configuration mode
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	<pre>router(config)# redundancy router(config-rdnt)#</pre>	
Error messages	N/A	
Related commands	N/A	

### redundancy mode

Use the **redundancy mode** global configuration command on the switch to change the redundancy protocol mode.

#### **Command**

**redundancy mode { rstp | turbo-ring-v2 }**

Syntax Description	redundancy	Enter redundancy configuration mode
	mode	Specify the redundancy protocol
	rstp	Rapid Spanning Tree
	turbo-ring-v2	Turbo ring version 2
Defaults	The default redundancy protocol mode is RSTP.	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	router(config)# redundancy mode rstp - Rapid Spanning Tree turbo-ring-v2 - Turbo ring version 2	
Error messages	N/A	
Related commands	show redundancy mode	

## RSTP

### spanning-tree forward-delay

Use the **spanning-tree forward-delay** redundancy configuration command on the switch to set the forward-delay time for the spanning-tree. The forwarding time specifies how long each of the listening and learning states last before the interface begins forwarding. Use the **no** form of this command to return to the default setting.

#### Commands

##### **spanning-tree forward-delay seconds**

##### **no spanning-tree forward-delay**

Syntax Description	spanning-tree	Configure spanning tree
	forward-delay	Configure spanning tree BPDU forward delay
	seconds	Range from 4 to 30 seconds
Defaults	Forward delay = 15 secs	
Command Modes	Redundancy configuration	
Usage Guidelines	$2 * (\text{hello-time} + 1.0 \text{ sec}) \leq \text{max-age} \leq 2 * (\text{forward-delay} - 1.0 \text{ sec})$	
Examples	router(config-rdnt)# spanning-tree forward-delay <UINT:seconds> - Range from 4 to 30 seconds	
Error messages	The BPDU forward delay time must be in the range from 4 to 30 secs	
	The formula must be obeyed: $2 * (\text{Hello Time} + 1 \text{ sec}) \leq \text{Max age} \leq 2 * (\text{Forward Delay} - 1 \text{ sec})$	
Related commands	spanning-tree hello-time spanning-tree max-age show redundancy spanning-tree	



## spanning-tree hello-time

Use the **spanning-tree hello-time** redundancy configuration command on the switch to set the interval between hello bridge protocol data units (BPDUs) sent by root switch configuration messages. Use the **no** form of this command to return to the default setting.

### Commands

**spanning-tree hello-time** seconds

**no spanning-tree hello-time**

Syntax Description	spanning-tree	Configure spanning tree
	hello-time	Configure spanning tree BPDU hello time
	seconds	Range from 1 to 2 seconds
Defaults	Hello time = 2 secs	
Command Modes	Redundancy configuration	
Usage Guidelines	$2 * (\text{hello-time} + 1.0 \text{ sec}) \leq \text{max-age} \leq 2 * (\text{forward-delay} - 1.0 \text{ sec})$	
Examples	router(config-rdnt)# spanning-tree hello-time <UINT:seconds> - Range from 1 to 2 seconds	
Error messages	BPDU hello time must be in the range from 1 to 2 secs	
	The formula must be obeyed: $2 * (\text{Hello Time} + 1 \text{ sec}) \leq \text{Max age} \leq 2 * (\text{Forward Delay} - 1 \text{ sec})$	
Related commands	spanning-tree forward-delay spanning-tree max-age show redundancy spanning-tree	

## spanning-tree max-age

Use the **spanning-tree max-age** redundancy configuration command on the switch to set the interval between messages that the spanning tree receives from the root switch. If a switch does not receive a bridge protocol data unit (BPDU) message from the root switch within this interval, it recomputes the spanning-tree topology. Use the **no** form of this command to return to the default setting.

### Commands

**spanning-tree max-age** seconds

**no spanning-tree max-age**

Syntax Description	spanning-tree	Configure spanning tree
	max-age	Configure spanning tree max age
	seconds	Range from 6 to 40 seconds
Defaults	Forward delay = 20 secs	
Command Modes	Redundancy configuration	
Usage Guidelines	$2 * (\text{hello-time} + 1.0 \text{ sec}) \leq \text{max-age} \leq 2 * (\text{forward-delay} - 1.0 \text{ sec})$	
Examples	router(config-rdnt)# spanning-tree max-age <UINT:seconds> - Range from 6 to 40 seconds	
Error messages	The BPDU forward delay time must be in the range from 4 to 30 secs	
	The formula must be obeyed: $2 * (\text{Hello Time} + 1 \text{ sec}) \leq \text{Max age} \leq 2 * (\text{Forward Delay} - 1 \text{ sec})$	

Related commands	spanning-tree forward-delay spanning-tree max-age show redundancy spanning-tree
------------------	---

## spanning-tree priority

Use the **spanning-tree priority** redundancy configuration command on the switch to set the switch priority for the spanning-tree. Use the **no** form of this command to return to the default setting.

### Commands

**spanning-tree priority** priority

**no spanning-tree priority**

Syntax	spanning-tree	Configure spanning tree
Description	priority	Configure spanning tree bridge priority
	priority	Range from 0 to 61440, and must be the multiples of 4096
Defaults	priority = 32768	
Command Modes	Redundancy configuration	
Usage Guidelines	0 <= priority <= 61440, and must be multiples of 4096.	
Examples	router(config-rdnt)# spanning-tree priority <UINT:prio> - Range from 0 to 61440, in steps of 4096	
Error messages	The bridge priority must be in the range from 0 to 61440	
	The bridge priority must be the multiples of 4096	
Related commands	show redundancy spanning-tree	

## spanning-tree

Use the **spanning-tree** interface configuration command on the switch to enable the spanning-tree feature of the specified interfaces. Use the **no** form of this command to disable it.

### Commands

**spanning-tree**

**no spanning-tree**

Syntax	spanning-tree	Enable spanning tree
Description		
Defaults	The default interface status of the spanning tree is disabled	
Command Modes	Interface configuration	
Usage Guidelines	N/A	
Examples	router(config-if)# spanning-tree	
Error messages	Cannot configure on trunk member port 1/1!	
Related commands	redundancy mode show redundancy spanning-tree	

## spanning-tree cost

Use the **spanning-tree cost** interface configuration command on the switch to set the path cost for the spanning-tree algorithms calculations. If a loop occurs, the spanning tree considers the path cost when selecting an interface to put in the forwarding state. Use the **no** form of this command to return to the default setting.

### Commands

**spanning-tree cost** cost

**no spanning-tree cost**

Syntax Description	spanning-tree	Enable spanning tree
	cost	Configure port path cost
	cost	Range from 1 to 200000000
Defaults	cost = 200000	
Command Modes	Interface configuration	
Usage Guidelines	1 <= Cost <= 200000000	
Examples	router(config-if)# spanning-tree cost <UINT:cost> - Range from 1 to 200000000	
Error messages	Cost value must be in the range 1 ~ 200000000	
	Cannot configure on trunk member port 1/1!	
Related commands	show redundancy spanning-tree	

## spanning-tree edge-port

Use the **spanning-tree edge-port** interface configuration command on the switch to enable the Edge Port feature on an interface in all its associated VLANs. When the Edge Port feature is enabled, the interface changes directly from a blocking state to a forwarding state without making the intermediate spanning-tree state changes. Use the **no** form of this command to disable the feature.

### Commands

**spanning-tree edge-port { auto | force }**

**no spanning-tree edge-port**

Syntax Description	spanning-tree	Enable spanning tree
	edge-port	Configure as edge port
	auto	Auto determine as edge port
	force	Force the port as edge port
Defaults	port-fast = auto	
Command Modes	Interface configuration	
Usage Guidelines	N/A	
Examples	router(config-if)# spanning-tree edge-port auto - Auto determine as edge port force - Force the port as edge port	

Error messages	Cannot configure on trunk member port 1/1!
Related commands	show redundancy spanning-tree

## spanning-tree priority

Use the **spanning-tree priority** interface configuration command on the switch to set the interfaces priority for the spanning-tree. Use the **no** form of this command to return to the default setting.

### Commands

**spanning-tree priority** priority

**no spanning-tree priority**

Syntax Description	spanning-tree	Enable spanning tree
	priority	Configure port priority
	priority	Range from 0 to 240, in steps of 16
Defaults	priority = 128	
Command Modes	interface configuration	
Usage Guidelines	0 <= priority <= 240, and must be multiples of 16.	
Examples	router(config-rdnt)# spanning-tree priority <UINT:prio> - Range from 0 to 61440, in steps of 4096	
Error messages	The bridge priority must be in the range from 0 to 240	
	The bridge priority must be multiples of 16	
Related commands	show redundancy spanning-tree	

## show redundancy spanning-tree

Use the **show redundancy spanning-tree** user EXEC command to display the spanning-tree state information

### Command

**show redundancy spanning-tree**

Syntax Description	redundancy	Display redundancy protocol status
	spanning-tree	Display spanning tree settings
Defaults	N/A	
Command Modes	Privileged EXEC/ User EXEC	
Usage Guidelines	N/A	
Examples	router# show redundant spanning-tree Spanning tree status : Enabled Role : Root Bridge priority : 32768 Hello time : 2 sec Forwarding delay : 30 sec Max age time : 20 sec	

	Int#	Enable	Edge Port	Prio	Cost	Status
	1/1	Disabled	Auto	128	200000	---
	1/2	Disabled	Auto	128	200000	---
	1/3	Disabled	Auto	128	200000	---
	1/4	Disabled	Auto	128	200000	---
	1/5	Disabled	Auto	128	200000	---
	1/6	Disabled	Auto	128	200000	---
Error messages	N/A					
Related commands	spanning-tree forward-delay spanning-tree hello-time spanning-tree max-age spanning-tree priority spanning-tree spanning-tree cost spanning-tree edge-port spanning-tree priority show redundancy spanning-tree					

## Turbo Ring V2

### turbo-ring-v2

Use the **turbo-ring-v2** redundancy configuration command on the switch to configure the Turbo Ring v2 with the specified Ring ports. Use the **no** form of this command to disable the specified ring.

#### Commands

**turbo-ring-v2** ring-id **primary interface** primary-port **secondary interface** secondary-port

**no turbo-ring-v2** ring-id

Syntax	turbo-ring-v2	Configure turbo ring v2
Description	ring-id	Turbo ring v2 ring id
	primary	Turbo ring v2 ring ports setting
	interface	Turbo ring v2 ring ports setting
	primary-port	Port ID. Ex. 1/3, 2/1,...
	secondary	Turbo ring v2 ring ports setting
	interface	Turbo ring v2 ring ports setting
	secondary-port	Port ID. Ex. 1/3, 2/1,...
	Defaults	
Command Modes	Redundancy configuration	
Usage Guidelines	At least enable one turbo-ring domain or coupling. But cannot enable two turbo-ring domains and coupling in the same time.	
Examples	router(config-rdnt)# turbo-ring-v2 1 primary interface 2/1 secondary interface 2/2 <STRING:pri_port> - Port ID. Ex. 1/3, Trk2, ... <STRING:sec_port> - Port ID. Ex. 1/3, Trk2, ...	
Error messages	Turbo ring v2 only supports maximum 2 ring domains	
	Interface 2-1 not exist	

	Ring1: One port couldn't be set as 1st and 2nd redundant port simultaneously!!!
	Ring2: One port couldn't be set as Ring1 redundant port simultaneously!!!
	Coupling: One port couldn't be set as 1st and 2nd redundant port simultaneously!!!
	Primary port couldn't be set as Ring2 redundant port simultaneously!!!
	Backup port couldn't be set as Ring2 redundant port simultaneously!!!
	Coupling port couldn't be set as Ring2 redundant port simultaneously!!!
	Please select at least one Ring!!!
	Ring1, ring2, coupling couldn't be enabled simultaneously!!!
	Please enable one Ring in "Ring Coupling" mode!!!
Related commands	show turbo-ring-v2

### turbo-ring-v2 coupling backup

Use the **turbo-ring-v2 coupling** redundancy configuration command on the switch to configure the backup port of Ring coupling for Turbo Ring v2. Use the **no** form of this command to disable the coupling.

#### Commands

**turbo-ring-v2 coupling backup interface** backup-port

**no turbo-ring-v2 coupling**

Syntax Description	turbo-ring-v2	Configure turbo ring v2
	coupling	Configure ring coupling
	backup	Configure ring coupling mode
	interface	Turbo ring v2 coupling ports setting
	backup-port	Port ID. Ex. 1/3, 2/1,...
Defaults		
Command Modes	Redundancy configuration	
Usage Guidelines	At least enable one turbo-ring domain or coupling. But cannot enable two turbo-ring domains and coupling in the same time.	
Examples	router(config-rdnt)# turbo-ring-v2 coupling backup interface 2/1 <STRING:pri_port> - Port ID. Ex. 1/3, Trk2,...	
Error messages	Turbo ring v2 only supports maximum 2 ring domains	
	Ring1: One port couldn't be set as 1st and 2nd redundant port simultaneously!!!	
	Ring2: One port couldn't be set as Ring1 redundant port simultaneously!!!	
	Coupling: One port couldn't be set as 1st and 2nd redundant port simultaneously!!!	
	Primary port couldn't be set as Ring2 redundant port simultaneously!!!	
	Backup port couldn't be set as Ring2 redundant port simultaneously!!!	
	Coupling port couldn't be set as Ring2 redundant port simultaneously!!!	
	Please select at least one Ring!!!	
	Ring1, ring2, coupling couldn't be enabled simultaneously!!!	
Please enable one Ring in "Ring Coupling" mode!!!		

Related commands	show turbo-ring-v2
------------------	--------------------

## turbo-ring-v2 coupling dual-homing

Use the **turbo-ring-v2 coupling dual-homing** redundancy configuration command on the switch to enable the dual homing feature of Ring coupling for the Turbo Ring v2. Use the **no** form of this command to disable it.

### Commands

**turbo-ring-v2 coupling dual-homing primary interface** primary-port **backup interface** secondary-port  
**no turbo-ring-v2 coupling**

Syntax Description	turbo-ring-v2	Configure turbo ring v2
	coupling	Configure ring coupling
	dual-homing	Configure dual homing mode
	primary	Turbo ring v2 ring ports setting
	interface	Turbo ring v2 ring ports setting
	primary-port	Port ID. Ex. 1/3, 2/1,...
	backup	Turbo ring v2 ring ports setting
	interface	Turbo ring v2 ring ports setting
	secondary-port	Port ID. Ex. 1/3, 2/1,...
Defaults		
Command Modes	Redundancy configuration	
Usage Guidelines	At least enable one turbo-ring domain or coupling. But cannot enable two turbo-ring domains and coupling in the same time.	
Examples	<pre>router(config-rdnt)# turbo-ring-v2 coupling dual-homing primary interface 2/1 secondary interface 2/2 &lt;STRING:pri_port&gt; - Port ID. Ex. 1/3, Trk2,... &lt;STRING:sec_port&gt; - Port ID. Ex. 1/3, Trk2,...</pre>	
Error messages	Turbo ring v2 only supports maximum 2 ring domains	
	Ring1: One port couldn't be set as 1st and 2nd redundant port simultaneously!!!	
	Ring2: One port couldn't be set as Ring1 redundant port simultaneously!!!	
	Coupling: One port couldn't be set as 1st and 2nd redundant port simultaneously!!!	
	Primary port couldn't be set as Ring2 redundant port simultaneously!!!	
	Backup port couldn't be set as Ring2 redundant port simultaneously!!!	
	Coupling port couldn't be set as Ring2 redundant port simultaneously!!!	
	Please select at least one Ring!!!	
	Ring1, ring2, coupling couldn't be enabled simultaneously!!!	
	Please enable one Ring in "Ring Coupling" mode!!!	
Related commands	show turbo-ring-v2	

## turbo-ring-v2 coupling primary

Use the **turbo-ring-v2 coupling primary** redundancy configuration command on the switch to configure the primary port of Ring coupling for Turbo Ring v2. Use the **no** form of this command to return to the default setting.

### Commands

**turbo-ring-v2 coupling primary interface** primary-port

**no turbo-ring-v2 coupling**

Syntax Description	turbo-ring-v2	Configure turbo ring v2
	coupling	Configure ring coupling
	primary	Configure ring coupling mode
	interface	Turbo ring v2 coupling ports setting
	primary-port	Port ID. Ex. 1/3, 2/1,...
Defaults		
Command Modes	Redundancy configuration	
Usage Guidelines	At least enable one turbo-ring domain or coupling. But cannot enable two turbo-ring domains and coupling in the same time.	
Examples	router(config-rdnt)# turbo-ring-v2 coupling primary interface 2/1 <STRING:pri_port> - Port ID. Ex. 1/3, Trk2,...	
Error messages	Turbo ring v2 only supports maximum 2 ring domains	
	Ring1: One port couldn't be set as 1st and 2nd redundant port simultaneously !!!	
	Ring2: One port couldn't be set as Ring1 redundant port simultaneously !!!	
	Coupling: One port couldn't be set as 1st and 2nd redundant port simultaneously !!!	
	Primary port couldn't be set as Ring2 redundant port simultaneously !!!	
	Backup port couldn't be set as Ring2 redundant port simultaneously !!!	
	Coupling port couldn't be set as Ring2 redundant port simultaneously !!!	
	Please select at least one Ring!!!	
	Ring1, ring2, coupling couldn't be enabled simultaneously!!!	
	Please enable one Ring in "Ring Coupling" mode!!!	
Related commands	show turbo-ring-v2	

## turbo-ring-v2 master

Use the **turbo-ring-v2 master** redundancy configuration command on the switch to configure the switch as the Ring Master of specified ring for Turbo Ring v2. Use the **no** form of this command to configure the switch as the normal member of specified ring for Turbo Ring v2.

### Commands

**turbo-ring-v2 ring-id master**

**no turbo-ring-v2 ring-id master**

Syntax Description	turbo-ring-v2	Configure turbo ring v2
	ring-id	Turbo ring v2 ring id
	master	Set turbo ring v2 ring id as master





	2nd Ring Port Status: --- Coupling: Mode: --- Coupling Port Status: ---
Error messages	N/A
Related commands	turbo-ring-v2

## Virtual LAN

### switchport access vlan

Use the **switchport access vlan** interface configuration command on the switch to configure the port as a static-access or dynamic-access port. If the switchport mode is set to access, the port operates as a member of the specified VLAN. If set to dynamic, the port starts discovery of VLAN assignment based on the incoming packets it receives. Use the **no** form of this command to reset the access mode to the default VLAN for the switch.

#### Commands

**switchport access vlan** vlan-id

**no switchport access vlan**

Syntax Description	switchport	Set switching mode characteristics
	access	Set access mode characteristics of the interface
	vlan	Set (default) pvid in access mode
	vlan-id	1 ~ 4094
Defaults	vlan-id = 1	
Command Modes	Interface configuration	
Usage Guidelines	You can only use this command mode for configuring normal-range VLANs, that is, VLAN IDs 1 to 4094.	
Examples	router(config-if)# switchport access vlan 2 <UINT:vlanid> - 1 ~ 4094	
Error messages	vlan 4097 is invalid!! should be range from 1 to 4094	
Related commands	show vlan show vlan config	

### switchport hybrid fixed vlan add

Use the **switchport hybrid fixed vlan add** interface configuration command on the switch to add the trunk hybrid characteristics when the interface is in the hybrid mode. Use the **no** form of this command to reset to the default.

#### Commands

**switchport hybrid fixed vlan add** vlan-id-list **tag**

**switchport hybrid fixed vlan add** vlan-id-list **untag**

**no switchport hybrid fixed vlan tag**

**no switchport hybrid fixed vlan untag**

Syntax Description	switchport	Set switching mode characteristics
	hybrid	Set hybrid mode characteristics of the interface
	fixed	Set fixed VLAN characteristics
	vlan	1 ~ 4094
	add	Add VLANs to the current list
	vlan-id-list	VLAN IDs of the VLANs
	untag	Configure egress traffic as VLAN untagged traffic
	tag	Configure egress traffic as VLAN tagged traffic
Defaults		
Command Modes	Interface configuration	
Usage Guidelines	You can only use this command mode for configuring normal-range VLANs, that is, VLAN IDs 1 to 4094.	
Examples	router(config-if)# switchport hybrid fixed vlan add 1,3-5,7 tag <STRING:vlanids> - VLAN IDs of the VLANs	
Error messages	vlan 4097 is invalid!! should be range from 1 to 4094	
	vlan interfaces are full, total vlan interface is 64 !!	
Related commands	show vlan show vlan config switchport trunk hybrid vlan remove	

**switchport hybrid native vlan**

Use **the switchport hybrid native vlan** interface configuration command on the switch to configure the PVID of a port. Use the **no** form of this command to return to the default PVID.

**Commands**

**switchport hybrid native vlan** vlan-id

**no switchport hybrid native vlan**

Syntax Description	switchport	Set switching mode characteristics
	hybrid	Set hybrid mode characteristics of the interface
	native	Set trunking native characteristics
	vlan	Set pvid vlanid in hybrid mode
	vlan-id	1 ~ 4094
Defaults	vlan-id = 1	
Command Modes	Interface configuration	
Usage Guidelines	You can only use this command mode for configuring normal-range VLANs, that is, VLAN IDs 1 to 4094.	
Examples	router(config-if)# switchport hybrid native vlan 2 <UINT:vlanid> - 1 ~ 4094	
Error messages	vlan 4097 is invalid!! should be range from 1 to 4094	
Related commands	show vlan show vlan config	

## switchport trunk fixed vlan add

Use the **switchport trunk fixed vlan add** interface configuration command on the switch to add the trunk characteristics when the interface is in the trunking mode. Use the **no** form of this command to reset a trunking characteristic to the default value.

### Commands

**switchport trunk fixed vlan add** vlan-id-list

**no switchport trunk fixed vlan**

Syntax Description	switchport	Set switching mode characteristics
	trunk	Set trunking mode characteristics of the interface
	fixed	Set fixed VLAN characteristics
	vlan	1 ~ 4094
	add	Add VLANs to the current list
	vlan-id-list	VLAN IDs of the VLANs
Defaults		
Command Modes	Interface configuration	
Usage Guidelines	You can only use this command mode for configuring normal-range VLANs, that is, VLAN IDs 1 to 4094.	
Examples	router(config-if)# switchport trunk fixed vlan add 1,3-5,7 <STRING:vlanids> - VLAN IDs of the VLANs	
Error messages	vlan 4097 is invalid!! should be range from 1 to 4094	
	vlan interfaces are full, total vlan interface is 64 !!	
Related commands	show vlan show vlan config switchport trunk fixed vlan remove	

## switchport trunk fixed vlan remove

Use the **switchport trunk fixed vlan add** configuration command on the switch stack to remove the trunk characteristics when the interface is in the trunking mode. Use the **no** form of this command to reset a trunking characteristic to the default value.

### Commands

**switchport trunk fixed vlan remove** vlan-id-list

**no switchport trunk fixed vlan**

Syntax Description	switchport	Set switching mode characteristics
	trunk	Set trunking mode characteristics of the interface
	fixed	Set fixed VLAN characteristics
	vlan	1 ~ 4094
	remove	Remove VLANs from the current list
	vlan-id-list	VLAN IDs of the VLANs
Defaults		
Command Modes	Interface configuration	
Usage Guidelines	You can only use this command mode for configuring normal-range VLANs, that is, VLAN IDs 1 to 4094.	
Examples	router(config-if)# switchport trunk fixed vlan remove 1,3-5,7	

	<STRING:vlanids> - VLAN IDs of the VLANs
Error messages	vlan 4097 is invalid!! should be range from 1 to 4094
	vlan interfaces are full, total vlan interface is 64 !!
Related commands	show vlan show vlan config switchport trunk fixed vlan add

## switchport trunk native vlan

Use the **switchport trunk native vlan** interface configuration command on the switch to configure the PVID of a port as a trunking port. Use the **no** form of this command to return to the default value.

### Commands

**switchport trunk native vlan** vlan-id

**no switchport trunk native vlan**

Syntax Description	switchport	Set switching mode characteristics
	trunk	Set trunking mode characteristics of the interface
	native	Set trunking native characteristics
	vlan	Set pvid vlanid in trunk mode
	vlan-id	1 ~ 4094
Defaults	vlan-id = 1	
Command Modes	Interface configuration	
Usage Guidelines	You can only use this command mode for configuring normal-range VLANs, that is, VLAN IDs 1 to 4094.	
Examples	router(config-if)# switchport trunk native vlan 2 <UINT:vlanid> - 1 ~ 4094	
Error messages	vlan 4097 is invalid!! should be range from 1 to 4094	
Related commands	show vlan show vlan config	

## show vlan

Use the **show vlan** user EXEC command to display VLAN status information.

### Command

**show vlan**

Syntax Description	show	Show running system information
	vlan	Display VLAN status
Defaults		
Command Modes	Privileged EXEC	
Usage Guidelines		
Examples	router# show vlan vlan mode: 802.1Q vlan mgmt vlan: 1	

	VLAN 1: Access Ports: 1-1, 1-2, 1-3, 1-4, 1-5, 1-6, 1-7, 1-8, Trunk Ports: Hybrid Ports:
Error messages	N/A
Related commands	N/A

## show vlan config

Use the **show vlan** user EXEC command to display VLAN configuration information.

### Command

#### show vlan config

Syntax Description	show	Show running system information
	vlan	Display VLAN status
	config	Display VLAN configuration
Defaults	N/A	
Command Modes	Privileged EXEC	
Usage Guidelines	N/A	
Examples	<pre> vlan mode: 802.1Q vlan VLAN    Ports(Type) -----  ----- 1       1-1(A), 1-2(A), 1-3(A), 1-4(A), 1-5(A), 1-6(A), 1-7(A), 1-8(A),  Port    Trunk Native vlan Port    Fixed VLAN (Tagged) Port    Forbidden VLAN Port    Fixed VLAN (Untagged) Current VLAN interface vid:         1, 2,                     </pre>	
Error messages	N/A	
Related commands	interface vlan	

## Multicast

### ip igmp static-group

Use the **ip igmp static-group** global configuration command on the switch to add a static multicast MAC address and its member ports. Use the **no** form of this command to remove the static multicast group or its member ports.

### Commands

**ip igmp static-group** MAC-address **interface** module/port

**no ip igmp static-group** [MAC-address] [ **interface** module/port]

Syntax Description	Ip	Global IP configuration subcommands
	Igmp	IGMP
	static-group	Add New Static Multicast MAC Address
	Mac-address	MAC address XX:XX:XX:XX:XX:XX
	Interface	Binding ports
	Module/port	Port (Trunk) ID or list. Ex. 1/1,2,4-5,2/1,Trk1,Trk2-Trk
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	router(config)# ip igmp static-group 01:00:00:00:00:01 interface 1/2-3 router(config)# no ip igmp static-group	
Error messages	Add new static multicast MAC address Fail!!! Please check the multicast mac address's type!!!	
	Add new static multicast MAC address Fail!!! Not enough space to add a new static multicast MAC address!!!	
	The member port should not be GMRP-enabled port!!!	
Related commands	show mac-address-table mcast	

## ip igmp-snooping

Use the **ip igmp-snooping** global configuration command on the switch to globally enable Internet Group Management Protocol (IGMP) snooping on the switch. Use the command with keywords to enable IGMP snooping. Use the **no** form of this command to disable IGMP snooping.

### Commands

#### ip igmp-snooping

#### no ip igmp-snooping

Syntax Description	ip	Global IP configuration subcommands
	igmp-snooping	IGMP snooping
Defaults	IGMP snooping is globally disabled.	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	router(config)# ip igmp-snooping router(config)# no ip igmp-snooping	
Error messages	IGMP Function is only supported by 802.1Q VLAN mode!	
Related commands	ip igmp-snooping vlan ip igmp-snooping querier ip igmp-snooping query-interval ip igmp-snooping enhanced show ip igmp	

## ip igmp-snooping querier vlan

Use the **ip igmp-snooping querier** global configuration command to enable and configure the IGMP querier feature on a VLAN interface. Use the **no** form of this command to disable the IGMP querier feature.

### Commands

**ip igmp-snooping querier vlan** vlan-id

**no ip igmp-snooping querier vlan** vlan-id

Syntax	ip	Global IP configuration subcommands
Description	igmp-snooping	IGMP snooping
	querier	IGMP snooping query enable
	vlan	VLAN parameters
	vlan-id	1 ~ 4094
Defaults	The IGMP snooping querier feature is globally disabled on the switch	
Command Modes	Global configuration	
Usage Guidelines	The IGMP snooping function must be enabled first.	
Examples	router(config)# ip igmp-snooping querier vlan 1 router(config)# no ip igmp-snooping querier vlan 1	
Error messages	Vlan entry not found!!!	
	Vlan IGMP Function is Disabled!!!	
	IGMP Function is Disabled!!!	
	IGMP Function is only supported by 802.1Q VLAN mode!	
Related commands	ip igmp-snooping ip igmp-snooping vlan ip igmp-snooping query-interval ip igmp-snooping enhanced show ip igmp	

## ip igmp-snooping querier vlan vlan-id v3

Use the **ip igmp-snooping querier** global configuration command to enable and configure the IGMP querier feature on a VLAN interface. Use **ip igmp-snooping querier vlan** vlan-id **v3** can make the switch to send IGMP V3 query, otherwise the default is V2 query.

### Command

**ip igmp-snooping querier vlan** vlan-id v3

Syntax	ip	Global IP configuration subcommands
Description	igmp-snooping	IGMP snooping
	querier	IGMP snooping query enable
	vlan	VLAN parameters
	vlan-id	1 ~ 4094
	v3	IGMPv3 mode
Defaults	The IGMP snooping querier feature is globally disabled on the switch	
Command Modes	Global configuration	
Usage Guidelines	The IGMP snooping function must be enabled first.	
Examples	router(config)# ip igmp-snooping querier vlan 1 v3	



Error messages	Vlan entry not found!!!
	Vlan IGMP Function is Disabled !!!
	IGMP Function is Disabled !!!
	IGMP Function is only supported by 802.1Q VLAN mode!
Related commands	ip igmp-snooping ip igmp-snooping vlan ip igmp-snooping query-interval

## ip igmp-snooping query-interval

Use the **ip igmp-snooping query-interval** global configuration command on the switch to configure the interval between IGMP queries. Use the **no** form of this command to return to the default.

### Command

**ip igmp-snooping query-interval** interval

Syntax Description	ip	Global IP configuration subcommands
	igmp-snooping	IGMP snooping
	query-interval	IGMP snooping query interval
	interval	20 ~ 600 seconds
Defaults	Query interval default value is 125 seconds	
Command Modes	Global configuration	
Usage Guidelines	The IGMP snooping function must be enabled first.	
Examples	router(config)# ip igmp-snooping query-interval 125	
Error messages	The range of Quierier interval value should be between 20 and 600 !!!	
	IGMP Function is Disabled !!!	
	IGMP Function is only supported by 802.1Q VLAN mode!	
Related commands	ip igmp-snooping ip igmp-snooping vlan ip igmp-snooping querier ip igmp-snooping enhanced show ip igmp	

## ip igmp-snooping vlan

Use the **ip igmp-snooping vlan** global configuration command on the switch to globally enable Internet Group Management Protocol (IGMP) snooping on a VLAN. Use the **no** form of this command to disable IGMP snooping on a VLAN.

### Commands

**ip igmp-snooping vlan** vlan-id [**mrouter** module/port]

**no ip igmp-snooping vlan** vlan-id [**mrouter** module/port]

Syntax Description	ip	Global IP configuration subcommands
	igmp-snooping	IGMP snooping
	vlan	VLAN parameters
	vlan-id	1 ~ 4094
	mrouter	IGMP snooping query port enable
	Module/port	Port(Trunk) ID or list. Ex. 1/1,2,4-5,2/1,Trk1,Trk2-Trk4

Defaults	N/A
Command Modes	Global configuration
Usage Guidelines	The IGMP snooping must be enabled first.
Examples	router(config)# ip igmp-snooping vlan 1 mrouter 1/1 router(config)# no ip igmp-snooping vlan 1 mrouter 1/1
Error messages	Vlan entry not found!!!
	IGMP Function is Disabled !!!
	IGMP Function is only supported by 802.1Q VLAN mode!
Related commands	ip igmp-snooping ip igmp-snooping querier ip igmp-snooping query-interval ip igmp-snooping enhanced show ip igmp config

### show ip igmp config

Use the **show ip igmp** user EXEC command to display the Internet Group Management Protocol (IGMP) snooping configuration and the IGMP table of the switch.

#### Command

#### show ip igmp

Commands	ip	Display IP information
	igmp	Show IGMP snooping settings
Defaults	N/A	
Command Modes	Privileged EXEC/ User EXEC	
Usage Guidelines	<pre>router# show ip igmp config IGMP Snooping           :Enable IGMP Snooping Enhanced Mode :Enable Query Interval          :125(sec)  VID  Static(S) / Learned(L)             Active IGMP Groups    Multicast Querier Port &amp;  IP            MAC            Members Port    Querier(Q) connected Port                                      ----- 1   1-1(S)                  224.1.1.8      01-00-5E-01-01-08  1-1                                239.255.255.250 01-00-5E-7F-FF-FA  1-1</pre>	
Examples	N/A	
Error messages	N/A	
Related commands	ip igmp-snooping	

## QoS and Rate Control

### qos highest-priority

Use the **qos highest-priority** interface configuration command on the switch to set the Port Priority of the ingress frames to "High" queues of the Ethernet ports/Trunks. Use **no** form of this command to return to the default value.

#### Commands

**qos highest-priority**

**no qos highest-priority**

Syntax Description	qos	Configure QoS
	highest-priority	Enable port highest priority queue
Defaults		
Command Modes	Interface configuration	
Usage Guidelines	N/A	
Examples	router(config-if)# qos highest-priority	
Error messages	Cannot configure on trunk member port 1/1!	
Related commands	show qos	

### qos default-cos

Use the **qos default-cos** interface configuration command on the switch to configure the default CoS priority of the Ethernet ports/Trunks. Use **no** form of this command to return to the default value.

#### Commands

**qos default-cos COS-value**

**no qos default-cos**

Syntax Description	qos	Configure QoS
	default-cos	Configure Default CoS of each port
	cos-value	CoS value (0~7)
Defaults	Default CoS value is 3	
Command Modes	Interface configuration	
Usage Guidelines	N/A	
Examples	router(config-if)# qos default-cos <UINT:cos> - CoS value (0~7)	

Error messages	Cannot configure on trunk member port 1/1!
Related commands	show qos

## qos inspect

Use the **qos inspect** global/interface configuration command on the switch to enable the inspect criteria. Use **no** form of this command to disable it.

### Commands

**qos inspect dscp** module\_id

**no qos inspect dscp** module\_id

**qos inspect cos**

**no qos inspect cos**

Syntax Description	qos	Configure QoS
	inspect	Configure inspection criteria
	dscp	Enable DSCP inspection
	module_id	Module ID from 1 to 4
	cos	Enable CoS inspection of each port
Defaults	N/A	
Command Modes	Global configuration Interface configuration	
Usage Guidelines	In product with 88E6095, the "qos inspect dscp" command is configured in interface configuration mode. In product with BCM5650, the "qos inspect dscp" command is configured in global configuration mode with module index.	
Examples	router(config)# qos inspect dscp                  - Enable DSCP inspection router(config-if)# qos inspect cos                  - Enable CoS inspection of each port	
Error messages	Cannot configure on trunk member port 1/1!	
Related commands	show qos	

## qos mapping

Use the **qos mapping** global configuration command on the switch to configure the CoS and DSCP mappings. Use **no** form of this command to return to the default value.

### Commands

**qos mapping cos-to-queue** cos-value queue

**no qos mapping cos-to-queue**

**qos mapping dscp-to-cos** dscp-value cos-value

**no qos mapping dscp-to-cos**

**qos mapping dscp-to-queue** dscp-value queue

**no qos mapping dscp-to-queue**

Syntax Description	qos	Configure QoS
	mapping	Configure QoS mapping
	cos-to-queue	CoS to traffic queue
	cos-value	CoS value (0~7)
	queue	Traffic queue
	dscp-to-cos	DSCP to CoS mapping
	dscp-value	DSCP value (0~63)
	dscp-to-queue	DSCP to traffic queue
Defaults	Cos (queue) : 0 (0), 1(0), 2(1), 3(1), 4(2), 5(2), 6(3), 7(3) DSCP(Cos) : 0-7(0), 8-15(1), 16-23(2), 24-31(3), 32-39(4), 40-47(5), 48-55(6), 56-63(7)	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	<pre>router(config)# qos mapping cos-to-queue 7 &lt;UINT:queue&gt;          - Traffic queue router(config)# qos mapping cos-to-queue 7 3 router(config)# qos mapping dscp-to-cos 23 &lt;UINT:cos&gt;            - CoS value (0~7) router(config)# qos mapping dscp-to-cos 23 7</pre>	
Error messages	Invalid parameter. CoS value must be 0~7 and queue number must be 0~3 Invalid parameter. CoS value must be 0~7 and DSCP value must be 0~63	
Related commands	show qos	

**qos mode**

Use the **qos mode** global configuration command on the switch to configure the current QoS strategy. Use **no** form of this command to return to the default.

**Commands**

**qos mode { weighted-fair | strict }**

**no qos mode**

Syntax Description	qos	Configure QoS
	mode	Configure queuing mechanism
	weighted-fair	Weighted fair queuing
	strict	Strict queuing
Defaults	Default QoS strategy is Weighted-fair queuing.	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	<pre>router(config)# qos mode weighted-fair    - Weighted fair queuing strict           - Strict queuing</pre>	

Error messages	N/A
Related commands	show qos

## show qos

Use the **show qos** user EXEC command to display QoS related settings.

### Command

**show qos [ cos-to-queue | dscp-to-cos | dscp-to-queue ]**

Syntax Description	qos	Display QoS configuration
	cos-to-queue	CoS to traffic queue mappings
	dscp-to-cos	DSCP to CoS mappings
	dscp-to-queue	DSCP to traffic queue mappings
Defaults	N/A	
Command Modes	Privileged	
Usage Guidelines	N/A	
Examples	<pre> router# show qos  Queuing Mechanism      : Weighted Fair (1:2:4:8) Tos Inspection   Module 1              : Disabled   Module 3              : Disabled  Int# CoS Inspection CoS ----- 1/3      Enabled  3 1/4      Enabled  3 1/5      Enabled  3 1/6      Enabled  3 3/1      Enabled  3 3/2      Enabled  3 3/3      Enabled  3 3/4      Enabled  3 3/5      Enabled  3 3/6      Enabled  3 3/7      Enabled  3 3/8      Enabled  3 Trk1     Enabled  3  router# show qos cos-to-queue  CoS Queue # ----- 0 Q0 1 Q0 2 Q1 3 Q1 4 Q2                     </pre>	

	<pre> 5 Q2 6 Q3 7 Q3 router# show qos dscp-to-cos  DSCP Cos DSCP Cos DSCP Cos DSCP Cos -----  0  0   1  0   2  0   3  0  4  0   5  0   6  0   7  0  8  1   9  1  10  1  11  1 12  1  13  1  14  1  15  1 16  2  17  2  18  2  19  2 20  2  21  2  22  2  23  2 24  3  25  3  26  3  27  3 28  3  29  3  30  3  31  3 32  4  33  4  34  4  35  4 36  4  37  4  38  4  39  4 40  5  41  5  42  5  43  5 44  5  45  5  46  5  47  5 48  6  49  6  50  6  51  6 52  6  53  6  54  6  55  6 56  7  57  7  58  7  59  7 60  7  61  7  62  7  63  7                     </pre>
Error messages	N/A
Related commands	<pre> qos mode qos inspect qos mapping qos default-cos                     </pre>

## rate-limit

Use the **rate-limit** interface configuration command on the switch to configure the traffic rate allowed for the specified port. Use **no** form of this command to return to the default value. For Marvell 88E6095 chipsets, use “**rate-limit ingress rate**” to set the ingress rate limiting; for Broadcom chipsets, use “**rate-limit ingress percentage**” to set the ingress rate limiting.

### Commands

**rate-limit { ingress | egress } percentage percentage**

**no rate-limit { ingress | egress }**

**rate-limit ingress rate { none | 128k | 256k | 512k | 1M | 2M | 4M | 8M }**

**rate-limit ingress mode { bcast | bcast-mcast | bcast-mcast-dlf | all }**

**rate-limit mode { normal | port-disable }**

**rate-limit normal { ingress | egress } percentage percentage**

**no rate-limit normal { ingress | egress }**

**rate-limit normal ingress rate { none | 128k | 256k | 512k | 1M | 2M | 4M | 8M }**

**rate-limit normal ingress mode { bcast | bcast-mcast | bcast-mcast-dlf | all }**

**rate-limit port-disable period period**

**rate-limit port-disable ingress rate { none | 44640 | 74410 | 148810 | 223220 | 372030 | 520840 | 744050 }**

Syntax Description	rate-limit	Rate limiting
	normal	Rate limiting normal mode
	port-disable	Rate limiting port-disable mode
	ingress	Ingress rate limiting
	egress	Egress rate limiting
	percentage	Percentage correspond to current port speed
	percentage	Limit percentage, and will take effect at the percentage 0/3/5/10/15/25/35/50/65/85
	rate	Specify the rate
	mode	Specify the mode
	bcast	Limit broadcast frames
	bcast-mcast	Limit broadcast and multicast frames
	bcast-mcast-dlf	Limit broadcast, multicast and DLF frames
	all	All traffic
	period	Port disable period
	period	Seconds
	Defaults	0 or none means unlimiting.
Command Modes	Interface configuration	
Usage Guidelines	The percentage will only take effect at the 0/3/5/10/15/25/35/50/65/85 %. For port disable mode, the port will be disabled when the ingress rate reach the specified packet rate.	
Examples	<pre>router(config-if)# rate-limit percentage &lt;UINT:percent&gt; - Limit percentage, and will take effect at the percentage 0/3/5/10/15/25/35/50/65/85 EDS-408A-1M2S-SC(config-if)# rate-limit ingress rate none none none none  router(config-if)# rate-limit port-disable ingress period 30 EDS-408A-1M2S-SC(config-if)# rate-limit port-disable ingress rate 148810</pre>	
Error messages	Cannot configure on trunk member port 1/1!	
	This setting cannot be applied on trunk port!	
Related commands	show interfaces rate-limit	



## MAC Address Table

### show mac-address-table

Use the **show mac-address-table** user EXEC command to display the MAC addresses in the MAC address table.

#### Commands

**show mac-address-table** [static | learned | mcast]

**show mac-address-table** [interface{ ethernet module/port | trunk trunk-id } ]

Syntax Description	mac-address-table	Display MAC address forwarding table
	static	Retrieve static MAC addresses
	learned	Retrieve learned MAC addresses
	mcast	Retrieve Multicast address
	interface	Retrieve MAC address by interface
	ethernet	Ethernet Port interface
	module/port	Port ID. Ex. 1/3, 2/1,...
	trunk	Trunk interface
	trunk-id	Trunk ID. From 1 to 4
Defaults	N/A	
Command Modes	Privileged EXEC/ User EXEC	
Usage Guidelines	N/A	
Examples	<pre> router# show mac-address-table Line Swap Fast Recovery : Enabled   MAC          Type  VLAN  Port ----- 00-40-F4-8D-0D-F7 ucast(l)  1 1/5  router# show mac-address-table learned   MAC          Type  VLAN  Port ----- 00-40-F4-8D-0D-F7 ucast(l)  1 1/5 </pre>	
Error messages	N/A	
Related commands	N/A	

### show mac-address-table aging-time

Use the **show mac-address-table aging-time** user EXEC command to display the aging time setting of the MAC address table.

#### Command

**show mac-address-table aging-time**

Syntax	mac-address-table	Display MAC address forwarding table
--------	-------------------	--------------------------------------

Description	aging-time	MAC entry aging time
Defaults	N/A	
Command Modes	Privileged EXEC/ User EXEC	
Usage Guidelines	N/A	
Examples	router# show mac-address-table aging-time - MAC entry aging time router# show mac-address-table aging-time MAC address aging time: 300 sec	
Error messages	N/A	
Related commands	mac-address-table aging-time	