

Moxa Command Line Interface (FW_4.x)

Version 5.3, August 2025

www.moxa.com/products



© 2025 Moxa Inc. All rights reserved.

Moxa Command Line Interface (FW_4.x)

The software described in this manual is furnished under a license agreement and may be used only in accordance with the terms of that agreement.

Copyright Notice

© 2025 Moxa Inc. All rights reserved.

Trademarks

The MOXA logo is a registered trademark of Moxa Inc.
All other trademarks or registered marks in this manual belong to their respective manufacturers.

Disclaimer

- Information in this document is subject to change without notice and does not represent a commitment on the part of Moxa.
- Moxa provides this document as is, without warranty of any kind, either expressed or implied, including, but not limited to, its particular purpose. Moxa reserves the right to make improvements and/or changes to this manual, or to the products and/or the programs described in this manual, at any time.
- Information provided in this manual is intended to be accurate and reliable. However, Moxa assumes no responsibility for its use, or for any infringements on the rights of third parties that may result from its use.
- This product might include unintentional technical or typographical errors. Changes are periodically made to the information herein to correct such errors, and these changes are incorporated into new editions of the publication.

Technical Support Contact Information

www.moxa.com/support

Table of Contents

| | |
|---|-----------|
| 1. Command Modes | 8 |
| CLI (Command Line Interface) | 8 |
| Configuring a Switch to CLI Mode | 8 |
| Basic Operation | 9 |
| Useful Interactive "Help" Features | 10 |
| Understanding All Commands..... | 10 |
| 2. Commands..... | 11 |
| access-ip | 11 |
| acl id..... | 12 |
| acl id ip-base | 13 |
| acl id mac-base | 14 |
| area | 15 |
| area range..... | 15 |
| area virtual-link..... | 16 |
| auth tacacs+ | 16 |
| auth tacacs+ auth-type..... | 17 |
| auth tacacs+ server | 18 |
| auto-backup..... | 19 |
| bind vlan | 19 |
| clear counters | 20 |
| clear logging event-log..... | 20 |
| clock set..... | 21 |
| clock summer-time | 21 |
| clock timezone | 22 |
| copy..... | 22 |
| dot1x auth..... | 23 |
| dot1x auth..... | 23 |
| dot1x local-userdb | 24 |
| dot1x reauth | 24 |
| dot1x reauth | 25 |
| dip-switch..... | 25 |
| eip | 27 |
| email-warning account | 27 |
| email-warning event | 27 |
| email-warning event | 29 |
| email-warning mail-address | 30 |
| email-warning send test email..... | 31 |
| email-warning server | 32 |
| exit | 32 |
| flowcontrol..... | 33 |
| gmrp..... | 33 |
| gvrp..... | 34 |
| hostname | 34 |
| interface mgmt..... | 35 |
| interface vlan | 35 |
| ip address..... | 36 |
| ip address..... | 36 |
| ip auto-assign | 37 |
| ip default-gateway..... | 37 |
| ip dhcp retry | 38 |
| ip dhcp-relay server..... | 39 |
| ip dhcp-relay option82 | 39 |
| ip dhcp-relay option82 remote-id-type | 40 |
| ip http-server | 41 |
| ip http-server auto-logout..... | 41 |
| ip igmp static-group..... | 42 |
| ip igmp-snooping..... | 42 |
| ip igmp-snooping enhanced | 43 |

| | |
|--|----|
| ip igmp-snooping querier vlan | 43 |
| ip igmp-snooping querier vlan vlan-id v3 | 44 |
| ip igmp-snooping query-interval | 44 |
| ip igmp-snooping vlan | 45 |
| ip filter-ip | 45 |
| ip name-server..... | 46 |
| ip ospf area..... | 46 |
| ip ospf auth | 47 |
| ip ospf cost..... | 47 |
| ip ospf dead-interval | 48 |
| ip ospf hello-interval | 48 |
| ip ospf priority..... | 49 |
| ip pim-dm..... | 49 |
| ip pim-sm | 50 |
| ip pim-sm dr-priority..... | 50 |
| ip pim-sm hello-interval..... | 51 |
| ip pim-sm join-prune-interval..... | 52 |
| ip proxy-arp | 52 |
| ip route | 53 |
| ipv6 address | 54 |
| line-swap-fast-recovery | 54 |
| lldp enable | 55 |
| lldp timer..... | 55 |
| logging..... | 56 |
| login mode..... | 56 |
| mac-address-table aging-time..... | 57 |
| mcast-filter | 57 |
| media cable-mode | 58 |
| modbus | 58 |
| monitor | 59 |
| Management-Interface | 60 |
| name | 60 |
| network..... | 61 |
| ntp refresh-time | 62 |
| ntp remote-server | 62 |
| ntp server..... | 63 |
| permit..... | 63 |
| ping | 64 |
| port-security | 64 |
| profinetio..... | 65 |
| ptp announce-receipt-timeout | 65 |
| ptp arb-time | 66 |
| ptp clockclass..... | 66 |
| ptp domain-number | 67 |
| ptp enable | 67 |
| ptp leap59 | 68 |
| ptp leap61 | 68 |
| ptp log-sync-interval | 69 |
| ptp log-announce-interval..... | 69 |
| ptp log-min-delay-req-interval | 70 |
| ptp log-min-pdelay-req-interval..... | 70 |
| ptp mode..... | 71 |
| ptp preferred-master..... | 71 |
| ptp priority1..... | 72 |
| ptp priority2..... | 72 |
| ptp timescale | 73 |
| ptp transport..... | 73 |
| ptp utc-offset | 74 |
| ptp utc-offset-valid | 74 |
| qos highest-priority..... | 75 |

| | |
|--|-----|
| qos default-cos..... | 75 |
| qos inspect | 76 |
| qos mapping | 77 |
| qos mode | 78 |
| quit..... | 78 |
| rate-limit | 79 |
| redistribute..... | 80 |
| redundancy..... | 80 |
| redundancy mode..... | 81 |
| relay-warning config relay | 81 |
| relay-warning event..... | 82 |
| relay-warning event..... | 83 |
| relay-warning override | 83 |
| reload | 84 |
| router ospf..... | 84 |
| router rip..... | 85 |
| router vrrp..... | 85 |
| router vrrp adver-interval | 86 |
| save config | 86 |
| show acl | 87 |
| show auth tacacs+..... | 88 |
| show clock..... | 88 |
| show dot1x..... | 89 |
| show dot1x local-userdb..... | 89 |
| show eip..... | 90 |
| show PROFINETIO | 90 |
| show email-warning config..... | 91 |
| show gmrp..... | 92 |
| show gvrp..... | 92 |
| show interfaces acl | 93 |
| show interfaces counters | 94 |
| show interfaces ethernet | 95 |
| show interfaces filter-ip | 96 |
| show interfaces mgmt | 97 |
| show interfaces mgmt access-ip | 97 |
| show interfaces rate-limit | 98 |
| show interfaces trunk..... | 99 |
| show interfaces vlan | 100 |
| show interfaces mgmt trusted-access..... | 100 |
| show ip auto-assign | 101 |
| show ip dhcp-relay config | 102 |
| show ip http-server status | 103 |
| show ip igmp | 103 |
| show ip ospf..... | 104 |
| show ip ospf database..... | 105 |
| show ip ospf interface | 105 |
| show ip ospf neighbor | 106 |
| show ip pim-dm..... | 106 |
| show ip pim-dm neighbor | 107 |
| show ip pim-sm..... | 108 |
| show ip pim-sm bsr | 109 |
| show ip pim-sm neighbor..... | 110 |
| show ip pim-sm routing | 111 |
| show ip pim-sm rp | 112 |
| show ip rip..... | 113 |
| show ip route | 113 |
| show ip vrrp..... | 114 |
| show lldp..... | 115 |
| show logging..... | 116 |
| show mac-address-table..... | 117 |

| | |
|---|-----|
| show mac-address-table aging-time..... | 118 |
| show mcast-filter..... | 118 |
| show modbus..... | 119 |
| show port monitor | 119 |
| show port-security | 120 |
| show qos | 120 |
| show redundancy mst configure | 122 |
| show redundancy mst instance..... | 123 |
| show redundancy spanning-tree | 124 |
| show redundancy turbo-chain | 125 |
| show redundancy turbo-ring-v1..... | 126 |
| show redundancy turbo-ring-v2..... | 127 |
| show relay-warning..... | 128 |
| show running-config..... | 129 |
| show startup-config | 130 |
| show snmp | 131 |
| show storm-control..... | 131 |
| show system..... | 132 |
| show users | 132 |
| show vlan | 133 |
| show vlan config..... | 133 |
| shutdown..... | 134 |
| snmp-server community..... | 134 |
| snmp-server contact | 135 |
| snmp-server description | 135 |
| snmp-server host | 136 |
| snmp-server location..... | 136 |
| snmp-server trap-mode..... | 137 |
| snmp-server user | 138 |
| snmp-server version | 138 |
| spanning-tree forward-delay | 139 |
| spanning-tree hello-time | 139 |
| spanning-tree max-age | 140 |
| spanning-tree mst cist cost | 140 |
| spanning-tree mst cist port-priority..... | 141 |
| spanning-tree mst cist priority..... | 141 |
| spanning-tree mst edge-port..... | 142 |
| spanning-tree mst enable | 142 |
| spanning-tree mst forward-time | 143 |
| spanning-tree mst hello-time | 143 |
| spanning-tree mst instance..... | 144 |
| spanning-tree mst instance cost | 144 |
| spanning-tree mst instance port-priority..... | 145 |
| spanning-tree mst instance priority..... | 145 |
| spanning-tree mst max-age | 146 |
| spanning-tree mst max-hops | 146 |
| spanning-tree mst name..... | 147 |
| spanning-tree mst revision | 147 |
| spanning-tree priority..... | 148 |
| spanning-tree..... | 148 |
| spanning-tree cost..... | 149 |
| spanning-tree edge-port..... | 149 |
| spanning-tree priority..... | 150 |
| speed-duplex | 150 |
| storm-control | 151 |
| switchport access vlan..... | 151 |
| switchport hybrid fixed vlan add | 152 |
| switchport hybrid forbidden vlan add..... | 153 |
| switchport hybrid forbidden vlan remove | 153 |
| switchport hybrid native vlan | 154 |

| | |
|--|-----|
| switchport pvlan | 154 |
| switchport trunk fixed vlan add | 155 |
| switchport trunk fixed vlan remove | 155 |
| switchport trunk forbidden vlan add | 156 |
| switchport trunk forbidden vlan remove | 156 |
| switchport trunk native vlan | 157 |
| trunk-group | 157 |
| trunk-mode | 158 |
| turbo-chain | 158 |
| turbo-ring-v1 | 159 |
| turbo-ring-v1 coupling | 159 |
| turbo-ring-v1 master | 160 |
| turbo-ring-v2 | 161 |
| turbo-ring-v2 coupling backup | 162 |
| turbo-ring-v2 coupling dual-homing | 163 |
| turbo-ring-v2 coupling primary | 164 |
| turbo-ring-v2 master | 164 |
| trusted-access | 165 |
| username | 165 |
| version | 166 |
| vlan create | 166 |
| vlan mode | 167 |
| vrrp | 167 |
| vrrp preempt | 168 |
| vrrp priority | 168 |
| warning-notification port-event | 169 |
| warning-notification system-event | 170 |

1. Command Modes

CLI (Command Line Interface)

The CLI (command line interface) for Moxa switches can be accessed through either the serial console or Telnet console. For either type of connection, access to the command line interface is generally referred to as an EXEC session.

Configuring a Switch to CLI Mode

The default configuration mode for both the serial console and Telnet console is MENU mode. To change the Moxa switch to CLI configuration mode, **Login Mode** from **Basic Settings** and then press **y** to activate the change. You will then be able to view the CLI display in the console.



NOTE

The default login user name is **admin**, without a password.

1. Select **Basic Settings**.

```
EDS-408A series V3.0 build 11062110
-----
1.Basic Settings      - Basic settings for network and system parameter.
2.SNMP Settings      - The settings for SNMP.
3.Comm. Redundancy   - Establish Ethernet communication redundant path.
4.Traffic Prioritization - Prioritize Ethernet traffic to help determinism.
5.Virtual LAN         - Set up a VLAN by IEEE802.1Q VLAN or Port-based VLAN.
6.Multicast Filtering - Enable the multicast filtering capability.
7.Bandwidth Management - Restrict unpredictable network traffic.
8.Auto Warning        - Warning email and/or relay output by events.
9.Line Swap           - Fast recovery after moving devices to different ports.
a.Set Device IP       - Assign IP addresses to connected devices.
b.Diagnosis           - Ping command and the settings for Mirror port, LLDP.
c.Monitor             - Monitor a port and network status.
d.MAC Address Table   - The complete table of Ethernet MAC Address List.
e.System log           - The settings for Syslog and Event log.
f.Exit                - Exit
- Use the up/down arrow keys to select a category,
  and then press Enter to select. -
```

2. Select **Login mode**.

```
MOXA EtherDevice Switch EDS-408A-3M-SC-T
Basic Settings
[System] [Password] [Accessible IP] [Port] [Network] [Time] [DIP] [GARP Timer]
[Backup Media] [Restart] [Factory default] [Upgrade] [Login mode] [Activate]
[Main menu]
Toggle login mode
ESC: Previous menu   Enter: Select

Basic Settings
```

3. Press **y** to activate.

```
MOXA EtherDevice Switch EDS-408A-3M-SC-T
Basic Settings
[System] [Password] [Accessible IP] [Port] [Network] [Time] [DIP] [GARP Timer]
[Backup Media] [Restart] [Factory default] [Upgrade] [Login mode] [Activate]
[Main menu]
  Toggle login mode
ESC: Previous menu   Enter: Select

Current login mode: Menu
Press Y to change to CLI mode? [y/N]
```

4. Now log in to access CLI display mode.

```
login as: [REDACTED]
```

After changing to CLI mode, CLI mode will be the default setting for the next reboot.

Basic Operation

The CLI is organized in different configuration levels. When you first enter CLI mode, type **?** to view a quick help panel that shows the basic commands of the first configuration level. Type any of the commands shown on the screen to access the next configuration level. The quick help panel, accessed from any level by typing **?**, is a useful tool for understanding the commands in any level.

```
-----  
EDS-408A-3M-SC-T#          EDS-408A series  V3.0 build 11062110  
-----  
quit                      - Exit command line interface  
exit                      - Exit command line interface  
reload                     - Halt and perform a cold restart  
terminal                   - Configure terminal page length  
login                      - Change login mode  
copy                       - Copy from one file to another  
save                       - Save running configuration to flash  
ping                       - Send echo messages  
clear                      - Clear information  
show                       - Show running system information  
configure                  - Enter configuration mode  
EDS-408A-3M-SC-T# [REDACTED]
```

To enter the next level, type the commands shown in the console.

```
EDS-408A-3M-SC-T# configure
EDS-408A-3M-SC-T(config)# [REDACTED]
```

To leave access the next higher level, type **exit**.

```
EDS-408A-3M-SC-T(config)# exit
EDS-408A-3M-SC-T# [REDACTED]
```

To jump directly back to the first level, type **Ctrl + z**.

```
EDS-408A-3M-SC-T(config-vlan)#
EDS-408A-3M-SC-T# [REDACTED]
```

Useful Interactive “Help” Features

The CLI includes several types of interactive commands. The **Help** commands are listed in the following table:

| Command | Purpose |
|----------------------|--|
| ? | Provides a brief description of the Help feature in any command level. |
| Partial command? | Provides a list of commands that begin with the character string (no space between the command and the question mark). |
| Partial command<Tab> | Completes a partial command name (no space between the command and <Tab>). |
| Command ? | Lists the keywords, arguments, or both associated with the command (type a space between the command and the question mark). |
| Command keyword ? | Lists the arguments that are associated with the keyword (type a space between the keyword and the question mark). |

Understanding All Commands

To understand all the details of the commands supported in the CLI of Moxa switches, refer to the following table.

| Mode | Access Method | Prompt | Exit Method | About This Mode |
|--------------------------|---|---|---|---|
| User EXEC | Begin a session with your switch and login with user . | Switch> | Enter exit or quit. | Use this mode to display system information. |
| Privileged EXEC | Begin a session with your switch and login with admin . | Switch# | Enter exit or quit. | Use this mode to verify commands that you have entered. |
| Global configuration | While in privileged EXEC mode, enter the configure command. | Switch(config)# | To exit to privileged EXEC mode, enter exit or press Ctrl-Z. | Use this mode to configure parameters that apply to the entire switch. |
| Redundancy configuration | From global configuration mode, enter the redundancy command. | Switch(config-rdnt)#+ | To exit to privileged EXEC mode, press Ctrl-Z. To exit to global configuration mode, enter the exit command. | Use this mode to configure Turbo Ring V1/V2, Turbo Chain, and Spanning Tree parameters. |
| Interface configuration | From global configuration mode, specify an interface by entering the interface command followed by an interface identification. | Switch(config-if)#+ | To exit to privileged EXEC mode, press Ctrl-Z. To exit to global configuration mode, enter the exit command. | |
| Router configuration | From global configuration mode, specify a protocol by entering the router command. | Switch(config-rip)#+ Switch(config-ospf)#+ | To exit to privileged EXEC mode, press Ctrl-Z. To exit to global configuration mode, enter the exit command. | |

2. Commands

access-ip

Use **access-ip** in the VLAN configuration command as to restrict access to the switch to specified IP addresses. Use the **no** form of this command to disable this feature or to remove the IP addresses from access list.

Commands

access-ip [*ip-address netmask*]

no access-ip [*ip-address netmask*]

| | | |
|-------------------------|--|-------------------------------|
| Syntax | access-ip | Enable the accessible IP list |
| Description | <i>ip-address</i> | IP address |
| | <i>netmask</i> | IP netmask |
| Defaults | The feature is disabled by default. | |
| Command Modes | VLAN configuration as management VLAN | |
| Usage Guidelines | This feature will take effect when the access-ip command is executed. | |
| Examples | <pre>PT-7828 (config) # interface mgmt PT-7828 (config-vlan) # access-ip 10.10.10.10 255.255.255.0 <IPV4ADDR:ipaddr> - IP address <IPV4ADDR:netmask> - IP netmask PT-7828 (config-vlan) # access-ip</pre> | |
| Error messages | IP or netmask invalid Access IP list full | |
| Related commands | show interface mgmt access-ip | |

acl id



NOTE

The command is supported only in Layer 3 switches.

Use **acl id** interface configuration commands on the switch to attach ACL to the port. Use the **no** form of this command to return to the default setting.

Commands

acl id { in | out}

no acl id

| | | |
|-------------------------|--|-------------------------------|
| Syntax | acl | Configure access control list |
| Description | <i>id</i> | The access list ID |
| | in | Inbound traffic |
| | out | Outbound traffic |
| Defaults | N/A | |
| Command Modes | Interface configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828(config-if)# acl 10 in PT-7828(config-if)# no acl 10 | |
| Error messages | Invalid ID! | |
| Related commands | N/A | |

acl id ip-base



NOTE

The command is supported only in Layer 3 switches.

Use the **acl id ip-base** global configuration commands on the switch to create an IP-base ACL and add rules. Use the **no** form of this command to remove the rule.

Commands

acl id ip-base { permit | deny } srcip [dstip] [protocol] [port]

acl id ip-base name name_str

no acl id

no acl id rule ruleindex

| Syntax Description | acl | Configure access control list |
|--------------------|--|---|
| | <i>id</i> | Set ACL ID |
| | ip-base | IP-base ACL |
| | permit | Forward packets |
| | deny | Drop packets |
| | <i>srcip</i> | Set source IP address and subnet mask. Ex: 192.168.1.1/255.255.255.0 or 192.168.127.1 |
| | <i>dstip</i> | Set destination IP address and subnet mask. Ex: 192.168.1.1/255.255.255.0 or 192.168.127.1 |
| | <i>protocol</i> | Set protocol number, Ex: ICMP, TCP, UDP, etc. |
| | <i>port</i> | Set TCP/UDP port number |
| | <i>name_str</i> | ACL name |
| Defaults | N/A | |
| Command Modes | Global configuration | |
| Usage Guidelines | The ACL ID is 1 ~ 16. | |
| Examples | PT-7828(config)# acl 8 ip-base permit 172.3.1.1/255.255.255.0 201.16.9.7/255.255.0.0 6 23 | |
| Error messages | <p>Invalid ID! This ID is used by MAC-base ACL! Invalid IP address format! Invalid subnet mask format!</p> | |
| Related commands | N/A | |

acl id mac-base



NOTE

The command is supported only in Layer 3 switches.

Use the **acl id mac-base** global configuration commands on the switch to create an MAC-base ACL and add rules. Use the **no** form of this command to remove the rule.

Commands

acl id mac-base { permit | deny } srcmac [dstmac] [ethertype] [vid]

acl id mac-base name name_str

no acl id

no acl id rule ruleindex

| Syntax Description | acl | Configure access control list |
|--------------------|---|--|
| | id | Set ACL ID |
| | mac-base | MAC-base ACL |
| | permit | Forward packets |
| | deny | Drop packets |
| | srcmac | Set source MAC address and MAC mask. Ex: 00:90:E8:1D:24:23/FF:FF:FF:FF:00:00 or 00:90:E8:1D:24:23 |
| | dstmac | Set destination IP address and subnet mask. Ex: 192.168.1.1/255.255.255.0 or 192.168.127.1 |
| | ethertype | Set ether type |
| | vid | Set VLAN ID |
| | name_str | ACL name |
| Defaults | N/A | |
| Command Modes | Global configuration | |
| Usage Guidelines | The ACL ID is 1 ~ 100. | |
| Examples | PT-7828 (config) # acl 10 mac-base deny 00:11:22:33:44:55/ff:ff:ff:00:00:00 aa:bb:cc:dd:ee:ff/ff:ff:00:00:00:00 2048 10 | |
| Error messages | Invalid ID! This ID is used by IP-base ACL! Invalid MAC address format! Invalid MAC mask format! | |
| Related commands | N/A | |

area

Use the **area** command in Router configuration mode as OSPF to add an OSPF area and configure its type. Use the **no** form of this command to remove the area.

Commands

area area-id [{ stub | nssa } metric value]

no area area-id

| | |
|---------------------------|---|
| Syntax Description | area Configure OSPF Area area-id OSPF Area id, format is ip address stub Configure OSPF area type to stub nssa Configure OSPF area type to NSSA metric Configure OSPF area metric value Metric value (1 to 65535) |
| Defaults | N/A |
| Command Modes | Router configuration mode as OSPF |
| Usage Guidelines | Metric value: 1 to 65535 |
| Examples | PT-7828 (config-ospf) # area 2.2.2.2 PT-7828 (config-ospf) # area 2.2.2.2 stub metric 4 PT-7828 (config-ospf) # area 2.2.2.2 nssa metric 4 |
| Error messages | Configuration Error!! Metric value error (1 to 65535)!! |
| Related commands | show ip ospf |

area range

To consolidate and summarize routes at an area boundary, use the **area range** command in router configuration mode. To disable this function, use the **no** form of this command.

Commands

area area-id range ip-address netmask

no area area-id range ip-address netmask

| | |
|---------------------------|--|
| Syntax Description | area Configure OSPF Area area-id OSPF Area id, format is ip address range Specify an address range for route aggregation ip-address E.g., 11.22.33.44 netmask E.g., 255.255.255.0 |
| Defaults | N/A |
| Command Modes | Router configuration mode as OSPF |
| Usage Guidelines | N/A |
| Examples | PT-7828 (config-ospf) # area 1.1.1.1 range 192.0.0.0 255.0.0.0 |
| Error messages | Configuration Error!! IP Prefix format Error!! Netmask format Error!! IP format Error!! |
| Related commands | show ip ospf |

area virtual-link

Use the **area virtual-link** command in Router configuration mode as OSPF to add an OSPF virtual link. Use the **no** form of this command to remove the specified OSPF virtual link.

Commands

area area-id virtual-link router-id

no area area-id virtual-link router-id

| | | |
|-------------------------|---|--------------------------|
| Syntax | area | Configure OSPF Area |
| Description | <i>area-id</i> | OSPF Area id |
| | virtual-link | Establish a virtual link |
| | <i>router-id</i> | Neighbor Router ID |
| Defaults | N/A | |
| Command Modes | Router configuration mode as OSPF | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config-ospf) # area 1.1.1.1 virtual-link 0.0.0.0 | |
| Error messages | Configuration Error!! | |
| Related commands | show ip ospf | |

auth tacacs+

Use the **auth tacacs+** global configuration command on the switch to enable TACACS+ authentication. Use the **no** form of this command to return to the default setting.

Commands

auth tacacs+

no auth tacacs+

| | | |
|-------------------------|----------------------------------|------------------------------------|
| Syntax | auth | Configure authentication mechanism |
| Description | tacacs+ | TACACS+ authentication |
| Defaults | The default setting is disabled. | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # auth tacacs+ | |
| Error messages | N/A | |
| Related commands | show auth tacacs+ | |

auth tacacs+ auth-type

Use the **auth tacacs+ auth-type** global configuration command on the switch to specify the type of TACACS+ authentication. Use the **no** form of this command to return to the default setting.

Commands

auth tacacs+ auth-type { ascii | pap | chap | arap | mschap }

no auth tacacs+ auth-type

| Syntax | auth | Configure authentication mechanism |
|------------------|--|---|
| Description | tacacs+ | TACACS+ authentication |
| | auth-type | Specify the authentication type |
| | ascii | Normal ASCII code authentication |
| | pap | Password Authentication Protocol |
| | chap | Challenge-handshake authentication protocol |
| | arap | AppleTalk Remote Access Protocol |
| | mschap | Microsoft Challenge-handshake authentication protocol |
| Defaults | Default type is ASCII code authentication | |
| Command Modes | Global configuration | |
| Usage Guidelines | To enable the TACACS+ authentication, the command "auth tacacs+" must be executed first. | |
| Examples | PT-7828 (config) # auth tacacs+ auth-type ascii - Normal ASCII code authentication pap - Password Authentication Protocol chap - Challenge-handshake authentication protocol arap - AppleTalk Remote Access Protocol mschap - Microsoft Challenge-handshake authentication protocol protocol | |
| Error messages | N/A | |
| Related commands | auth tacacs+ show auth tacacs+ | |

auth tacacs+ server

Use the **auth tacacs+ server** global configuration command on the switch to set the TACACS+ authentication server address and the shared key information. Use the **no** form of this command to remove the settings.

Commands

auth tacacs+ server *server-address* **shared-key** *key* [**timeout** *seconds*]

no auth tacacs+ server

| | | |
|---------------------------|---|------------------------------------|
| Syntax Description | auth | Configure authentication mechanism |
| | tacacs+ | TACACS+ authentication |
| | server | TACACS+ authentication server |
| | server-address | Authentication server address |
| | shared-key | Configure the shared key |
| | key | Key string, max 15 characters |
| | timeout | Configure server timeout |
| | seconds | 1 to 255 sec. |
| Defaults | Default timeout is 30 seconds Default tacacs+ server port is 49 | |
| Command Modes | Global configuration | |
| Usage Guidelines | To enable the TACACS+ authentication, the command "auth tacacs+" must be executed first. | |
| Examples | <pre>PT-7828 (config) # auth tacacs+ server <STRING:auth_server> - Authentication server address PT-7828 (config) # auth tacacs+ server tacacs.server.moxa.com shared-key - Configure the shared key PT-7828 (config) # auth tacacs+ server tacacs.server.moxa.com shared-key <STRING:key> - Key string, max 15 characters PT-7828 (config) # auth tacacs+ server tacacs.server.moxa.com shared-key 1234 <LF> timeout - Configure server timeout PT-7828 (config) # auth tacacs+ server tacacs.server.moxa.com shared-key 1234 timeout <UINT:seconds> - 1 to 255 sec. PT-7828 (config) # auth tacacs+ server tacacs.server.moxa.com shared-key 1234 timeout 200</pre> | |
| Error messages | Timeout value must be in the range from 1 to 255 seconds Invalid IP protocol port | |
| Related commands | auth tacacs+ show auth tacacs+ | |

auto-backup

Use **auto-backup** to enable Auto load system configurations when the system boots up. To disable it, use the **no** form of this command.

Commands

auto-backup

no auto-backup

| | | |
|-------------------------|---|---|
| Syntax | auto-backup | Use auto backup configurator to restore configuration |
| Defaults | Auto-backup configuration is enabled by default. | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828# configure terminal PT-7828(config)# auto-backup PT-7828(config)# no au auto-backup - Deactive auto-backup configurator PT-7828(config)# no auto-backup</pre> | |
| Error messages | N/A | |
| Related commands | N/A | |

bind vlan

Use the **bind vlan** configuration command on the switch to bind the management address with a specified VLAN ID. Use the **no** form of this command to return to the default.

Commands

bind vlan *VLAN-ID*

| | | |
|-------------------------|---|------------------------------|
| Syntax | bind | Bind VLAN as management VLAN |
| Description | vlan | VLAN parameters |
| | VLAN-ID | 1 to 4094 |
| Defaults | Default management VLAN ID is 1 | |
| Command Modes | VLAN configuration mode as management VLAN | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # interface mgmt PT-7828 (config-vlan) # bind vlan <UINT:vlanid> - 1 to 4094 | |
| Error messages | L3 interface cannot be assigned as management interface VLAN id is out of range! | |
| Related commands | show interfaces mgmt | |

clear counters

Use the **clear counters** user EXEC command on the switch to clear the switch's statistics counters.

Commands

clear counters

| | | |
|-------------------------|--------------------------|----------------------------|
| Syntax | clear | Clear information |
| Description | counters | Clear statistic counters |
| Defaults | N/A | |
| Command Modes | Privileged | |
| Usage Guidelines | N/A | |
| Examples | PT-7828# clear counters | - Clear statistic counters |
| Error messages | N/A | |
| Related commands | show interfaces counters | |

clear logging event-log

Use the **clear logging event-log** user EXEC command on the switch to clear the system log of the switch.

Commands

clear logging event-log

| | | |
|-------------------------|----------------------------------|---------------------|
| Syntax | clear | Clear information |
| Description | logging | System event logs |
| | event-log | System event logs |
| Defaults | N/A | |
| Command Modes | Privileged | |
| Usage Guidelines | N/A | |
| Examples | PT-7828# clear logging | - System event logs |
| | PT-7828# clear logging event-log | - System event logs |
| Error messages | N/A | |
| Related commands | show logging | |

clock set

Use the **clock set** global configuration command on the switch to set the current switch time.

Commands

clock set *hh:mm:ss month day year*

| | | |
|-------------------------|--|-----------------------------|
| Syntax | clock | Configure time-of-day clock |
| Description | set | Adjust the clock |
| | <i>hh:mm:ss</i> | <i>hh:mm:ss</i> |
| | <i>month</i> | 1 to 12 |
| | <i>day</i> | 1 to 31 |
| | <i>year</i> | 2000 to 2037 |
| Defaults | N/A | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # clock set 11:11:11 1 1 2010 | |
| Error messages | Illegal parameters! | |
| Related commands | show clock | |

clock summer-time

Use the **clock summer-time** global configuration command on the switch to enable the daylight saving time offset and set the apply duration. Use the **no** form of this command to disable it.

Commands

clock summer-time start-date *month week day hour*

clock summer-time end-date *month week day hour*

clock summer-time offset *offset-hour*

| | | |
|-------------------------|--|--|
| Syntax | clock | Configure time-of-day clock |
| Description | summer-time | Configure Summer time parameter |
| | start-date | The date when summer time offset start |
| | end-date | The date when summer time offset end |
| | <i>month</i> | From 'Jan', 'January' or '1' to 'Dec', 'December', or '12' |
| | <i>week</i> | From '1st' or '1' to 'Last' or '6' |
| | <i>day</i> | From 'Sun', 'Sunday' or '1' to 'Sat', 'Saturday' or '7' |
| | <i>hour</i> | 0 to 23 |
| | offset | Summer time offset |
| | <i>offset-hour</i> | 1 to 12 |
| Defaults | N/A | |
| Command Modes | Global configuration | |
| Usage Guidelines | When configuring the summer time offset, the start-date and end-date must be configured correctly first. | |
| Examples | PT-7828 (config) # clock timezon gmt -4 | |
| Error messages | Invalid parameter Month must be configured as 'Jan', 'January' or a numerical '1'. Week must be configured as '1st', '2nd', '3rd', '4th', '5th' or 'Last' Day must be configured as 'Sun', 'Sunday' or a numerical '1'. Hour must be in the range from 0 to 23. Please input the correct start/end date of the summer time first! Hour offset is out of range. | |
| Related commands | show clock | |

clock timezone

Use the **clock timezone** global configuration command on the switch to set the current time zone.

Commands

clock timezone gmt offset-hour

| | | |
|-------------------------|--|-----------------------------|
| Syntax | clock | Configure time-of-day clock |
| Description | timezone | Time zone hour shifting |
| | gmt | Greenwich Mean Time |
| | offset-hour | -12 to 12 |
| | <i>Half an hour</i> | Only type 30 |
| Defaults | N/A | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | EDS-G516E(config)# clock timezone gmt 5 30 | |
| Error messages | This timezone doesn't support half an hour | |
| Related commands | show clock | |

copy

Use the **copy** privileged command on the switch to copy an image or configuration file from a remote server to the Flash memory or copy the running configuration, startup configuration, or event log to a remote server via TFTP.

Commands

copy tftp device-firmware

copy tftp running-config

copy {running-config|event-log|startup-config} tftp [tftp-address]

copy tftp ssl-certificate

| | | |
|-------------------------|--|--|
| Syntax | copy | Copy from one file to another |
| Description | tftp | Remote server through TFTP |
| | device-firmware | System firmware |
| | running-config | Current running configuration of system |
| | startup-config | System startup configuration |
| | event-log | Event log file |
| | tftp-address | TFTP address. E.g., tftp://192.168.127.1/abc.txt |
| | ssl-certificate | SSL certificate |
| Defaults | N/A | |
| Command Modes | Privileged EXEC | |
| Usage Guidelines | N/A | |
| Examples | PT-7828# copy tftp device-firmware - System firmware running-config - Current running configuration of system PT-7828# copy tftp running-config Address or name of remote host [192.168.127.1]? 192.168.127.95 Source file name ? cli.ini Save import config to flash ? [Y/n] Saving configuration ...Success PT-7828# copy tftp ssl-certificate moxa Address or name of remote host [192.168.127.1]? 192.168.127.100 | |

| | |
|-------------------------|--|
| | Source file name ? SSL_Certificate.pfx Importing SSL certificate, please wait..... Save ssl certification to flash ? [Y/n] Saving ssl certification ...Success |
| Error messages | Input error Invalid TFTP Server IP/Name !!! TFTP Configuration File Download Failed Invalid Config Files Path and Name !!! Invalid Firmware Files Path and Name !!! TFTP Firmware Download Failed !!! TFTP Configuration File Upload Failed !!! TFTP Log File Upload Failed !!! Importing had some error, please check password of the file. |
| Related commands | N/A |

dot1x auth

Use the **dot1x auth** global configuration command to set dot1x authentication type and relative configurations.

Commands

dot1x auth local

dot1x auth radius server server port port shared-key string
dot1x auth radius-local server server port port shared-key string

| | | |
|---------------------------|---|---|
| Syntax Description | dot1x | 802.1x setting |
| | auth | 802.1x auth type |
| | local | 802.1x authentication uses local database |
| | radius | 802.1x authentication uses radius server |
| | radius-local | 802.1x authentication uses both local and radius server |
| | server | 802.1x radius server name/ip |
| | server | 802.1x radius server name/ip string |
| | port | 802.1x radius server port |
| | port | 802.1x radius server port (default 1812) |
| | shared-key | 802.1x Shared Key |
| | string | Shared Key string |
| Defaults | 802.1x local authentication | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828(config)# dot1x auth local PT-7828(config)# dot1x auth radius server moxanet port 1812 shared-key moxa PT-7828(config)# dot1x auth radius-local server moxanet port 1812 shared-key moxa | |
| Error messages | Local Database is Full !!! Invalid User Name !!! Invalid User Password !!! Invalid User Description !!! | |
| Related commands | show dot1x | |

dot1x auth

Use the **dot1x auth** interface configuration command on the switch to enable port 802.1x authenticate. Use the **no** form of this command to return to the default setting.

Commands

dot1x auth
no dot1x auth

| | | |
|-------------------------|--|---|
| Syntax | dot1x | 802.1x setting |
| Description | auth | 802.1x port authentication enable/disable |
| Defaults | 802.1x port authentication default disable | |
| Command Modes | interface configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828(config)# interface ethernet 1/1 PT-7828(config-if)# dot1x auth PT-7828(config-if)# no dot1x auth | |
| Error messages | N/A | |

dot1x local-userdb

To add 802.1x local user database, use the **dot1x local-userdb** global configuration command. To remove the user database, use the **no** form of this command.

Commands

dot1x local-userdb username user password password [desc description]

no dot1x local-userdb username user

| | | |
|-------------------------|--|--|
| Syntax | dot1x | 802.1x setting |
| Description | local-userdb | Local user settings |
| | username | Local user |
| | user | Local user name (max. 30 characters) |
| | password | Local user password |
| | password | Local user password (max. 16 characters) |
| | desc | User description |
| | description | Description string |
| Defaults | N/A | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828(config)# dot1x local-userdb username moxa password moxanet PT-7828(config)# no dot1x local-userdb username moxa | |
| Error messages | Local Database is Full !!! Invalid User Name !!! Invalid User Password !!! Invalid User Description !!! | |
| Related commands | show dot1x local-userdb | |

dot1x reauth

Use the **dot1x reauth** global configuration command on the switch to globally enable periodic re-authentication of the client. Use the **no** form of this command to return to the default setting.

Commands

dot1x reauth [period period]

no dot1x reauth [period period]

| | |
|--------------|----------------|
| dot1x | 802.1x setting |
|--------------|----------------|

| | | |
|-------------------------|---|----------------------|
| Syntax | reauth | 802.1x reauth enable |
| Description | period | 802.1x reauth period |
| | <i>period</i> | 60 to 65535 seconds |
| Defaults | 802.1x reauth default enable and period 3600 seconds | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828(config)# dot1x reauth period 3600 PT-7828(config)# no dot1x reauth | |
| Error messages | Invalid Re-Auth Period!!! Must not be smaller than 65535 or greater than 60 | |
| Related commands | show dot1x | |

dot1x reauth

Use the **dot1x reauth** interface configuration command on the switch to trigger port 802.1x re-authenticate immediately.

Commands

dot1x reauth

| | | |
|-------------------------|---|---|
| Syntax | dot1x | 802.1x setting |
| Description | reauth | 802.1x port re-authenticate immediately |
| Defaults | N/A | |
| Command Modes | interface configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828(config)# interface ethernet 1/1 PT-7828(config-if)# dot1x reauth | |
| Error messages | N/A | |
| Related commands | N/A | |

dip-switch

Use the **dip-switch** command to disable/enable HW dip-switch function.

Commands

dip-switch

| | | |
|-------------------------|--|---|
| Syntax | disable | Disable HW dip-switch function. |
| Description | enable | Enable HW dip-switch function. |
| | mode turbo-ring-v1 | set dip-switch function as turbo-ring-v1. |
| | mode turbo-ring-v2 | set dip-switch function as turbo-ring-v2. |
| Defaults | 1.Enable dip-switch. 2.set to turbo-ring-v2. | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828(config)# dip-switch disable PT-7828(config-if)# dip-switch mode turbo-ring-v1 | |
| Error messages | N/A | |
| Related commands | N/A | |

eip

Use the **eip** command to disable/enable Ethernet/IP support.

Commands

eip

no eip

| | | |
|---------------------------|------------------------|--------------------|
| Syntax Description | eip | Enable Ethernet/IP |
| Defaults | Default is disable | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # eip | |
| Error messages | N/A | |
| Related commands | show eip | |

email-warning account

Use **email-warning account** to configure the account and the password to log in to the remote Mail Server. To clear the setting, use the **no** form of this command.

Commands

email-warning account name password

no email-warning account

| | | |
|---------------------------|---|-------------------------|
| Syntax Description | email-warning account | Email warning setting |
| | account | Email account on server |
| | name | User name |
| | password | User password |
| Defaults | N/A | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # email-warning account test1 1234 PT-7828 (config) # email-warning account test1 | |
| Error messages | Length of SMTP User name is too long !!! Invalid User name Length of password is too long!!! | |
| Related commands | show email-warning | |

email-warning event

Use the **email-warning event** global configuration command to enable the system warning events to send through the email if the event occurs. Use the **no** form of this command to disable the specified warning event notifications.

Commands

email-warning event { all | cold-start | warm-start | power-trans-off | power-trans-on | config-change | auth-fail | topology-change }

no email-warning event { cold-start | warm-start | power-trans-off | power-trans-on | config-change | auth-fail | topology-change}

| | | |
|---------------------------|---|---|
| Syntax Description | email-warning | Email warning setting |
| | event | System events |
| | all | Enable all events |
| | cold-start | Switch cold start |
| | warn-start | Switch warm start |
| | power-trans-off | Power transition (on->off) |
| | power-trans-on | Power transition (off->on) |
| | config-change | Configuration changed |
| | auth-fail | Authentication failed |
| | topology-change | Topology changed (from redundant protocols) |
| Defaults | All system events are disabled by default. | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828 (config) # email-warning event all - Enable all events cold-start - Switch cold start warm-start - Switch warm start power-trans-off - Power transition (on->off) power-trans-on - Power transition (off->on) config-change - Configuration changed auth-fail - Authentication failed topology-change - Communication redundancy topology changed PT-7828 (config) # email-warning event cold-start PT-7828 (config) # email-warning event topology-change PT-7828 (config) # email-warning event auth-fail PT-7828 (config) # exit PT-7828# show email-warning config Mail Server and Email Setup SMTP Server IP/Name : ms1.hinet.net SMTP Port : 25 Account Name : test1 Account Password : 1234 1st email address: test2@moxa.com 2nd email address : 3rd email address: test3@hinet.net 4th email address : System Events Cold Start : Enable Warm Start : Disable Conf. Changed : Disable Power On->Off : Disable Power Off->On : Disable Auth. Failure : Enable Topology Changed : Enable --More--</pre> | |
| Error messages | N/A | |
| Related commands | show email-warning | |

email-warning event

Use the **email-warning event** interface configuration command to allow interface warning events to be sent through the email if the event occurs. Use the **no** form of this command to disable the specified warning event notifications.

Commands

```
email-warning event { link-on | link-off }
no mail-warning event { link-on | link-off }
email-warning event traffic-overload [rxThreshold duration]
no email-warning event traffic-overload
```

| Syntax Description | email-warning Configure email warning event Port events link-on Link ON link-off Link OFF traffic-overload Traffic overloading rxThreshold 0 to 100 duration 1 to 300 |
|-------------------------|---|
| Defaults | All port events are disabled by default. |
| Command Modes | Interface configuration |
| Usage Guidelines | N/A |
| Examples | <pre>PT-7828# configure terminal PT-7828(config)# interface ethernet 3/1 PT-7828(config-if)# email-warning event - Port events PT-7828(config-if)# email-warning event link-on - Link ON link-off - Link OFF traffic-overload - Traffic overloading PT-7828(config-if)# email-warning event link-on PT-7828(config-if)# email-warning event traffic-overload 80 20 PT-7828(config-if)# PT-7828# show email-warning config Mail Server and Email Setup SMTP Server IP/Name : ms1.hinet.net SMTP Port : 25 Account Name : test1 Account Password : 1234 1st email address: test2@moxa.com 2nd email address : 3rd email address: test3@hinet.net 4th email address : System Events Cold Start : Enable Warm Start : Disable Conf. Changed : Disable Power On->Off : Disable Power Off->On : Disable Auth. Failure : Enable Topology Changed : Enable</pre> |
| Error messages | Threshold should be between 0 and 100 Duration should be between 1 and 300 |
| Related commands | show email-warning |

email-warning mail-address

Use **email-warning mail-address** to configure the email address(es) to which warning messages will be sent. To clear the setting, use **no** form of this command.

Commands

email-warning mail-address *mailIndex mailAddress*

no email-warning mail-address *mailIndex*

| | | |
|---------------------------|--|-----------------------|
| Syntax Description | email-warning | Email warning setting |
| | mail-address | Target email address |
| | <i>mailIndex</i> | 1 to 4 |
| | <i>mailAddress</i> | Email address |
| Defaults | N/A | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828 (config) # email-warning mail-address <UINT:mailIdx> - 1 to 4 PT-7828 (config) # email-warning mail-address 1 test2@moxa.com PT-7828 (config) # email-warning mail-address 3 test3@hinet.net</pre> | |
| Error messages | <p>Index should be between 1 and 4 Length of email address is too long !!! Invalid Email address format</p> | |
| Related commands | show email-warning | |

email-warning send test email

Use **email-warning send test email** to send a test email.

Commands

switch(config)# email-warning send test email

| | | |
|-------------------------|---|-----------------------|
| Syntax | email-warning | Email warning setting |
| Description | send | Send test email |
| | test | Test email |
| | email | Test email address |
| Defaults | N/A | |
| Command Modes | Global configuration | |
| Usage Guidelines | The test email will be sent to the mail address that " email-warning mail-address " command configured. | |
| Examples | <pre>PT-7828 (config) # email-warning server 192.168.127.95 <LF> <UINT:smtpPort> - SMTP Port PT-7828 (config) # email-warning server 192.168.127.95 25 PT-7828 (config) # email-warning account admin 1234 PT-7828 (config) # email-warning mail-address 1 <STRING:mailAddress> - Email address PT-7828 (config) # email-warning mail-address 1 alanc.wu@moxa.com PT-7828 (config) # email-warning send test email Sending test email ... You may check if your dedicated email addresses have received this email! PT-7828 (config) #</pre> | |
| Error messages | Warning !!! You must first do Email Setup before sending the test email. Warning !!! You must first configure DNS Server IP Address before sending the test email. Sending test email failed !!! | |
| Related commands | email-warning server email-warning account email-warning mail-address | |

email-warning server

Use **email-warning server** to configure Mail Server IP/Name (IP address or name) for the switch. To clear the setting, use the **no** form of this command.

Commands

email-warning server *smtpServerIp* [*smtpPort*]

no email-warning server

| | | |
|---------------------------|---|---------------------------|
| Syntax Description | email-warning | Email warning setting |
| | server | Email Server |
| | <i>smtpServerIp</i> | Email Server name/address |
| | <i>smtpPort</i> | SMTP Port, 1 to 65535 |
| Defaults | N/A | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # email-warning server mail.hinet.net 25 PT-7828 (config) # email-warning server ms1.hinet.net | |
| Error messages | Length of server address is too long !!! Invalid SMTP server name/address Invalid Mail Server Port, Range(1 to 65535) !!! | |
| Related commands | show email-warning | |

exit

Use **exit** to exit the current configuration mode.

Commands

exit

| | | |
|---------------------------|--------------------------------------|--|
| Syntax Description | exit | Exit from configure mode Exit from port setting mode Exit command line interface Exit from management interface setting |
| Defaults | N/A | |
| Command Modes | N/A | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # exit PT-7828 # | |
| Error messages | N/A | |
| Related commands | quit | |

flowcontrol

To set the method of data flow control between the terminal or other device, use the **flowcontrol** interface configuration command. Use the **no** form of this command to disable flow control

Commands

flowcontrol

no flowcontrol

| | | |
|---------------------------|--|-----------------------|
| Syntax Description | flowcontrol | Configure flowcontrol |
| Defaults | The default is disable | |
| Command Modes | Interface configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828(config)# interface ethernet 1/1 PT-7828(config-if)# flowcontrol PT-7828(config-if)# no flowcontrol | |
| Error messages | Fiber port can not be set flow control!! Force speed can not be set flow control!! Cannot configure on trunk member port 1/1! This setting cannot be applied on trunk port! | |
| Related commands | show interfaces ethernet | |

gmrp

Use the **gmrp** interface configuration command on the switch to active the IEEE 802.1D-1998 GMRP (GARP Multicast Registration Protocol). Use the **no** form of this command to stop this function.

Commands

gmrp

no gmrp

| | | |
|---------------------------|--|--|
| Syntax Description | gmrp | Enable GMRP (GARP Multicast Registration Protocol) |
| Defaults | gmrp is default disable | |
| Command Modes | Interface configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828(config)# interface ethernet 1/1 PT-7828(config-if)# gmrp PT-7828(config-if)# no gmrp | |
| Error messages | GMRP cannot be enabled on static multicast member port!!! | |
| Related commands | N/A | |

gvrp

Use the **gvrp** global configuration command on the switch to enable GVRP. Use the **no** form of this command to disable it.

Commands

gvrp

no gvrp

| | | |
|---------------------------|---|---------------------|
| Syntax Description | gvrp | Enable/Disable GVRP |
| Defaults | The feature is enabled by default. | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # gvrp gvrp - Enable GVRP | |
| Error messages | N/A | |
| Related commands | show gvrp | |

hostname

To specify or modify the host name for the network server, use the **hostname** global configuration command. To return to the default, use the **no** form of this command.

Commands

hostname name

no hostname

| | | |
|---------------------------|--|---|
| Syntax Description | hostname | Set system's network name (maximum 30 characters) |
| | name | Switch name string |
| Defaults | Name is the default switch name with the serial number | |
| Command Modes | Global configuration | |
| Usage Guidelines | Maximum string tokens are 5. Maximum switch name length is 30 characters. | |
| Examples | PT-7828 (config) # hostname MOXA Ethernet Switch PT 7828 PT-7828 (config) # exit PT-7828# show system System Information System Name : MOXA Ethernet Switch PT 7828 System Location : Switch Location System Description : MOXA PT-7828 Maintainer Information : MAC Address : 00:90:E8:1D:24:36 System Uptime : 0d0h36m57s | |
| Error messages | Length of switch hostname is too long | |
| Related commands | show system | |

interface mgmt

Use the **interface mgmt** global configuration command on the switch to enter the VLAN configuration mode of Mgmt-VLAN.

Commands

interface mgmt

| | | |
|-------------------------|--|----------------------------------|
| Syntax | interface | Select an interface to configure |
| Description | mgmt | Configure management VLAN |
| Defaults | N/A | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # interface mgmt - Configure management VLAN PT-7828 (config) # interface mgmt PT-7828 (config-vlan) # | |
| Error messages | N/A | |
| Related commands | show interfaces mgmt | |

interface vlan

Use the **interface vlan** global configuration command on the switch to create or access a dynamic switch virtual interface (SVI) and to enter interface configuration mode. Use the **no** form of this command to delete an SVI.

Commands

interface vlan *vlan-id*

no interface vlan *vlan-id*

| | | |
|-------------------------|--|----------------------------------|
| Syntax | interface | Select an interface to configure |
| Description | vlan | Configure L3 interface |
| | vlan-id | Configure L3 interface vlan id |
| Defaults | N/A | |
| Command Modes | Global configuration | |
| Usage Guidelines | Management vlan id cannot be same as interface vlan id. | |
| Examples | PT-7828 (config) # interface vlan 2 <UINT:vlanid> - Configure L3 interface vlan id | |
| Error messages | interface vlan 2 is not exist mgmt vlan id cannot be same as interface vlan id!! vlan interface full | |
| Related commands | show interfaces vlan | |

ip address

Use the **ip address** VLAN configuration command on the switch to configure the address of a Layer 3 interface.

Commands

ip address *ip-address netmask*

ip address

Use the **ip address VLAN** configuration command on the switch to configure the IP retrieve mechanism of the switch. Use **no** form of this command to return to the default.

Commands

ip address {static *ip-address netmask* | dhcp | bootp }

no ip address

| | | |
|---------------------------|---|--|
| Syntax Description | ip | Configure IP parameters |
| | address | Configure IP address |
| | static | E.g., 11.22.33.44 |
| | <i>ip-address</i> | IP address |
| | <i>netmask</i> | Subnet mask |
| | dhcp | Use DHCP to retrieve IP setting automatically |
| | bootp | Use BOOTP to retrieve IP setting automatically |
| Defaults | N/A | |
| Command Modes | VLAN configuration as management VLAN | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828 (config-vlan) # ip address static - Configure static IP dhcp - Use DHCP to retrieve IP setting automatically bootp - Use BOOTP to retrieve IP setting automatically</pre> | |
| Error messages | N/A | |
| Related commands | show interfaces mgmt | |

ip auto-assign

Use the **ip auto-assign** interface configuration command on the switch to enable and set the auto IP assignment of specified interfaces. Use the **no** form of this command to remove an Ethernet port from a trunk group.

Commands

ip auto-assign *ipaddr*

no ip auto-assign

| | | |
|-----------------------------|---|--|
| Syntax | ip | Configure IP paramters |
| Description | auto-assign | Automatic port IP assignment through DHCP/BootP/RARP |
| | <i>ipaddr</i> | E.g., 11.22.33.44 |
| Defaults | N/A | |
| Command Modes | Interface configuration | |
| Usage Guidelines | This specified IP address must be in the same subnet of the system IP address | |
| Examples (static IP) | PT-7828 (config-if) # ip auto-assign <IPV4ADDR:ipaddr> - E.g., 11.22.33.44 | |
| Error messages | Cannot configure on trunk member port | |
| | This IP address must be in the same subnet of the system IP address | |
| Related commands | show ip auto-assign | |

ip default-gateway

Use the **ip default-gateway** VLAN configuration command on the switch to configure the IP default gateway address. Use the **no** form of this command to return to the default.

Commands

ip default-gateway *ip-address*

no default-gateway

| | | |
|-------------------------|--|-----------------------------------|
| Syntax | ip | Configure IP paramters |
| Description | default-gateway | Configure default gateway address |
| | <i>ip-address</i> | IP address |
| Defaults | N/A | |
| Command Modes | VLAN configuration as management VLAN | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config-vlan) # ip default-gateway 192.168.1.1 | |
| Error messages | Warning! IP and gateway are not in the same subnet | |
| Related commands | show interfaces mgmt | |

ip dhcp retry

Use **ip dhcp retry** to enable the DHCP request retry for a specified period and times. Use the **no** form of this command to return to the default.

Commands

ip dhcp retry *times period seconds*

no ip dhcp retry

| | |
|---------------------------|--|
| Syntax Description | ip Global IP configuration subcommands dhcp DHCP related configuration retry Configure DHCP client request retry parameter times 0 - 65535 times, 0 means retry forever period Retry period seconds 1 - 30 seconds |
| Defaults | Default retry times = 0, retry period=1 |
| Command Modes | VLAN configuration as management VLAN |
| Usage Guidelines | N/A |
| Examples | <pre>PT-508(config-vlan)# ip dhcp retry 500 period 30 PT-508# show interfaces mgmt IPv4 Management VLAN id : 1 IP configuration : DHCP IP address : 192.168.127.253 Subnet mask : 255.255.255.0 Default gateway : 0.0.0.0 DNS server : Dhcp Retry Periods : 30 seconds Dhcp Retry Times : 500</pre> |
| Error messages | Illegal parameter! |
| Related commands | show interface mgmt |

ip dhcp-relay server

Use **ip dhcp-relay server** to configure the DHCP server address that the switch will forward DHCP messages to. To remove the DHCP server address, use the **no** form of this command.

Commands

ip dhcp-relay server *serverIndex* *serverAddr*

no ip dhcp-relay server *serverIndex*

| | | |
|---------------------------|--|--------------------------------------|
| Syntax Description | ip | Global IP configuration subcommands |
| | dhcp-relay | Configure DHCP relay agent parameter |
| | server | DHCP server IP address |
| | serverIndex | DHCP server address index, 1 to 4 |
| | serverAddr | DHCP server IP address |
| Defaults | N/A | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # ip dhcp-relay server 1 192.168.127.100 PT-7828 (config) # ip dhcp-relay server 3 192.168.127.200 | |
| Error messages | Invalid server index Invalid IPv4 address | |
| Related commands | show ip dhcp-relay | |

ip dhcp-relay option82

Use the **ip dhcp-relay option82** global and interface configuration command to enable DHCP Relay with Option 82 messages. To disable it, use the **no** form of this command.

Commands

ip dhcp-relay option82

no ip dhcp-relay option82

| | | |
|---------------------------|--|--------------------------------------|
| Syntax Description | ip | Configure IP parameters |
| | dhcp-relay | Configure DHCP relay agent parameter |
| | option82 | Option 82 |
| Defaults | Default is disabled. | |
| Command Modes | Global configuration / Interface configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # ip dhcp-relay option82 ? <LF> remote-id-type - Remote Id type man-id - Manual remote ID PT-7828 (config) # ip dhcp-relay option82 | |
| Error messages | N/A | |
| Related commands | N/A | |

ip dhcp-relay option82 remote-id-type

Use the **ip dhcp-relay option82 remote-id-type** global configuration command to select the remote ID information of DHCP option82 messages. Use **ip dhcp-relay option82 man-id** to manually set the remote id instead of the predefined ones.

Commands

ip dhcp-relay option82 remote-id-type *remoteIdType*

ip dhcp-relay option82 man-id *manualId*

| | | |
|-------------------------|---|---|
| Syntax | ip | Global IP configuration subcommands |
| Description | dhcp-relay | Configure DHCP relay agent parameter |
| | option82 | Option 82 |
| | remote-id-type | Remote Id type |
| | <i>remoteIdType</i> | ip mac client-id other |
| | man-id | Manual remote ID |
| | <i>manualId</i> | Manual remote ID, maximum 15 characters |
| Defaults | DHCP-relay option82 is disable in factory default. Default remote-id-type is IP. | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828 (config) # ip dhcp-relay option82 remote-id-type <STRING:remoteIdType> - ip mac client-id other PT-7828 (config) # ip dhcp-relay option82 remote-id-type mac PT-7828 (config) # ip dhcp-relay option82 remote-id-type other PT-7828 (config) # ip dhcp-relay option82 man-id abcdef</pre> | |
| Error messages | Invalid remote ID type Manual Id is over 15 characters | |
| Related commands | N/A | |

ip http-server

Use **ip http-server** global configuration commands on the switch to enable HTTP/HTTPs service. Use the **no** form of this command to disable HTTP/HTTPs service.

Commands

ip http-server

ip http-server secure

no ip http-server

| | | |
|-------------------------|--|-------------------------------------|
| Syntax | ip | Global IP configuration subcommands |
| Description | http-server | Enable HTTP/HTTPS web service |
| | secure | HTTPS support only |
| Defaults | HTTP service is enabled. | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # ip http-server auto-logout - Web auto-logout timer <LF> secure - HTTPS support only PT-7828 (config) # ip http-server secure PT-7828 (config) # ip http-server PT-7828 (config) # no ip http-server | |
| Error messages | N/A | |
| Related commands | show ip http-server | |

ip http-server auto-logout

Use **ip http-server auto-logout** global configuration commands on the switch to enable the auto-logout for the HTTP/HTTPs connections with specified seconds. Use the **no** form of this command to disable it.

Commands

ip http-server auto-logout seconds

| | | |
|-------------------------|--|---------------------------------------|
| Syntax | ip | Global IP configuration subcommands |
| Description | http-server | Enable HTTP/HTTPS web service |
| | auto-logout | Web auto-logout timer |
| | seconds | 0 for disable, or 60 to 86400 seconds |
| Defaults | Auto-logout is disabled by default. | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # ip http-server auto-logout 120 | |
| Error messages | Switch Web auto-logout interval should be 0(disable) or 60 to 86400s !!! | |
| Related commands | show ip http-server | |

ip igmp static-group

Use the **ip igmp static-group** global configuration command on the switch to add a static multicast MAC address and its member ports. Use the **no** form of this command to remove the static multicast group or just its member ports.

Commands

ip igmp static-group *MAC-address interface module/port*

no ip igmp static-group [*MAC-address*] [**interface** *module/port*]

| | | |
|---------------------------|--|---|
| Syntax Description | ip | Global IP configuration subcommands |
| | igmp | IGMP |
| | static-group | Add New Static Multicast MAC Address |
| | <i>MAC-address</i> | MAC address XX:XX:XX:XX:XX:XX |
| | interface | Binding ports |
| | <i>module/port</i> | Port(Trunk) ID or list. E.g., 1/1,2,4-5,2/1,Trk1,Trk2-Trk |
| Defaults | N/A | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828(config)# ip igmp static-group 01:00:00:00:00:01 interface 1/2-3 PT-7828(config)# no ip igmp static-group | |
| Error messages | Add new static multicast MAC address Fail !!! Please check the multicast mac address's type !!! Add new static multicast MAC address Fail !!! Not enough space to add a new static multicast MAC address !!! The member port should not be GMRP-enabled port !!! | |
| Related commands | show mac-address-table mcast | |

ip igmp-snooping

Use the **ip igmp-snooping** global configuration command on the switch to globally enable Internet Group Management Protocol (IGMP) snooping on the switch. Use the command with keywords to enable IGMP snooping. Use the **no** form of this command to disable IGMP snooping.

Commands

ip igmp-snooping

no ip igmp-snooping

| | | |
|---------------------------|---|-------------------------------------|
| Syntax Description | ip | Global IP configuration subcommands |
| | igmp-snooping | IGMP snooping |
| Defaults | IGMP snooping is globally disable | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828(config)# ip igmp-snooping PT-7828(config)# no ip igmp-snooping | |
| Error messages | IGMP Function is only supported by 802.1Q VLAN mode! | |
| Related commands | ip igmp-snooping vlan ip igmp-snooping querier ip igmp-snooping query-interval ip igmp-snooping enhanced show ip igmp | |

ip igmp-snooping enhanced

Use the **ip igmp-snooping enhanced** global configuration command on the switch to enable the enhanced mode. Use the **no** form of this command to disable the enhanced mode.

Commands

ip igmp-snooping enhanced

no ip igmp-snooping enhanced

| | | |
|---------------------------|--|---|
| Syntax Description | ip igmp-snooping enhanced | Global IP configuration subcommands IGMP snooping IGMP snooping enhanced mode |
| Defaults | Enhanced mode is globally disabled on the switch | |
| Command Modes | Global configuration | |
| Usage Guidelines | The IGMP snooping function must be enabled first. | |
| Examples | PT-7828(config)# ip igmp-snooping enhanced PT-7828(config)# no ip igmp-snooping enhanced | |
| Error messages | IGMP Function is Disabled !!! IGMP Function is only supported by 802.1Q VLAN mode! | |
| Related commands | ip igmp-snooping ip igmp-snooping vlan ip igmp-snooping querier ip igmp-snooping query-interval show ip igmp | |

ip igmp-snooping querier vlan

Use the **ip igmp-snooping querier** global configuration command to enable and configure the IGMP querier feature on a VLAN interface. Use the **no** form of this command to disable the IGMP querier feature.

Commands

ip igmp-snooping querier vlan *vlan-id*

no ip igmp-snooping querier vlan *vlan-id*

| | | |
|---------------------------|--|--|
| Syntax Description | ip igmp-snooping querier vlan <i>vlan-id</i> | Global IP configuration subcommands IGMP snooping IGMP snooping querier enable VLAN parameters 1 to 4094 |
| Defaults | The IGMP snooping querier feature is globally disabled on the switch | |
| Command Modes | Global configuration | |
| Usage Guidelines | The IGMP snooping function must be enabled first. | |
| Examples | PT-7828(config)# ip igmp-snooping querier vlan 1 PT-7828(config)# no ip igmp-snooping querier vlan 1 | |
| Error messages | Vlan entry not found!!! Vlan IGMP Function is Disabled !!! IGMP Function is Disabled !!! IGMP Function is only supported by 802.1Q VLAN mode! | |
| Related commands | ip igmp-snooping ip igmp-snooping vlan ip igmp-snooping querier ip igmp-snooping enhanced show ip igmp | |

ip igmp-snooping querier vlan vlan-id v3



NOTE

The command is supported only in Layer 3 switches.

Use the **ip igmp-snooping querier** global configuration command to enable and configure the IGMP querier feature on a VLAN interface. Use **ip igmp-snooping querier vlan *vlan-id* v3** can make the switch to send IGMP V3 query, otherwise the default is V2 query.

| | | |
|---------------------------|--|-------------------------------------|
| Syntax Description | ip | Global IP configuration subcommands |
| | igmp-snooping | IGMP snooping |
| | querier | IGMP snooping querier enable |
| | vlan | VLAN parameters |
| | <i>vlan-id</i> | 1 ~ 4094 |
| | v3 | IGMPv3 mode |
| Defaults | The IGMP snooping querier feature is globally disabled on the switch | |
| Command Modes | Global configuration | |
| Usage Guidelines | The IGMP snooping function must be enabled first. | |
| Examples | PT-7828(config)# ip igmp-snooping querier vlan 1 v3 | |
| Error messages | Vlan entry not found!!! Vlan IGMP Function is Disabled !!! IGMP Function is Disabled !!! IGMP Function is only supported by 802.1Q VLAN mode! | |
| Related commands | ip igmp-snooping ip igmp-snooping vlan ip igmp-snooping query-interval | |

ip igmp-snooping query-interval

Use the **ip igmp-snooping query-interval** global configuration command on the switch to configure the interval between IGMP queries. Use the **no** form of this command to return to the default.

Commands

ip igmp-snooping query-interval *interval*

| | | |
|---------------------------|---|-------------------------------------|
| Syntax Description | ip | Global IP configuration subcommands |
| | igmp-snooping | IGMP snooping |
| | query-interval | IGMP snooping query interval |
| | <i>interval</i> | 20 to 600 seconds |
| Defaults | Query interval default value is 125 seconds | |
| Command Modes | Global configuration | |
| Usage Guidelines | The IGMP snooping function must be enabled first. | |
| Examples | PT-7828(config)# ip igmp-snooping query-interval 125 | |
| Error messages | The range of Querier interval value should be between 20 and 600 !!! IGMP Function is Disabled !!! IGMP Function is only supported by 802.1Q VLAN mode! | |
| Related commands | ip igmp-snooping ip igmp-snooping vlan ip igmp-snooping querier ip igmp-snooping enhanced show ip igmp | |

ip igmp-snooping vlan

Use the **ip igmp-snooping vlan** global configuration command on the switch to globally enable Internet Group Management Protocol (IGMP) snooping on a VLAN. Use the **no** form of this command to disable IGMP snooping on a vlan.

Commands

ip igmp-snooping vlan *vlan-id* [mrouter** *module/port*]**

no ip igmp-snooping vlan *vlan-id* [mrouter** *module/port*]**

| | | |
|---------------------------|--|---|
| Syntax Description | ip igmp-snooping vlan vlan-id mrouter module/port | Global IP configuration subcommands IGMP snooping VLAN parameters 1 to 4094 IGMP snooping query port enable Port(Trunk) ID or list. E.g., 1/1,2,4-5,2/1,Trk1,Trk2-Trk4 |
| Defaults | N/A | |
| Command Modes | Global configuration | |
| Usage Guidelines | The IGMP snooping must be enabled first. | |
| Examples | PT-7828(config)# ip igmp-snooping vlan 1 mrouter 1/1 PT-7828(config)# no ip igmp-snooping vlan 1 mrouter 1/1 | |
| Error messages | Vlan entry not found!!! IGMP Function is Disabled !!! IGMP Function is only supported by 802.1Q VLAN mode! | |
| Related commands | ip igmp-snooping ip igmp-snooping querier ip igmp-snooping query-interval ip igmp-snooping enhanced show ip igmp | |

ip filter-ip

Use the **ip filter-ip** interface configuration command on the switch to add the IP filtering address entries. Use the **no** form of this command to delete the filtering entries.

Commands

ip filter-ip allowed *ip-address*

no ip filter-ip allowed *ip-address*

| | | |
|---------------------------|--|--|
| Syntax Description | ip filter-ip allowed ip-address | Configure IP paramters IP filter Configured traffic allowed from specified IP E.g., 11.22.33.44 |
| Defaults | N/A | |
| Command Modes | Interface configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828(config-if)# ip filter-ip allowed 192.168.127.1 <LF> | |
| Error messages | Not a unicast IP Allowed only 8 filters at most | |
| Related commands | show interfaces filter-ip | |

ip name-server

Use the **ip name-server** VLAN configuration command on the switch to configure the DNS server for the switch. Use the **no** form of this command to return to the default.

Commands

ip name-server *dns-ip-address1* [*dns-ip-address2*]

no name-server

| | | |
|-------------------------|--|------------------------------|
| Syntax | ip | Configure IP paramters |
| Description | name-server | Configure DNS server address |
| | <i>ip-address</i> | IP address |
| Defaults | N/A | |
| Command Modes | VLAN configuration as management VLAN | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config-vlan) # ip name-server 192.168.1.1 | |
| Error messages | Warning! IP and gateway are not in the same subnet | |
| Related commands | show interfaces mgmt | |

ip ospf area

Use the **ip ospf area** command in VLAN configuration mode to bind the interfaces with an OSPF area. Use **no ip ospf** to unbind the OSPF area.

Commands

ip ospf area *area-id*

no ip ospf

| | | |
|-------------------------|--|---------------------------|
| Syntax | ip | Configure L3 interface ip |
| Description | ospf | Configure OSPF |
| | area | OSPF Area binding |
| | <i>area-id</i> | OSPF Area id |
| Defaults | This command is disabled by default. | |
| Command Modes | VLAN configuration | |
| Usage Guidelines | Auth Key lengths up to 8 characters MD5 Key ID range 1 to 255 | |
| Examples | PT-7828 (config-vlan) # ip ospf auth md5 5 auth-key abcdabcd | |
| Error messages | Auth Key lengths up to 8 characters MD5 Key ID range 1 to 255 | |
| Related commands | show ip ospf interface | |

ip ospf auth

Use the **ip ospf auth** command in VLAN configuration mode to specify the authentication type for an interface. Use the **no** form of this command to remove the authentication type for an interface.

Commands

ip ospf auth simple auth-key key

ip ospf auth md5 key-id auth-key key

no ip ospf auth

| Syntax Description | ip | Configure L3 interface ip |
|-------------------------|--|--|
| | ospf | Configure OSPF |
| | auth | Configure OSPF authentication type |
| | simple | Configure OSPF authentication type to SIMPLE |
| | md5 | Configure OSPF authentication type to MD5 |
| | key-id | MD5 key id |
| | auth-key | Configure authentication key |
| | key | Key string |
| Defaults | This command is disabled by default. | |
| Command Modes | VLAN configuration | |
| Usage Guidelines | Auth Key lengths up to 8 characters MD5 Key ID range 1 to 255 | |
| Examples | PT-7828(config-vlan)# ip ospf auth md5 5 auth-key abcdabcd | |
| Error messages | Auth Key lengths up to 8 characters MD5 Key ID range 1 to 255 | |
| Related commands | show ip ospf interface | |

ip ospf cost

Use the **ip ospf cost** command in VLAN configuration mode to explicitly specify the cost of sending a packet on a VLAN interface. Use the **no** form of this command to return to the default.

Commands

ip ospf cost cost

no ip ospf cost

| Syntax Description | ip | Configure L3 interface ip |
|-------------------------|---------------------------------------|----------------------------|
| | ospf | Configure OSPF |
| | cost | Configure OSPF Metric |
| | cost | Metric value (1 to 65535) |
| Defaults | Default cost is 1 | |
| Command Modes | VLAN configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828(config-vlan)# ip ospf cost 10 | |
| Error messages | Metric Range 1 to 65535 | |
| Related commands | show ip ospf interface | |

ip ospf dead-interval

Use the **ip ospf dead-interval** command in interface configuration mode to set the interval at which hello packets must not be seen before neighbors declare the router down. Use the **no** form of this command to return to the default time.

Commands

ip ospf dead-interval *seconds*

no ip ospf dead-interval

| | | |
|---------------------------|---|--------------------------------|
| Syntax Description | ip | Configure L3 interface ip |
| | ospf | Configure OSPF |
| | dead-interval | Configure OSPF dead interval |
| | seconds | Dead Interval Range 1 to 65535 |
| Defaults | Default dead interval is 40 seconds | |
| Command Modes | VLAN configuration | |
| Usage Guidelines | Dead interval Range 1 to 65535 | |
| Examples | PT-7828 (config-vlan) # ip ospf dead-interval 100 | |
| Error messages | Dead Interval Range 1 to 65535 | |
| Related commands | show ip ospf interface | |

ip ospf hello-interval

Use the **ip ospf hello-interval** command in VLAN configuration mode to specify the interval between hello packets sent on the interface. Use the **no** form of this command to return to the default.

Commands

ip ospf hello-interval *seconds*

no ip ospf hello-interval

| | | |
|---------------------------|--|---------------------------------|
| Syntax Description | ip | Configure L3 interface ip |
| | ospf | Configure OSPF |
| | hello-interval | Configure OSPF hello interval |
| | seconds | Hello Interval Range 1 to 65535 |
| Defaults | Default interval is 10 seconds | |
| Command Modes | VLAN configuration | |
| Usage Guidelines | Hello Interval Range 1 to 65535 | |
| Examples | PT-7828 (config-vlan) # ip ospf hello-interval 100 | |
| Error messages | Hello Interval Range 1 to 65535 | |
| Related commands | show ip ospf interface | |

ip ospf priority

Use the **ip ospf priority** command in VLAN configuration mode to set the router priority for the determination of the designated router. Use the **no** form of this command to return to the default.

Commands

ip ospf priority priority

no ip ospf priority

| | |
|---------------------------|---|
| Syntax Description | ip Configure L3 interface ip ospf Configure OSPF priority Configure OSPF router priority priority priority range (0 to 255) |
| Defaults | Default priority is 1 |
| Command Modes | VLAN configuration |
| Usage Guidelines | priority range 0 to 255 |
| Examples | PT-7828 (config-vlan) # ip ospf priority 10 |
| Error messages | Priority Range 0 to 255 |
| Related commands | show ip ospf interface |

ip pim-dm



NOTE

This command is only supported by Layer 3 switches.

Use the **ip pim-dm** command to enable the PIM-DM function.

Commands

ip pim-dm

no ip pim-dm

| | |
|---------------------------|---|
| Syntax Description | ip Configure L3 interface IP pim-dm Configure PIM-DM |
| Defaults | This command is disabled by default |
| Command Modes | VLAN interface configuration |
| Usage Guidelines | N/A |
| Examples | ICS-G7852A-4XG (config-vif) # ip pim-dm ICS-G7852A-4XG (config-vif) # no ip pim-dm |
| Error messages | N/A |
| Related commands | show ip pim-dm show ip pim-dm neighbor |

ip pim-sm



NOTE

This command is only supported by Layer 3 switches.

Use the **ip pim-sm** command to enable the PIM-SM function.

Commands

ip pim-sm

no ip pim-sm

| | | |
|-------------------------|--|---------------------------|
| Syntax | ip | Configure L3 interface IP |
| Description | pim-sm | Configure PIM-SM |
| Defaults | This command is disabled by default | |
| Command Modes | VLAN interface configuration | |
| Usage Guidelines | N/A | |
| Examples | ICS-G7852A-4XG(config-vif)# ip pim-sm ICS-G7852A-4XG(config-vif)# no ip pim-sm | |
| Error messages | N/A | |
| Related commands | show ip pim-sm show ip pim-sm routing show ip pim-sm neighbor show ip pim-sm rp show ip pim-sm bsr | |

ip pim-sm dr-priority



NOTE

This command is only supported by Layer 3 switches.

Use **ip pim-sm dr-priority** command in VLAN interface configuration mode to setup DR priority.

Commands

ip pim-sm dr-priority *priority*

| | | |
|-------------------------|--|---------------------------|
| Syntax | ip | Configure L3 interface IP |
| Description | pim-sm | Configure PIM-SM |
| | dr-priority | Configure DR priority |
| | priority | Priority value |
| Defaults | Default priority is 0 | |
| Command Modes | VLAN interface configuration | |
| Usage Guidelines | The priority range is 0 to 4294967296 | |
| Examples | ICS-G7852A-4XG(config-vif)# ip pim-sm dr-priority 100 | |
| Error messages | N/A | |
| Related commands | show ip pim-sm show ip pim-sm routing show ip pim-sm neighbor show ip pim-sm rp show ip pim-sm bsr | |

ip pim-sm hello-interval



NOTE

This command is only supported by Layer 3 switches.

Use **ip pim-sm hello-interval** command in VLAN interface configuration mode to setup PIM-SM hello interval.

Commands

ip pim-sm hello-interval *interval*

| | | |
|---------------------------|--|---------------------------|
| Syntax Description | ip | Configure L3 interface IP |
| | pim-sm | Configure PIM-SM |
| | hello-interval | Configure hello interval |
| | <i>interval</i> | Interval value |
| Defaults | Default hello-interval is 30 | |
| Command Modes | VLAN interface configuration | |
| Usage Guidelines | The hello interval range is 1 to 65535 | |
| Examples | ICS-G7852A-4XG(config-vif) # ip pim-sm hello-interval 10 | |
| Error messages | N/A | |
| Related commands | show ip pim-sm show ip pim-sm routing show ip pim-sm neighbor show ip pim-sm rp show ip pim-sm bsr | |

ip pim-sm join-prune-interval



NOTE

This command is only supported by Layer 3 switches.

Use **ip pim-sm join-prune-interval** command in VLAN interface configuration mode to setup PIM-SM join-prune interval.

Commands

ip pim-sm join-prune-interval *interval*

| | | |
|-------------------------|--|---------------------------|
| Syntax | ip | Configure L3 interface IP |
| Description | pim-sm | Configure PIM-SM |
| | join-prune-interval | Configure hello interval |
| | <i>interval</i> | Interval value |
| Defaults | Default hello-interval is 30 | |
| Command Modes | VLAN interface configuration | |
| Usage Guidelines | The join-prune interval range is 1 to 65535 | |
| Examples | ICS-G7852A-4XG(config-vif)# ip pim-sm join-prune-interval 10 | |
| Error messages | N/A | |
| Related commands | show ip pim-sm show ip pim-sm routing show ip pim-sm neighbor show ip pim-sm rp show ip pim-sm bsr | |

ip proxy-arp

Use the **ip proxy-arp** VLAN configuration command on the switch to enable Proxy ARP. Use the **no** form of this command to disable Proxy ARP.

Commands

ip proxy-arp

no ip proxy-arp

| | | |
|-------------------------|--|-------------------------------|
| Syntax | ip | Configure L3 interface ip |
| Description | proxy-arp | Enable L3 interface proxy arp |
| Defaults | N/A | |
| Command Modes | VLAN configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config-vlan)# ip proxy-arp proxy-arp - Enable L3 interface proxy arp | |
| Error messages | vlan 4097 is invalid!! should be range from 1 to 4094 Interface not exist! Please create interface and set ip and netmask first | |
| Related commands | show interfaces vlan | |

ip route

Use the **ip route** command in global configuration mode to establish static routes. Use the **no** form of this command to remove the specified static routes.

Commands

ip route *prefix mask next-hop [distance]*

no ip route *prefix mask next-hop*

| | | |
|---------------------------|--|-------------------------------------|
| Syntax Description | ip | Global IP configuration subcommands |
| | route | Static routing entry |
| | <i>prefix</i> | Address prefix |
| | <i>mask</i> | Subnet mask |
| | <i>next-hop</i> | Next hop address |
| | <i>distance</i> | Distance metric |
| Defaults | N/A | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828(config)# ip route 2.2.0.0 255.0.0.0 2.2.3.1 10 | |
| Error messages | Route Entry Full!!! | |
| Related commands | show ip route show ip route static | |

ipv6 address

Use the **ipv6 address** command in VLAN configuration mode as a management VLAN to set the IPv6 address for the device. Use the **no** form of the command to return to the default.

Commands

ipv6 address *ipv6_prefix*

no ipv6 address

| | | |
|---------------------------|--|----------------------|
| Syntax Description | ipv6 | Configure IPv6 |
| | address | IPv6 address setting |
| | <i>ipv6_prefix</i> | IPv6 address prefix |
| Command Modes | VLAN configuration as management VLAN | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-510(config-vlan)# ipv6 address 1::1 PT-510# show interfaces mgmt IPv4 Management VLAN id : 1 IP configuration : Static IP address : 192.168.127.253 Subnet mask : 255.255.255.0 Default gateway : 0.0.0.0 DNS server :</pre> <pre>IPv6 Global Unicast Address Prefix : 1:0:0:1:201:2ff:fe03 Global Unicast Address : 1::1:201:2ff:fe03:405 Link-Local Address : fe80::201:2ff:fe03:405</pre> | |
| Error messages | Invalid prefix! | |
| Related commands | show interface mgmt | |

line-swap-fast-recovery

Use the **line-swap-fast-recovery** global configuration command on the switch to enable the fast recovery feature of the MAC address table when line swapping. Use the **no** form of this command to disable it.

Commands

line-swap-fast-recovery

no line-swap-fast-recovery

| | | |
|---------------------------|---|--|
| Syntax Description | line-swap-fast-recovery | Enable Line Swap Fast Recovery feature |
| Defaults | This feature is enabled by default. | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828(config) # line-swap-fast-recovery <LF></pre> | |
| Error messages | N/A | |
| Related commands | show mac-address-table | |

lldp enable

Use the **lldp enable** global configuration command to enable LLDP. To stop LLDP, use the **no** form of this command.

Commands

lldp run

no lldp run

| | | |
|-------------------------|---|---------------------------|
| Syntax | lldp | Configure LLDP parameters |
| Description | run | Start up |
| Defaults | LLDP is enable in factory default. | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # lldp enable PT-7828 (config) # no lldp enable | |
| Error messages | N/A | |
| Related commands | show lldp | |

lldp timer

Use the **lldp timer** global configuration command to configure the transmission frequency of LLDP messages. To reset the timer to default, use the **no** form of this command.

Commands

lldp timer transFreq

no lldp timer

| | | |
|-------------------------|---|--|
| Syntax | lldp | Configure LLDP parameters |
| Description | timer | Transmission frequency of LLDP updates |
| | transFreq | 5 to 32768 seconds |
| Defaults | Transmission frequency of LLDP updates is 30 seconds. | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # lldp timer <UINT:transFreq> - 5 to 32768 seconds PT-7828 (config) # lldp timer 4 % LLDP transmit frequency should be between 5 to 32768 PT-7828 (config) # lldp timer 50 | |
| Error messages | LLDP transmit frequency should be between 5 to 32768 | |
| Related commands | show lldp | |

logging

Use the **logging** global configuration command on the switch to configure the remote SYSLOG server. Use the **no** form of this command to remove the server.

Commands

logging ip-address

no logging ip-address

| | | |
|-------------------------|--|---|
| Syntax | logging | Syslog server setting |
| Description | <i>ip-address</i> | IP or DNS name w/wo. port, Ex:1.2.3.4 or 1.2.3.4:5678 |
| Defaults | N/A | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # logging 192.168.1.1 <LF> | |
| Error messages | Logging server configurations are full! | |
| Related commands | show logging | |

login mode

Use the **login mode** global configuration command to change the login UI mode from the console or telnet connection of the switch.

Commands

login mode { cli | menu }

| | | |
|-------------------------|---|------------------------|
| Syntax | login | Change login mode |
| Description | mode | Login mode |
| | cli | Command line interface |
| | menu | Legacy Menu Mode |
| Defaults | Default UI mode is MENU mode | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # login mode menu - Legacy Menu Mode cli - Command line interface PT-7828 (config) # login mode cli PT-7828 (config) # login mode menu | |
| Error messages | N/A | |
| Related commands | N/A | |

mac-address-table aging-time

Use the **mac-address-table aging-time** global configuration command on the switch to configure the aging time of the MAC address. Use the **no** form of this command to return to the default.

Commands

mac-address-table aging-time *seconds*

no mac-address-table aging-time

| | | |
|---------------------------|--|-----------------------------|
| Syntax Description | mac-address-table | Configure MAC address table |
| | aging-time | Aging time |
| | seconds | 15 to 3825 seconds |
| Defaults | Default aging time is 300 sec | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # mac-address-table aging-time <UINT:seconds> - 15 to 3825 seconds | |
| Error messages | N/A | |
| Related commands | show mac-address-table aging-time | |

mcast-filter

Use the **mcast-filter** interface configuration command on the switch to activate the multicast filter. Use the **no** form of this command to stop this function.

Commands

mcast-filter [forward-all | forward-unknown | filter-unknown]

no mcast-filter

| | | |
|---------------------------|---|------------------|
| Syntax Description | mcast-filter | Multicast filter |
| | forward-all | Forward all |
| | forward-unknown | Forward unknown |
| | filter-unknown | Filter unknown |
| Defaults | Default forward unknown | |
| Command Modes | Interface configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # interface ethernet 1/1 PT-7828 (config-if) # mcast-filter forward-all PT-7828 (config-if) # mcast-filter forward-unknown PT-7828 (config-if) # mcast-filter filter-unknown PT-7828 (config-if) # no mcast-filter | |
| Error messages | N/A | |
| Related commands | show mcast-filter | |

media cable-mode

Use the **media cable-mode** interface configuration command on the switch to enable the medium-dependent interface crossover feature on the interface. Use the **no** form of this command to disable Auto-MDIX.

Commands

media cable-mode [mdi | mdix | auto]

no media cable-mode

| | | |
|---------------------------|---|----------------------|
| Syntax Description | media | Select a media |
| | cable-mode | Select cable mode |
| | mdi | MDI |
| | mdix | MDIX |
| | auto | Auto select MDI/MDIX |
| Defaults | The default is auto | |
| Command Modes | Interface configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828(config)# interface ethernet 1/1 PT-7828(config-if)# media cable-mode auto PT-7828(config-if)# no media cable-mode | |
| Error messages | Fiber port can not be set MDI/MDIX!! This setting cannot be applied on trunk port! Cannot configure on trunk member port 1/1! | |
| Related commands | show interface ethernet | |

modbus

Use the **modbus** global configuration command on the switch to enable Modbus/TCP industrial Ethernet protocol supported. Use the **no** form of this command to disable Modbus support.

Commands

modbus

no modbus

| | | |
|---------------------------|-------------------------|---------------|
| Syntax Description | modbus | Enable Modbus |
| Defaults | Default is enable | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828(config)# modbus | |
| Error messages | N/A | |
| Related commands | show modbus | |

monitor

Use **monitor** global configuration commands to enable the monitoring of data transmitted/received by a specific port. Use the **no** form of this command to disable the monitoring.

Commands

monitor source interface mod_port [direction]

no monitor source interface

monitor destination interface mod_port

no monitor destination interface

| | | |
|---------------------------|--|------------------------------|
| Syntax Description | monitor | Configure Port mirror |
| | source | Monitored port |
| | interface | Port |
| | destination | Mirror port |
| | mod_port | Port ID. E.g., 1/3, Trk2,... |
| | direction | tx rx both |
| Defaults | N/A | |
| Command Modes | Global configuration | |
| Usage Guidelines | Traffic send/receive by a source port (Monitored port) will be mirrored to the destination port (Mirror port). | |
| Examples | <pre>PT-7828 (config) # monitor source interface 3/1 both Warning !!! Mirror Port don't set ! PT-7828 (config) # monitor destination interface <STRING:mirrorPort> - Port ID. E.g., 1/3, 2/1,... PT-7828 (config) # monitor destination interface 3/1,2 % Invalid format PT-7828 (config) # monitor destination interface 3/1 % Monitored Port is the same with Mirror Port !! PT-7828 (config) # monitor destination interface 3/2 PT-7828 (config) # monitor source interface 1/1-2</pre> | |
| Error messages | <p>Monitored Port is the same with Mirror Port !!!</p> <p>Invalid parameter</p> <p>Warning !!! Mirror Port don't set !</p> <p>Warning !!! Monitored Port don't set !</p> | |
| Related commands | show port monitor | |

Management-Interface

Use the **ip** global configuration command on the switch to set management interface

Commands

ip { http-server [secure] | telnet | ssh } [port *port-number*]

no ip { http-server [secure] | telnet | ssh }

| | | |
|---------------------------|--|----------------------------|
| Syntax Description | http-server | Enable Http-server service |
| | secure | Enable SSL service |
| | telnet | Enable Telnet service |
| | ssh | Enable SSH service |
| | port | Port |
| | <i>port-number</i> | Listening port number |
| Defaults | The feature is enabled by default. | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | <pre>EDS-G516E(config)# ip http-server port 80 Enable HTTP server? [Y/n] EDS-G516E(config)# ip http-server secure port 443 Enable HTTPS secure server? [Y/n] EDS-G516E(config)# ip telnet 23 EDS-G516E(config)# ip ssh port 22 EDS-G516E(config)# no ip http-server secure</pre> | |
| Error messages | Assigning duplicate port numbers is not allowed HTTP/SSH/Telnet/SSL port number is invalid, the interval is from 1 to 65535. | |
| Related commands | N/A | |

name

Use the **name** interface configuration command to configure the interface name. To remove the configuration, use the **no** form of this command.

Commands

name

no name

| | | |
|---------------------------|--|-----------|
| Syntax Description | name | Port name |
| Defaults | N/A | |
| Command Modes | Interface configuration | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828(config)# interface ethernet 1/1 PT-7828(config-if)# name interface1_port1 PT-7828(config-if)# no name</pre> | |
| Error messages | The length of port name must between 1 and 63! Cannot configure on trunk member port 1/1 | |
| Related commands | show interfaces ethernet show interfaces trunk | |

network

Use the **network** command in router configuration mode to enable the routing process on the specified interface. Use the **no** form of this command to disable it.

Commands

network if-name

no network if-name

| | | |
|--|---|---|
| Syntax | network | Enable dynamic routing on an IP network |
| Description | <i>if-name</i> | Interface name |
| Defaults | N/A | |
| Command Modes | Router configuration of RIP, OSPF, and Static routes | |
| Usage Guidelines | N/A | |
| Examples (for RIP settings) | <pre>PT-7828 (config)# vlan create 2 % create vlan id:2 PT-7828 (config)# interface vlan 2 PT-7828 (config-vlan)# ip address 192.168.102.1 255.255.255.0 PT-7828 (config-vlan)# name vlan2if PT-7828 (config-vlan)# exit PT-7828 (config)# router rip PT-7828 (config-rip)# network <STRING:ifname> - Interface name PT-7828 (config-rip)# network vlan2if PT-7828 (config-rip)# PT-7828# show ip rip RIP Protocol : Enable RIP version : V1 Distribution Connected : Enable Static : Disable OSPF : Disable RIP Enable Table Interface Name IP VID Enable ----- vlan2if 192.168.102.1 2 Enable PT-7828#</pre> | |
| Error messages | No such interface existed | |
| Related commands | show ip rip | |

ntp refresh-time

Use the **ntp refresh-time** global configuration command on the switch to configure the interval of each NTP query. Use the **no** form of this command to return to the default.

Commands

ntp refresh-time seconds

no ntp refresh-time

| | | |
|---------------------------|---|---------------------------------|
| Syntax Description | ntp | Configure Network Time Protocol |
| | refresh-time | Configure NTP query intervals |
| | seconds | 1-9999 seconds |
| Defaults | Default query interval is 600 sec | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # ntp refresh-time 600 <LF> | |
| Error messages | Time is out of range | |
| Related commands | show clock | |

ntp remote-server

Use the **ntp remote-server** global configuration command on the switch to configure the remote NTP server. Use the **no** form of this command to return to the default.

Commands

ntp remote-server server-addr-1 [server-addr-2]

no ntp remote-server

| | | |
|---------------------------|--|---|
| Syntax Description | ntp | Configure Network Time Protocol |
| | remote-server | Configure NTP server for time query |
| | simple | Configure Simple Network Time Protocol instead of Network Time Protocol |
| | server-addr-1 | IP address or DNS name |
| | server-addr-2 | IP address or DNS name |
| Defaults | The default configuration contains one time server "time.nist.gov". | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # ntp remote-server 192.168.127.1 time.stdtime.gov.tw | |
| Error messages | N/A | |
| Related commands | show clock | |

ntp server

Use the **ntp server** global configuration command on the switch to enable the switch as an NTP server. Use the **no** form of this command to return to disable it.

Commands

ntp server

no ntp server

| | | |
|-------------------------|-------------------------------|---------------------------------|
| Syntax | ntp | Configure Network Time Protocol |
| Description | server | Enable NTP server |
| Defaults | Default is disabled | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # ntp server | |
| Error messages | N/A | |
| Related commands | show clock | |

permit

Use the **permit** ACL configuration command on the switch to add a permit rule in the current ACL for traffic with specified IPs. Use the **no** form of this command to delete the rule.

Commands

permit ip-address

no permit ip-address

| | | |
|-------------------------|---|-------------------------|
| Syntax | permit | Configure PERMIT filter |
| Description | <i>ip-address</i> | E.g., 11.22.33.44 |
| Defaults | N/A | |
| Command Modes | ACL configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config-acl) # permit <IPV4ADDR:ipaddr> - E.g., 11.22.33.44 | |
| Error messages | Invalid IPv4 address | |
| Related commands | Show ip access-list ip access-list | |

ping

Use the **ping** user EXEC command on the switch to diagnose the remote host if it is alive.

Commands

ping *ip-address*

| | | |
|-------------------------|---|--------------------|
| Syntax | ping | Send echo messages |
| Description | <i>ip-address</i> | E.g., 11.22.33.44 |
| Defaults | N/A | |
| Command Modes | Privileged | |
| Usage Guidelines | N/A | |
| Examples | PT-7828# ping 192.168.127.1 PING 192.168.127.1, Send/Recv/Lost = 4/4/0 | |
| Error messages | N/A | |
| Related commands | N/A | |

port-security

Use the **port-security** interface configuration command on the switch to add a static unicast MAC-address on a specified port. Use the **no** form of this command to remove the specified MAC address.

Commands

port-security *MAC-address*

no port-security *MAC-address*

| | | |
|-------------------------|---|-------------------------------|
| Syntax | port-security | Set port security |
| Description | <i>MAC-address</i> | MAC address XX:XX:XX:XX:XX:XX |
| Defaults | N/A | |
| Command Modes | interface configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828(config-if)# port-security 00:00:00:00:00:01 PT-7828(config-if)# no port-security 00:00:00:00:00:01 | |
| Error messages | Add new static unicast MAC address Fail !!! | |
| Related commands | N/A | |

profinetio

Use the **profinetio** command to disable/enable PROFINET support (EDS-400A-PN series support only).

Commands

profientio

no profientio

| | | |
|---------------------------|---|--------------------|
| Syntax Description | profinetio | Enable PROFINET IO |
| Defaults | Default is disabled | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | EDS-G516E(config)# profinetio EDS-G516E(config)# no profinetio | |
| Error messages | N/A | |
| Related commands | Show profinetio | |

ptp announce-receipt-timeout

Use the **ptp announce-receipt-timeout** configuration command on the switch to set the announce-receipt-timeout parameter.

Commands

ptp announce-receipt-timeout *interval*

| | | |
|---------------------------|--|--|
| Syntax Description | ptp announce-receipt-timeout <i>interval</i> | Configure PTP Set the integral multiple of announceInterval <i>interval</i> 2 to 10 |
| Defaults | default is 3 | |
| Command Modes | configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828(config) # ptp announce-receipt-timeout | |
| Error messages | announceReceiptTimeout must be in the range from 2 to 10 | |
| Related commands | Show ptp settings Show ptp status Show ptp port | |

ptp arb-time

Use the **ptp arb-time** configuration command on the switch to set the arb-time parameter of the local clock.

Commands

ptp arb-time *time*

| | | |
|-------------------------|---|---|
| Syntax | ptp | Configure PTP |
| Description | arb-time | Set the ARB time parameter of the local clock |
| | <i>time</i> | 0 to 2147483646 |
| Defaults | default is 0 | |
| Command Modes | configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # ptp arb-time 0 | |
| Error messages | Arb time must be in the range from 0 to 2147483646 | |
| Related commands | Show ptp settings Show ptp status Show ptp port | |

ptp clockclass

Use the **ptp clockclass** configuration command on the switch to set the clockclass parameter of the local clock.

Commands

ptp clockclass *class*

| | | |
|-------------------------|---|--|
| Syntax | ptp | Configure PTP |
| Description | clockclass | Set the clock class parameter of the local clock |
| | <i>class</i> | 0 to 255 |
| Defaults | default is 248 | |
| Command Modes | configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # ptp clockclass 248 | |
| Error messages | clockclass must be in the range from 0 to 255 | |
| Related commands | Show ptp settings Show ptp status Show ptp port | |

ptp domain-number

Use the **ptp domain-number** configuration command on the switch to set the domain number of the local clock.

Commands

ptp domain-number *interval*

| | | |
|-------------------------|---|--|
| Syntax | ptp | Configure PTP |
| Description | domain-number | Set the domain number of the local clock |
| | <i>interval</i> | 0 to 3 |
| Defaults | default is 0 | |
| Command Modes | configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # ptp domain-number | |
| Error messages | domainNum must be in the range from 0 to 3 | |
| Related commands | Show ptp settings Show ptp status Show ptp port | |

ptp enable

Use the **ptp enable** command on the switch to enable the PTP operation. Use the **no** form of this command to disable the PTP operation on the switch.

Commands

ptp enable

no ptp

| | | |
|-------------------------|--|--------------------------|
| Syntax | ptp | Configure PTP |
| Description | enable | Enable the ptp operation |
| Defaults | ptp is default disable | |
| Command Modes | Configuration Interface configuration mode | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # ptp enable PT-7828 (config) # no ptp PT-7828 (config-if) # ptp enable PT-7828 (config-if) # no ptp | |
| Error messages | N/A | |
| Related commands | Show ptp settings Show ptp status Show ptp port | |

ptp leap59

Use the **ptp leap59** global configuration command on the switch to enable the PTP leap59. Use the **no** form of this command to disable the PTP leap59 on the switch.

Commands

ptp leap59

no ptp leap59

| | | |
|-------------------------|---|---|
| Syntax | ptp | Configure PTP |
| Description | leap59 | Enable the last minute of the current UTC day contains 59 seconds |
| Defaults | default disable | |
| Command Modes | configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # ptp leap59 PT-7828 (config) # no ptp leap59 | |
| Error messages | N/A | |
| Related commands | Show ptp settings Show ptp status Show ptp port | |

ptp leap61

Use the **ptp leap61** global configuration command on the switch to enable the PTP leap61. Use the **no** form of this command to disable the PTP leap61 on the switch.

Commands

ptp leap61

no ptp leap61

| | | |
|-------------------------|---|---|
| Syntax | ptp | Configure PTP |
| Description | leap61 | Enable the last minute of the current UTC day contains 61 seconds |
| Defaults | default disable | |
| Command Modes | configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # ptp leap61 PT-7828 (config) # no ptp leap61 | |
| Error messages | N/A | |
| Related commands | Show ptp settings Show ptp status Show ptp port | |

ptp log-sync-interval

Use the **ptp log-sync-interval** global configuration command on the switch to set the log-sync-interval parameter.

Commands

ptp log-sync-interval *interval*

| | | |
|-------------------------|---|--|
| Syntax | ptp | Configure PTP |
| Description | log-sync-interval | Set the logarithm to the base 2 of the mean SyncInterval |
| | <i>interval</i> | -3 to 1 |
| Defaults | default is 0 | |
| Command Modes | configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # ptp log-sync-interval | |
| Error messages | logSyncInterval must be in the range from -3 to 1 | |
| Related commands | Show ptp settings Show ptp status Show ptp port | |

ptp log-announce-interval

Use the **ptp log-announce-interval** global configuration command on the switch to set the log-announce-interval parameter.

Commands

ptp log-announce-interval *interval*

| | | |
|-------------------------|---|--|
| Syntax | ptp | Configure PTP |
| Description | log-announce-interval | Set the logarithm to the base 2 of the mean AnnounceInterval |
| | <i>interval</i> | 0 to 4 |
| Defaults | default is 1 | |
| Command Modes | configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # ptp log-announce-interval | |
| Error messages | logAnnounceInterval must be in the range from 0 to 4 | |
| Related commands | Show ptp settings Show ptp status Show ptp port | |

ptp log-min-delay-req-interval

Use the **ptp log-min-delay-req-interval** global configuration command on the switch to set the log-min-delay-req-interval parameter.

Commands

ptp log-min-delay-req-interval *interval*

| | | |
|-------------------------|---|---|
| Syntax | ptp | Configure PTP |
| Description | log-min-delay-req-interval | Set the logarithm to the base 2 of the mean minDelayReqInterval |
| | <i>interval</i> | 0 to 5 |
| Defaults | default is 0 | |
| Command Modes | configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # ptp log-min-delay-req-interval | |
| Error messages | logMinDelayReqInterval must be in the range from 0 to 5 | |
| Related commands | Show ptp settings Show ptp status Show ptp port | |

ptp log-min-pdelay-req-interval

Use the **ptp log-min-pdelay-req-interval** global configuration command on the switch to set the log-min-pdelay-req-interval parameter.

Commands

ptp log-min-pdelay-req-interval *interval*

| | | |
|-------------------------|---|--|
| Syntax | ptp | Configure PTP |
| Description | log-min-delay-req-interval | Set the logarithm to the base 2 of the mean minPDelayReqInterval |
| | <i>interval</i> | -1 to 5 |
| Defaults | default is 0 | |
| Command Modes | configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # ptp log-min-pdelay-req-interval | |
| Error messages | logMinPDelayReqInterval must be in the range from -1 to 5 | |
| Related commands | Show ptp settings Show ptp status Show ptp port | |

ptp mode

Use the **ptp mode** global configuration command on the switch to set the PTP operation mode.

Commands

ptp mode v1-bc
ptp mode v2-e2e-bc
ptp mode v2-p2p-bc
ptp mode v2-e2e-2step-tc
ptp mode v2-p2p-2step-tc

| Syntax Description | ptp mode | Configure PTP |
|-------------------------|---|---|
| | v1-bc | Set the ptp operation mode |
| | v2-e2e-bc | ptp v1 boundary clock mode |
| | v2-p2p-bc | ptp v2 end-to-end boundary clock mode |
| | v2-e2e-2step-tc | ptp v2 peer-to-peer boundary clock mode |
| | v2-p2p-2step-tc | ptp v2 end-to-end 2-step transparent clock mode |
| | v2-p2p-2step-tc | ptp v2 peer-to-peer 2-step transparent clock mode |
| Defaults | Default setting of ptp is v1-bc mode | |
| Command Modes | configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # ptp mode v1-bc | |
| Error messages | N/A | |
| Related commands | Show ptp settings Show ptp status Show ptp port | |

ptp preferred-master

Use the **ptp enable** configuration command on the switch to enable PTP operation. Use the **no** form of this command to disable PTP operation on the switch.

Commands

ptp enable
no ptp

| Syntax Description | ptp preferred-master | Configure PTP |
|--|---|--|
| | | Set the local clock as the master clock (only valid in v1-bc mode) |
| Defaults | default disable | |
| Command Modes | configuration | |
| Usage Guidelines | N/A | |
| Examples (set switch as local master clock) | PT-7828 (config) # ptp preferred-master | |
| Error messages | N/A | |
| Related commands | Show ptp settings Show ptp status Show ptp port | |

ptp priority1

Use the **ptp priority1** configuration command on the switch to set the priority1 parameter of the local clock.

Commands

ptp priority1 *priority*

| | | |
|-------------------------|---|--|
| Syntax | ptp | Configure PTP |
| Description | priority1 | Set the priority1 parameter of the local clock |
| | <i>priority</i> | 0 to 255 |
| Defaults | default is 128 | |
| Command Modes | configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # ptp priority1 128 | |
| Error messages | priority1 must be in the range from 0 to 255 | |
| Related commands | Show ptp settings Show ptp status Show ptp port | |

ptp priority2

Use the **ptp priority2** configuration command on the switch to set the priority2 parameter of the local clock.

Commands

ptp priority2 *priority*

| | | |
|-------------------------|---|--|
| Syntax | ptp | Configure PTP |
| Description | Priority2 | Set the priority2 parameter of the local clock |
| | <i>priority</i> | 0 to 255 |
| Defaults | default is 128 | |
| Command Modes | configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # ptp priority2 128 | |
| Error messages | priority2 must be in the range from 0 to 255 | |
| Related commands | Show ptp settings Show ptp status Show ptp port | |

ptp timescale

Use the **ptp timescale** configuration command on the switch to set the transport type of the ptp domain.

Commands

ptp timescale [arb|ptp]

| | | |
|-------------------------|--|---|
| Syntax | ptp | Configure PTP |
| Description | timescale | Set the timescale parameter of the local clock |
| | arb | Set the timescale parameter of the local clock to ARB |
| | ptp | Set the timescale parameter of the local clock to PTP |
| Defaults | default is ptp | |
| Command Modes | configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # ptp timescale arb PT-7828 (config) # ptp timescale ptp | |
| Error messages | N/A | |
| Related commands | Show ptp settings Show ptp status Show ptp port | |

ptp transport

Use the **ptp transport** configuration command on the switch to set the transport type of the ptp domain.

Commands

ptp transport [802_3|ipv4]

| | | |
|-------------------------|---|--|
| Syntax | ptp | Configure PTP |
| Description | transport | Set the transport type of the ptp domain |
| | 802_3 | Set the transport type of the PTP domain to 802.3/Ethernet |
| | Ipv4 | Set the transport type of the PTP domain to IPv4 |
| Defaults | default is ipv4 | |
| Command Modes | configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # ptp transport 802_3 PT-7828 (config) # ptp transport ipv4 | |
| Error messages | N/A | |
| Related commands | Show ptp settings Show ptp status Show ptp port | |

ptp utc-offset

Use the **ptp utc-offset** configuration command on the switch to set the PTP utc-offset field.

Commands

ptp utc-offset *interval*

| | | |
|-------------------------|--|-------------------------------------|
| Syntax | ptp | Configure PTP |
| Description | utc-offset | sets the offset between TAI and UTC |
| | <i>interval</i> | 0 to 65535 |
| Defaults | default is 0 | |
| Command Modes | configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # ptp utc-offset 0 | |
| Error messages | utc_offset must be in the range from 0 to 65535 | |
| Related commands | Show ptcp settings Show ptcp status Show ptcp port | |

ptp utc-offset-valid

Use the **ptp utc-offset-valid** configuration command on the switch to enable the PTP utc-offset field. Use the **no** form of this command to disable the PTP utc-offset field on the switch.

Commands

ptp utc-offset-valid

no ptp utc-offset-valid

| | | |
|-------------------------|---|---------------------------|
| Syntax | ptp | Configure PTP |
| Description | utc-offset-valid | UTC Offset field is valid |
| Defaults | default disable | |
| Command Modes | configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # ptp utc-offset-valid PT-7828 (config) # no ptp utc-offset-valid | |
| Error messages | N/A | |
| Related commands | Show ptcp settings Show ptcp status Show ptcp port | |

qos highest-priority

Use the **qos highest-priority** interface configuration command on the switch to set the Port Priority of the ingress frames to "High" queues of the Ethernet ports/Trunks. Use the **no** form of this command to return to the default.

Commands

qos highest-priority

no qos highest-priority

| | | |
|-------------------------|--|------------------------------------|
| Syntax | qos | Configure QoS |
| Description | highest-priority | Enable port highest priority queue |
| Defaults | N/A | |
| Command Modes | Interface configuration | |
| Usage Guidelines | N/A | |
| Examples | EDS-518A(config-if) # qos highest-priority | |
| Error messages | Cannot configure on trunk member port 1/1! | |
| Related commands | show qos | |

qos default-cos

Use the **qos default-cos** interface configuration command on the switch to configure the default CoS priority of the Ethernet ports/Trunks. Use the **no** form of this command to return to the default.

Commands

qos default-cos cos-value

no qos default-cos

| | | |
|-------------------------|---|------------------------------------|
| Syntax | qos | Configure QoS |
| Description | default-cos | Configure Default CoS of each port |
| | cos-value | CoS value (0 to 7) |
| Defaults | Default CoS value is 3 | |
| Command Modes | Interface configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config-if) # qos default-cos <UINT:cos> - CoS value (0 to 7) | |
| Error messages | Cannot configure on trunk member port 1/1! | |
| Related commands | show qos | |

qos inspect

Use the **qos inspect** global/interface configuration command on the switch to enable the inspect criteria. Use the **no** form of this command to disable it.

Commands

qos inspect dscp module_id

no qos inspect dscp module_id

qos inspect cos

no qos inspect cos

| | | |
|---------------------------|---|------------------------------------|
| Syntax Description | qos | Configure QoS |
| | Inspect | Configure inspection criteria |
| | dscp | Enable DSCP inspection |
| | <i>module_id</i> | Module ID from 1 to 4 |
| | cos | Enable CoS inspection of each port |
| Defaults | N/A | |
| Command Modes | Global configuration Interface configuration | |
| Usage Guidelines | In product with 88E6095, the "qos inspect dscp" command is configured in interface configuration mode. In product with BCM5650, the "qos inspect dscp" command is configured in global configuration mode with module index. | |
| Examples | PT-7828 (config) # qos inspect dscp - Enable DSCP inspection PT-7828 (config-if) # qos inspect cos - Enable CoS inspection of each port | |
| Error messages | Cannot configure on trunk member port 1/1! | |
| Related commands | show qos | |

qos mapping

Use the **qos mapping** global configuration command on the switch to configure the CoS and DSCP mappings. Use the **no** form of this command to return to the default.

Commands

qos mapping cos-to-queue *cos-value queue*

no qos mapping cos-to-queue

qos mapping dscp-to-cos *dscp-value cos-value*

no qos mapping dscp-to-cos

qos mapping dscp-to-queue *dscp-value queue*

no qos mapping dscp-to-queue

| Syntax | qos | Configure QoS |
|------------------|---|-----------------------|
| Description | mapping | Configure QoS mapping |
| | cos-to-queue | CoS to traffic queue |
| | cos-value | CoS value (0 to 7) |
| | queue | Traffic queue |
| | dscp-to-cos | DSCP to CoS mapping |
| | dscp-value | DSCP value (0 to 63) |
| | dscp-to-queue | DSCP to traffic queue |
| Defaults | Cos (queue): 0 (0), 1(0), 2(1), 3(1), 4(2), 5(2), 6(3), 7(3) DSCP(Cos): 0-7(0), 8-15(1), 16-23(2), 24-31(3), 32-39(4), 40-47(5), 48-55(6), 56-63(7) | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # qos mapping cos-to-queue 7 <UINT:queue> - Traffic queue PT-7828 (config) # qos mapping cos-to-queue 7 3 PT-7828 (config) # qos mapping dscp-to-cos 23 <UINT:cos> - CoS value (0 to 7) PT-7828 (config) # qos mapping dscp-to-cos 23 7 | |
| Error messages | Invalid parameter. CoS value must be 0 to 7 and queue number must be 0 to 3 Invalid parameter. CoS value must be 0 to 7 and DSCP value must be 0 to 63 | |
| Related commands | show qos | |

qos mode

Use the **qos mode** global configuration command on the switch to configure the current QoS strategy. Use the **no** form of this command to return to the default.

Commands

qos mode { weighted-fair | strict }

no qos mode

| | | |
|---------------------------|---|-----------------------------|
| Syntax Description | qos | Configure QoS |
| | mode | Configure queuing mechanism |
| | weighted-fair | Weighted fair queuing |
| | strict | Strict queuing |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # qos mode weighted-fair - Weighted fair queuing strict - Strict queuing | |
| Error messages | N/A | |
| Related commands | show qos | |

quit

Use **quit** to quit the current configuration mode.

Commands

quit

| | | |
|---------------------------|----------------|-----------------------------|
| Syntax Description | quit | Exit command line interface |
| Defaults | N/A | |
| Command Modes | N/A | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 # quit | |
| Error messages | N/A | |
| Related commands | Exit | |

rate-limit

Use the **rate-limit** interface configuration command on the switch to configure the traffic rate allowed for the specified port. Use the **no** form of this command to return to the default. For Marvell 88E6095 chipsets, use **rate-limit ingress rate** to set the ingress rate limiting; for Broadcom chipsets, use **rate-limit ingress percentage** to set the ingress rate limiting.

Commands

```
rate-limit { ingress | egress } percentage percentage  
no rate-limit { ingress | egress }
```

```
rate-limit ingress rate { none | 128k | 256k | 512k | 1M | 2M | 4M | 8M }  
rate-limit ingress mode { bcast | bcast-mcast | bcast-mcast-dlf | all }
```

```
rate-limit mode {normal | port-disable}
```

```
rate-limit normal { ingress | egress } percentage percentage  
no rate-limit normal { ingress | egress }
```

```
rate-limit normal ingress rate { none | 128k | 256k | 512k | 1M | 2M | 4M | 8M }  
rate-limit normal ingress mode { bcast | bcast-mcast | bcast-mcast-dlf | all }
```

```
rate-limit port-disable period period
```

```
rate-limit port-disable ingress rate { none | 44640 | 74410 | 148810 | 223220 | 372030 |  
20840 | 744050 }
```

| Syntax Description | rate-limit | Rate limiting |
|-------------------------|---|--|
| | normal | Rate limiting normal mode |
| | port-disable | Rate limiting port-disable mode |
| | ingress | Ingress rate limiting |
| | egress | Egress rate limiting |
| | percentage | Percentage correspond to current port speed |
| | <i>percentage</i> | Limit percentage, and will take effect at the percentage 0/3/5/10/15/25/35/50/65/85 |
| | rate | Specify the rate |
| | mode | Specify the mode |
| | bcast | Limit broadcast frames |
| | bcast-mcast | Limit broadcast and multicast frames |
| | bcast-mcast-dlf | Limit broadcast, multicast and DLF frames |
| | all | All traffic |
| | period | Port disable period |
| | <i>period</i> | Seconds |
| Defaults | 0 or none means unlimiting. | |
| Command Modes | Interface configuration | |
| Usage Guidelines | The percentage will only take effect at the 0/3/5/10/15/25/35/50/65/85 %. For port disable mode, the port will be disabled when the ingress rate reach the specified packet rate. | |
| Examples | <pre>PT-7828(config-if)# rate-limit percentage <UINT:percent> - Limit percentage, and will take effect at the percentage 0/3/5/10/15/25/35/50/65/85 EDS-408A-1M2S-SC(config-if)# rate-limit ingress rate none none none none PT-7828(config-if)# rate-limit port-disable ingress period 30 EDS-408A-1M2S-SC(config-if)# rate-limit port-disable ingress rate 148810</pre> | |
| Error messages | Cannot configure on trunk member port 1/1! This setting cannot be applied on trunk port! | |
| Related commands | show interfaces rate-limit | |

redistribute

Use the **redistribute** commands to enable learning routes from another IP routing protocol. Use the **no** form of this command to disable it.

Commands

redistribute connected
no redistribute connected

redistribute static
no redistribute static

redistribute rip
no redistribute rip

redistribute ospf
no redistribute ospf

| | | |
|---------------------------|--|---|
| Syntax Description | redistribute | Enable the switch's import routes learned through another IP routing protocol |
| | connected | Import routes learned through directly connected |
| | Static | Import routes learned through static route |
| | rip | Import routes learned through RIP |
| | ospf | Import routes learned through OSPF |
| Defaults | N/A | |
| Command Modes | Router configuration mode as OSPF / RIP | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config-ospf) # redistribute rip PT-7828 (config-rip) # redistribute ospf | |
| Error messages | N/A | |
| Related commands | show ip ospf show ip rip | |

redundancy

Use the **redundancy** global configuration command on the switch to enter the redundancy configuration mode.

Commands

redundancy

| | | |
|---------------------------|--|-------------------------------------|
| Syntax Description | redundancy | Enter redundancy configuration mode |
| Defaults | N/A | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # redundancy PT-7828 (config-rdnt) # | |
| Error messages | N/A | |
| Related commands | N/A | |

redundancy mode

Use the **redundancy mode** global configuration command on the switch to change the redundancy protocol mode.

Commands

redundancy mode { mst | rstp | turbo-ring-v1 | turbo-ring-v2 | turbo-chain }

| | | |
|-------------------------|---|-------------------------------------|
| Syntax | redundancy | Enter redundancy configuration mode |
| Description | mode | Specify the redundancy protocol |
| | mst | MSTP |
| | rstp | Rapid Spanning Tree |
| | turbo-ring-v1 | Turbo ring version 1 |
| | turbo-ring-v2 | Turbo ring version 2 |
| | turbo-chain | Turbo chain |
| Defaults | The default redundancy protocol mode is RSTP. | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # redundancy mode rstp - Rapid Spanning Tree turbo-ring-v1 - Turbo ring version 1 turbo-ring-v2 - Turbo ring version 2 turbo-chain - Turbo chain mst - MSTP | |
| Error messages | N/A | |
| Related commands | show redundancy mode | |

relay-warning config relay

Use **relay-warning config relay** to select relay to trigger when a warning event occurs.

Commands

relay-warning config relay [relayId]

| | | |
|-------------------------|---|---------------------------------|
| Syntax | relay-warning | Configure relay warning |
| Description | config | Choose which relay to configure |
| | relay | Relay |
| | relayId | Relay's ID = 1 or 2 |
| Defaults | N/A | |
| Command Modes | Global configuration / Interface configuration | |
| Usage Guidelines | These commands only existed in device with multiple relays. | |
| Examples | N/A | |
| Error messages | Please designate the relay ID Invalid relay ID | |
| Related commands | show relay-warning | |

relay-warning event

Use **relay-warning event** global configuration commands to enable the warning events trigger to the relay. Use the **no** form of this command to disable it.

Commands

relay-warning event { power-input1-fail | power-input2-fail | turbo-ring-break }

no relay-warning event { power-input1-fail | power-intput2-fail | turbo-ring-break }

| | | |
|---------------------------|---|---------------------------------|
| Syntax Description | relay-warning | Configure relay warning |
| | event | System events |
| | power-input1-fail | Power input 1 failure (On->Off) |
| | power-input2-fail | Power input 2 failure (On->Off) |
| | turbo-ring-break | Turbo Ring break |
| Defaults | All system events are disabled by default. | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828# configure terminal PT-7828(config)# relay-warning override - Override the relay warning setting event - System events PT-7828(config)# relay-warning event power-input1-fail - Power input 1 failure (ON->Off) power-input2-fail - Power input 2 failure (ON->Off) turbo-ring-break - Turbo Ring break PT-7828(config)# relay-warning event turbo-ring-break</pre> | |
| Error messages | N/A | |
| Related commands | show relay-warning | |

relay-warning event

Use **relay-warning event** interface configuration commands to enable the warning events trigger to the relay. Use the **no** form of this command to disable it.

Commands

```
relay-warning event { link-on | link-off }
relay-warning event traffic-overload [ rxThreshold duration ]
no relay-warning event { link | traffic-overload }
```

| Syntax Description | relay-warning event | Configure relay warning |
|-------------------------|--|-------------------------|
| | event | Port events |
| | link-on | Link ON |
| | link-off | Link OFF |
| | traffic-overload | Traffic overloading |
| | <i>rxThreshold</i> | 0 to 100 |
| | <i>duration</i> | 1 to 300 |
| | link | All link events |
| Defaults | All interface events are disabled by default. | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828 (config) # interface ethernet 3/1 PT-7828 (config-if) # relay-warning event ? link-on - Link ON link-off - Link OFF traffic-overload - Traffic overloading PT-7828 (config-if) # relay-warning event link-off PT-7828 (config-if) # relay-warning event traffic-overload</pre> | |
| Error messages | Threshold should be between 0 and 100 Duration should be between 1 and 300 | |
| Related commands | show relay-warning | |

relay-warning override

Use **relay-warning override** relay to override the relay warning setting temporarily. Releasing the relay output will allow administrators to fix any problems with the warning condition. Use the no form of this command to disable the override.

Commands

```
relay-warning override relay [ relayId ]
no relay-warning override relay [ relayId ]
```

| Syntax Description | relay-warning override | Configure relay warning |
|-------------------------|---|------------------------------------|
| | override | Override the relay warning setting |
| | relay | Relay |
| | <i>relayId</i> | Relay's ID = 1 or 2 |
| Defaults | N/A | |
| Command Modes | Global configuration | |
| Usage Guidelines | relayId will only be used on the product that have multiple relays. | |
| Examples | <pre>PT-7828 (config) # relay-warning override relay</pre> | |
| Error messages | Please designate the relay ID Invalid relay ID | |
| Related commands | show relay-warning | |

reload

Use the **reload** privileged command on the switch to restart the Moxa Switch. Use the **reload factory-default** privileged command to restore the switch configuration to the factory default values.

Commands

reload [factory-default]

| | | |
|-------------------------|---|--|
| Syntax | reload | Halt and perform a cold restart |
| Description | factory-default | Halt and perform a cold restart with factory default |
| Defaults | N/A | |
| Command Modes | Privileged EXEC | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828# reload <LF> factory-default - Halt and perform a cold restart with factory default PT-7828# rel reload - Halt and perform a cold restart PT-7828# reload factory-default <LF> PT-7828# reload Proceed with reload ? [Y/n] PT-7828# reload factory-default Proceed with reload to factory default? [Y/n]</pre> | |
| Error messages | N/A | |
| Related commands | N/A | |

router ospf

To configure an Open Shortest Path First (OSPF) routing process, use the **router ospf** command in global configuration mode. To terminate an OSPF routing process, use the **no** form of this command.

Commands

router ospf [router-id]

no router ospf

| | | |
|-------------------------|---|--|
| Syntax | router | Enable a routing process |
| Description | ospf | Enable OSPF routing, and enter router configuration mode |
| | <i>router-id</i> | OSPF routing ID has a unique value |
| Defaults | N/A | |
| Command Modes | Global configuration | |
| Usage Guidelines | Use router ospf commands to enable OSPF routing process. Use router ospf router-id to entering the Router configuration mode as OSPF. | |
| Examples | <pre>PT-7828(config)# router ospf PT-7828(config)# router ospf 0.0.1.1 PT-7828(config-ospf) #</pre> | |
| Error messages | Invalid parameters! | |
| Related commands | show ip ospf | |

router rip

Use the **router rip** global configuration command to Enable a RIP routing process, and enter router configuration mode. To turn off the RIP routing process, use the **no** form of this command.

Commands

router rip

no router rip

| | | |
|-------------------------|---|---|
| Syntax | router | Enable a routing process |
| Description | rip | Enable RIP (Routing Information Protocol) |
| Defaults | RIP is disabled in factory default. | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # router rip PT-7828 (config-rip) # | |
| Error messages | N/A | |
| Related commands | show ip rip | |

router vrrp

To enable Virtual Router Redundancy Protocol (VRRP), use the **router vrrp** command in global configuration mode. To disable the VRRP, use the no form of this command

Commands

router vrrp

no router vrrp

| | | |
|-------------------------|---|--|
| Syntax | router | Enable a routing process |
| Description | vrrp | Enable VRRP (Virtual Router Redundancy Protocol) |
| Defaults | VRRP is not default disabled. | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # router vrrp PT-7828 (config) # no router vrrp | |
| Error messages | N/A | |
| Related commands | show ip vrrp | |

router vrrp adver-interval



NOTE

This command is only supported by Layer 3 switches.

Use **router vrrp adver-interval** command in global configuration mode to setup VRRP advertisement interval.

Commands

router vrrp adver-interval *interval*

| | | |
|-------------------------|--|--|
| Syntax | router | Enable a routing process |
| Description | vrrp | Enable VRRP (Virtual Router Redundancy Protocol) |
| | adver-interval | Configure advertisement interval |
| | <i>interval</i> | Interval value |
| Defaults | Default VRRP adver-interval is 1000 ms | |
| Command Modes | Global configuration | |
| Usage Guidelines | The join-prune interval range is 25 to 1000 ms | |
| Examples | ICS-G7852A-4XG(config) # router vrrp adver-interval 25 | |
| Error messages | N/A | |
| Related commands | show ip vrrp | |

save config

Use the **save config** command to save the running configuration to the startup configuration on flash.

Commands

save config

| | | |
|-------------------------|---|-------------------------------------|
| Syntax | save | Save running configuration to flash |
| Description | config | Save running configuration to flash |
| Defaults | N/A | |
| Command Modes | Privileged EXEC | |
| Usage Guidelines | N/A | |
| Examples | PT-7828# save config Saving configuration ...Success | |
| Error messages | N/A | |
| Related commands | N/A | |

show acl



NOTE

The command is supported only in Layer 3 switches.

Use the **show acl** user EXEC command to display the ACL configuration.

Commands

show acl [id]

show acl summary

| | | |
|---------------------------|--|---------------------------------|
| Syntax Description | show | Show running system information |
| | acl | Display ACL information |
| | <i>id</i> | The access list ID |
| | summary | Display active ACL status |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828# show acl 10 ACL ID : 10 Name : Type : MAC-base Rule Index : 1 Action : deny Source MAC Address : 00:11:22:33:44:55/FF:FF:FF:00:00:00 Destination MAC Address : AA:BB:CC:DD:EE:FF/FF:FF:FF:00:00:00:00 Ether Type : 2048 VLAN ID : 10 Ingress Port Map : 0 Egress Port Map : 0 ----- PT-7828# show acl summary Type ID Attached Port Name ----- MAC-base 1 test_acl1 MAC-base 10</pre> | |
| Error messages | Invalid ID! | |
| Related commands | | |

show auth tacacs+

Use the **show auth tacacs+** user EXEC command to display the setting of TACACS+ authentication traffic statistic information of interfaces.

Commands

show auth tacacs+

| | | |
|-------------------------|---|---------------------------------|
| Syntax | auth | Display authentication settings |
| Description | tacacs+ | Tacacs+ authentication |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | PT-7828# show auth tacacs+ Tacacs+ information: Status : Disabled Auth server : tacacs.server.moxa.com, port:49 Shared key : Auth type : ASCII Server Timeout : 23 sec. | |
| Error messages | N/A | |
| Related commands | auth tacacs+ auth tacacs+ server auth tacacs+ auth-type | |

show clock

Use the **show clock** user EXEC command to display time-related settings.

Commands

show clock

| | | |
|---------------------------|--|--------------------------|
| Syntax Description | clock | Display the system clock |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | PT-7828# show clock Current Time : Fri Jan 01 08:38:28 2010 Daylight Saving Start Date : End Date : Offset : Time Zone : GMT-4:00 Time Server : Query Period : 600 sec NTP/SNTP Server : Disabled | |
| Error messages | N/A | |
| Related commands | clock set clock summer-time clock timezone ntp refresh-time ntp remote-server ntp server | |

show dot1x

To check the 802.1x setting, use the **show dot1x** command.

Commands

show dot1x

| | | |
|---------------------------|---|-------------------------|
| Syntax Description | dot1x | Display 802.1x settings |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | PT-7828# show dot1x Database Option: Local Radius Server : localhost Server Port : 1812 Shared Key : Re-Auth : Enable Re-Auth Period : 3600 Port 802.1X Enable ----- 1-1 Disable 1-2 Enable 1-3 Disable 1-4 Disable | |
| Error messages | N/A | |
| Related commands | dot1x auth dot1x reauth | |

show dot1x local-userdb

To check the 802.1x local user database, use the **show dot1x local-userdb** command.

Commands

show dot1x local-userdb

| | | |
|---------------------------|---|--------------------------------|
| Syntax Description | dot1x | Display 802.1x settings |
| | local-userdb | Display current local database |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | PT-7828# show dot1x local-userdb Index User Name Description ----- 1 moxanet moxanet | |
| Error messages | N/A | |
| Related commands | dot1 local-userdb | |

show eip

Commands

show eip

| | | |
|---------------------------|----------------------------------|-----------------------------------|
| Syntax Description | eip | Display Ethernet/IP configuration |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | PT-7828# show eip eip disable | |
| Error messages | N/A | |
| Related commands | eip | |

show PROFINETIO

*Use the **show profinetio** user EXEC command to display PROFINET configuration*

Commands

show profinetio

| | | |
|---------------------------|---|---|
| Syntax Description | show profinetio | Show running system information Display PROFINET configuration |
| Defaults | N/A | |
| Command Modes | Privileged EXEC / User EXEC | |
| Usage Guidelines | N/A | |
| Examples | EDS-G516E> show profinetio profinet io disable | |
| Error messages | N/A | |
| Related commands | profinetio | |

show email-warning config

Commands

show email-warning config

| | | |
|---------------------------|---|-------------------------------------|
| Syntax Description | show | Show running system information |
| | email-warning | Display Email warning configuration |
| | config | Email warning configuration |
| Defaults | N/A | |
| Command Modes | Privileged EXEC /User EXEC | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828# show email-warning config Mail Server and Email Setup SMTP Server IP/Name : SMTP Port : 25 Account Name : Account Password : 1st email address : 2nd email address : 3rd email address : 4th email address : System Events Cold Start : Disable Warm Start : Disable Conf. Changed : Disable Power On->Off : Disable Power Off->On : Disable Auth. Failure : Disable Topology Changed : Disable --More-- Port Events Setting Link Link Traffic RX Traffic Port ON OFF Overload Threshold(%) Duration(s) ----- ----- 1-1 Disable Disable Disable 0 1 1-2 Disable Disable Disable 0 1 1-3 Disable Disable Disable 0 1 1-4 Disable Disable Disable 0 1 1-5 Disable Disable Disable 0 1 1-6 Disable Disable Disable 0 1 1-7 Disable Disable Disable 0 1 1-8 Disable Disable Disable 0 1 3-1 Disable Disable Disable 0 1 3-2 Disable Disable Disable 0 1 3-3 Disable Disable Disable 0 1 3-4 Disable Disable Disable 0 1 3-5 Disable Disable Disable 0 1 3-6 Disable Disable Disable 0 1 3-7 Disable Disable Disable 0 1 3-8 Disable Disable Disable 0 1 PT-7828#</pre> | |
| Error messages | N/A | |
| Related commands | email-warning event email-warning account email-warning server email-warning mail-address | |

show gmrp

Use the **show gmrp** user EXEC command to display the GMRP table of the switch.

Commands

show gmrp

| | | |
|--------------------|---|--------------------|
| Syntax Description | gmrp | Show GMRP Settings |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | PT-7828# show gmrp Index Multicast Address Fixed Ports ----- ----- | Learned Ports |
| Error messages | N/A | |
| Related commands | gmrp | |

show gvrp

Use the **show gvrp** user EXEC command to display GVRP state information.

Commands

show gvrp

| | | |
|-------------------------|-------------|-----------------------------------|
| Syntax | show | Show running system information |
| Description | gvrp | Display GVRP configuration |
| Defaults | N/A | |
| Command Modes | | Privileged EXEC / User Exec |
| Usage Guidelines | N/A | |
| Examples | | PT-7828# show gvrp gvrp enable |
| Error messages | N/A | |
| Related commands | | gvrp |

show interfaces acl



NOTE

The command is supported only in Layer 3 switches.

Use the **show interfaces acl** user EXEC command to display ACL configurations by port.

Command

show interfaces ethernet [module/port] acl

| Syntax | show | Show running system information | | | | | | | | | | | | | | | | | | | | |
|-------------------------|--|--|-------|----|-----------|-------|---------|---|---------|---|----------|---|---------|---|---------|---|---------|---|----------|----|----------|---|
| Description | interfaces | Interface status and configuration | | | | | | | | | | | | | | | | | | | | |
| | ethernet | IEEE 802.3/IEEE 802.3z | | | | | | | | | | | | | | | | | | | | |
| | module/port | Port ID or list. Ex. 1/1,2,3,2/1-3,5,... | | | | | | | | | | | | | | | | | | | | |
| | acl | Display ACL configurations by port | | | | | | | | | | | | | | | | | | | | |
| Defaults | N/A | | | | | | | | | | | | | | | | | | | | | |
| Command Modes | Privileged EXEC/ User EXEC | | | | | | | | | | | | | | | | | | | | | |
| Usage Guidelines | N/A | | | | | | | | | | | | | | | | | | | | | |
| Examples | PT-7828# show interfaces ethernet 2/1 acl | | | | | | | | | | | | | | | | | | | | | |
| | <table><thead><tr><th>Type</th><th>ID</th><th>Direction</th><th>Index</th></tr></thead><tbody><tr><td>IP-base</td><td>2</td><td>Inbound</td><td>1</td></tr><tr><td>MAC-base</td><td>4</td><td>Inbound</td><td>2</td></tr><tr><td>IP-base</td><td>7</td><td>Inbound</td><td>3</td></tr><tr><td>MAC-base</td><td>11</td><td>Outbound</td><td>4</td></tr></tbody></table> | | Type | ID | Direction | Index | IP-base | 2 | Inbound | 1 | MAC-base | 4 | Inbound | 2 | IP-base | 7 | Inbound | 3 | MAC-base | 11 | Outbound | 4 |
| Type | ID | Direction | Index | | | | | | | | | | | | | | | | | | | |
| IP-base | 2 | Inbound | 1 | | | | | | | | | | | | | | | | | | | |
| MAC-base | 4 | Inbound | 2 | | | | | | | | | | | | | | | | | | | |
| IP-base | 7 | Inbound | 3 | | | | | | | | | | | | | | | | | | | |
| MAC-base | 11 | Outbound | 4 | | | | | | | | | | | | | | | | | | | |
| Error messages | Invalid ID! | | | | | | | | | | | | | | | | | | | | | |
| Related commands | | | | | | | | | | | | | | | | | | | | | | |

show interfaces counters

Use the **show interfaces counters** user EXEC command to display traffic statistics information of interfaces.

Commands

show interfaces counters

show interfaces ethernet port-id counters

show interfaces trunk trunk-id counters

| | | |
|---------------------------|---|--|
| Syntax Description | interfaces | Interface status and configuration |
| | counters | Display counters |
| | <i>port-id</i> | Port ID or list. E.g., 1/1,2,3,2/1-3,5,... |
| | <i>trunk-id</i> | Trunk ID (or list) |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | Detail counter information will contain the differences information from last query. | |
| Examples | <pre>PT-7828# show interfaces counters Port Tx Packets (Load%) Rx Packets (Load%) ----- ----- 1/ 5 662 (0) 364 (0) 1/ 6 0 (0) 0 (0) Trk1 1608 (0) 1608 (0) Trk2 0 (0) 0 (0) PT-7828# show interfaces ethernet 1/5 counters Port 1/5 (last sample time: 16577 sec. ago) - TX - Unicast Packets : 108 +108 Multicast Packets : 553 +553 Broadcast Packets : 2 +2 Collision Packets : 0 +0 - RX - Unicast Packets : 109 +109 Multicast Packets : 0 +0 Broadcast Packets : 255 +255 Pause Packets : 0 +0 - Error - TX Late : 0 +0 TX Excessive : 0 +0 RX CRC error : 0 +0 RX Discard : 0 +0 RX Undersize : 0 +0 RX Fragments : 0 +0 RX Oversize : 0 +0 RX Jabber : 0 +0</pre> | |
| Error messages | N/A | |
| Related commands | N/A | |

show interfaces ethernet

To check the status of interfaces, use the **show interfaces ethernet** command.

Commands

show interfaces ethernet [module/port [config]]

| | | |
|---------------------------|--|--|
| Syntax Description | interfaces | Interface status and configuration |
| | ethernet | IEEE 802.3/IEEE 802.3z |
| | <i>module/port</i> | Port ID or list. E.g., 1/1,2,3,2/1-3,5,... |
| | config | Show interface module/port settings |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828# show interfaces ethernet Port Link Description Speed FDX Flow Ctrl MDI/MDIX --- --- ----- 1-1 Down 100TX,RJ45. -- -- -- 1-2 Down 100TX,RJ45. -- -- -- 1-3 Down 100TX,RJ45. -- -- -- 1-4 Down 100TX,RJ45. -- -- -- 1-5 Up 100TX,RJ45. 100M-Full Off MDI 1-6 Down 100TX,RJ45. -- -- -- 1-7 Down 100TX,RJ45. -- -- -- 1-8 Down 100TX,RJ45. -- -- -- PT-7828# show interfaces ethernet 1/1-3 config Port Enable Description Speed FDX Flow Ctrl MDI/MDIX --- --- ----- 1-1 Yes 100FX,SC,Single,40. 100M-Full Disable Auto 1-2 Yes 100FX,SC,Single,40. 100M-Full Disable Auto 1-3 Yes 100TX,RJ45. Auto Disable Auto</pre> | |
| Error messages | N/A | |
| Related commands | N/A | |

show interfaces filter-ip

Use the **show interfaces filter-ip** user EXEC command to display the setting of IP filtering entries.

Commands

show interfaces ethernet module/port filter-ip

| | | |
|-------------------------|---|--|
| Syntax | interfaces | Interface status and configuration |
| Description | ethernet | IEEE 802.3/IEEE 802.3z |
| | <i>module/port</i> | Port ID or list. E.g., 1/1,2,3,2/1-3,5,... |
| | filter-ip | Rate limiting configuration |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828# show interfaces ethernet 1/1-6 filter-ip Allowed IP in Port 1/1: 192.168.127.1 192.168.127.2 192.168.127.3 192.168.127.4 192.168.127.5 192.168.127.6 192.168.127.7 192.168.127.8 Allowed IP in Port 1/2: Allowed IP in Port 1/3: Allowed IP in Port 1/4: --More-- Allowed IP in Port 1/5: 192.168.127.1 Allowed IP in Port 1/6:</pre> | |
| Error messages | N/A | |
| Related commands | ip filter-ip | |

show interfaces mgmt

Use the **show interfaces mgmt** user EXEC command to display the Mgmt-VLAN settings.

Commands

show interfaces mgmt

| | | |
|-------------------------|---|-------------------------------------|
| Syntax | interfaces | Interface status and configuration |
| Description | mgmt | Display management VLAN information |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828# show interfaces mgmt IPv4 Management VLAN id : 1 IP configuration : Static IP address : 192.168.127.253 Subnet mask : 255.255.255.0 Default gateway : 0.0.0.0 DNS server :</pre> | |
| Error messages | N/A | |
| Related commands | ip address ip default-gateway ip name-server bind vlan | |

show interfaces mgmt access-ip

Use the **show interfaces mgmt access-ip** user EXEC command to display the settings of accessible IP list.

Commands

show interfaces mgmt access-ip

| | | |
|-------------------------|--|-------------------------------------|
| Syntax | show | Show running system information |
| Description | interfaces | Interface status and configuration |
| | mgmt | Display management VLAN information |
| | access-ip | Display accessible IP list |
| Defaults | N/A | |
| Command Modes | Privileged EXEC / User EXEC | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828# show interfaces mgmt access-ip Accessible IP List: Enable Index IP / Netmask 1 192.168.127.253 / 255.255.255.0</pre> | |
| Error messages | N/A | |
| Related commands | access-ip | |

show interfaces rate-limit

Use the **show interfaces rate-limit** user EXEC command to display the setting of Rate-limiting.

Commands

show interfaces ethernet module/port rate-limit

| | | |
|-------------------------|---|--|
| Syntax | interfaces | Interface status and configuration |
| Description | ethernet | IEEE 802.3/IEEE 802.3z |
| | <i>module/port</i> | Port ID or list. E.g., 1/1,2,3,2/1-3,5,... |
| | rate-limit | Rate limiting configuration |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-508# show interfaces ethernet 1/1-3 rate-limit</pre> <pre>Port 1/1: Ingress Limit Mode: Broadcast, Multicast, DLF Ingress Limit Rate: 8M Egress Limit Rate : Not Limited</pre> <pre>Port 1/2: Ingress Limit Mode: Broadcast Ingress Limit Rate: 8M Egress Limit Rate : Not Limited</pre> <pre>Port 1/3: Ingress Limit Mode: Broadcast Ingress Limit Rate: 8M Egress Limit Rate : Not Limited</pre> | |
| Error messages | N/A | |
| Related commands | rate-limit | |

show interfaces trunk

Use the **show interfaces trunk** user EXEC command to display spanning-tree state information

Commands

show interfaces trunk [trunk-id-list]

| | | |
|-------------------------|--|------------------------------------|
| Syntax | interfaces | Interface status and configuration |
| Description | trunk | Show interface trunk information |
| | <i>trunk-id-list</i> | Trunk ID (or list) |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828# show interfaces trunk Trk# Type Enable Description Speed ----- ----- 1 Static Yes 100M-Full 2 Static Yes 100M-Full PT-7828# show interfaces trunk 1-2 Trunk-1 (Static): Member Status ----- 1/1 Success 1/2 Success Trunk-2 (Static): Member Status ----- 1/3 Fail 1/4 Fail</pre> | |
| Error messages | There is no member in Trunk 1 | |
| Related commands | trunk-mode trunk-group | |

show interfaces vlan

Use the **show interfaces vlan** user EXEC command to display vlan ip interface information.

Commands

show interfaces vlan [vlan-id-list]

| | | |
|-------------------------|---|--------------------------------------|
| Syntax | show | Show running system information |
| Description | interfaces | Interface status and configuration |
| | vlan | Display layer3 IP interface settings |
| | vlan-id-list | 1 to 4094 |
| Defaults | N/A | |
| Command Modes | Privileged EXEC | |
| Usage Guidelines | N/A | |
| Examples | PT-7828# show interfaces vlan Interface Name: VLAN2 IP Address: 10.10.10.10 Subnet Mask: 255.255.255.0 VLAN ID: 2 Proxy ARP: Disable | |
| Error messages | N/A | |
| Related commands | Interface vlan | |

show interfaces mgmt trusted-access

Same as **show interfaces mgmt access-ip**.

Commands

show interfaces mgmt trusted-access

| | | |
|-------------------------|---|-------------------------------------|
| Syntax | show | Show running system information |
| Description | interfaces | Interface status and configuration |
| | mgmt | Display management VLAN information |
| | trusted-access | Display trusted access IP list |
| Defaults | N/A | |
| Command Modes | Privileged EXEC / User EXEC | |
| Usage Guidelines | N/A | |
| Examples | PT-7828# show interfaces mgmt trusted-access Trusted Access IP List: Enable Index IP / netmask 1 192.168.127.253 / 255.255.255.0 | |
| Error messages | N/A | |
| Related commands | trusted-access | |

show ip auto-assign

Use the **show ip auto-assign** user EXEC command to display the setting of the Auto IP Assignment feature.

Commands

show ip auto-assign

| | | |
|-------------------------|---|--|
| Syntax | ip | Display IP information |
| Description | auto-assign | Display automatic ip assignment settings |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | PT-7828# show ip auto-assign Port Device's Current IP Active Function Desired IP ----- 1/ 6 NA -- 192.168.127.8 Trk1 NA -- 192.168.127.7 | |
| Error messages | N/A | |
| Related commands | ip auto-assign | |

show ip dhcp-relay config

Use the **show ip dhcp-relay config** user EXEC command to display the setting of the DHCP relay feature.

Commands

show ip dhcp-relay config

| | | |
|-------------------------|--|----------------------------------|
| Syntax | show | Show running system information |
| Description | ip | Display IP information |
| | dhcp-relay | Display DHCP relay configuration |
| | config | DHCP relay configuration |
| Defaults | N/A | |
| Command Modes | Privileged EXEC / User EXEC | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828# show ip dhcp-relay config DHCP Relay Agent Setting 1st server IP : 2nd server IP : 3rd server IP : 4th server IP : DHCP Relay Option 82: Enable Remote ID type : Other Remote ID value : 1234567890123 Remote ID display: 31323334353637383930313233 --More-- DHCP Function Table Port Circuit-ID Option 82 ----- ----- 1-1 01000101 Disable 1-2 01000102 Disable 1-3 01000103 Disable 1-4 01000104 Disable 1-5 01000105 Disable 1-6 01000106 Disable 1-7 01000107 Disable 1-8 01000108 Disable 3-1 01000111 Disable 3-2 01000112 Disable 3-3 01000113 Disable 3-4 01000114 Disable 3-5 01000115 Disable 3-6 01000116 Disable 3-7 01000117 Disable 3-8 01000118 Disable PT-7828#</pre> | |
| Error messages | N/A | |
| Related commands | N/A | |

show ip http-server status

Use **show ip http-server status** to display HTTP server related settings.

Commands

show ip http-server status

| | | |
|-------------------------|---|---------------------------------|
| Syntax | show | Show running system information |
| Description | ip | Display IP information |
| | http-server | HTTP server information |
| | status | Status |
| Defaults | N/A | |
| Command Modes | Privileged EXEC / User EXEC | |
| Usage Guidelines | N/A | |
| Examples | PT-7828# show ip http-server status HTTP service is enable HTTP server capability: Present HTTPS secure server capability: Present Auto-logout: disable | |
| Error messages | N/A | |
| Related commands | N/A | |

show ip igmp

Use the **show ip igmp** user EXEC command to display the Internet Group Management Protocol (IGMP) snooping configuration and IGMP table of the switch.

Commands

show ip igmp

| | | |
|-------------------------|--|-----------------------------|
| Syntax | ip | Display IP information |
| Description | igmp | Show IGMP snooping settings |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | PT-7828# show ip igmp IGMP Snooping :Enable IGMP Snooping Enhanced Mode :Enable Query Interval :125 (sec) VID Static(S) / Learned(L) Active IGMP Groups Multicast Querier Port & IP MAC Members Port Querier(Q) connected Port ----- 1 1-1(S) 224.1.1.8 01-00-5E-01-01-08 1-1 239.255.255.250 01-00-5E-7F-FF-FA 1-1 | |
| Error messages | N/A | |
| Related commands | ip igmp ip igmp snooping | |

show ip ospf

Use the **show ip ospf** user EXEC command to display general information about OSPF routing processes.

Commands

show ip ospf

| | | |
|-------------------------|---|---------------------------------|
| Syntax | show | Show running system information |
| Description | ip | Display IP information |
| | ospf | Display OSPF configurations |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828# show ip ospf OSPF Global Configuration ----- OSPF Enabled Router ID 192.168.1.1 Current Router ID 192.168.1.1 Redistribute [Connected] OSPF Area Configuration Idx Area ID Area Type Metric ----- 1 192.168.1.1 Normal 0 OSPF Virtual Link Configuration Idx Transit Area ID Neighbor Router ID ----- 1 192.168.1.1 192.168.0.0 OSPF Aggregation Configuration Idx Area ID Network Address Network Mask -----</pre> | |
| Error messages | N/A | |
| Related commands | area area virtual-link network area redistribute | |

show ip ospf database

Use the **show ip ospf database** user EXEC command to display information related to the OSPF database for a specific router.

Commands

show ip ospf database

| | | |
|-------------------------|--------------------------------|---------------------------------|
| Syntax | show | Show running system information |
| Description | ip | Display IP information |
| | ospf | Display OSPF configurations |
| | database | OSPF database |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | PT-7828# show ip ospf database | |
| Error messages | N/A | |
| Related commands | ip ospf area | |

show ip ospf interface

Use the **show ip ospf interface** user EXEC command to display the OSPF related interfaces information.

Commands

show ip ospf interface

| | | |
|-------------------------|---|---------------------------------|
| Syntax | show | Show running system information |
| Description | ip | Display IP information |
| | ospf | Display OSPF configurations |
| | interface | OSPF routing interface |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | PT-7828# show ip ospf interface | |
| Error messages | N/A | |
| Related commands | ip ospf area ip ospf priority ip ospf hello-interval ip ospf dead-interval ip ospf cost | |

show ip ospf neighbor

Use the **show ip ospf neighbor** user EXEC command to display OSPF neighbor information.

Commands

show ip ospf neighbor

| | | |
|-------------------------|--------------------------------|---------------------------------|
| Syntax | show | Show running system information |
| Description | ip | Display IP information |
| | ospf | Display OSPF configurations |
| | neighbor | OSPF neighbor information |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | PT-7828# show ip ospf neighbor | |
| Error messages | N/A | |
| Related commands | ip ospf area | |

show ip pim-dm



NOTE

This command is only supported by Layer 3 switches.

Use show **ip pim-dm** command to display the settings of PIM-DM.

Commands

show ip pim-dm

| | | |
|-------------------------|--|---------------------------------|
| Syntax | show | Show running system information |
| Description | ip | Display IP information |
| | pim-dm | Display PIM-DM information |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | ICS-G7852A-4XG# show ip pim-dm PIM-DM: Enable Interface Address VID Enable Mode ----- V100 172.100.1.2 100 V V200 172.200.1.2 200 V V10 172.10.1.2 10 V V20 172.20.1.2 20 V | |
| Error messages | N/A | |
| Related commands | ip pim-dm no ip pim-dm | |

show ip pim-dm neighbor



NOTE

This command is only supported by Layer 3 switches.

Use **show ip pim-dm neighbor** command to display PIM-DM neighbor information.

Commands

show ip pim-dm neighbor

| | | |
|-------------------------|---|---------------------------------|
| Syntax | show | Show running system information |
| Description | ip | Display IP information |
| | pim-dm | Display PIM-DM information |
| | neighbor | PIM-DM neighbor information |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | ICS-G7852A-4XG# show ip pim-dm neighbor PIM Neighbor Table Index Neighbor Address Interface Uptime Expire ----- 1 172.100.1.4 V100 89 --- 2 172.100.1.1 V100 89 --- 3 172.200.1.3 V200 75 --- | |
| Error messages | N/A | |
| Related commands | ip pim-dm no ip pim-dm | |

show ip pim-sm



NOTE

This command is only supported by Layer 3 switches.

Use **show ip pim-sm** command to display the settings of PIM-SM.

Commands

show ip pim-sm

| | | |
|-------------------------|--|---------------------------------|
| Syntax | show | Show running system information |
| Description | ip | Display IP information |
| | pim-sm | Display PIM-SM information |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | <pre>ICS-G7852A-4XG# show ip pim-sm PIM-SM: Enable Interface Address VID Enable Mode ----- V100 172.100.1.2 100 V V200 172.200.1.2 200 V V10 172.10.1.2 10 V V20 172.20.1.2 20 V</pre> | |
| Error messages | N/A | |
| Related commands | <pre>ip pim-sm no ip pim-sm ip pim-sm dr-priority ip pim-sm hello-interval ip pim-sm join-prune-interval</pre> | |

show ip pim-sm bsr



NOTE

This command is only supported by Layer 3 switches.

Use **show ip pim-sm bsr** command to display PIM-SM BSR information.

Commands

show ip pim-sm bsr

| Syntax Description | show | Show running system information |
|--------------------|--|---------------------------------|
| | ip | Display IP information |
| | pim-sm | Display PIM-SM information |
| | bsr | PIM-SM BSR information |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | ICS-G7852A-4XG# show ip pim-sm bsr PIM BSR BSR Address Priority Hash Mask Length ----- 172.230.1.1 0 4 | |
| Error messages | N/A | |
| Related commands | ip pim-sm no ip pim-sm ip pim-sm dr-priority ip pim-sm hello-interval ip pim-sm join-prune-interval | |

show ip pim-sm neighbor



NOTE

This command is only supported by Layer 3 switches.

Use **show ip pim-sm neighbor** command to display PIM-SM neighbor information.

Commands

show ip pim-sm neighbor

| Syntax | show | Show running system information |
|------------------|---|---------------------------------|
| Description | ip | Display IP information |
| | pim-sm | Display PIM-SM information |
| | neighbor | PIM-SM neighbor information |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | ICS-G7852A-4XG# show ip pim-sm neighbor PIM Neighbor Table Index Neighbor Address Interface Uptime Expire ----- 1 172.100.1.4 V100 89 --- 2 172.100.1.1 V100 89 --- 3 172.200.1.3 V200 75 --- | |
| Error messages | N/A | |
| Related commands | ip pim-sm no ip pim-sm ip pim-sm dr-priority ip pim-sm hello-interval ip pim-sm join-prune-interval | |

show ip pim-sm routing



NOTE

This command is only supported by Layer 3 switches.

Use **show ip pim-sm routing** command to display current PIM-SM routing table entries.

Commands

show ip pim-sm routing

| Syntax | show | Show running system information |
|------------------|--|--|
| Description | ip | Display IP information |
| | pim-sm | Display PIM-SM information |
| | routing | Display routing entries |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | ICS-G7852A-4XG# show ip pim-sm routing PIM-SM Routing Multicast Source RP Address VID Left time Downstream Group Address Address (Second) Interface VID ===== | <pre>0.0.0.0 * 0.0.0.0 local - NULL 232.0.0.1 172.20.2.1 0.0.0.0 20 38s 100 200 10 0 232.0.0.1 * 0.0.0.0 local - NULL 232.0.0.2 172.20.2.1 0.0.0.0 20 48s 100 200 10 0</pre> |
| Error messages | N/A | |
| Related commands | ip pim-sm no ip pim-sm ip pim-sm dr-priority ip pim-sm hello-interval ip pim-sm join-prune-interval | |

show ip pim-sm rp



NOTE

This command is only supported by Layer 3 switches.

Use **show ip pim-sm rp** command to display PIM-SM RP information.

Commands

show ip pim-sm rp

| | | |
|-------------------------|--|---------------------------------|
| Syntax | show | Show running system information |
| Description | ip | Display IP information |
| | pim-sm | Display PIM-SM information |
| | rp | PIM-SM RP information |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | <pre>ICS-G7852A-4XG# show ip pim-sm rp PIM-SM RP Set Group Address R RP Address Holdtime Priority Hash ===== 224.0.0.0/4 172.230.1.4 112 0 7331bd32 224.0.0.0/4 172.230.1.1 78 0 2a523511 224.0.0.0/4 *172.200.1.3 86 0 7d18d1eb 224.0.0.0/4 172.200.1.2 112 0 3edf2058</pre> | |
| Error messages | N/A | |
| Related commands | <ul style="list-style-type: none">ip pim-smno ip pim-smip pim-sm dr-priorityip pim-sm hello-intervalip pim-sm join-prune-interval | |

show ip rip

Use the **show ip rip** command to display the settings of RIP.

Commands

show ip rip

| | | |
|-------------------------|--|---------------------------------|
| Syntax | show | Show running system information |
| Description | ip | Display IP information |
| | rip | Display RIP configurations |
| Defaults | N/A | |
| Command Modes | Privileged EXEC / User EXEC | |
| Usage Guidelines | N/A | |
| Examples | PT-7828# show ip rip RIP Protocol : Enable RIP version : V2 Distribution Connected : Enable Static : Disable OSPF : Disable RIP Enable Table Interface Name IP VID Enable ----- vlan2if 192.168.102.1 2 Enable | |
| Error messages | N/A | |
| Related commands | N/A | |

show ip route

Use the **show ip route** user EXEC command to display current routing table entries.

Commands

show ip route [static]

| | | |
|-------------------------|--------------------------------|---------------------------------|
| Syntax | show | Show running system information |
| Description | ip | Display IP information |
| | route | Display routing entries |
| | static | Static routing entries |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | PT-7828# show ip ospf neighbor | |
| Error messages | N/A | |
| Related commands | N/A | |

show ip vrrp

To display a detailed status of all Virtual Router Redundancy Protocol (VRRP) virtual routers, use the **show ip vrrp** command in EXEC mode.

Commands

show ip vrrp

| | | |
|-------------------------|---|--------------------------|
| Syntax | ip | Display IP information |
| Description | vrrp | Display VRRP information |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828# show ip vrrp VRRP Enable Enable VRRP Interface Table Interface Name IP Address VID Status 1 1.1.1.1 2 Init VRRP Basic Setting VRRP Entry Enable :Enable Virtual IP :0.0.0.0 Virtual Router ID :0 Priority :100 Preemption Mode :Enable ----- Interface Name IP Address VID Status 2 2.2.2.2 3 Init VRRP Basic Setting VRRP Entry Enable :Disable Virtual IP :0.0.0.0 Virtual Router ID :0 Priority :100 Preemption Mode :Enable -----</pre> | |
| Error messages | N/A | |
| Related commands | router vrrp vrrp vrrp preempt vrrp priority | |

show lldp

Use the **show lldp** command to display the LLDP settings and the LLDP neighbor information.

Commands

show lldp

show lldp entry

| | | |
|-------------------------|--|---------------------------------|
| Syntax | show | Show running system information |
| Description | lldp | Display LLDP information |
| | entry | LLDP entries |
| Defaults | N/A | |
| Command Modes | Privileged EXEC / User EXEC | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828# show lldp LLDP Enable : Enable Message Transmit Interval: 30 seconds PT-7828# show lldp entry Port : 23 Neighbor ID : 00:90:e8:0a:0a:0a Neighbor Port : 3 Neighbor Port Descript : 100TX,RJ45. Neighbor System : Managed Redundant Switch 00000 Port : 19 Neighbor ID : 00:90:e8:0a:0a:0a Neighbor Port : 2 Neighbor Port Descript : 100TX,RJ45. Neighbor System : Managed Redundant Switch 00000 Port : 24 Neighbor ID : 00:90:e8:0a:0a:0a Neighbor Port : 1 Neighbor Port Descript : 100TX,RJ45. Neighbor System : Managed Redundant Switch 00000</pre> | |
| Error messages | N/A | |
| Related commands | lldp timer lldp run | |

show logging

Use the **show logging** user EXEC command to display the setting of the IP filter feature.

Commands

show logging [event-log]

| | | |
|-------------------------|--|----------------------------|
| Syntax | logging | Display syslog information |
| Description | event-log | Display system event logs |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828# show logging Syslog server #1: Syslog server #2: 192.168.1.2, port: 514 Syslog server #3: 192.168.1.3, port: 514 PT-7828# show logging event-log Idx Boot Time or Uptime Log --- ----- 1 337 2037/06/23, 20:46:08 192.168.127.1 admin Auth. ok 2 337 2037/06/23, 20:52:47 Authentication fail 3 338 2037/06/23, 21:51:59 Port 1-1(Trk1) link on 4 338 2037/06/23, 21:51:59 Port 1-2 link on 5 338 2037/06/23, 21:51:59 Port 1-5 link on 6 338 2037/06/23, 21:52:03 Port 1-5 link off 7 338 2037/06/23, 21:52:03 Warm start by Firmware Upgrade 8 338 2037/06/23, 21:52:04 Port 1-5 link on 9 338 2037/06/23, 22:03:43 192.168.127.1 admin Auth. ok 10 338 2037/06/23, 22:04:04 192.168.127.1 admin Auth. ok 11 338 2037/06/24, 00:02:47 Port 1-5 link off 12 338 2037/06/24, 00:02:48 Port 1-5 link on</pre> | |
| Error messages | N/A | |
| Related commands | logging | |

show mac-address-table

Use the **show mac-address-table** user EXEC command to display MAC addresses in the MAC address table.

Commands

show mac-address-table [static | learned | mcast]

show mac-address-table [interface{ ethernet module/port | trunk trunk-id }]

| | | |
|---------------------------|---|--------------------------------------|
| Syntax Description | mac-address-table | Display MAC address forwarding table |
| | static | Retrieve static MAC addresses |
| | learned | Retrieve learned MAC addresses |
| | mcast | Retrieve Multicast address |
| | interface | Retrieve MAC address by interface |
| | ethernet | Ethernet Port interface |
| | <i>module/port</i> | Port ID. E.g., 1/3, 2/1,... |
| | trunk | Trunk interface |
| | <i>trunk-id</i> | Trunk ID. From 1 to 4 |
| | Defaults | N/A |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828# show mac-address-table Line Swap Fast Recovery : Enabled MAC Type VLAN Port ----- 00-40-F4-8D-0D-F7 ucast(1) 1 1/5 PT-7828# show mac-address-table learned MAC Type VLAN Port ----- 00-40-F4-8D-0D-F7 ucast(1) 1 1/5</pre> | |
| Error messages | N/A | |
| Related commands | N/A | |

show mac-address-table aging-time

Use the **show mac-address-table aging-time** user EXEC command to display the aging time setting of the MAC address table.

Commands

show mac-address-table aging-time

| | | |
|-------------------------|---|--------------------------------------|
| Syntax | mac-address-table | Display MAC address forwarding table |
| Description | aging-time | MAC entry aging time |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | PT-7828# show mac-address-table aging-time - MAC entry aging time PT-7828# show mac-address-table aging-time MAC address aging time: 300 sec | |
| Error messages | N/A | |
| Related commands | mac-address-table aging-time | |

show mcast-filter

Use the **show mcast-filter** user EXEC command to display the multicast filter configuration.

Commands

show mcast-filter [module/port]

| | | |
|-------------------------|--|--|
| Syntax | mcast-filter | Multicast Filtering Behavior |
| Description | module/port | Port(Trunk) ID or list. E.g., 1/1,2,4-5,2/1,Trk1,Trk2-Trk4 |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | PT-7828# show mcast-filter Port Multicast Filtering Behavior ----- 1-1 Forward All 1-2 Forward Unknown 1-3 Filter Unknown | |
| Error messages | N/A | |
| Related commands | mcast-filter | |

show modbus

Use the **show modbus** user EXEC command to display Modbus configuration.

Commands

show modbus

| | | |
|---------------------------|---------------------------------------|------------------------------|
| Syntax Description | modbus | Display Modbus configuration |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | PT-7828# show modbus Modbus enable | |
| Error messages | N/A | |
| Related commands | modbus | |

show port monitor

Use the **show port monitor** EXEC command to display the port mirror settings.

Commands

show port monitor

| | | |
|---------------------------|--|-----------------------------------|
| Syntax Description | show | Show running system information |
| | port | Display Port configuration |
| | monitor | Display Port mirror configuration |
| Defaults | N/A | |
| Command Modes | Privileged EXEC / User EXEC | |
| Usage Guidelines | N/A | |
| Examples | PT-7828# show port monitor Port Being Monitored | Direction Mirror Port |
| | ----- 1-1 1-2 | both 3-2 |
| | PT-7828# | |
| Error messages | N/A | |
| Related commands | monitor | |

show port-security

To check the port access control table, use the **show port-security** command.

Commands

show port-security [module/port]

| | | |
|-------------------------|--|--|
| Syntax | port-security | Display port access control table |
| Description | <i>module/port</i> | Port ID or list. E.g., 1/1,2,3,2/1-3,5,... |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828# show port-security Port Index Mac Address Status ----- ----- 1-2 1 00-00-00-00-00-01 static lock</pre> | |
| Error messages | N/A | |
| Related commands | port-security | |

show qos

Use the **show qos** user EXEC command to display QoS related settings.

Commands

show qos [cos-to-queue | dscp-to-cos | dscp-to-queue]

| | | |
|-------------------------|--|--------------------------------|
| Syntax | qos | Display QoS configuration |
| Description | cos-to-queue | CoS to traffic queue mappings |
| | dscp-to-cos | DSCP to CoS mappings |
| | dscp-to-queue | DSCP to traffic queue mappings |
| Defaults | N/A | |
| Command Modes | Privileged | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828# show qos Queuing Mechanism : Weighted Fair (1:2:4:8) Tos Inspection Module 1 : Disabled Module 3 : Disabled Int# CoS Inspection CoS ----- ----- 1/3 Enabled 3 1/4 Enabled 3 1/5 Enabled 3 1/6 Enabled 3 3/1 Enabled 3 3/2 Enabled 3 3/3 Enabled 3 3/4 Enabled 3 3/5 Enabled 3 3/6 Enabled 3 3/7 Enabled 3</pre> | |

| | |
|--|---|
| | <pre> 3/8 Enabled 3 Trk1 Enabled 3 </pre> |
| PT-7828# show qos cos-to-queue | |
| CoS Queue # | |
| ----- | |
| 0 Q0 | |
| 1 Q0 | |
| 2 Q1 | |
| 3 Q1 | |
| 4 Q2 | |
| 5 Q2 | |
| 6 Q3 | |
| 7 Q3 | |
| PT-7828# show qos dscp-to-cos | |
| <pre> DSCP Cos DSCP Cos DSCP Cos DSCP Cos ----- ----- 0 0 1 0 2 0 3 0 4 0 5 0 6 0 7 0 8 1 9 1 10 1 11 1 12 1 13 1 14 1 15 1 16 2 17 2 18 2 19 2 20 2 21 2 22 2 23 2 24 3 25 3 26 3 27 3 28 3 29 3 30 3 31 3 32 4 33 4 34 4 35 4 36 4 37 4 38 4 39 4 40 5 41 5 42 5 43 5 44 5 45 5 46 5 47 5 48 6 49 6 50 6 51 6 52 6 53 6 54 6 55 6 56 7 57 7 58 7 59 7 60 7 61 7 62 7 63 7 </pre> | |
| Error messages | N/A |
| Related commands | qos mode qos inspect qos mapping qos default-cos |

show redundancy mst configure

Use the **show redundancy mst configure** user EXEC command to display settings of Multiple Spanning Tree (MSTP).

Commands

show redundancy mst configuration

| | | |
|-------------------------|--|--|
| Syntax | show | Show running system information |
| Description | redundancy | Display redundancy protocol status |
| | mst | Display multiple spanning tree settings |
| | configure | Display multiple spanning tree global settings |
| Defaults | N/A | |
| Command Modes | Privileged EXEC | |
| Usage Guidelines | N/A | |
| Examples | PT-7828# show redundancy mst configuration MSTP global setting: Forwarding Delay: 15 Hello Time: 2 Max Hops: 20 Max Age: 20 Revision Level: 0 Region Name: MSTP | |
| Error messages | N/A | |
| Related commands | spanning-tree mst | |

show redundancy mst instance

Use the **show redundancy mst instance** user EXEC command to display Multiple Spanning Tree (MSTP) instance state information.

Commands

show redundancy mst instance *instance-id*

| | | |
|-------------------------|--|---|
| Syntax | show | Show running system information |
| Description | redundancy | Display redundancy protocol status |
| | mst | Display multiple spanning tree settings |
| | instance | Display MSTP msti status |
| | <i>instance-id</i> | MSTP instance ID |
| Defaults | N/A | |
| Command Modes | Privileged EXEC | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828# show redundancy mst instance 1 MSTP msti root status: MSTI Root: --- MSTP msti 1 bridge status: Vlan Mapping: Bridge Priority: 32768 Int# Enable Prio Cost Oper Cost Edge State Role ----- ----- ----- ----- ----- ----- ----- ----- -----</pre> | |
| Error messages | N/A | |
| Related commands | spanning-tree mst instance | |

show redundancy spanning-tree

Use the **show redundancy spanning-tree** user EXEC command to display spanning-tree state information

Commands

show redundancy spanning-tree

| | | |
|-------------------------|---|------------------------------------|
| Syntax | redundancy | Display redundancy protocol status |
| Description | spanning-tree | Display spanning tree settings |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828# show redundant spanning-tree Spanning tree status: Enabled Role : Root Bridge priority : 32768 Hello time : 2 sec Forwarding delay: 30 sec Max age time : 20 sec Int# Enable Edge Port Prio Cost Status ----- ----- 1/1 Disabled Auto 128 200000 --- 1/2 Disabled Auto 128 200000 --- 1/3 Disabled Auto 128 200000 --- 1/4 Disabled Auto 128 200000 --- 1/5 Disabled Auto 128 200000 --- 1/6 Disabled Auto 128 200000 ---</pre> | |
| Error messages | N/A | |
| Related commands | <ul style="list-style-type: none">spanning-tree forward-delayspanning-tree hello-timespanning-tree max-agespanning-tree priorityspanning-treespanning-tree costspanning-tree edge-portspanning-tree priorityshow redundancy spanning-tree | |

show redundancy turbo-chain

Use the **show redundancy turbo-chain** user EXEC command to display turbo-chain state information

Commands

show redundancy turbo-chain

| | | |
|-------------------------|--|----------------------------|
| Commands | redundancy | Display redundant settings |
| | turbo-chain | Display turbo chain status |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828# show redundancy turbo-chain Role :HEAD ----- Port Role Port Number Port Status ----- Head Port 1-1 Forwarding Member Port 1-2 Forwarding</pre> | |
| Error messages | N/A | |
| Related commands | turbo-chain | |

show redundancy turbo-ring-v1

Use the **show redundancy turbo-ring-v1** user EXEC command to display Turbo Ring v1 configure and state information.

Commands

show redundancy turbo-ring-v1

| | | |
|-------------------------|---|------------------------------------|
| Syntax | show | Show running system information |
| Description | redundancy | Display redundancy protocol status |
| | turbo-ring-v1 | Display turbo ring v1 status |
| Defaults | N/A | |
| Command Modes | Privileged EXEC | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828# show redundancy turbo-ring-v1 Turbo Ring V1 settings: Set as master: Disabled 1st port: 4-3 2nd port: 4-4 Ring Coupling: Disabled Coupling Port: 4-1 Coupling Control Port: 4-2 Turbo Ring V1 status: Master/Slave: --- Redundant Ports Status: 1st port: --- 2nd port: --- Ring Coupling Ports Status: --- Coupling Port: --- Coupling Control Port: ---</pre> | |
| Error messages | N/A | |
| Related commands | turbo-ring-v1 | |

show redundancy turbo-ring-v2

Use the **show spanning-tree turbo-ring-v2** user EXEC command to display Turbo Ring v2 configuration and state information.

Commands

show redundancy turbo-ring-v2

| | | |
|-------------------------|--|------------------------------------|
| Syntax | show | Show running system information |
| Description | redundancy | Display redundancy protocol status |
| | turbo-ring-v2 | Display turbo ring v2 status |
| Defaults | N/A | |
| Command Modes | Privileged EXEC | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828# show redundancy turbo-ring-v2 Turbo Ring V2 settings: Ring 1: Enabled Set as master: Disabled 1st port: 4-3 2nd port: 4-4 Ring 2: Disabled Set as master: Disabled 1st port: 4-1 2nd port: 4-2 Ring Coupling: Disabled Primary Port:4-1 Backup Port:4-2 Turbo Ring V2 status: Ring 1: Status:--- Master/Slave:--- 1st Ring Port Status:--- 2nd Ring Port Status:--- Ring 2: Status:--- Master/Slave:--- 1st Ring Port Status:--- 2nd Ring Port Status:--- Coupling: Mode:--- Coupling Port Status: ---</pre> | |
| Error messages | N/A | |
| Related commands | turbo-ring-v2 | |

show relay-warning

Use the **show relay-warning** command to display the Relay Warning settings.

Commands

show relay-warning config

show relay-warning status

| | | |
|---------------------------|---|-------------------------------------|
| Syntax Description | show | Show running system information |
| | relay-warning | Display relay warning configuration |
| | config | Relay warning configuration |
| | status | Current relay warning list |
| Defaults | N/A | |
| Command Modes | Privileged EXEC / User EXEC | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828# show relay-warning config System Events Setting Override Relay Warning Settings : Disable Power Input 1 failure(On->Off) : Disable Power Input 2 failure(On->Off) : Disable Turbo Ring Break : Disable --More-- Port Events Setting Traffic RX Traffic Overload Threshold(%) Duration(s) ----- ----- ----- ----- 1-1 Ignore Disable 1 1 1-2 Ignore Disable 1 1 1-3 Ignore Disable 1 1 1-4 Ignore Disable 1 1 1-5 Ignore Disable 1 1 1-6 Ignore Disable 1 1 1-7 Ignore Disable 1 1 1-8 Ignore Disable 1 1 3-1 Ignore Disable 1 1 3-2 Ignore Disable 1 1 3-3 Ignore Disable 1 1 3-4 Ignore Disable 1 1 3-5 Ignore Disable 1 1 3-6 Ignore Disable 1 1 3-7 Ignore Disable 1 1 3-8 Ignore Disable 1 1 PT-7828#</pre> | |
| Error messages | N/A | |
| Related commands | N/A | |

show running-config

Use **show running-config** to display the current running configuration of the switch.

Commands

show running-config

| | | |
|-------------------------|--|---------------------------------|
| Syntax | show | Show running system information |
| Description | running-config | Current operating configuration |
| Defaults | N/A | |
| Command Modes | Privileged EXEC / User EXEC | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828# show running-config Building configuration ... ! ip telnet ip http-server ip http-server auto-logout 120 ! ntp remote-server time.nist.gov ! ! vlan mode 1qvlan gvrp ! snmp-server version v1-v2c snmp-server community public ro snmp-server community private rw snmp-server trap-mode trap ! lldp run lldp timer 30 ! ! dhcp-relay option82 dhcp-relay option82 remote-id-type other dhcp-relay option82 man-id 1234567890123 ! ! interface ethernet 1/1 no shutdown speed-duplex Auto no flowcontrol media cable-mode auto --More--</pre> | |
| Error messages | N/A | |
| Related commands | show startup-config | |

show startup-config

Use **show startup-config** to display the system startup configuration of the switch.

Commands

show running-config

| | | |
|-------------------------|--|-----------------------------------|
| Syntax | show | Show running system information |
| Description | startup-config | Contents of startup configuration |
| Defaults | N/A | |
| Command Modes | Privileged EXEC / User EXEC | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828# show startup-config Building configuration ... ! ip telnet ip http-server ip http-server auto-logout 120 ! ntp remote-server time.nist.gov ! ! vlan mode 1qvlan gvrp ! snmp-server version v1-v2c snmp-server community public ro snmp-server community private rw snmp-server trap-mode trap ! lldp run lldp timer 30 ! ! dhcp-relay option82 dhcp-relay option82 remote-id-type other dhcp-relay option82 man-id 1234567890123 ! ! interface ethernet 1/1 no shutdown speed-duplex Auto no flowcontrol media cable-mode auto --More--</pre> | |
| Error messages | N/A | |
| Related commands | show running-config | |

show snmp

To check the status of Simple Network Management Protocol (SNMP) communications, use the **show snmp** command.

Commands

show snmp

| | | |
|---------------------------|---|----------------------------|
| Syntax Description | snmp | Display SNMP configuration |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | PT-7828# show snmp SNMP Read/Write Settings SNMP Versions : v1-v2c V1,V2c Read Community : public V1,V2c Write/Read Community: private Trap Settings 1st Trap Server IP/Name : 1st Trap Community : public 2nd Trap Server IP/Name : 2nd Trap Community : public Trap Mode Mode : Trap Private MIB information Switch Object ID : enterprise.8691.7.15 | |
| Error messages | N/A | |
| Related commands | snmp-server community snmp-server host snmp-server trap-mode snmp-server user snmp-server version | |

show storm-control

Use the **show storm-control** user EXEC command to display the setting of storm protection.

Commands

show storm-control

| | | |
|---------------------------|---|-----------------------------------|
| Syntax Description | storm-control | Display storm protection settings |
| Defaults | N/A | |
| Command Modes | Privileged EXEC/ User EXEC | |
| Usage Guidelines | N/A | |
| Examples | PT-7828# show storm-control Storm Supress: Broadcast,DLF | |
| Error messages | N/A | |
| Related commands | storm-control | |

show system

Use the **show system** command to display system identification settings.

Commands

show system

| | | |
|-------------------------|---|-------------------------------------|
| Syntax | show | Show running system information |
| Description | system | System hardware and software status |
| Defaults | N/A | |
| Command Modes | | Privileged EXEC/ User EXEC |
| Usage Guidelines | | N/A |
| Examples | PT-7828# show system System Information System Name : Managed Redundant Switch 09458 System Location : Xidian No. 135 6F Taiwan System Description : MOXA PT Series Maintainer Information : 8860289191230 MAC Address : 00:90:E8:1D:24:36 System Uptime : 0d0h6m46s | |
| Error messages | N/A | |
| Related commands | snmp-server description snmp-server contact snmp-server location | |

show users

Use the **show users** user EXEC command to display the username/password configuration.

Commands

show users

| | | |
|-------------------------|--|---------------------------------|
| Syntax | show | Show running system information |
| Description | users | Display login user settings |
| Defaults | N/A | |
| Command Modes | | Privileged EXEC/ User EXEC |
| Usage Guidelines | | N/A |
| Examples | EDS-G516E# show users Login account information: Name Authority ----- admin admin user user | |
| Error messages | N/A | |
| Related commands | username | |

show vlan

Use the **show vlan** user EXEC command to display VLAN status information.

Commands

show vlan

| | | |
|-------------------------|--|---------------------------------|
| Syntax | show | Show running system information |
| Description | vlan | Display VLAN status |
| Defaults | N/A | |
| Command Modes | Privileged EXEC | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828# show vlan vlan mode: 802.1Q vlan mgmt vlan: 1 VLAN 1: Access Ports: 1-1, 1-2, 1-3, 1-4, 1-5, 1-6, 1-7, 1-8, Trunk Ports: Hybrid Ports: PT</pre> | |
| Error messages | N/A | |
| Related commands | N/A | |

show vlan config

Use the **show vlan config** user EXEC command to display VLAN configuration information.

Commands

show vlan config

| | | |
|-------------------------|--|---------------------------------|
| Syntax | show | Show running system information |
| Description | vlan | Display VLAN status |
| config | Display VLAN configuration | |
| Defaults | N/A | |
| Command Modes | Privileged EXEC | |
| Usage Guidelines | N/A | |
| Examples | <pre>vlan mode: 802.1Q vlan VLAN Ports(Type) ----- ----- 1 1-1(A), 1-2(A), 1-3(A), 1-4(A), 1-5(A), 1-6(A), 1-7(A), 1-8(A), Port Trunk Native vlan Port Fixed VLAN (Tagged) Port Forbidden VLAN Port Fixed VLAN (Untagged) Current VLAN interface vid: 1, 2,</pre> | |
| Error messages | N/A | |
| Related commands | interface vlan | |

shutdown

To disable an interface, use the **shutdown** interface configuration command. To restart a disabled interface, use the **no** form of this command.

Commands

shutdown

no shutdown

| | | |
|---------------------------|---|---------------------------------|
| Syntax Description | shutdown | Shutdown the selected interface |
| Defaults | None | |
| Command Modes | Interface configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config-if) # shutdown PT-7828 (config-if) # no shutdown | |
| Error messages | Cannot configure on trunk member port 1/1! | |
| Related commands | show interfaces ethernet show interfaces trunk | |

snmp-server community

To set up the community access string to permit access to the Simple Network Management Protocol (SNMP), use the **snmp-server community** global configuration command.

Commands

snmp-server community text mode

| | | |
|---------------------------|---|------------------------|
| Syntax Description | snmp-server | Configure SNMP server |
| | community | SNMP community setting |
| | <i>text</i> | SNMP community string |
| | <i>mode</i> | ro rw |
| Defaults | Public community is ro Private community is rw | |
| Command Modes | Global configuration | |
| Usage Guidelines | Specifies read-only access. Authorized management stations are only able to retrieve MIB objects. Specifies read-write access. Authorized management stations are able to both retrieve and modify MIB objects | |
| Examples | PT-7828 (config) # snmp-server community public ro | |
| Error messages | SNMP community mode must be (ro rw)!! The longest snmp community string length is 30!! | |
| Related commands | show snmp | |

snmp-server contact

To set the system contact string, use the **snmp-server contact** global configuration command. To remove the contact string, use the **no** form of this command.

Commands

snmp-server contact *text*

no snmp-server contact

| | |
|---------------------------|---|
| Syntax Description | snmp-server Configure SNMP server contact Switch maintainer contact information <i>text</i> Maintainer contact information |
| Defaults | N/A |
| Command Modes | Global configuration |
| Usage Guidelines | " <i>text</i> " parameter can be set as string separated by space. Maximum string tokens are 5. Maximum length of switch maintainer contact info is 40. |
| Examples | PT-7828 (config) # snmp-server contact <STRING:token1> - Maintainer contact information PT-7828 (config) # no snmp-server contact |
| Error messages | Length of maintainer info is too long |
| Related commands | show snmp |

snmp-server description

To set the system description string, use the **snmp-server description** global configuration command. To remove the description string, use the **no** form of this command.

Commands

snmp-server description *text*

no snmp-server description

| | |
|---------------------------|--|
| Syntax Description | snmp-server Configure SNMP server description Switch description <i>text</i> Description string |
| Defaults | The default description is the model name. |
| Command Modes | Global configuration |
| Usage Guidelines | " <i>text</i> " parameter can be set as string separated by space. Maximum string tokens are 5. Maximum length of switch maintainer contact info is 40. |
| Examples | PT-7828 (config) # snmp-server description MOXA PT Series PT-7828 (config) # exit PT-7828# show system System Information System Name : Managed Redundant Switch 09458 System Location : Xidian No. 135 6F Taiwan System Description : MOXA PT Series Maintainer Information : 8860289191230 MAC Address : 00:90:E8:1D:24:36 System Uptime : 0d0h6m46s |
| Error messages | Length of system description is too long |
| Related commands | show snmp |

snmp-server host

To specify the recipient of a Simple Network Management Protocol (SNMP) notification operation, use the **snmp-server host** global configuration command. To remove the specified host, use the **no** form of this command.

Commands

snmp-server host *host-addr* *community-string*

no snmp-server host [*host-addr*]

| | | |
|-------------------------|---|-----------------------|
| Syntax | snmp-server | Configure SNMP server |
| Description | host | SNMP host setting |
| | <i>host-addr</i> | SNMP host address |
| | <i>community-string</i> | SNMP Community string |
| Defaults | N/A | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # snmp-server host 192.168.127.253 moxacli PT-7828 (config) # no snmp-server host | |
| Error messages | Trap server are full, please remove at least one first!!! | |
| Related commands | show snmp | |

snmp-server location

To set the system location string, use the **snmp-server location** global configuration command. To remove the location string, use the **no** form of this command.

Commands

snmp-server location *text*

no snmp-server location

| | | |
|-------------------------|--|-----------------------|
| Syntax | snmp-server | Configure SNMP server |
| Description | location | Switch location |
| | <i>text</i> | Location string |
| Defaults | The default text is Switch Location | |
| Command Modes | Global configuration | |
| Usage Guidelines | "text" parameter can be set as string separated by space. Maximum string tokens are 5. Maximum length of switch location is 80. | |
| Examples | PT-7828 (config) # snmp-server location <STRING:token1> - Location string token 1 PT-7828 (config) # no snmp-server location | |
| Error messages | Length of location is too long | |
| Related commands | show snmp | |

snmp-server trap-mode

To enable all Simple Network Management Protocol (SNMP) notifications (traps or informs) available on your system, use the **snmp-server trap-mode** global configuration command. To disable all available SNMP notifications, use the **no** form of this command

Commands

snmp-server trap-mode trap

snmp-server trap-mode trap-v2c

snmp-server trap-mode inform [retry times timeout seconds]

no snmp-server trap-mode

| | | |
|-------------------------|---|-------------------------------|
| Syntax | snmp-server | Configure SNMP server |
| Description | trap-mode | SNMP Trap/Inform mode setting |
| | trap | SNMP Trap |
| | trap-v2c | SNMP Trap v2c instead of v1 |
| | inform | SNMP Inform |
| | retry | Inform retries times |
| | times | 1 to 99 |
| | timeout | Timeout timer |
| | seconds | 1 to 300 seconds |
| Defaults | The default mode is "trap" | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828 (config) # snmp-server trap-mode trap PT-7828 (config) # snmp-server trap-mode inform retry 3 timeout 10 PT-7828 (config) # no snmp-server trap-mode</pre> | |
| Error messages | Invalid inform retries value !!! Invalid inform timeout value !!! | |
| Related commands | show snmp | |

snmp-server user

To configure a user and its authentication type and password to a Simple Network Management Protocol (SNMP), use the **snmp-server user** global configuration command.

Commands

snmp-server user *username auth auth-type password*

| | | |
|-------------------------|--|---|
| Syntax | snmp-server | Configure SNMP server |
| Description | user | SNMP user setting |
| | <i>user-privilege</i> | SNMP user privilege |
| | auth | Specifies which authentication level should be used |
| | <i>auth-type</i> | no-auth md5 sha |
| | <i>password</i> | Password (maximum 30 characters) |
| Defaults | N/A | |
| Command Modes | Global configuration | |
| Usage Guidelines | username is only allowed to be set as "admin" or "user" auth-type is only allowed to be set as "no-auth", "md5" or "sha" | |
| Examples | PT-7828 (config) # snmp-server user admin auth md5 moxacli | |
| Error messages | SNMP user must be (admin user)!! SNMP authtype must be (no-auth md5 sha)!! Admin/User Password must be at least 8 bytes !!! Admin/User Data Encryption must be at least 8 bytes !!! | |
| Related commands | show snmp | |

snmp-server version

To set up the snmp version, use the **snmp-server version** global configuration command.

Commands

snmp-server version [**v1-v2c-v3** | **v1-v2c** | **v3**]

| | | |
|-------------------------|---|-----------------------------|
| Syntax | snmp-server | Configure SNMP server |
| Description | version | SNMP version setting |
| | v1-v2c-v3 | Version 1, 2C and 3 support |
| | v1-v2c | Version 1 and 2C support |
| | v3 | Only version 3 support |
| Defaults | Default version is v1-v2c | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # snmp-server version v1-v2c-v3 - Version 1, 2C and 3 support v1-v2c - Version 1 and 2C support v3 - Only version 3 support | |
| Error messages | N/A | |
| Related commands | show snmp | |

spanning-tree forward-delay

Use the **spanning-tree forward-delay** redundancy configuration command on the switch to set the forward-delay time for the spanning-tree. The forwarding time specifies how long each of the listening and learning states last before the interface begins forwarding. Use the **no** form of this command to return to the default setting.

Commands

spanning-tree forward-delay *seconds*

no spanning-tree forward-delay

| | | |
|-------------------------|--|--|
| Syntax | spanning-tree | Configure spanning tree |
| Description | forward-delay | Configure spanning tree BPDU forward delay |
| | <i>seconds</i> | Range from 4 to 30 seconds |
| Defaults | Forward delay = 15 sec. | |
| Command Modes | Redundancy configuration | |
| Usage Guidelines | $2 * (\text{hello-time} + 1.0 \text{ sec}) \leq \text{max-age} \leq 2 * (\text{forward-delay} - 1.0 \text{ sec})$ | |
| Examples | PT-7828 (config-rdnt) # spanning-tree forward-delay <UINT:seconds> - Range from 4 to 30 seconds | |
| Error messages | The BPDU forward delay time must be in the range from 4 to 30 sec. The formula must be obeyed: $2 \times (\text{Hello Time} + 1 \text{ sec}) \leq \text{Max age} \leq 2 \times (\text{Forward Delay} - 1 \text{ sec})$ | |
| Related commands | spanning-tree hello-time spanning-tree max-age show redundancy spanning-tree | |

spanning-tree hello-time

Use the **spanning-tree hello-time** redundancy configuration command on the switch to set the interval between hello bridge protocol data units (BPDUs) sent by root switch configuration messages. Use the **no** form of this command to return to the default setting.

Commands

spanning-tree hello-time *seconds*

no spanning-tree hello-time

| | | |
|-------------------------|---|---|
| Syntax | spanning-tree | Configure spanning tree |
| Description | hello-time | Configure spanning tree BPDU hello time |
| | <i>seconds</i> | Range from 1 to 2 seconds |
| Defaults | Hello time = 2 sec. | |
| Command Modes | Redundancy configuration | |
| Usage Guidelines | $2 * (\text{hello-time} + 1.0 \text{ sec}) \leq \text{max-age} \leq 2 * (\text{forward-delay} - 1.0 \text{ sec})$ | |
| Examples | PT-7828 (config-rdnt) # spanning-tree hello-time <UINT:seconds> - Range from 1 to 2 seconds | |
| Error messages | BPDU hello time must be in the range from 1 to 2 sec. The formula must be obeyed: $2 \times (\text{Hello Time} + 1 \text{ sec}) \leq \text{Max age} \leq 2 \times (\text{Forward Delay} - 1 \text{ sec})$ | |
| Related commands | spanning-tree forward-delay spanning-tree max-age show redundancy spanning-tree | |

spanning-tree max-age

Use the **spanning-tree max-age** redundancy configuration command on the switch to set the interval between messages that the spanning tree receives from the root switch. If a switch does not receive a bridge protocol data unit (BPDU) message from the root switch within this interval, it recomputes the spanning-tree topology. Use the **no** form of this command to return to the default setting.

Commands

spanning-tree max-age seconds

no spanning-tree max-age

| | | |
|-------------------------|--|---------------------------------|
| Syntax | spanning-tree | Configure spanning tree |
| Description | max-age | Configure spanning tree max age |
| | seconds | Range from 6 to 40 seconds |
| Defaults | Forward delay = 20 sec. | |
| Command Modes | Redundancy configuration | |
| Usage Guidelines | $2 * (\text{hello-time} + 1.0 \text{ sec}) \leq \text{max-age} \leq 2 * (\text{forward-delay} - 1.0 \text{ sec})$ | |
| Examples | PT-7828 (config-rdnt) # spanning-tree max-age <UINT:seconds> – Range from 6 to 40 seconds | |
| Error messages | The BPDU forward delay time must be in the range from 4 to 30 sec. The formula must be obeyed: $2 \times (\text{Hello Time} + 1 \text{ sec}) \leq \text{Max age} \leq 2 \times (\text{Forward Delay} - 1 \text{ sec})$ | |
| Related commands | spanning-tree forward-delay spanning-tree max-age show redundancy spanning-tree | |

spanning-tree mst cist cost

Use the **spanning-tree mst cist cost** interface configuration command on the switch to set the port cost of the Multiple Spanning Tree (MSTP). Use the **no** form of this command to return to the default setting.

Commands

spanning-tree mst cist cost cost

no spanning-tree mst cist cost

| | | |
|-------------------------|---|------------------------------------|
| Syntax | spanning-tree | Configure spanning tree |
| Description | mst | Configure mstp |
| | cist | Configure mstp cist port |
| | cost | Configure mstp cist port path cost |
| | cost | Configure mstp cist port path cost |
| Defaults | cost = 0 | |
| Command Modes | Interface configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config-if) # spanning-tree mst cist cost 2000000 <UINT:time> – Set mstp forwarding delay | |
| Error messages | MSTP port path cost must be in the range from 0 to 200000000 MSTP port 2/1 path cost set error | |
| Related commands | show redundancy mst configuration | |

spanning-tree mst cist port-priority

Use the **spanning-tree mst cist port-priority** interface configuration command on the switch to set the port priority for the Multiple Spanning Tree (MSTP). Use the **no** form of this command to return to the default setting.

Commands

spanning-tree mst cist port-priority *priority*

no spanning-tree mst cist port-priority

| | | |
|---------------------------|---|-----------------------------------|
| Syntax Description | spanning-tree | Configure spanning tree |
| | mst | Configure mstp |
| | cist | Configure mstp cist port |
| | port-priority | Configure mstp cist port priority |
| | <i>priority</i> | Configure mstp cist port priority |
| Defaults | priority = 128 | |
| Command Modes | Interface configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config-if) # spanning-tree mst cist port-priority 128 <UINT:>priority - Configure mstp cist port priority | |
| Error messages | MSTP port priority must be in the range from 0 to 240 MSTP port %s priority set error MSTP port priority should be 16 times the value | |
| Related commands | show redundancy mst configuration | |

spanning-tree mst cist priority

Use the **spanning-tree mst cist priority** redundancy configuration command on the switch to set the switch priority for the Multiple Spanning Tree (MSTP). Use the **no** form of this command to return to the default setting.

Commands

spanning-tree mst cist priority *priority*

no spanning-tree mst cist priority

| | | |
|---------------------------|---|-------------------------------|
| Syntax Description | spanning-tree | Configure spanning tree |
| | mst | Configure mstp |
| | cist | Configure mstp cist |
| | priority | Set mstp cist bridge priority |
| | <i>priority</i> | Set mstp cist bridge priority |
| Defaults | priority = 32768 | |
| Command Modes | Redundancy configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config-rdnt) # spanning-tree mst cist priority 32768 <UINT:>priority - Set mstp cist bridge priority | |
| Error messages | MSTP bridge priority must be in the range from 0 to 61140 MSTP cist bridge priority set error CIST bridge priority should be 4096 times the value | |
| Related commands | show redundancy mst cist | |

spanning-tree mst edge-port

Use the **spanning-tree mst edge-port** interface configuration command on the switch to enable the Edge port feature for the Multiple Spanning Tree (MSTP). Use the **no** form of this command to disable the setting.

Commands

spanning-tree mst edge-port

no spanning-tree mst edge-port

| | | |
|-------------------------|--|-------------------------|
| Syntax | spanning-tree | Configure spanning tree |
| Description | mst | Configure mstp |
| | edge-port | Enable mstp edge port |
| Defaults | N/A | |
| Command Modes | Interface configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config-if) # spanning-tree mst edge <edge> - Enable mstp edge port | |
| Error messages | MSTP edge port enable set error | |
| Related commands | show redundancy mst configuration | |

spanning-tree mst enable

Use the **spanning-tree mst enable** interface configuration command on the switch to enable the Multiple Spanning Tree (MSTP) feature on the port. Use the **no** form of this command to disable the setting.

Commands

spanning-tree mst enable

no spanning-tree mst

| | | |
|-------------------------|---|-------------------------|
| Syntax | spanning-tree | Configure spanning tree |
| Description | mst | Configure mstp |
| | enable | Enable mstp port |
| Defaults | N/A | |
| Command Modes | Interface configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config-if) # spanning-tree mst enable <enable> - Enable mstp port | |
| Error messages | MSTP port 2-1 enable set error | |
| Related commands | show redundancy mst configuration | |

spanning-tree mst forward-time

Use the **spanning-tree mst forward-time** redundancy configuration command on the switch to set the forward delay of Multiple Spanning Tree (MSTP). Use the **no** form of this command to return to the default setting.

Commands

spanning-tree mst forward-time *time*

no spanning-tree mst forward-time

| | | |
|---------------------------|---|---------------------------|
| Syntax Description | spanning-tree | Configure spanning tree |
| | mst | Configure mstp |
| | forward-time | Set mstp forwarding delay |
| | time | Set mstp forwarding delay |
| Defaults | time=15 | |
| Command Modes | Redundancy configuration | |
| Usage Guidelines | $2 * (\text{hello-time} + 1.0 \text{ sec}) \leq \text{max-age} \leq 2 * (\text{forward-delay} - 1.0 \text{ sec})$ | |
| Examples | PT-7828 (config-rdnt) # spanning-tree mst forward-time 15 <UINT:time> - Set mstp forwarding delay | |
| Error messages | MSTP forward delay must be in the range from 4 to 30 | |
| Related commands | show redundancy mst configuration | |

spanning-tree mst hello-time

Use the **spanning-tree mst hello-time** redundancy configuration command on the switch to set the hello time of Multiple Spanning Tree (MSTP). Use the **no** form of this command to return to the default setting.

Commands

spanning-tree mst hello-time *time*

no spanning-tree mst hello-time

| | | |
|---------------------------|---|-------------------------|
| Syntax Description | spanning-tree | Configure spanning tree |
| | mst | Configure mstp |
| | hello-time | set mstp hello time |
| | time | set mstp hello time |
| Defaults | time=2 | |
| Command Modes | Redundancy configuration | |
| Usage Guidelines | $2 * (\text{hello-time} + 1.0 \text{ sec}) \leq \text{max-age} \leq 2 * (\text{forward-delay} - 1.0 \text{ sec})$ | |
| Examples | PT-7828 (config-rdnt) # spanning-tree mst hello-time 1 <UINT:time> - set mstp hello time | |
| Error messages | MSTP hello time must be in the range from 1 to 10 | |
| Related commands | show redundancy mst configuration | |

spanning-tree mst instance

Use the **spanning-tree mst instance** redundancy configuration command on the switch to setting the MSTP instances. Use the **no** form of this command to remove the setting.

Commands

spanning-tree mst instance *instance-id* **vlan** *vlan-id-list*

no spanning-tree mst instance *instance-id* **vlan** *vlan-id-list*

| | | |
|---------------------------|---|----------------------------------|
| Syntax Description | spanning-tree | Configure spanning tree |
| | mst | Configure mstp |
| | instance | Configure mstp msti |
| | <i>instance-id</i> | MSTP instance ID |
| | vlan | Configure mstp msti vlan mapping |
| | <i>vlan-id-list</i> | Configure mstp msti vlan mapping |
| Defaults | N/A | |
| Command Modes | Redundancy configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # spanning-tree mst instance 1 vlan 2 <STRING:instids> - Configure mstp msti <STRING:vidlist> - Configure mstp msti vlan mapping | |
| Error messages | The instance id must be in the range from 1 to 16. vlan 4097 is invalid!! should be range from 1 to 4094 The maximum VLAN mapping is 64. The vlan id 2 setting is exist in another instance. MSTI 1 vlan id 2 set error | |
| Related commands | show redundancy mst instance | |

spanning-tree mst instance cost

Use the **spanning-tree mst instance cost** interface configuration command on the switch to set the port cost of the MSTP instances. Use the **no** form of this command to return to the default setting.

Commands

spanning-tree mst instance *instance-id-list* **cost** *cost*

no spanning-tree mst instance *instance-id-list* **cost**

| | | |
|---------------------------|---|------------------------------------|
| Syntax Description | spanning-tree | Configure spanning tree |
| | mst | Configure mstp |
| | instance | Configure mstp msti port |
| | <i>instance-id-list</i> | MSTP instance IDs |
| | cost | Configure mstp msti port path cost |
| | <i>cost</i> | Configure mstp msti port path cost |
| Defaults | cost = 0 | |
| Command Modes | Interface configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config-if) # spanning-tree mst cist cost 0 <UINT:cost> - Configure mstp msti port path cost | |
| Error messages | MSTP port path cost must be in the range from 0 to 200000000 MSTP forward delay set error | |
| Related commands | show redundancy mst configuration | |

spanning-tree mst instance port-priority

Use the **spanning-tree mst instance port-priority** interface configuration command on the switch to set the port priority for the MSTP instances. Use the **no** form of this command to return to the default setting.

Commands

spanning-tree mst instance *instance-id-list* port-priority *priority*

no spanning-tree mst instance *instance-id-list* port-priority

| | | |
|---------------------------|---|-----------------------------------|
| Syntax Description | spanning-tree | Configure spanning tree |
| | mst | Configure mstp |
| | instance | Configure mstp msti port |
| | <i>instance-id-list</i> | MSTP instance ID |
| | port-priority | Configure mstp msti port priority |
| | <i>priority</i> | Configure mstp msti port priority |
| Defaults | priority = 128 | |
| Command Modes | Interface configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config-if) # spanning-tree mst instance 1 port-priority 128 <STRING:instids> - Configure mstp msti port priority <UINT:priority> - Configure mstp msti port priority | |
| Error messages | MSTP port priority must be in the range from 0 to 240 MSTI 2 port 2-1 priority set error MSTI 2 port priority should be 16 times the value | |
| Related commands | show redundancy mst configuration | |

spanning-tree mst instance priority

Use the **spanning-tree mst instance priority** redundancy configuration command on the switch to set the switch priority for the MSTP instances. Use the **no** form of this command to return to the default setting.

Commands

spanning-tree mst instance *instance-id-list* priority *priority*

no spanning-tree mst instance *instance-id-list* priority

| | | |
|---------------------------|---|-------------------------------|
| Syntax Description | spanning-tree | Configure spanning tree |
| | mst | Configure mstp |
| | instance | Configure mstp msti |
| | <i>instance-id</i> | MSTP instance ID |
| | priority | Set mstp msti bridge priority |
| | <i>priority</i> | Set mstp msti bridge priority |
| Defaults | priority = 32768 | |
| Command Modes | Redundancy configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config-rdnt) # spanning-tree mst instance 1 priority 32768 <UINT:priority> - Set mstp msti bridge priority | |
| Error messages | MSTP bridge priority must be in the range from 0 to 61140 MSTP cist bridge priority set error MSTI bridge priority should be 4096 times the value | |
| Related commands | show redundancy mst instance | |

spanning-tree mst max-age

Use the **spanning-tree mst max-age** redundancy configuration command on the switch to set the switch maximum age time for Multiple Spanning Tree (MSTP). Use the **no** form of this command to return to the default setting.

Commands

spanning-tree mst max-age age

no spanning-tree mst max-age

| | | |
|-------------------------|--|-------------------------|
| Syntax | spanning-tree | Configure spanning tree |
| | mst | Configure mstp |
| | max-age | Set mstp max age |
| | age | Set mstp max age |
| Defaults | age = 20 | |
| Command Modes | Redundancy configuration | |
| Usage Guidelines | 2*(hello-time + 1.0 sec) <= max-age <= 2*(forward-delay - 1.0 sec) | |
| Examples | PT-7828 (config-rdnt) # spanning-tree mst max-age 10 <UINT:age> - Set mstp max age | |
| Error messages | MSTP max age must be in the range from 6 to 40 MSTP max age set error | |
| Related commands | show redundancy mst configuration | |

spanning-tree mst max-hops

Use the **spanning-tree max-hops** redundancy configuration command on the switch to set the switch maximum hop number for Multiple Spanning Tree (MSTP). Use the **no** form of this command to return to the default setting.

Commands

spanning-tree mst max-hops hops

no spanning-tree mst max-hops

| | | |
|-------------------------|---|-------------------------|
| Syntax | spanning-tree | Configure spanning tree |
| | mst | Configure mstp |
| | max-hops | Set mstp max hops |
| | hops | Set mstp max hops |
| Defaults | hops = 20 | |
| Command Modes | Redundancy configuration | |
| Usage Guidelines | 2*(hello-time + 1.0 sec) <= max-age <= 2*(forward-delay - 1.0 sec) | |
| Examples | PT-7828 (config-rdnt) # spanning-tree mst max-hops 10 <UINT:hops> - Set mstp max hops | |
| Error messages | MSTP max hops must be in the range from 6 to 40 MSTP max hops set error | |
| Related commands | show redundancy mst configuration | |

spanning-tree mst name

Use the **spanning-tree mst name** redundancy configuration command on the switch stack to set the name of MSTP region for the spanning-tree.

Commands

spanning-tree mst name *region-name*

| | | |
|-------------------------|---|-------------------------|
| Syntax | spanning-tree | Configure spanning tree |
| Description | mst | Configure mstp |
| | name | Set mstp regional name |
| | <i>region-name</i> | Set mstp regional name |
| Defaults | N/A | |
| Command Modes | Redundancy configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config-rdnt) # spanning-tree mst name mstp <STRING:region> - Set mstp regional name | |
| Error messages | The length of mstp regional name should be smaller than 32 MSTP regional name set error | |
| Related commands | show redundancy mst instance | |

spanning-tree mst revision

Use the **spanning-tree mst revision** redundancy configuration command on the switch to set revision level for Multiple Spanning Tree (MSTP).

Commands

spanning-tree mst revision *revision-level*

| | | |
|-------------------------|--|-------------------------|
| Syntax | spanning-tree | Configure spanning tree |
| Description | mst | Configure mstp |
| | revision | Set mstp revision level |
| | <i>revision-level</i> | Set mstp revision level |
| Defaults | revision-level = 0 | |
| Command Modes | Redundancy configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config-rdnt) # spanning-tree mst revision 1 <UINT:level> - Set mstp revision level | |
| Error messages | MSTP revision level must be in the range from 0 to 65535 MSTP revision level set error | |
| Related commands | show redundancy mst configuration | |

spanning-tree priority

Use the **spanning-tree priority** redundancy configuration command on the switch to set the switch priority for the spanning-tree. Use the **no** form of this command to return to the default setting.

Commands

spanning-tree priority *priority*

no spanning-tree priority

| | | |
|---------------------------|---|--|
| Syntax Description | spanning-tree | Configure spanning tree |
| | priority | Configure spanning tree bridge priority |
| | <i>priority</i> | Range from 0 to 61440, and must be the multiples of 4096 |
| Defaults | priority = 32768 | |
| Command Modes | Redundancy configuration | |
| Usage Guidelines | 0 <= priority <= 61440, and must be multiples of 4096. | |
| Examples | PT-7828 (config-rdnt) # spanning-tree priority <UINT:prio> - Range from 0 to 61440, in steps of 4096 | |
| Error messages | The bridge priority must be in the range from 0 to 61440 | |
| | The bridge priority must be the multiples of 4096 | |
| Related commands | show redundancy spanning-tree | |

spanning-tree

Use the **spanning-tree** interface configuration command on the switch to enable the spanning-tree feature of the specified interfaces. Use the **no** form of this command to disable it.

Commands

spanning-tree

no spanning-tree

| | | |
|---------------------------|--|----------------------|
| Syntax Description | spanning-tree | Enable spanning tree |
| Command Modes | Interface configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config-if) # spanning-tree | |
| Error messages | Cannot configure on trunk member port 1/1! | |
| Related commands | redundancy mode show redundancy spanning-tree | |

spanning-tree cost

Use the **spanning-tree cost** interface configuration command on the switch to set the path cost for spanning-tree algorithms calculations. If a loop occurs, spanning tree considers the path cost when selecting an interface to put in the forwarding state. Use the **no** form of this command to return to the default setting.

Commands

spanning-tree cost *cost*

no spanning-tree cost

| | | |
|-------------------------|--|---------------------------|
| Syntax | spanning-tree | Enable spanning tree |
| Description | cost | Configure port path cost |
| | <i>cost</i> | Range from 1 to 200000000 |
| Defaults | cost = 200000 | |
| Command Modes | Interface configuration | |
| Usage Guidelines | 1 <= Cost <= 200000000 | |
| Examples | PT-7828 (config-if) # spanning-tree cost <UINT:cost> - Range from 1 to 200000000 | |
| Error messages | Cost value must be in the range 1 to 200000000 Cannot configure on trunk member port 1/1! | |
| Related commands | show redundancy spanning-tree | |

spanning-tree edge-port

Use the **spanning-tree edge-port** interface configuration command on the switch to enable the Edge Port feature on an interface in all its associated VLANs. When the Edge Port feature is enabled, the interface changes directly from a blocking state to a forwarding state without making the intermediate spanning-tree state changes. Use the **no** form of this command to disable the feature.

Commands

spanning-tree edge-port { auto | force }

no spanning-tree edge-port

| | | |
|-------------------------|--|-----------------------------|
| Syntax | spanning-tree | Enable spanning tree |
| Description | edge-port | Configure as edge port |
| | auto | Auto determine as edge port |
| | force | Force the port as edge port |
| Defaults | port-fast = auto | |
| Command Modes | Interface configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config-if) # spanning-tree edge-port auto - Auto determine as edge port force - Force the port as edge port | |
| Error messages | Cannot configure on trunk member port 1/1! | |
| Related commands | show redundancy spanning-tree | |

spanning-tree priority

Use the **spanning-tree priority** interface configuration command on the switch to set the interfaces priority for the spanning-tree. Use the **no** form of this command to return to the default setting.

Commands

spanning-tree priority *priority*

no spanning-tree priority

| | | |
|---------------------------|---|-------------------------------------|
| Syntax Description | spanning-tree | Enable spanning tree |
| | priority | Configure port priority |
| | <i>priority</i> | Range from 0 to 240, in steps of 16 |
| Defaults | priority = 128 | |
| Command Modes | interface configuration | |
| Usage Guidelines | 0 <= priority <= 240, and must be multiples of 16. | |
| Examples | PT-7828 (config-rdnt) # spanning-tree priority <UINT:prio> - Range from 0 to 61440, in steps of 4096 | |
| Error messages | The bridge priority must be in the range from 0 to 240 The bridge priority must be multiples of 16 | |
| Related commands | show redundancy spanning-tree | |

speed-duplex

Use the **speed-duplex** interface configuration command to specify the speed of the interface and its duplex mode. Use the **no** form of this command to return the interface to its default value.

Commands

speed-duplex {10M-Full | 10M-Half | 100M-Full| 100M-Half | 1G-Full | Auto}

no speed-duplex

| | | |
|---------------------------|--|--------------------------------------|
| Syntax Description | speed-duplex | Configure speed and duplex operation |
| | 10M-Full | Speed 10M-full |
| | 10M-Half | Speed 10M-Half |
| | 100M-Full | Speed 100M-Full |
| | 100M-Half | Speed 100M-Half |
| | 1G-Full | Speed 1G-Full |
| | Auto | Speed Auto |
| Defaults | The default is Auto | |
| Command Modes | Interface configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # interface ethernet 1/1 PT-7828 (config-if) # speed-duplex 100M-Full | |
| Error messages | Fiber port can not be set speed-duplex!!! This port can not be set to 1G!!! Parameter does not be defined!!! Cannot configure on trunk member port 1/1 This setting cannot be applied on trunk port! | |
| Related commands | show interfaces ethernet | |

storm-control

Use the **storm-control** global configuration command on the switch to enable the storm protection. Use the **no** form of this command to disable it or return to the default.

Commands

storm-control { bcast | mcast }

no storm-control bcast

no storm-control mcast

no storm-control

| | |
|---------------------------|---|
| Syntax Description | storm-control Storm protection bcast Storm protection for broadcast traffic mcast Storm protection for Multicast traffic |
| Defaults | The broadcast storm protection is default enabled. |
| Command Modes | Global configuration |
| Usage Guidelines | N/A |
| Examples | <pre>storm-control bcast mcast</pre> <ul style="list-style-type: none"> - Storm protection for broadcast traffic - Storm protection for Multicast traffic |
| Error messages | N/A |
| Related commands | show storm-control |

switchport access vlan

Use the **switchport access vlan** interface configuration command on the switch to configure a port as a static-access or dynamic-access port. If the switchport mode is set to access, the port operates as a member of the specified VLAN. If set to dynamic, the port starts discovery of VLAN assignment based on the incoming packets it receives. Use the **no** form of this command to reset the access mode to the default VLAN for the switch.

Commands

switchport access vlan *vlan-id*

no switchport access vlan

| | | |
|---------------------------|---|--|
| Syntax Description | switchport | Set switching mode characteristics |
| | access | Set access mode characteristics of the interface |
| | vlan | Set (default) pvid in access mode |
| | <i>vlan-id</i> | 1 to 4094 |
| Defaults | vlan-id = 1 | |
| Command Modes | Interface configuration | |
| Usage Guidelines | You can only use this command mode for configuring normal-range VLANs, that is, VLAN IDs 1 to 4094. | |
| Examples | <pre>PT-7828(config-if)# switchport access vlan 2 <UINT:vlanid> - 1 to 4094</pre> | |
| Error messages | vlan 4097 is invalid!! should be range from 1 to 4094 | |
| Related commands | show vlan show vlan config | |

switchport hybrid fixed vlan add

Use the **switchport hybrid fixed vlan add** interface configuration command on the switch to add the trunk hybrid characteristics when the interface is in hybrid mode. Use the **no** form of this command to reset to the default.

Commands

switchport hybrid fixed vlan add *vlan-id-list tag*

switchport hybrid fixed vlan add *vlan-id-list untag*

no switchport hybrid fixed vlan tag

no switchport hybrid fixed vlan untag

| | | |
|---------------------------|--|---|
| Syntax Description | switchport | Set switching mode characteristics |
| | hybrid | Set hybrid mode characteristics of the interface |
| | fixed | Set fixed VLAN characteristics |
| | vlan | 1 to 4094 |
| | add | Add VLANs to the current list |
| | <i>vlan-id-list</i> | VLAN IDs of the VLANs |
| | untag | Configure egress traffic as VLAN untagged traffic |
| | tag | Configure egress traffic as VLAN tagged traffic |
| Defaults | N/A | |
| Command Modes | Interface configuration | |
| Usage Guidelines | You can only use this command mode for configuring normal-range VLANs, that is, VLAN IDs 1 to 4094. | |
| Examples | PT-7828 (config-if) # switchport hybrid fixed vlan add 1,3-5,7 tag <STRING:vlanids> - VLAN IDs of the VLANs | |
| Error messages | vlan 4097 is invalid!! should be range from 1 to 4094 vlan interfaces are full, total vlan interface is 64 !! | |
| Related commands | show vlan show vlan config switchport trunk hybrid vlan remove | |

switchport hybrid forbidden vlan add

Use the **switchport hybrid forbidden vlan add** interface configuration command on the switch to add the trunk forbidden characteristics when the interface is in hybrid mode. Use the **no** form of this command to reset to the default.

Commands

switchport hybrid forbidden vlan add *vlan-id-list*

no switchport hybrid forbidden vlan

| | | |
|---------------------------|--|--|
| Syntax Description | switchport | Set switching mode characteristics |
| | hybrid | Set hybrid mode characteristics of the interface |
| | forbidden | Set forbidden VLAN characteristics |
| | vlan | 1 to 4094 |
| | add | Add VLANs to the current list |
| | vlan-id-list | VLAN IDs of the VLANs |
| Defaults | N/A | |
| Command Modes | Interface configuration | |
| Usage Guidelines | You can only use this command mode for configuring normal-range VLANs, that is, VLAN IDs 1 to 4094. | |
| Examples | PT-7828 (config-if) # switchport hybrid forbidden vlan add 1,3-5,7 <STRING:vlanids> - VLAN IDs of the VLANs | |
| Error messages | vlan 4097 is invalid!! should be range from 1 to 4094 vlan interfaces are full, total vlan interface is 64 !! | |
| Related commands | show vlan show vlan config switchport hybrid forbidden vlan remove | |

switchport hybrid forbidden vlan remove

Use the **switchport hybrid forbidden vlan remove** interface configuration command on the switch to remove the trunk forbidden characteristics when the interface is in hybrid mode. Use the **no** form of this command to reset to the default.

Commands

switchport hybrid forbidden vlan remove *vlan-id-list*

no switchport hybrid forbidden vlan

| | | |
|---------------------------|---|--|
| Syntax Description | switchport | Set switching mode characteristics |
| | hybrid | Set hybrid mode characteristics of the interface |
| | forbidden | Set forbidden VLAN characteristics |
| | vlan | 1 to 4094 |
| | remove | Remove VLANs from the current list |
| | vlan-id-list | VLAN IDs of the VLANs |
| Defaults | N/A | |
| Command Modes | Interface configuration | |
| Usage Guidelines | You can only use this command mode for configuring normal-range VLANs, that is, VLAN IDs 1 to 4094. | |
| Examples | PT-7828 (config-if) # switchport hybrid forbidden vlan remove 1,3-5,7 <STRING:vlanids> - VLAN IDs of the VLANs | |
| Error messages | vlan 4097 is invalid!! should be range from 1 to 4094 vlan interfaces are full, total vlan interface is 64 !! | |
| Related commands | show vlan show vlan config switchport hybrid forbidden vlan add | |

switchport hybrid native vlan

Use the **switchport hybrid native vlan** interface configuration command on the switch to configure PVID of a port. Use the **no** form of this command to return to the default PVID.

Commands

switchport hybrid native vlan *vlan-id*

no switchport hybrid native vlan

| | | |
|-------------------------|---|--|
| Syntax | switchport | Set switching mode characteristics |
| | hybrid | Set hybrid mode characteristics of the interface |
| | native | Set trunking native characteristics |
| | vlan | Set pvid vlanid in hybrid mode |
| | vlan-id | 1 to 4094 |
| Defaults | vlan-id = 1 | |
| Command Modes | Interface configuration | |
| Usage Guidelines | You can only use this command mode for configuring normal-range VLANs, that is, VLAN IDs 1 to 4094. | |
| Examples | PT-7828 (config-if) # switchport hybrid native vlan 2 <UINT:vlanid> - 1 to 4094 | |
| Error messages | vlan 4097 is invalid!! should be range from 1 to 4094 | |
| Related commands | show vlan show vlan config | |

switchport pvlan

Use the **switchport pvlan** interface configuration command on the switch stack to define a port-based VLAN association for an isolated or community port or a mapping for a promiscuous port. Use the **no** form of this command to remove the port-based VLAN association or mapping from the port.

Commands

switchport pvlan *vlan-groups*

no switchport pvlan *vlan-groups*

| | | |
|-------------------------|--|------------------------------------|
| Syntax | switchport | Set switching mode characteristics |
| | pvlan | Configure port-based vlan |
| | vlan-groups | Set/unset port-based vlan group |
| Defaults | N/A | |
| Command Modes | Interface configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config-if) # switchport pvlan 2,3,4 <STRING:groups> - set port-based vlan group | |
| Error messages | vlan 4097 is invalid!! should be range from 1 to 4094 | |
| Related commands | show vlan show vlan config | |

switchport trunk fixed vlan add

Use the **switchport trunk fixed vlan add** interface configuration command on the switch to add the trunk characteristics when the interface is in trunking mode. Use the **no** form of this command to reset a trunking characteristic to the default.

Commands

switchport trunk fixed vlan add *vlan-id-list*

no switchport trunk fixed vlan

| | | |
|---------------------------|--|--|
| Syntax Description | switchport | Set switching mode characteristics |
| | trunk | Set trunking mode characteristics of the interface |
| | fixed | Set fixed VLAN characteristics |
| | vlan | 1 to 4094 |
| | add | Add VLANs to the current list |
| | vlan-id-list | VLAN IDs of the VLANs |
| Defaults | N/A | |
| Command Modes | Interface configuration | |
| Usage Guidelines | You can only use this command mode for configuring normal-range VLANs, that is, VLAN IDs 1 to 4094. | |
| Examples | PT-7828 (config-if) # switchport trunk fixed vlan add 1,3-5,7 <STRING:vlanids> - VLAN IDs of the VLANs | |
| Error messages | vlan 4097 is invalid!! should be range from 1 to 4094 vlan interfaces are full, total vlan interface is 64 !! | |
| Related commands | show vlan show vlan config switchport trunk fixed vlan remove | |

switchport trunk fixed vlan remove

Use the **switchport trunk fixed vlan remove** configuration command on the switch stack to remove the trunk characteristics when the interface is in trunking mode. Use the **no** form of this command to reset a trunking characteristic to the default.

Commands

switchport trunk fixed vlan remove *vlan-id-list*

no switchport trunk fixed vlan

| | | |
|---------------------------|--|--|
| Syntax Description | switchport | Set switching mode characteristics |
| | trunk | Set trunking mode characteristics of the interface |
| | fixed | Set fixed VLAN characteristics |
| | vlan | 1 to 4094 |
| | remove | Remove VLANs from the current list |
| | vlan-id-list | VLAN IDs of the VLANs |
| Defaults | N/A | |
| Command Modes | Interface configuration | |
| Usage Guidelines | You can only use this command mode for configuring normal-range VLANs, that is, VLAN IDs 1 to 4094. | |
| Examples | PT-7828 (config-if) # switchport trunk fixed vlan remove 1,3-5,7 <STRING:vlanids> - VLAN IDs of the VLANs | |
| Error messages | vlan 4097 is invalid!! should be range from 1 to 4094 vlan interfaces are full, total vlan interface is 64 !! | |
| Related commands | show vlan show vlan config switchport trunk fixed vlan add | |

switchport trunk forbidden vlan add

Use the **switchport trunk forbidden vlan add** configuration command on the switch to add the trunk forbidden characteristics when the interface is in trunking mode. Use the **no** form of this command to reset a trunking characteristic to the default.

Commands

switchport trunk forbidden vlan add *vlan-id-list*

no switchport trunk forbidden vlan

| | | |
|---------------------------|--|--|
| Syntax Description | switchport | Set switching mode characteristics |
| | trunk | Set trunking mode characteristics of the interface |
| | forbidden | Set forbidden VLAN characteristics |
| | vlan | 1 to 4094 |
| | add | Add VLANs to the current list |
| | vlan-id-list | VLAN IDs of the VLANs |
| Defaults | N/A | |
| Command Modes | Interface configuration | |
| Usage Guidelines | You can only use this command mode for configuring normal-range VLANs, that is, VLAN IDs 1 to 4094. | |
| Examples | PT-7828 (config-if) # switchport trunk forbidden vlan add 1,3-5,7 <STRING:vlanids> - VLAN IDs of the VLANs | |
| Error messages | vlan 4097 is invalid!! should be range from 1 to 4094 vlan interfaces are full, total vlan interface is 64 !! | |
| Related commands | show vlan show vlan config switchport trunk forbidden vlan remove | |

switchport trunk forbidden vlan remove

Use the **switchport trunk forbidden vlan remove** configuration command on the switch stack or on a standalone switch to remove the trunk forbidden characteristics when the interface is in trunking mode. Use the **no** form of this command to reset a trunking characteristic to the default.

Commands

switchport trunk forbidden vlan remove *vlan-id-list*

no switchport trunk forbidden vlan

| | | |
|---------------------------|--|--|
| Syntax Description | switchport | Set switching mode characteristics |
| | trunk | Set trunking mode characteristics of the interface |
| | forbidden | Set forbidden VLAN characteristics |
| | vlan | 1 to 4094 |
| | remove | Remove VLANs from the current list |
| | vlan-id-list | VLAN IDs of the VLANs |
| Defaults | N/A | |
| Command Modes | Interface configuration | |
| Usage Guidelines | You can only use this command mode for configuring normal-range VLANs, that is, VLAN IDs 1 to 4094. | |
| Examples | PT-7828 (config-if) # switchport trunk forbidden vlan remove 1,3-5,7 <STRING:vlanids> - VLAN IDs of the VLANs | |
| Error messages | vlan 4097 is invalid!! should be range from 1 to 4094 vlan interfaces are full, total vlan interface is 64 !! | |
| Related commands | show vlan show vlan config switchport trunk forbidden vlan add | |

switchport trunk native vlan

Use the **switchport trunk native vlan** interface configuration command on the switch to configure PVID of a port as a trunking port. Use the **no** form of this command to return to the default.

Commands

switchport trunk native vlan *vlan-id*

no switchport trunk native vlan

| | | |
|-------------------------|---|--|
| Syntax | switchport | Set switching mode characteristics |
| | trunk | Set trunking mode characteristics of the interface |
| | native | Set trunking native characteristics |
| | vlan | Set pvid vlanid in trunk mode |
| | vlan-id | 1 to 4094 |
| Defaults | vlan-id = 1 | |
| Command Modes | Interface configuration | |
| Usage Guidelines | You can only use this command mode for configuring normal-range VLANs, that is, VLAN IDs 1 to 4094. | |
| Examples | PT-7828 (config-if) # switchport trunk native vlan 2 <UINT:vlanid> - 1 to 4094 | |
| Error messages | vlan 4097 is invalid!! should be range from 1 to 4094 | |
| Related commands | show vlan show vlan config | |

trunk-group

Use the **trunk-group** interface configuration command on the switch to assign an Ethernet port to a trunk group. Use the **no** form of this command to remove an Ethernet port from a trunk group.

Commands

trunk-group *trunk_id*

no trunk-group

| | | |
|-------------------------|---|-----------------------------|
| Syntax | trunk-group | Join trunk group as members |
| | <i>trunk_id</i> | Trunk ID. From 1 to 4 |
| Defaults | N/A | |
| Command Modes | Interface configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config-if) # trunk-group <UINT:trunk_id> - Trunk ID. From 1 to 4 | |
| Error messages | This setting cannot be applied on trunk port! Trunk ID is only allowed from 1 to 4 | |
| Related commands | show interfaces trunk | |

trunk-mode

Use the **trunk-mode** interface configuration command on the switch to set the trunk mode of the specified trunk group. Use the **no** form of this command to return to the default setting.

Commands

trunk-mode { static | lacp }

no trunk-mode

| | | |
|---------------------------|--|---------------------------|
| Syntax Description | trunk-mode | Trunk mode configuration |
| | static | Configure as static trunk |
| | lacp | Configure as LACP trunk |
| Defaults | The default trunk mode of creating trunk manually is static. | |
| Command Modes | Interface configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config-if) # trunk-mode static - Configure as static trunk lacp - Configure as LACP trunk | |
| Error messages | This setting cannot be applied on normal port! | |
| Related commands | show interfaces trunk | |

turbo-chain

Use the **turbo-chain** redundancy configuration command on the switch stack or on a standalone switch to configure Turbo Chain.

Commands

turbo-chain role {head | member | tail} primary interface module/port secondary interface module/port

| | | |
|---------------------------|--|------------------------------------|
| Syntax Description | turbo-chain | Configure turbo chain |
| | role | Turbo chain role setting |
| | head | Turbo chain role head setting |
| | member | Turbo chain role member setting |
| | tail | Turbo chain role tail setting |
| | primary | Turbo chain primary port setting |
| | interface | Turbo chain port interface setting |
| | secondary | Turbo chain secondary port setting |
| | module/port | Port ID. E.g., 1/3, 2/1,... |
| Defaults | N/A | |
| Command Modes | redundancy configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config-rdnt) # turbo-chain role head primary interface 1/1 secondary interface 1/2 | |
| Error messages | N/A | |
| Related commands | show redundancy turbo-chain | |

turbo-ring-v1

Use the **turbo-ring-v1** redundancy configuration command on the switch to enable the Turbo Ring v1 with specified Ring ports.

Commands

turbo-ring-v1 primary interface *primary-port* secondary interface *secondary-port*

| | | |
|-------------------------|---|----------------------------------|
| Syntax | turbo-ring-v1 | Configure turbo ring v1 |
| Description | primary | Turbo ring v1 ring ports setting |
| | interface | Turbo ring v1 ring ports setting |
| | <i>primary-port</i> | Port ID. E.g., 1/3, Trk2,... |
| | secondary | Turbo ring v1 ring ports setting |
| | interface | Turbo ring v1 ring ports setting |
| | <i>secondary-port</i> | Port ID. E.g., 1/3, Trk2,... |
| Defaults | N/A | |
| Command Modes | Redundancy configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config-rdnt) # turbo-ring-v1 primary interface 2/1 secondary interface 2/2 <STRING:pri_port> - Port ID. E.g., 1/3, Trk2,... <STRING:sec_port> - Port ID. E.g., 1/3, Trk2,... | |
| Error messages | Interface 2-1 not exist One port is the same in ring ports or coupling ports | |
| Related commands | show turbo-ring-v1 | |

turbo-ring-v1 coupling

Use the **turbo-ring-v1 coupling** redundancy configuration command on the switch to set the coupling for Turbo Ring v1. Use the **no** form of this command to disable it.

Commands

turbo-ring-v1 coupling interface *primary-port* coupling-control-port interface *secondary-port*

no turbo-ring-v1 coupling

| | | |
|-------------------------|--|--|
| Syntax | turbo-ring-v1 | Configure turbo ring v1 |
| Description | coupling | Configure ring coupling |
| | interface | Turbo ring v1 ring ports setting |
| | <i>primary-port</i> | Primary port ID. E.g., 1/3, Trk2,... |
| | coupling-control-port | Turbo ring v1 coupling ports setting |
| | interface | Turbo ring v1 ring ports setting |
| | <i>secondary-port</i> | Secondary port ID. E.g., 1/3, Trk2,... |
| Defaults | N/A | |
| Command Modes | Redundancy configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config-rdnt) # turbo-ring-v1 coupling interface 2/1 coupling-control-port interface 2/2 <STRING:pri_port> - Port ID. E.g., 1/3, Trk2,... <STRING:sec_port> - Port ID. E.g., 1/3, Trk2,... | |
| Error messages | Interface 2-1 not exist One port is the same in ring ports or coupling ports | |
| Related commands | show turbo-ring-v1 | |

turbo-ring-v1 master

Use the **turbo-ring-v1 master** redundancy configuration command on the switch to set the switch as the Turbo Ring v1 Master. Use the **no** form of this command to return to the normal Turbo Ring v1 member.

Commands

turbo-ring-v1 master

no turbo-ring-v1 master

| | | |
|------------------|--|-------------------------|
| Syntax | turbo-ring-v1 | Configure turbo ring v1 |
| Description | master | Set ring as master |
| Defaults | N/A | |
| Command Modes | Redundancy configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config-rdnt) # turbo-ring-v1 master - Set ring as master | |
| Error messages | N/A | |
| Related commands | show turbo-ring-v1 | |

turbo-ring-v2

Use the **turbo-ring-v2** redundancy configuration command on the switch to configure the Turbo Ring v2 with specified Ring ports. Use the **no** form of this command to disable the specified ring.

Commands

turbo-ring-v2 *ring-id* **primary interface** *primary-port* **secondary interface** *secondary-port*

no turbo-ring-v2 *ring-id*

| | | |
|-------------------------|--|----------------------------------|
| Syntax | turbo-ring-v2 | Configure turbo ring v2 |
| | <i>ring-id</i> | Turbo ring v2 ring id |
| | primary | Turbo ring v2 ring ports setting |
| | interface | Turbo ring v2 ring ports setting |
| | <i>primary-port</i> | Port ID. E.g., 1/3, 2/1,... |
| | secondary | Turbo ring v2 ring ports setting |
| | interface | Turbo ring v2 ring ports setting |
| | <i>secondary-port</i> | Port ID. E.g., 1/3, 2/1,... |
| Defaults | N/A | |
| Command Modes | Redundancy configuration | |
| Usage Guidelines | At least enable one turbo-ring domain or coupling. But cannot enable two turbo-ring domains and coupling in the same time. | |
| Examples | PT-7828 (config-rdnt) # turbo-ring-v2 1 primary interface 2/1 secondary interface 2/2 <STRING:pri_port> - Port ID. E.g., 1/3, Trk2,... <STRING:sec_port> - Port ID. E.g., 1/3, Trk2,... | |
| Error messages | Turbo ring v2 only supports maximum 2 ring domains Interface 2-1 not exist Ring1: One port couldn't be set as 1st and 2nd redundant port simultaneously !!! Ring2: One port couldn't be set as Ring1 redundant port simultaneously !!! Coupling: One port couldn't be set as 1st and 2nd redundant port simultaneously !!! Primary port couldn't be set as Ring2 redundant port simultaneously !!! Backup port couldn't be set as Ring2 redundant port simultaneously !!! Coupling port couldn't be set as Ring2 redundant port simultaneously !!! Please select at least one Ring!!! Ring1, ring2, coupling couldn't be enabled simultaneously!!! Please enable one Ring in "Ring Coupling" mode!!! | |
| Related commands | show turbo-ring-v2 | |

turbo-ring-v2 coupling backup

Use the **turbo-ring-v2 coupling** redundancy configuration command on the switch to configure the backup port of Ring coupling for Turbo Ring v2. Use the **no** form of this command to disable the coupling.

Commands

turbo-ring-v2 coupling backup interface *backup-port*

no turbo-ring-v2 coupling

| | | |
|-------------------------|---|--------------------------------------|
| Syntax | turbo-ring-v2 | Configure turbo ring v2 |
| | coupling | Configure ring coupling |
| | backup | Configure ring coupling mode |
| | interface | Turbo ring v2 coupling ports setting |
| | <i>backup-port</i> | Port ID. E.g., 1/3, 2/1,... |
| Defaults | N/A | |
| Command Modes | Redundancy configuration | |
| Usage Guidelines | At least enable one turbo-ring domain or coupling. But cannot enable two turbo-ring domains and coupling in the same time. | |
| Examples | PT-7828 (config-rdnt) # turbo-ring-v2 coupling backup interface 2/1 <STRING:pri_port> - Port ID. E.g., 1/3, Trk2,... | |
| Error messages | Turbo ring v2 only supports maximum 2 ring domains Ring1: One port couldn't be set as 1st and 2nd redundant port simultaneously !!! Ring2: One port couldn't be set as Ring1 redundant port simultaneously !!! Coupling: One port couldn't be set as 1st and 2nd redundant port simultaneously !!! Primary port couldn't be set as Ring2 redundant port simultaneously !!! Backup port couldn't be set as Ring2 redundant port simultaneously !!! Coupling port couldn't be set as Ring2 redundant port simultaneously !!! Please select at least one Ring!!! Ring1, ring2, coupling couldn't be enabled simultaneously!!! Please enable one Ring in "Ring Coupling" mode!!! | |
| Related commands | show turbo-ring-v2 | |

turbo-ring-v2 coupling dual-homing

Use the **turbo-ring-v2 coupling dual-homing** redundancy configuration command on the switch to enable dual homing feature of Ring coupling for the Turbo Ring v2. Use the **no** form of this command to disable it.

Commands

turbo-ring-v2 coupling dual-homing primary interface *primary-port* backup interface *secondary-port*

no turbo-ring-v2 coupling

| | | |
|-------------------------|-----------------------|---|
| Syntax | turbo-ring-v2 | Configure turbo ring v2 |
| Description | coupling | Configure ring coupling |
| | dual-homing | Configure dual homing mode |
| | primary | Turbo ring v2 ring ports setting |
| | interface | Turbo ring v2 ring ports setting |
| | primary-port | Port ID. E.g., 1/3, 2/1,... |
| | backup | Turbo ring v2 ring ports setting |
| | interface | Turbo ring v2 ring ports setting |
| | secondary-port | Port ID. E.g., 1/3, 2/1,... |
| Defaults | N/A | |
| Command Modes | | Redundancy configuration |
| Usage Guidelines | | At least enable one turbo-ring domain or coupling. But cannot enable two turbo-ring domains and coupling in the same time. |
| Examples | | PT-7828 (config-rdnt) # turbo-ring-v2 coupling dual-homing primary interface 2/1 secondary interface 2/2 <STRING:pri_port> - Port ID. E.g., 1/3, Trk2,... <STRING:sec_port> - Port ID. E.g., 1/3, Trk2,... |
| Error messages | | Turbo ring v2 only supports maximum 2 ring domains Ring1: One port couldn't be set as 1st and 2nd redundant port simultaneously !!! Ring2: One port couldn't be set as Ring1 redundant port simultaneously !!! Coupling: One port couldn't be set as 1st and 2nd redundant port simultaneously !!! Primary port couldn't be set as Ring2 redundant port simultaneously !!! Backup port couldn't be set as Ring2 redundant port simultaneously !!! Coupling port couldn't be set as Ring2 redundant port simultaneously !!! Please select at least one Ring!!! Ring1, ring2, coupling couldn't be enabled simultaneously!!! Please enable one Ring in "Ring Coupling" mode!!! |
| Related commands | | show turbo-ring-v2 |

turbo-ring-v2 coupling primary

Use the **turbo-ring-v2 coupling primary** redundancy configuration command on the switch to configure the primary port of Ring coupling for Turbo Ring v2. Use the **no** form of this command to return to the default setting.

Commands

turbo-ring-v2 coupling primary interface *primary-port*

no turbo-ring-v2 coupling

| | | |
|---------------------------|---|--------------------------------------|
| Syntax Description | turbo-ring-v2 | Configure turbo ring v2 |
| | coupling | Configure ring coupling |
| | primary | Configure ring coupling mode |
| | interface | Turbo ring v2 coupling ports setting |
| | <i>primary-port</i> | Port ID. E.g., 1/3, 2/1,... |
| Defaults | N/A | |
| Command Modes | Redundancy configuration | |
| Usage Guidelines | At least enable one turbo-ring domain or coupling. But cannot enable two turbo-ring domains and coupling in the same time. | |
| Examples | PT-7828 (config-rdnt) # turbo-ring-v2 coupling primary interface 2/1 <STRING:pri_port> - Port ID. E.g., 1/3, Trk2,... | |
| Error messages | Turbo ring v2 only supports maximum 2 ring domains Ring1: One port couldn't be set as 1st and 2nd redundant port simultaneously !!! Ring2: One port couldn't be set as Ring1 redundant port simultaneously !!! Coupling: One port couldn't be set as 1st and 2nd redundant port simultaneously !!! Primary port couldn't be set as Ring2 redundant port simultaneously !!! Backup port couldn't be set as Ring2 redundant port simultaneously !!! Coupling port couldn't be set as Ring2 redundant port simultaneously !!! Please select at least one Ring!!! Ring1, ring2, coupling couldn't be enabled simultaneously!!! Please enable one Ring in "Ring Coupling" mode!!! | |
| Related commands | show turbo-ring-v2 | |

turbo-ring-v2 master

Use the **turbo-ring-v2 master** redundancy configuration command on the switch to configure the switch as the Ring Master of specified ring for Turbo Ring v2. Use the **no** form of this command to configure the switch as the normal member of specified ring for Turbo Ring v2.

Commands

turbo-ring-v2 *ring-id* **master**

no turbo-ring-v2 *ring-id* master

trusted-access

Same as **access-ip**.

Commands

trusted-access [*ip-address netmask*]

no trusted-access [*ip-address netmask*]

| | | |
|---------------------------|--|---------------------------------------|
| Syntax Description | trusted-access | Enable the trusted IP list for access |
| | <i>ip-address</i> | IP address |
| | <i>netmask</i> | IP netmask |
| Defaults | The feature is disabled by default. | |
| Command Modes | VLAN configuration as management VLAN | |
| Usage Guidelines | This feature will take effect when the " trusted-access " command is executed. | |
| Examples | PT-7828 (config) # interface mgmt PT-7828 (config-vlan) # trusted-access 10.10.10.10 255.255.255.0 <IPV4ADDR:ipaddr> - IP address <IPV4ADDR:netmask> - IP netmask PT-7828 (config-vlan) # trusted-access | |
| Error messages | Trusted access ip list full IP: IP-format mask: mask-format does not exist in trusted access IP list | |
| Related commands | show interface mgmt trusted-access | |

username

Use the **username** global configuration command on the switch to set the username and password of the local login user. Use the **no** form of this command will clear the password setting of the specified user.

Commands

username { admin | user } password *password*

no username { admin | user } password

| | | |
|---------------------------|---|--|
| Syntax Description | username | Configuration for login account authentication |
| | <i>username</i> | User name |
| | privilege | Privilege for account |
| | <i>privilege-level</i> | 3 values, "admin" and "user" for account leve, "no login" indicates account as non-login user |
| | password | Specify the password |
| | <i>password</i> | Password string (Length of password should be from 4 to 16, and empty password is no longer allowed) |
| Defaults | There is no password for each user | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828 (config) # username admin password 1234 <LF> PT-7828 (config) # username user password 5678 <LF> | |
| Error messages | N/A | |
| Related commands | show users | |

version

Use the **version** command in router configuration mode as RIP on the switch to change the version of the current running RIP.

Commands

version *version*

| | | |
|-------------------------|---|-----------------|
| Syntax | version | Set RIP version |
| Description | version | 1 2 1c |
| Defaults | Default is 1 (i.e. RIP version 1) | |
| Command Modes | Router configuration as RIP | |
| Usage Guidelines | N/A | |
| Examples | <pre>PT-7828# configure terminal PT-7828(config)# router rip PT-7828(config-rip)# version 2 PT-7828(config-rip)# PT-7828# show ip rip RIP Protocol : Enable RIP version : V2 Distribution Connected : Enable Static : Disable OSPF : Disable RIP Enable Table Interface Name IP VID Enable ----- ----- vlan2if 192.168.102.1 2 Enable</pre> | |
| Error messages | Invalid version | |
| Related commands | N/A | |

vlan create

Use the **vlan create** global configuration command on the switch to create a VLAN in the VLAN database. Use the **no** form of this command to delete a VLAN.

Commands

vlan create *vlan-id-list*

no vlan create *vlan-id-list*

| | | |
|-------------------------|---|---------------------------|
| Syntax | vlan | Configure VLAN parameters |
| Description | create | Configure VLAN parameters |
| | <i>vlan-id-list</i> | VLAN IDs of the VLANs |
| Defaults | N/A | |
| Command Modes | Global configuration | |
| Usage Guidelines | You can only use this command mode for configuring normal-range VLANs, that is, VLAN IDs 1 to 4094. | |
| Examples | <pre>PT-7828(config) # vlan create 1,3-5,7 <STRING:vlanids> - VLAN IDs of the VLANs</pre> | |
| Error messages | vlan 4097 is invalid!! should be range from 1 to 4094 vlan interfaces are full, total vlan interface is 64 !! | |
| Related commands | show vlan config | |

vlan mode

Use the **vlan mode** configuration command on the switch to change current VLAN mode operated on the switch. Use the **no** form of this command to return to the default.

Commands

vlan mode { 1qvlan | pvlan | unaware }

no vlan mode

| | | |
|---------------------------|--|---------------------------|
| Syntax Description | vlan | Configure VLAN parameters |
| | mode | Set (default) vlan mode |
| | 1qvlan | IEEE 802.1Q |
| | pvlan | Port-based vlan |
| | unaware | Unaware vlan |
| Defaults | The default mode is 802.1Q mode in the product with 802.1Q supported; otherwise is port-based VLAN mode. | |
| Command Modes | Global configuration | |
| Usage Guidelines | N/A | |
| Examples | PT-7828(config)# vlan mode 1qvlan 1qvlan - IEEE 802.1Q pvlan - Port-based vlan unaware - Unaware vlan | |
| Error messages | N/A | |
| Related commands | show vlan | |

vrrp

To configure the Virtual Router Redundancy Protocol (VRRP) on an interface, use the **vrrp** command in VRRP interface configuration mode. To disable the VRRP configuration, use the **no** form of this command

Commands

vrrp

vrrp vrid vrip ip-address

no vrrp

| | | |
|---------------------------|--|--------------------------------------|
| Syntax Description | vrrp | VRRP interface setting |
| | vrid | VRRP interface virtual router ID |
| | vrip | set virtual router ID and virtual IP |
| | ip-address | virtual IP(IPv4 address) |
| Defaults | VRRP is not configured | |
| Command Modes | VRRP interface configuration | |
| Usage Guidelines | Use vrrp command in VLAN configuration mode to enable vrrp in the VLAN interface. | |
| Examples | PT-7828(config-vlan)# vrrp 1 vrip 1.1.1.1 PT-7828(config-vlan)# no vrrp | |
| Error messages | Entry not Found! | |
| Related commands | vrrp preempt vrrp priority show ip vrrp | |

vrrp preempt

VRRP preempt is enabled by default. This means that a VRRP router with higher priority than the master VRRP router will take over as master router. To disable this feature, use the **no** form of this command.

Commands

vrrp preempt

no vrrp preempt

| | |
|---------------------------|--|
| Syntax Description | vrrp VRRP interface setting preempt VRRP preemption mode enable VRRP preemption mode disable |
| Defaults | VRRP preempt is enable |
| Command Modes | VRRP interface configuration |
| Usage Guidelines | Use vrrp command in VLAN configuration mode to enable vrrp in the VLAN interface. |
| Examples | PT-7828(config-vlan)# vrrp preempt PT-7828(config-vlan)# no vrrp preempt |
| Error messages | Entry not Found! |
| Related commands | vrrp vrrp priority |

vrrp priority

To set the priority of the virtual router, use the **vrrp priority** command in VRRP interface configuration mode. To remove the priority of the virtual router, use the **no** form of this command.

Commands

vrrp priority

no vrrp priority

| | |
|---------------------------|---|
| Syntax Description | vrrp VRRP interface setting priority VRRP priority (1 to 254) Set VRRP priority to default(100) |
| Defaults | priority 100 |
| Command Modes | VRRP interface configuration |
| Usage Guidelines | Use vrrp command in VLAN configuration mode to enable vrrp in the VLAN interface. |
| Examples | PT-7828(config-vlan)# vrrp priority 100 PT-7828(config-vlan)# no vrrp priority |
| Error messages | Entry not Found! Invalid parameters! |
| Related commands | vrrp vrrp preempt |

warning-notification port-event

Use **warning-notification port-event** interface configuration commands to enable the port warning events trigger to email, relay, syslog or trap. Use **no** form of this command to disable it.

Commands

warning-notification port-event {event { link-on | link-off | traffic-overload rx-threshold duration} | action action-index |severity severity-level | active}

no warning-notification port-event {event { link-on | link-off | traffic-overload} | active}

| Syntax Description | warning-notification | Warning notification |
|-------------------------|--|----------------------|
| port-event | Port event setting | |
| event | Select and configure event | |
| link-on | Link ON | |
| link-off | Link OFF | |
| traffic-overload | Traffic overloading | |
| <i>rx-threshold</i> | 0 ~ 100 | |
| <i>duration</i> | 1 ~ 300 | |
| action | Enable Action setting | |
| <i>action-index</i> | 0 ~ 31 | |
| severity | Severity setting | |
| <i>severity-level</i> | 0 ~ 7 | |
| active | Activate | |
| Defaults | N/A | |
| Command Modes | Interface configuration | |
| Usage Guidelines | action-index as follow, Trap only(1), Email only(2), Trap+Email(3), Syslog only(4), Trap+Syslog(5), Email+Syslog(6), Trap+Email+Syslog(7), Relay1 only(8), Trap+Relay1(9), Email+Relay1(10), Trap+Email+Relay1(11), Syslog+Relay1(12), Trap+Syslog+Relay1(13), Email+Syslog+Relay1(14), Trap+Email+Syslog+Relay1(15), Relay2 only(16), Trap+Relay2(17), Email+Relay2(18), Trap+Email+Relay2(19), Syslog+Relay2(20), Trap+Syslog+Relay2(21), Email+Syslog+Relay2(22), Trap+Email+Syslog+Relay2(23), Relay1+Relay2(24), Trap+Relay1+Relay2(25), Syslog+Relay1+Relay2(28), Email+Syslog+Relay1+Relay2(30), Trap+Email+Syslog+Relay1+Relay2(31), None(0) severity-level as follow, Emergency(0), Alert(1), Critical(2), Error(3), Warning(4), Notice(5), Information(6), Debug(7) | |
| Examples | EDS-G516E(config-if) #warning-notification port-event event traffic-overload 30 150 EDS-G516E(config-if) #no warning-notification port-event event link-on | |
| Error messages | Invalid action value or non-support this combination action Invalid severity type | |
| Related commands | show relay-warning config | |

warning-notification system-event

Use **warning-notification system-event** global configuration commands to enable the system warning events trigger to email, relay, syslog or trap. Use **no** form of this command to disable it.

Commands

```
warning-notification system-event { cold-start | warm-start | config-changed | pwr1-trans-on | pwr2-trans-on | pwr1-trans-off | pwr2-trans-off | auth-fail | password-changed | tacacs-auth-fail | radius-auth-fail | topology-changed | coupling-changed | master-changed | rstp-admin-changed | rstp-topology-changed | turbo-ring-break | di1-trans-on|di1-trans-off } {action action-index | severity severity-level | active}
```

```
no warning-notification system-event { cold-start | warm-start | config-changed | pwr1-trans-on | pwr2-trans-on | pwr1-trans-off | pwr2-trans-off | auth-fail | password-changed | tacacs-auth-fail | radius-auth-fail | topology-changed | coupling-changed | master-changed | rstp-admin-changed | rstp-topology-changed | turbo-ring-break | di1-trans-on|di1-trans-off } active}
```

| Syntax Description | warning-notification | Configure warning-notification |
|------------------------------|---|--------------------------------|
| system-event | System event | |
| cold-start | Power is cut off and then reconnected. | |
| warm-start | The Moxa switch is rebooted, such as when network parameters are changed (IP address, subnet mask, etc.). | |
| config-changed | Any configuration item has been changed. | |
| pwr1-trans-on | The Moxa switch power 1 is powered on. | |
| pwr2-trans-on | The Moxa switch power 2 is powered on. | |
| pwr1-trans-off | The Moxa switch power 1 is powered down. | |
| pwr2-trans-off | The Moxa switch power 2 is powered down. | |
| auth-fail | An incorrect password was entered. | |
| password-changed | User changes the account password | |
| tacacs-auth-fail | Incorrect authentication details were entered | |
| radius-auth-fail | Incorrect authentication details were entered | |
| topology-changed | If the Master of the Turbo Ring has changed or the backup path is activated | |
| coupling-changed | If the Turbo Ring path is disconnected | |
| master-changed | If the MSTP topology has changed | |
| rstp-admin-changed | If the RSTP root has changed | |
| rstp-topology-changed | If any Rapid Spanning Tree Protocol switches have changed their position(applies only to the root of the tree) | |
| turbo-ring-break | Turbo Ring path is disconnected | |
| di1-trans-on | Digital Input 1 is triggered by an off to on transition | |
| di1-trans-off | Digital Input 1 is triggered by an on to off transition | |
| action | Action | |
| action-index | Action option | |
| severity | Severity | |
| severity-level | Severity option | |
| active | active | |
| Defaults | N/A | |
| Command Modes | Global configuration | |
| Usage Guidelines | action-index as follow, Trap only(1), Email only(2), Trap+Email(3), Syslog only(4), Trap+Syslog(5), Email+Syslog(6), Trap+Email+Syslog(7), Relay1 only(8), Trap+Relay1(9), Email+Relay1(10), Trap+Email+Relay1(11), Syslog+Relay1(12), Trap+Syslog+Relay1(13), Email+Syslog+Relay1(14), Trap+Email+Syslog+Relay1(15), Relay2 only(16), Trap+Relay2(17), Email+Relay2(18), Trap+Email+Relay2(19), Syslog+Relay2(20), Trap+Syslog+Relay2(21), Email+Syslog+Relay2(22), Trap+Email+Syslog+Relay2(23), Relay1+Relay2(24), Trap+Relay1+Relay2(25), Syslog+Relay1+Realy2(28), Email+Syslog+Relay1+Relay2(30), Trap+Email+Syslog+Relay1+Relay2(31), None(0) severity-level as follow, | |

| | |
|-------------------------|---|
| | Emergency(0), Alert(1), Critical(2), Error(3), Warning(4), Notice(5), Information(6), Debug(7) |
| Examples | <pre>EDS-G516E(config) # warning-notification system-event cold-start action 5 EDS-G516E(config) # warning-notification system-event cold-start severity 3 EDS-G516E(config) # no warning-notification system-event cold-start active</pre> |
| Error messages | Invalid action value or non-support this combination action Invalid severity type |
| Related commands | show relay-warning config |