# ioPAC 6500 Series User Manual

Version 1.1, October 2025

www.moxa.com/products



#### ioPAC 6500 Series User Manual

The software described in this manual is furnished under a license agreement and may be used only in accordance with the terms of that agreement.

## **Copyright Notice**

© 2025 Moxa Inc. All rights reserved.

#### **Trademarks**

The MOXA logo is a registered trademark of Moxa Inc.
All other trademarks or registered marks in this manual belong to their respective manufacturers.

#### **Disclaimer**

- Information in this document is subject to change without notice and does not represent a commitment on the part of Moxa.
- Moxa provides this document as is, without warranty of any kind, either expressed or implied, including, but not limited to, its particular purpose. Moxa reserves the right to make improvements and/or changes to this manual, or to the products and/or the programs described in this manual, at any time.
- Information provided in this manual is intended to be accurate and reliable. However, Moxa assumes no
  responsibility for its use, or for any infringements on the rights of third parties that may result from its
  use.
- This product might include unintentional technical or typographical errors. Changes are periodically made to the information herein to correct such errors, and these changes are incorporated into new editions of the publication.

**Technical Support Contact Information** 

www.moxa.com/support

# **Table of Contents**

1.	About This Manual	_
	Revision History	5
	Relevant Models	5
	Package Contents	6
	Usage Scenarios	6
	Hardware and Software Requirements	7
	Safety Precautions	7
	Additional Resources	8
2.	Product Overview	9
	Technical Data	9
	Physical Dimensions	22
	LED Definition	31
	I/O Pin Definitions	43
3.	Hardware Installation	
	Mounting the Unit	46
	Horizontal Installation	
	Installing the System on the DIN Rail	
	Unmounting the System from a DIN Rail	
	Grounding the System	
	Wiring System and Field Power	
	System Power	
	Field Power	
	Wiring Ethernet Ports	
	Wiring Serial Port(s)	
	Wiring the Fiber Port(s)	
	100/1000BaseSFP (mini-GBIC) Fiber Port	
	Connecting Expansion Module	
	Wiring I/O Channels	
	Inserting the microSD™ Card	
	Powering on the Unit	
	Mode Switch	
	Reset Button: Reset Origin Device	
4.	Software Configuration	
4.	Connecting the Web Interface	
	Dashboard	
	System Configuration	
	,	
	Maintenance	
	Diagnostic	
	Certificate	
	Security	
_	Logging in by Console Port	
5.	IINxpress	
	Menu and Toolbar	
	Build New Project	
	ioPAC 6500 Project	
	Network Scan	
	Empty Project	
	ioPAC 6500 Configuration	
	Home	98
	System	110
	Diagnostic	113
	Log Manager	
	Account Manager	
	Firmware Update	118
	Service Settings	119
	System Status	133
	Library Manager	133
	POU	134

	GVL	
6.	Switch Module Configuration	138
	About this Chapter	138
	Meanings of the Symbols in the Web Interface Configurations	138
	Configuration Reminders	140
	Getting Started	141
	Log in by Web Interface	141
	Log In by RS-232 Console	143
	Log In by Telnet	145
	Web Interface Configuration	147
	Device Summary	148
	System	152
	Port	185
	Layer 2 Switching	193
	Network Redundancy	
	Management	
	Security	
	Diagnostics	
	Industrial Applications	
	Maintenance and Tool	
Α.	Activate and Transfer the IINxpress	
	Activate the IINxpress	
	Transfer the Activation Code Between IINxpress	
В.	Account Privileges List of 65M-5011M (Managed Switch Module)	
	Account Privileges List	
C.	Event Log Description of 65M-5011M (Managed Switch Module)	
	Event Log Description	
D.	SNMP MIB File of 65M-5011M (Managed Switch Module)	
	Standard MIB Installation Order	322
	MIB Tree	323
E.	Security Guidelines of 65M-5011M (Managed Switch Module)	
	Installation	
	Physical Installation	324
	Account Management	
	Vulnerable Network Ports	
	Operation	
	Maintenance	
	Decommission	
F.	SFP Module List of 65M-5011M (Managed Switch Module)	

# 1. About This Manual

In this chapter, we explain the scope of and how to use this document.

# **Revision History**

Version	Change	Date		
v1.0	First release	2024-		
V1.0	riist release			
v1.1	Add E200, 2000H, E001, Undating Convices, Coffware Configuration	2025-		
V1.1	Add 5290, 3800H, 5801. Updating Services, Software Configuration	08-01		

# **Relevant Models**

This document only applies to the models listed below.

Model Name	Description
65M-CPU14-IEC-CT-T	Control CPU Module with IEC61131 programming, 3-in-1 serial port x 2,
03M-CP014-1LC-C1-1	10/100/1000 Ethernet port x 2
65M-PW0075-CT-T	Power module, 24 VDC, 75 W
65M-5011M-CT-T	Layer 2 managed Ethernet switch module 100/1000 Fiber x 2 + 10/100/1000 RJ45 x 8
65M-5290-CT-T	Expansion module, RJ45 x 2, SFP x 2, Combo Port
65M-1900-CT-T	32 DI module, 24 VDC, with 8CH/10 KHz counter mode
65M-2901-CT-T	32 DO module, 24 VDC, with 8CH pulse-out mode
65M-3600-CT-T	16 AI modules 0-20 mA/4-20 mA
65M-3610-CT-T	16 AI modules 1 to 5 VDC/0 to 10 VDC/-10 to 10 V
65M-3800H-CT-T	8 AI module 4-20 mA with HART
65M-4820-CT-T	8 AO group isolation modules 4-20 mA/1 to 5 VDC
65M-5801-CT-T	8 serial module RS232/422/485-2w
65M-BMPW01-CT-T	Power module backplane 1 slot
65M-BMPW02-CT-T	Power module backplane 2 slots
65M-BMCM01-CT-T	Communication or networking module backplane 1 slot
65M-BMCM02-CT-T	Communication or networking module backplane 2 slots
65M-BMCPU01-CT-T	CPU module backplane 1 slot
65M-BMCPU02-CT-T	CPU module backplane 2 slots
65M-BMIO02-CT-T	I/O module backplane 2 slots
65M-BMIO04-CT-T	I/O module backplane 4 slots
65M-TB-1900-CT-T	Terminal block for 32 DI modules, 24 VDC, with 8CH/10 KHz counter mode
65M-TB-2901-CT-T	Terminal block for 32 DO modules, 24 VDC, with 8CH pulse-out mode
65M-TB-3600-CT-T	Terminal block for 16 AI modules 4-20 mA
65M-TB-3610-CT-T	Terminal block for 16 AI modules 1 to 5 VDC/0 to 10 VDC
65M-TB-4820-CT-T	Terminal block for 8 AO group isolation modules 4-20 mA/1 to 5 VDC
65M-TB-3800H-CT-T	Terminal block for 8 AI module 4-20 mA with HART
65M-TB-5801-CT-T	Terminal block for 8 serial modules

# **Package Contents**

The following items are included in the product package.

- The 65M module device
- Quick installation guide (Printed)
- Pinout card (65M-TB Series only)
- Warranty card


# **Usage Scenarios**


The ioPAC 6500 Series is designed with 6C core competencies.

- Control: the ability to perform precision control
- Communication: the ability to support protocols to connect to other devices or systems
- Computing: the ability to execute the program that is not related to precision control
- · Connectivity: the wired, wireless interface, which is supported by the ioPAC 6500 Series
- Cloud: the ability of cloud connectivity and cloud edge computing
- Cybersecurity: the ability to protect the users' device, information, and data

The major functions of the ioPAC 6500 Series are categorized into 5 groups.

- Southbound: the I/O and the protocols to collect the data from other devices
- Northbound: the protocols to deliver the data to other systems
- · Computing: the ability to process the data and event
- · Networking: the ability to enhance the network reliability
- Expandability: the ability to have more I/O points





# **Hardware and Software Requirements**

You will need the following hardware and software to use the ioThinx 6500 Series.

- A power source that provides 12 to 48 VDC, and power wires
- A PC running a Windows OS with Chrome installed and an Ethernet cable
- IINxpress software utility (Refer to the IINxpress chapter for more details.)

# **Safety Precautions**

Observe the following safety precautions when installing and using the ioPAC 6500 Series:



#### **DANGER**

Never work on the device while the power source is switched on. Disconnect all power sources to the device before performing installation, repair, or maintenance work.



### **DANGER**

Disconnect the power when you want to remove or replace components or disconnect equipment unless the area is free of ignitable substances.

- If you connect or disconnect the Removable Terminal Block when field power is applied, an electrical arc can occur. This could cause an explosion when installed in hazardous locations. Ensure that power is removed, or the area is nonhazardous before installation.
- If you connect or disconnect wiring while the power is on, an electrical arc can occur. This could cause an explosion in hazardous environments. Ensure that power is removed, or the area is nonhazardous before installation.
- Do not disconnect the unit unless the power has been disconnected, or the area is nonhazardous. In a hazardous area, the unit must be powered down before removing it.



### **WARNING**

This unit is sensitive to Electrostatic Discharge, which can cause internal damage and affect operations. Follow these guidelines when you handle this unit:

- Touch a grounded object to discharge potential static.
- Wear an approved grounding wristband.
- Do not touch connectors or pins on component boards.
- Do not touch circuit components inside the equipment.
- Use a static-safe workstation, if available.
- Store the device in static-safe packaging when not in use.



## **WARNING**

Check the voltage supplied by the power source. Make sure the voltage provided by the power source matches the voltage required by the device.



### **WARNING**

Check the voltage or current of the sensors or loads. Make sure the voltage and/or current shown on the sensors or loads correspond to the specifications of your 45M module before you connect the device.



#### **WARNING**

Connect your device to an earthed ground.



### **CAUTION**

Do not use the device if the device is already damaged. Replace defective or damaged devices to ensure that your devices function properly.



#### **CAUTION**

Do not repair the device yourself. If your device needs to be repaired, return the device to Moxa's customer service department. Attempting to repair the device yourself could invalidate the device's warranty.

# **Additional Resources**

Refer to the following documents for additional information.

- Datasheets for the following products:
  - ▶ ioPAC 6500 Series

In this chapter, we summarize each ioPAC 6500 Series device.

# **Technical Data**

# **Common Specifications**

**System Performance** 

Maximum Unit(s): 1 (Control unit)

Maximum Expansion Unit (s): 4 (Expansion units)

Maximum Power backplane in control unit: 1 (1-slot or 2-slot)

Maximum CPU backplane in control unit: 1 (1-slot or 2-slot)

**Maximum Communication backplane in control unit:** 1 (1-slot or 2-slot)

Maximum I/O backplane in control unit: 2 (2-slot or 4-slot)

**Physical Characteristics** 

Housing: Plastic

Mounting Options

DIN-rail Mounting: Default

Rack Mounting: Supported (with optional kit)

**Environmental** 

Operating Temperature: -40 to 75°C (-40 to 167°F, airflow is required in an environment over 65°C)

Storage Temperature: -40 to 85°C (-40 to 185°F, package included)

Relative Humidity: 5 to 95% (non-condensing)

IP Protection: IP20

Operating Altitude: Up to 2000 meters

**Standard and Certifications** 

EMC:

EN 55032/35 EN 61000-6-2/6-4

EMI: CISPR 32

FCC Part 15B Class A

EMS:

IEC 61000-4-2 ESD: Contact: 4 kV; Air: 8 kV IEC 61000-4-3 RS: 80 MHz to 1 GHz: 10 V/m IEC 61000-4-4 EFT: DC Power: 1 kV; Signal: 1 kV

IEC 61000-4-5 Surge: DC Power: 0.5 kV L-N, 1 kV L/N-PE; Signal: 1 kV; IO: 0.5 kV

IEC 61000-4-6 CS: DC Power: 10 Vrms; Signal: 10 Vrms

IEC 61000-4-8 PFMF: 30 A/m **Safety:** UL 61010-1, UL 61010-2-201

Shock: IEC 60068-2-27 Half Sine Wave:

Acceleration: 15 g
Duration Time: 11 ms
Vibration: IEC 60068-2-6

DIN-rail Mounted: 7 mm peak-peak (p-p) (2 to 8.42 Hz), 1 g (8.42 to 150 Hz)

Rack Mounted (with optional kit): 7 mm peak-peak (p-p) (2 to 8.42 Hz), 0.5 g (8.42 to 150 Hz)

Package vibration / drop test: STA-1A

Warranty

Warranty period: 5 years

Details: See www.moxa.com/tw/warranty

### 65M-CPU14-IEC-CT-T

Controller

CPU: ARM Cortex-A53 Quad-core 1.6 GHz

DDR SDRAM: 4 GB

Storage (eMMC): 8 GB (4 GB reserved for users)

NVRAM: 512 kB MRAM for data logger

OS: Moxa Industrial Linux

**Automation Language:** IEC 61131-3 **Physical I/O Capacity:** 512 points

**Interface** 

Ethernet Ports: Auto-sensing 10/100/1000 Mbps ports (RJ45 connector) x 2

Serial Ports: RS-232/422/485 ports x 2, software selectable (DB9)

Console Ports: RS-232 (TxD, RxD, GND), 4-pin header output (115200, n, 8, 1)

**Mode Switch:** Remote, Run, Stop **microSD slot:** 1 (function reserved)

Reset button: 1
Ethernet

**LAN:** 2 x 10/100/1000 Mbps, 2 MACs (IPs), RJ45

Magnetic Isolation Protection: 1.5 kV magnetic isolation

Serial

No. of Ports: 2, DB9

Serial standard: RS-232, RS-422, RS-485-2w

Baudrate: 300, 1200, 1800, 2400, 4800, 9600, 19200, 28800, 38400, 57600, 115200 bps

Data Bits: 8 Stop Bits: 1, 2

Parity: None, Even, Odd

Flow Control: RTS/CTS, XON/XOFF

**Serial Signals** 

RS-232: TxD, RxD, RTS, CTS, DTR, DSR, DCD, GND

**RS-422:** Tx+, Tx-, Rx+, Rx-, GND **RS-485-2w:** Data+, Data-, GND **RS-485-4w:** Tx+, Tx-, Rx+, Rx-, GND

**Power Parameters** 

**Input Current:** 0.8 A @ 12 VDC **Physical Characteristics** 

**Dimensions:** 42 x 177 x 134.8 mm (1.65 x 6.97 x 5.31 in)

Weight: 625 g (1.38 lb)

**MTBF** 

Time: 1,830,589 hrs Standard: Telcordia SR332

#### 65M-PW0075-CT-T

**System Power** 

Input Voltage: 24 VDC; 21.6 to 26.4 VDC

Input Current: 4 A (max.)
Inrush Current: 20 A (max.)
Input Internal Fuse Rating: 10 A

Output Voltage: 12 VDC
Output Current: 6.25 A (max.)
Output Power: 75 W (max.)
Output Hold Up Time: 10 ms (min.)

Output Startup Delay Time: 100 ms (max.)
Output Over Voltage Protection: 15.6 V (max.)
Output Over Current Protection: 9 A (min.)

Efficiency: 87%

**Isolation:** 3k VDC (input to output), 3k VDC (system-to-field power)

**Field Power** 

Input Voltage: 24 VDC; 21.6 to 26.4 VDC

Input Current: 3 A (max.)
Input Internal Fuse Rating: 8 A

Output Voltage: Input voltage minus 0.4 VDC (max. matching-diode drop at 3 A)

Output Current: 3 A (max.)

**Output Over Voltage Protection:** 29 V (max.) **Output Over Current Protection:** 5 A (min.)

**Physical Characteristics** 

**Dimensions:** 42 x 177 x 149.4 mm (1.65 x 6.97 x 5.88 in)

**Weight:** 713 g (1.57 lb)

**MTBF** 

Time: 2,847,774 hrs

Standard: Telcordia SR332

#### 65M-5011M-CT-T

#### **Ethernet Interface**

#### 10/100/1000BaseT(X) Ports (RJ45 connector): 8

Auto MDI/MDI-X connection Auto-negotiation speed Full/Half-duplex mode 100/1000BaseSFP Ports: 2

#### Standards:

IEEE 802.3 for 10BaseT, IEEE 802.3u for 100BaseT(X), IEEE 802.3ab for 1000BaseT(X),

IEEE 802.3z for 1000BaseX, IEEE 802.3x for flow control, IEEE 802.3ad for port trunk with LACP,

IEEE 802.1Q for VLAN Tagging, IEEE 802.1D-2004 for Spanning Tree Protocol,

IEEE 802.1w for Rapid Spanning Tree Protocol, IEEE 802.1p for Class of Service,

IEEE 802.1X for authentication

#### **Ethernet Software Features**

Filter: GMRP, GVRP, GARP, 802.1Q VLAN, IGMP Snooping v1/v2/v3, IGMP Querier

**Management:** IPv4/IPv6, Flow control, Back Pressure Flow Control, DHCP Server/Client, ARP, RARP, LLDP, Port Mirror, Linkup Delay, SMTP, SNMP Trap, SNMP Inform, SNMPv1/v2c/v3, RMON, TFTP, SFTP, HTTP, HTTPS, Telnet, Syslog, Private MIB, fiber check

MIB: P-BRIDGE MIB, Q-BRIDGE MIB, IEEE8021-SPANNING-TREE-MIB, IEEE8021-PAE-MIB, IEEE8023-LAG-

MIB, LLDP-EXT-DOT1-MIB, LLDP-EXT-DOT3-MIB, SNMPv2-MIB, RMON MIB Groups 1, 2, 3, 9

**Redundancy Protocols:** STP, RSTP, Turbo Ring v2, Turbo Chain, Ring Coupling, Dual-Homing, Link Aggregation

Security: Broadcast storm protection, Rate Limit, Trust access control, Static Port Lock, MAC Sticky,

HTTPS/SSL, SSH, RADIUS, TACACS+, Login and Password Policy

Time Management: SNTP, NTP Server/Client, NTP Authentication

Protocols: IPv4/IPv6, TCP/IP, UDP, ICMP, ARP, RARP, TFTP, DNS, NTP Client, DHCP Server, DHCP Client,

802.1X, QoS, HTTPS, HTTP, Telnet, SMTP, SNMPv1/v2c/v3, RMON, Syslog

### **Switch Properties**

MAC Table Size: 16 K

Jumbo Frame Size: 9.216 KB Max. No. of VLANs: 256 VLAN ID Range: VID 1 to 4094

IGMP Groups: 512
Priority Queues: 4

Packet Buffer Size: 1 MB

**Serial Interface** 

Console Port: RS-232 (TxD, RxD, GND), 8-pin RJ45 (115200, n, 8, 1)

Input/Output Interface
Buttons: RESET Button

**USB Connector:** USB Type A (only supports the ABC-02-USB from Moxa)

**Power Parameters** 

**Input Current:** 0.9 A @ 12 VDC **Physical characteristics** 

**Dimensions:** 42 x 177 x 131.5 mm (1.65 x 6.97 x 5.18 in)

Weight: 660 g (1.46 lb)

## **Environmental**

#### **Operating Temperature:**

-40 to 75°C (-40 to 167°F)

-40 to 65°C (-40 to 149°F) with SFP module installed

NOTE: Proper airflow is required in an environment over 65°C.

MTBF

Time: 3,104,403 hrs Standard: Telcordia SR332

#### 65M-5290-CT-T

**Ethernet Interface** 

Port Interfaces: RJ45 Ports x 2, SFP Fiber Ports x 2

**Protocol:** Proprietary **Power Consumption** 

**System Power:** 0.38 A @ 12 VDC **Physical characteristics** 

**Dimensions:** 42 x 116 x 130 mm (1.65 x 4.57 x 5.12 in)

Weight: 501 g (1.1 lb)

**MTBF** 

Time: 2,800,019 hrs Standard: Telcordia SR332

#### 65M-1900-CT-T

**Digital Input** 

**Number of Channels: 32** 

Input Type: Current Sink (internal or external sensor supply for dry contact)

Input Pulse Width: 50 µs (min.)

Internal Field Circuit Supply (only for dry contact):

Voltage: 24 VDC; 22.8 to 25.2 VDC

Current: 125 mA (max.) (Only for dry contact)

Input ON Voltage: 11 to 30 VDC Input OFF Voltage: 0 to 5 VDC

Input Current: 2.35 mA ±20 % per channel (at Input ON Voltage)

**Input Filtering:** Software configurable **Isolation:** 3k VDC (signal to system)

Counter

Number of Channels: 8 (Channel 1 to 8, group configurable by software)

Counting Frequency: Square wave 0 to 10 kHz

Frequency Measurement: No

Counter Size: 32 bits

**Diagnostic** 

**Input Wire-Break Detection:** 

Input Current < 50 μA

Detection Delay Time: 20 ms (typ.)

Internal Field Circuit Supply Detection: 17.5 VDC (typ.); 16 to 19 VDC

**Power Consumption** 

System Power: 0.068 A @ 12 VDC

Field Power:

0.019 A @ 24 VDC (without field circuit supply)

0.115 A @ 24 VDC (32 channels dry contact with internal field circuit supply)

**Physical characteristics** 

**Dimensions:** 42 x 116 x 130 mm (1.65 x 4.57 x 5.12 in)

Weight: 253 g (0.56 lb)

**MTBF** 

Time: 2,057,118 hrs Standard: Telcordia SR332

### 65M-2901-CT-T

**Digital Output** 

Number of Channels: 32 Output Type: Current source

Common Power Input Voltage: 24 VDC; 19.2 to 28.8 VDC

Common Power Input Current: 6.4 A (max.)

**Load Current:** 

200 mA / 1 channel (typ.) 500 mA / 1 channel (max.)

Leakage Current: 0.11 mA (max. at OFF State)

Load Resistance Range: 48 to 8k  $\Omega$ 

**Protection:** 

Output short-circuit protection

Common power input over voltage protection Inductive load shutdown voltage protection **Isolation:** 3k VDC (signal to system)

**Pulse** 

**Number of Channels:** 8 (Channel 1 to 8, group configurable by software)

**Pulse Duration:** 500 μs (min.)

**Diagnostic** 

**Output Wire-Break Detection:** 

Output Current < 3 mA (ON state);

Output Load Impedance > 58 K $\Omega$  (OFF state)

Output Short-Circuit Detection: Output current > 0.87 A (typ.); 0.64 to 1.2 A

External Power Detection: 17.5 VDC (typ.); 16 to 19 VDC

Fail-Safe Configuration: Hold last / Fail-safe state

**Power Consumption** 

System Power: 0.068 A @ 12 VDC Field Power: 0.01 A @ 24 VDC

**Physical characteristics** 

**Dimensions:** 42 x 116 x 130 mm (1.65 x 4.57 x 5.12 in)

Weight: 254 g (0.56 lb)

**MTBF** 

Time: 2,007,795 hrs Standard: Telcordia SR332

### 65M-3600-CT-T

#### **Analog Input**

Number of Channels: 16 (8 channels per group)

Input Mode: 0 to 20 mA 4 to 20 mA

Permitted Overload on Inputs: ±30 mA

IO type: Differential

Internal Loop Power Supply (only for 2-wire connection):

Voltage: 24 VDC; 22.8 to 25.2 VDC Current: 200 mA/Group (max.)

**Resolution:** 16 bits **Measurement Resolution:** 

2 μA (0 to 20 mA) 1.6 μA (4 to 20 mA) **Conversion Time:** 100 ms

**Normal Mode Rejection Ratio:** > 60 dB @ 60 Hz ; conversion time: 100 ms **Common Mode Rejection Ratio:** > 90 dB @ 60 Hz ; conversion time: 100 ms

Accuracy:

 $\pm$  0.1% Full-scale range @ 25°C  $\pm$  0.3% Full-scale range @ -40 to 75°C

Input Resistance: 250  $\Omega$ 

**Isolation:** 

3k VDC (signal to system)

1k VDC for 1 min. (group to group)

Diagnostic

Internal Loop Power Detection: 17.5 VDC (typ.); 16 to 19 VDC

Input Wire-Break Detection: Yes, (4 to 20 mA mode only, detection delay time: 0.8 s (max.))

**Input Short-Circuit Detection:** Yes

Input Underflow / Overflow Detection: Yes

**Power Consumption** 

System Power: 0.073 A @ 12 VDC

Field Power:

0.053 A @ 24 VDC (without internal loop power)

0.466 A @ 24 VDC (16 channels 20 mA current input with internal loop power)

**Physical characteristics** 

**Dimensions:** 42 x 116 x 130 mm (1.65 x 4.57 x 5.12 in)

Weight: 267 g (0.59 lb)

**MTBF** 

Time: 1,686,798 hrs Standard: Telcordia SR332

### 65M-3610-CT-T

**Analog Input** 

Number of Channels: 16 (8 channels per group)

Input Mode: 0 to 10 V 1 to 5 V

Permitted Overload: ±12 V

**IO type:** Differential **Resolution:** 16 bits

**Measurement Resolution:** 

1 mV (0 to 10 V) 0.4 mV (1 to 5 V)

Conversion Time: 100 ms

Normal Mode Rejection Ratio: > 60 dB @ 60 Hz; conversion time: 100 ms Common Mode Rejection Ratio: > 90 dB @ 60 Hz; conversion time: 100 ms

Accuracy:

± 0.1% Full-scale range @ 25°C ± 0.3% Full-scale range @ -40 to 75°C

Input Resistance: > 1 M $\Omega$ 

**Isolation:** 

3k VDC (signal to system)

1k VDC for 1 min. (group to group)

**Diagnostic** 

Input Wire-Break Detection: Yes (detection delay time: 1.6 s (max.))

Input Underflow / Overflow Detection: Yes

**Power Consumption** 

**System Power:** 0.069 A @ 12 VDC **Field Power:** 0.038 A @ 24 VDC

**Physical characteristics** 

**Dimensions:** 42 x 116 x 130 mm (1.65 x 4.57 x 5.12 in)

Weight: 250 g (0.55 lb)

**MTBF** 

Time: 1,885,953 hrs Standard: Telcordia SR332

### 65M-3800H-CT-T

HART Analog Input Number of Channels: 8 Channel Enable/Disable: Yes Input Mode: 4 to 20 mA

Permitted Overload on Inputs: 30 mA

IO type: Differential

Internal Loop Power Supply (only for 2-wire connection):

Voltage: 24 VDC; 22.8 to 25.2 VDC

Current: 500 mA (max.) **Resolution:** 16 bits

Measurement Resolution: 1.6 µA (4 to 20 mA)

Conversion Time: 100 ms

Accuracy:

± 0.1% Full-scale range @ 25°C ± 0.3% Full-scale range @ -40 to 75°C

Input Resistance: 250  $\Omega$ 

**Isolation:** 

3k VDC (signal to system)

1k VDC for 1 min. (group to group)

**HART** 

**Number of HART Modem:** 1

Data Update Time: 1 sec/field device Operation Type: Primary client Topology: Point-to-point HART Enable/Disable: Yes

**Diagnostic** 

Internal Power Detection: 17.5 VDC (typ.); 16 to 19 V DC

Internal Wire-Break Detection: Yes Input Wire-Break Detection: Yes Input Short-Circuit Detection: Yes

**Power Consumption** 

System Power: 0.072 A @ 12 VDC

Field Power:

0.05 A (max.), 24 VDC (without using internal loop power)

0.25 A (max.), 24 VDC (8 channels 4 to 20 mA input using internal loop power all in 20 mA)

0.66 A (max.), 24 VDC (internal loop power supply at 500 mA)

**Physical characteristics** 

**Dimensions:** 42 x 116 x 130 mm (1.65 x 4.57 x 5.12 in)

Weight: 262 g (0.58 lb)

**MTBF** 

Time: 1,016,573 hrs Standard: Telcordia SR332

### 65M-4820-CT-T

#### **Analog Output**

Number of Channels: 8 (4 channels per group)

### **Output Mode:**

0 to 10 V 1 to 5 V 0 to 20 mA 4 to 20 mA

**IO type:** Differential **Resolution:** 16 bit **Output Resolution:** 0.1 mV (0 to 10 V) 0.4 mV (1 to 5 V) 2 μA (0 to 20 mA) 1.6 μA (4 to 20 mA)

Output Refresh Time: 16 ms

Output Step Response Time: 1 ms (max.)

#### Accuracy:

 $\pm$  0.1% Full-scale range @ 25°C  $\pm$  0.3% Full-scale range @ -40 to 75°C

### **Output Load Impedance:**

 $\geq$  1 K $\Omega$  ( 0 to 10 V/1 to 5 V)  $\leq$  750  $\Omega$  (0 to 20 mA/4 to 20 mA)

#### **Isolation:**

3k VDC (signal to system)
1k VDC for 1 min. (group to group)

#### **Diagnostic**

Output Wire-Break Detection: Yes, for Current Mode Output Short-Circuit Detection: Yes, for Voltage Mode Fail-Safe Configuration: Hold last/Fail-safe state

#### **Power Consumption**

System Power: 0.069 A @ 12 VDC

#### Field Power:

0.022 A @ 24 VDC (without external load)

0.266 A @ 24 VDC (4 channels with 20 mA current output)

#### **Physical characteristics**

**Dimensions:** 42 x 116 x 130 mm (1.65 x 4.57 x 5.12 in)

Weight: 257 g (0.57 lb)

### **MTBF**

Time: 1,874,152 hrs Standard: Telcordia SR332

### 65M-5801-CT-T

Serial

**No. of Ports:** 8 (4 Channels/Group), Terminal Block **Serial Standards:** RS-232, RS-422, RS-485-2w

Baud Rate: 300, 1200, 1800, 2400, 4800, 9600, 19200, 28800, 38400, 57600, 115200 bps

Data Bits: 7, 8 Stop Bits: 1, 2

Parity: None, Even, Odd

Flow Control: RTS/CTS, XON/XOFF

Isolation: 3k VDC (signal to system), 1k VDC (between groups)

**Power Consumption** 

System Power: 0.143 A @ 12 VDC Field Power: 0.11 A @ 24 VDC Physical characteristics

**Dimensions:** 42 x 116 x 130 mm (1.65 x 4.57 x 5.12 in)

Weight: 259 g (0.57 lb)

**MTBF** 

Time: 2,310,512 hrs Standard: Telcordia SR332

#### 65M-BMPW01-CT-T

## **Physical characteristics**

**Slots:** 1 (for Power module)

**Dimensions:** 43 x 177 x 45.5 mm (1.69 x 6.97 x 1.79 in)

Weight: 162 g (0.36 lb)

**MTBF** 

**Time:** 1,130,092,735 hrs **Standard:** Telcordia SR332

### 65M-BMPW02-CT-T

#### **Physical characteristics**

**Slots:** 2 (for power module)

**Dimensions:** 86 x 177 x 45.5 mm (3.39 x 6.97 x 1.79 in)

Weight: 320 g (0.71 lb)

**MTBF** 

**Time:** 1,382,748,219 hrs **Standard:** Telcordia SR332

#### 65M-BMCM01-CT-T

#### **Physical characteristics**

Slots: 1 (for switch module)

**Dimensions:** 43 x 177 x 45.5 mm (1.69 x 6.97 x 1.79 in)

**Weight:** 169 g (0.37 lb)

**MTBF** 

**Time:** 1,856,744,727 hrs **Standard:** Telcordia SR332

#### 65M-BMCM02-CT-T

### **Physical characteristics**

Slots: 2 (for switch module)

**Dimensions:** 86 x 177 x 45.5 mm (3.39 x 6.97 x 1.79 in)

Weight: 330 g (0.73 lb)

**MTBF** 

**Time:** 1,856,744,727 hrs **Standard:** Telcordia SR332

#### 65M-BMEXP01-CT-T

### **Physical characteristics**

**Slots:** 1 (for Expansion module)

**Dimensions:** 43 x 177 x 45.5 mm (1.69 x 6.97 x 1.79 in)

**Weight:** 173 g (0.38 lb)

**MTBF** 

**Time:** 1,856,744,727 hrs **Standard:** Telcordia SR332

### 65M-BMEXP02-CT-T

#### **Physical characteristics**

Slots: 2 (for Expansion module)

**Dimensions:** 86 x 177 x 45.5 mm (3.39 x 6.97 x 1.79 in)

**Weight:** 322 g (0.71 lb)

**MTBF** 

**Time:** 1,856,744,727 hrs **Standard:** Telcordia SR332

### 65M-BMCPU01-CT-T

#### **Physical characteristics**

Slots: 1 (for CPU module)

**Dimensions:** 43 x 177 x 45.5 mm (1.69 x 6.97 x 1.79 in)

**Weight:** 170 g (0.37 lb)

**MTBF** 

**Time:** 5,032,783,357 hrs **Standard:** Telcordia SR332

#### 65M-BMCPU02-CT-T

## **Physical characteristics**

**Slots:** 2 (for CPU module)

**Dimensions:** 86 x 177 x 45.5 mm (3.39 x 6.97 x 1.79 in)

Weight: 325 g (0.72 lb)

**MTBF** 

**Time:** 3,554,206,267 hrs **Standard:** Telcordia SR332

### 65M-BMIO02-CT-T

**Power Consumption** 

System Power: 0.093 A @ 12 VDC

**Physical characteristics** 

Slots: 2 (for IO module)

**Dimensions:** 86 x 177 x 45.5 mm (3.39 x 6.97 x 1.79 in)

Weight: 205 g (0.45 lb)

**MTBF** 

Time: 6,140,939 hrs Standard: Telcordia SR332

#### 65M-BMIO04-CT-T

**Power Consumption** 

System Power: 0.117 A @ 12 VDC

**Physical characteristics** 

Slots: 4 (for IO module)

**Dimensions:** 172 x 177 x 45.5 mm (6.77 x 6.97 x 1.79 in)

Weight: 395 g (0.87 lb)

**MTBF** 

**Time:** 6,124,471 hrs **Standard:** Telcordia SR332

#### 65M-TB-1900-CT-T

#### **Physical characteristics**

**ID:** D1

**Dimensions:** 42.3 x 102.38 x 80.8 mm (1.67 x 4.03 x 3.18 in)

Weight: 164 g (0.36 lb)

### 65M-TB-2901-CT-T

### **Physical characteristics**

**ID:** D2

**Dimensions:** 42.3 x 102.38 x 80.8 mm (1.67 x 4.03 x 3.18 in)

Weight: 164 g (0.36 lb)

#### 65M-TB-3600-CT-T

#### **Physical characteristics**

**ID:** A1

**Dimensions:** 42.3 x 102.38 x 80.8 mm (1.67 x 4.03 x 3.18 in)

Weight: 164 g (0.36 lb)

## 65M-TB-3610-CT-T

#### **Physical characteristics**

**ID:** A2

**Dimensions:** 42.3 x 102.38 x 80.8 mm (1.67 x 4.03 x 3.18 in)

Weight: 164 g (0.36 lb)

#### 65M-TB-3800H-CT-T

#### **Physical characteristics**

**ID:** A3

**Dimensions:** 42.3 x 102.38 x 80.8 mm (1.67 x 4.03 x 3.18 in)

Weight: 164 g (0.36 lb)

### 65M-TB-4820-CT-T

**Physical characteristics** 

**ID:** A5

**Dimensions:** 42.3 x 102.38 x 80.8 mm (1.67 x 4.03 x 3.18 in)

Weight: 164 g (0.36 lb)

## 65M-TB-5801-CT-T

**Physical characteristics** 


**ID:** F1

**Dimensions:** 42.3 x 102.38 x 80.8 mm (1.67 x 4.03 x 3.18 in)


**Weight:** 164 g (0.36 lb)

# **Physical Dimensions**


## 65M-CPU14-IEC-CT-T



## 65M-PW0075-CT-T




# 65M-5011M-CT-T




## 65M-5290-CT-T

Unit: mm (inch)













# 65M-1XXX/2XXX/3XXX/4XXX/5801-CT-T (IO Module)


Unit: mm (inch)

OFF?











EQ\_I:




# **65M-BMPW01-CT-T**




# **65M-BMPW02-CT-T**




# 65M-BMCM01-CT-T




# 65M-BMCM02-CT-T




# 65M-BMEXP01-CT-T




# 65M-BMEXP02-CT-T




# **65M-BMCPU01-CT-T**




# 65M-BMCPU02-CT-T




## **65M-BMIO02-CT-T**



# **65M-BMIO04-CT-T**



# 65M-TB-1XXX/2XXX/3XXX/4XXX/5801-CT-T



# **LED Definition**

# 65M-CPU14-IEC-CT-T

# **Front View**



# **LED Description**

Labeling	Indication	Qty	Color	Behavior	Description
				On	Normal
			C	Blinking at 5 Hz	Firmware upgrade in Progress
			Green	Blinking at 0.5 Hz	Booting up
				Double Blinking	Module locating
STATUS	System	1		On	System failure
SIAIUS	status	*		Blinking at 0.5 Hz	Service failure
			Red		Press reset button for 15 seconds, the
			Red	Double Blinking	STATUS will start to RED double blinking,
				Double billiking	release the reset button to start the reset to
					default.
ACT	Active	1	N/A	N/A	Reserved
	Program	1	Green	On	Program is running
PROG			Red On		Runtime failure
			Off		Program has stopped
SD	SD card	1	Green	Blinking at 0.5 Hz	SD card is reading
P1/P2	Serial	1 for	Green Blinking at 0.5 Hz		Tx
F1/F2	Serial	each	Amber	Blinking at 0.5 Hz	Rx
		1 for each	Green	On	Connected on 1000M
I A NI 1 /			Green	Blinking	Data is transmitting
LAN1/ LAN2	Ethernet		Amber	On	Connected on 10/100M
LAINZ				Blinking	Data is transmitting
			Off		Disconnected

# 65M-PW0075-CT-T

# **LED Indicators**




# **LED Description**

Labeling	Indication	Qty	Color	Behavior	Description
			Green	On	Normal
				Blinking at 5 Hz	Firmware upgrade in progress
	System status	1		Blinking at 0.5 Hz	Booting up
STATUS				Double Blinking	Module located
				On	System failure
				Blinking at 5 Hz	Lost the connection to CPU
				Blinking at 0.5 Hz	Diagnostic error
SP	System	1	Green	On	Normal
31	Power	1	Green	Blinking at 5 Hz	Abnormal
FP	Pield Power	1	Green	On	Normal
1 1		1		Blinking at 5 Hz	Abnormal

# 65M-5011M-CT-T

# **Front view**



# **LED Definition**

Labeling	Indication	Qty	Color	Behavior	Description
	System		Green	On	When the system has passed a power-on self-test (POST) and is ready to run.
				Blinking at 1 Hz	<ol> <li>When pressing the reset button, depress for 1 second to reboot the switch.</li> <li>System service initialization.</li> </ol>
STATUS	status	1		Blinking at 2 Hz	<ol> <li>When pressing the reset button, depress for 5 seconds to reset to factory default.</li> <li>While external storage is connected to the switch.</li> </ol>
			Red	On	System failed in boot up process. Reading system info failed or EEPROM info error.
FAULT	Fault indication	1	Red	On	<ol> <li>Network loop is detected when loop protection is enabled.</li> <li>External storage Loading/Saving Fail.</li> <li>The port is being disabled because exceeding the ingress rate limit of shut down mode.</li> <li>Invalid Ring port connection.</li> </ol>
				Off	When the system boots up and runs correctly or a user-configured event is not triggered.
				On	When the switch is Client/Head of Turbo Ring/Turbo Chain.
Client/ HEAD	Client or head	1	Green	Blinking at 4 Hz	<ol> <li>The switch has become the Client of Turbo Ring after Turbo Ring has gone down.</li> <li>The switch is set as Head of Turbo Chain and Turbo Chain has gone down.</li> <li>The switch is set as the Turbo Ring's Member and the corresponding Ring port is down.</li> <li>The switch is set as the Turbo Chain's Member/ Tail and the corresponding Head-end Chain port is down.</li> </ol>

Labeling	Indication	Qty	Color	Behavior	Description
				Off	When the switch is not the Client/Head of this Turbo Ring/Turbo Chain.
		1	Green	On	<ol> <li>The switch's ring coupling or dual homing function is enabled.</li> <li>The switch is set as the Tail of Turbo Chain.</li> </ol>
CPRL/ TAIL	Coupling or Tail			Blinking at 4 Hz	<ol> <li>Chain and the Chain has gone down.</li> <li>The switch is set as the Turbo Chain's Member/ Head and the corresponding Tail-end Chain port is down.</li> </ol>
				Off	When the switch disables the coupling or tail role of Turbo Chain.
SYNC	Synchroniz ation	1	N/A	N/A	Reserved
	10M/100M/		Green	On	When the port is active and links on 1000Mbps.
	1000M	1 for each		Blinking	When the port's data is being transmitted at 1000Mbps.
	RJ45 Top LED			Off	When the port is inactive or link is down.
3-10	10M/100M/	1 for	Amber	On	When the port is active and links on 10/100Mbps.
	1000M RJ45			Blinking	When the port's data is being transmitted at 10/100Mbps.
	Bottom LED			Off	When the port is inactive or link is down.
				On	When the port is active and links on 1,000Mbps.
		00 1 for rt each		Blinking	When the port's data is being transmitted at 1,000Mbps.
1-2	100M/1000			Off	When the port is inactive or link is down.
1-2	M SFP Port		Amber	On	When the port is active and links on 100Mbps.
				Blinking	When the port's data is being transmitted at 100Mbps.
				Off	When the port is inactive or link is down.

# 65M-5290-CT-T

# **Front view**



# **LED Definition**

Labeling	Indication	Qty	Color	Behavior	Description
			Green	Blinking at 0.5 Hz	Module starts up
				On	Module operates normally
	Module			Double Blinking	Locate
STATUS	status	1		Blinking at 5 Hz	Firmware upgrade in process
	status			On	Startup failed or other component error
			Red	Blinking at 5 Hz	Connection to CPU lost
				Blinking at 0.5 Hz	Firmware upgrade failed
PREV	PREV status	1	Green	On	Module starts up     I/O link connection established between the client PRE and server NEXT
				Blinking at 0.5 Hz	Acting as the client PREV module without an active IO link
NEXT	NEXT status	1	Green	On	Module Startup     IO link connection established between the client NEXT and server PREV
				Blinking at 0.5 Hz	Acting as the client NEXT module without an active I/O link

# 65M-1900-CT-T

# **Front View**



# **LED Definition**

Labeling	Indication	Qty	Color	Behavior	Description
	System status	1	Green	On	Normal
				Blinking at 5 Hz	Firmware upgrade in progress
				Blinking at 0.5 Hz	Booting up
STATUS				Double Blinking	Module located
SIAIUS			Red	On	System failure
				Blinking at 5 Hz	Lost the connection to CPU
				Blinking at 0.5 Hz	Diagnostic failure
				Double Blinking	No field power
	DI channels	1 for each	for Red	On	ON
1-32				On	Diagnostic error
			Off		OFF/Inactive

# 65M-2901-CT-T

## **Front View**



Labeling	Indication	Qty	Color	Behavior	Description
				On	Normal
STATUS System		Green	Blinking at 5 Hz	Firmware upgrade in progress	
		Green	Blinking at 0.5 Hz	Booting up	
	1		Double Blinking	Module located	
SIAIUS	status	1	Red	On	System failure
				Blinking at 5 Hz	Failsafe mode
				Blinking at 0.5 Hz	Diagnostic failure
				Double Blinking	No field power
	DO	1 for	Green	On	ON
1-32		each	Red	On	Diagnostic error
	CHAIIHEIS		Off		OFF/Inactive

## 65M-3600-CT-T

## **Front view**



Labeling	Indication	Qty	Color	Behavior	Description
				On	Normal
			Green	Blinking at 5 Hz	Firmware upgrade in progress
STATUS System		Green	Blinking at 0.5 Hz	Booting up	
	1		Double Blinking	Module located	
SIAIUS	status	1	Red	On	System failure
				Blinking at 5 Hz	Lost the connection to CPU
				Blinking at 0.5 Hz	Diagnostic failure
				Double Blinking	No field power
	ΑI	1 for	Green	On	ON
1-16		each	Red	On	Diagnostic error
	Chamieis	Cacii	Off		Inactive

# 65M-3610-CT-T

## **Front View**



Labeling	Indication	Qty	Color	Behavior	Description
				On	Normal
			Green	Blinking at 5 Hz	Firmware upgrade in progress
STATUS System		Green	Blinking at 0.5 Hz	Booting up	
	1		Double Blinking	Module located	
SIAIUS	status	1	Red	On	System failure
				Blinking at 5 Hz	Lost the connection to CPU
				Blinking at 0.5 Hz	Diagnostic failure
				Double Blinking	No field power
	ΑI	1 for	Green	On	ON
1-16		each	Red	On	Diagnostic error
	Chamieis	Cacii	Off		Inactive

## 65M-3800H-CT-T

## **Front View**



Labeling	Indication	Qty	Color	Behavior	Description
				On	Normal
				Blinking at 5 Hz	Firmware upgrade in progress
STATUS System	1		Blinking at 0.5 Hz	Booting up	
			Double Blinking	Module located	
SIAIUS	status	1	Red	On	System failure
				Blinking at 5 Hz	Lost the connection to CPU
				Blinking at 0.5 Hz	Diagnostic failure
				Double Blinking	No field power
	ΑI	1 for	Green	On	ON
1-8		each	Red	On	Diagnostic error
	CHarmels		Off		Inactive

## 65M-4820-CT-T

## **Front View**



Labeling	Indication	Qty	Color	Behavior	Description
				On	Normal
STATUS System		Green	Blinking at 5 Hz	Firmware upgrade in progress	
		Green	Blinking at 0.5 Hz	Booting up	
	1		Double Blinking	Module located	
SIAIUS	status	1	Red	On	System failure
				Blinking at 5 Hz	Failsafe mode
				Blinking at 0.5 Hz	Diagnostic failure
				Double Blinking	No field power
	AO	1 for	Green	On	ON
1-8	_	each	Red	On	Diagnostic error
	CHAINEIS		Off		Inactive

## 65M-5801-CT-T

## **Front View**



Labeling	Indication	Qty	Color	Behavior	Description
				On	Normal
			Green	Blinking at 5 Hz	Firmware upgrade in progress
STATUS System		Green	Blinking at 0.5 Hz	Booting up	
	1		Double Blinking	Module located	
SIAIUS	status	1		On	System failure
				Blinking at 5 Hz	Failsafe mode
			Reu	Blinking at 0.5 Hz	Diagnostic failure
				Double Blinking	No field power
	Serial	1 for	Green	Blinking at 0.5 Hz	Tx
1-8		each	Red	Dilliking at 0.5 Hz	Rx
	Chamieis		Off		Inactive

# I/O Pin Definitions

The terminal blocks of ioPAC 6500 Series have 40 pins. The pin definitions of each module are listed in the following.

#### 65M-TB-1900

5	10	15	20	25	30	35	40
FCS	FCS	GND	GND	NC	NC	NC	NC
4	9	14	19	24	29	34	39
DI4	DI8	DI12	DI16	DI20	DI24	DI28	DI32
3	8	13	18	23	28	33	38
DI3	DI7	DI11	DI15	DI19	DI23	DI27	DI31
2	7	12	17	22	27	32	37
DI2	DI6	DI10	DI14	DI18	DI22	DI26	DI30
1	6	11	16	21	26	31	36
DI1	DI5	DI9	DI13	DI17	DI21	DI25	DI29

#### 65M-TB-2901

5	10	15	20	25	30	35	40
V+	V+	V-	V-	NC	NC	NC	NC
4	9	14	19	24	29	34	39
DO4	D08	DO12	DO16	DO20	DO24	DO28	DO32
3	8	13	18	23	28	33	38
DO3	D07	DO11	DO15	DO19	DO23	DO27	DO31
2	7	12	17	22	27	32	37
DO2	D06	DO10	DO14	DO18	DO22	DO26	DO30
1	6	11	16	21	26	31	36
DO1	DO5	DO9	DO13	DO17	DO21	DO25	DO29

## 65M-TB-3600

5	10	15	20	25	30	35	40
LS1+	LS1+	LS1-	LS1-	LS2+	LS2+	LS2-	LS2-
4	9	14	19	24	29	34	39
AI4+	AI4-	AI8+	AI8-	AI12+	AI12-	AI16+	AI16-
3	8	13	18	23	28	33	38
AI3+	AI3-	AI7+	AI7-	AI11+	AI11-	AI15+	AI15-
2	7	12	17	22	27	32	37
AI2+	AI2-	AI6+	AI6-	AI10+	AI10-	AI14+	AI14-
1	6	11	16	21	26	31	36
AI1+	AI1-	AI5+	AI5-	AI9+	AI9-	AI13+	AI13-

#### 65M-TB-3610

5	10	15	20	25	30	35	40
NC	NC	NC	NC	NC	NC	NC	NC
4	9	14	19	24	29	34	39
AI4+	AI4-	AI8+	AI8-	AI12+	AI12-	AI16+	AI16-
3	8	13	18	23	28	33	38
AI3+	AI3-	AI7+	AI7-	AI11+	AI11-	AI15+	AI15-
2	7	12	17	22	27	32	37
AI2+	AI2-	AI6+	AI6-	AI10+	AI10-	AI14+	AI14-
1	6	11	16	21	26	31	36
AI1+	AI1-	AI5+	AI5-	AI9+	AI9-	AI13+	AI13-

# 65M-TB-3800H

5	10	15	20	25	30	35	40
LS+	LS+	LS-	LS-	NC	NC	NC	NC
4	9	14	19	24	29	34	39
AI4+	AI4-	AI8+	AI8-	NC	NC	NC	NC
3	8	13	18	23	28	33	38
AI3+	AI3-	AI7+	AI7-	NC	NC	NC	NC
2	7	12	17	22	27	32	37
AI2+	AI2-	AI6+	AI6-	NC	NC	NC	NC
1	6	11	16	21	26	31	36
AI1+	AI1-	AI5+	AI5-	NC	NC	NC	NC

#### 65M-TB-4820

5	10	15	20	25	30	35	40
NC							
4	9	14	19	24	29	34	39
IO2+	IO2-	IO4+	IO4-	IO6+	IO6-	IO8+	IO8-
3	8	13	18	23	28	33	38
VO2+	VO2-	VO4+	VO4-	VO6+	VO6-	VO8+	VO8-
2	7	12	17	22	27	32	37
IO1+	IO1-	IO3+	IO3-	IO5+	IO5-	IO7+	IO7-
1	6	11	16	21	26	31	36
VO1+	VO1-	VO3+	VO3-	VO5+	VO5-	V07+	V07-

## 65M-TB-5801

#### **RS-232**

5	10	15	20	25	30	35	40
GND1	GND1	GND1	GND1	GND2	GND2	GND2	GND2
4	9	14	19	24	29	34	39
CTS1	CTS2	CTS3	CTS4	CTS5	CTS6	CTS7	CTS8
3	8	13	18	23	28	33	38
RTS1	RTS2	RTS3	RTS4	RTS5	RTS6	RTS7	RTS8
2	7	12	17	22	27	32	37
Rx1	Rx2	Rx3	Rx4	Rx5	Rx6	Rx7	Rx8
1	6	11	16	21	26	31	36
Tx1	Tx2	Tx3	Tx4	Tx5	Tx6	Tx7	Tx8

#### **RS-422**

5	10	15	20	25	30	35	40
GND1	GND1	GND1	GND1	GND2	GND2	GND2	GND2
4	9	14	19	24	29	34	39
Rx1-	Rx2-	Rx3-	Rx4-	Rx5-	Rx6-	Rx7-	Rx8-
3	8	13	18	23	28	33	38
Rx1+	Rx2+	Rx3+	Rx4+	Rx5+	Rx6+	Rx7+	Rx8+
2	7	12	17	22	27	32	37
Tx1-	Tx2-	Tx3-	Tx4-	Tx5-	Tx6-	Tx7-	Tx8-
1	6	11	16	21	26	31	36
Tx1+	Tx2+	Tx3+	Tx4+	Tx5+	Tx6+	Tx7+	Tx8+

## RS-485-2w

5	10	15	20	25	30	35	40
GND1	GND1	GND1	GND1	GND2	GND2	GND2	GND2
4	9	14	19	24	29	34	39
D1-	D2-	D3-	D4-	D5-	D6-	D7-	D8-
3	8	13	18	23	28	33	38
D1+	D2+	D3+	D4+	D5+	D6+	D7+	D8+
2	7	12	17	22	27	32	37
NC							
1	6	11	16	21	26	31	36
NC							

# 3. Hardware Installation

In this chapter, we describe how to install the ioPAC 6500 Series devices.

# **Mounting the Unit**

In this section, we describe how to mount the devices and how to dismount the device.



#### **NOTE**

ioPAC 6500 Series supports the following modules, collecting all the modules you need before installing the system.

- CPU module
- · Power module
- Backplane module for CPU
- Backplane module for power
- Communication (switch) module (optional, based on the application)
- IO module (optional, based on the application)
- Backplane module for communication (switch) (optional, based on the application)
- Backplane module for IO (optional, based on the application)
- Terminal block (TB) module for IO (optional, based on the application)
- Backplane module for expansion
- Expansion (optional, based on the application)




#### **NOTE**

The ioPAC 6500 Series needs to be installed by the order: **Power Module > communication(switch) Module (optional) > CPU Module > Expansion Module (optional) > IO Module (optional)** 

## **Horizontal Installation**

Before mounting the device onto the DIN rail, make sure that there is enough space around the device so that heat generated from the system can be dissipated. The suggested space dimension is shown below.





#### **CAUTION**

DO NOT install the device upright, as the fanless heat dissipation design will not perform as intended.

# **Installing the System on the DIN Rail**

Follow the steps to mount the modules onto the DIN rail.




#### NOTE


Use a DIN rail with a thickness of 1.5 mm and made of stainless steel to ensure a safe installation.

The demonstrated configuration includes one power module, one communication module (Switch), one CPU module, one expansion module, and two IO modules.


**Step 1:** Assemble all the backplane modules you need all at once before mounting them onto the DIN-rail. Follow the order: Power Module > Communication Module (Switch) > CPU Module > Expansion Module > IO Module. When hearing a "click" from the top clip, meaning the backplane modules are connected.




**Step 2:** Mount the upper mounting hook of all assembled backplanes onto the DIN rail while making sure the lower mounting hook of it is at an open position as shown below (side view). Push the assembled backplane towards the DIN rail, then push the lower mounting hook upward until latch so that all the backplane modules are fixed in position.




**Step 3:** Hold the Power module with two hands and install onto the power backplane module vertically. As with the CPU module, also the expansion module and communication module (if applicable).



**Step 4:** Place the terminal block module on the I/O backplane module, then pull down the TB module to fix the position.



**Step 5:** Hold the I/O module and install it onto the I/O backplane module horizontally. Note that there is a poka-yoke design to make sure the I/O module is installed on the correct terminal block.




# **Unmounting the System from a DIN Rail**


Follow the steps to demount the modules from the DIN rail.

The demonstrated configuration includes 1 power module, 1 communication module (switch), 1 CPU module, and 2 IO modules.


- **Step 1:** Turn off the power to shut down the system.
- **Step 2:** Press the release tab on top of the IO module, then remove the I/O module from the backplane as shown below.




**Step 3:** Pull up the terminal block module, then remove it from the backplane.




**Step 4:** Press the release tab on top of the CPU module, then remove the CPU module from the backplane horizontally. Remove the module with two hands to prevent dropping. Repeat the same procedure for removing the switch and power module as well.



**Step 5:** Pull down all backplane modules' lower mounting hook as shown below, then demount all the backplane modules from the DIN rail.




**Step 6:** Pull up the top clip (yellow part) of the IO backplane module to disassemble. Repeat the procedure for the CPU backplane and switch the backplane module.




# **Grounding the System**

Ensure that you properly ground the system. There are three places that should be grounded as shown below. Use the different power supplies for system and field power to ensure the system and I/Os are isolated.

The first and second grounding points are the earth ground pin of the system, and field power connector.



The third grouding point is on the back side of each backplane module. The grounding spring will be connected to the DIN rail directly when successfully mounted.



# **Wiring System and Field Power**

Wire range: 12 to 18 AWG (ferrule diameter: 2.0 to 1.0 mm)

Wire strip length: 12 to 13 mm

Unit: mm (in.)




#### **NOTE**

We recommend using different power supplies for system power and field power to ensure the system and I/Os are isolated.

# **System Power**

The system requires a 24-VDC system power input. The system powers this system via an internal bus, which is on the backplane module.






#### **NOTE**

The suggested tightening torque: 5.0 kgf-cm.

## **Field Power**

The ioPAC 6500 provides a field power input of 24 VDC that powers up the IO circuit inside the I/O module through the internal bus.






#### **NOTE**

The suggested tightening torque: 5.0 kgf-cm.

# Wiring Ethernet Ports


The maximum cable length is 100 m (350 feet), but the actual limit for your application could be longer or shorter depending on the amount of electrical noise in the environment. To minimize the amount of noise, Ethernet cables should not run parallel to power cables or other types of cables that generate electrical noise. The following diagram and table show the pin assignments for the RJ45 Ethernet ports:



Pin	Media Direct Interface Signal
1	TRD(0)+
2	TRD(0)-
3	TRD(1)+
4	TRD(2)+
5	TRD(1)-
6	TRD(2)-
7	TRD(3)+
8	TRD(3)-

# Wiring Serial Port(s)

The ioPAC 6500 is equipped with two 3-in-1 serial ports that support RS-232/422/485, making it more convenient to connect field serial devices.



Pin	RS-232	RS-422	2-wire RS-485
1	DCD	TxD-(A)	_
2	RXD	TxD+(B)	-
3	TXD	RxD+(B)	Data+(B)
4	DTR	RxD-(A)	Data-(A)
5	GND	GND	GND
6	DSR	-	-
7	RTS	-	-
8	CTS	-	-
9	RI	-	-


# Wiring the Fiber Port(s)

# 100/1000BaseSFP (mini-GBIC) Fiber Port

The Gigabit Ethernet fiber ports on the switch are 100/1000BaseSFP fiber ports, which must use 100/1000M mini-GBIC fiber transceivers to work properly.

The concept behind the LC port and cable is straightforward. Suppose you are connecting devices I and II. Contrary to electrical signals, optical signals do not require a circuit to transmit data. Consequently, one of the optical lines is used to transmit data from device I to device II, and the other optical line is used to transmitting data from device II to device I for full-duplex transmission.


Remember to connect the Tx (transmit) port of device I to the Rx (receive) port of device II, and the Rx (receive) port of device I to the Tx (transmit) port of device II. If you make your own cable, we suggest labeling the two sides of the same line with the same letter (A-to-A and B-to-B, as shown below, or A1-to-A2 and B1-to-B2).




# **Connecting Expansion Module**

The ioPAC 6500 supports expansion modules, ensuring the expandability of the system. The connecting method shown below ensures redundancy. However, if no expansion unit is required, do not install expansion modules on the control unit.

1 Expansion module per Unit Ring Topology — Redundancy for single cable failure. Please be noted, data will be lost during expansion module hot swapping.



2 Expansion modules per Unit Ring Topology — Redundancy for single-cable or single-module failure. We recommend employing this structure for critical applications, as it provides higher level of communication reliability between Control unit and Expansion Units.





#### **ATTENTION**


This is a Class 1 Laser/LED product. To avoid causing serious damage to your eyes, do not stare directly into the laser beam.

# Wiring I/O Channels


The ioPAC 6500 supports general DI, DO, AI, AO channels, which can be used to collect the data in the field site.

#### 65M-1900-CT-T


#### **Dry Contact**



# Dry Contact (with Wire Break Diagnostic)




#### **Wet Contact**




#### 65M-2901-CT-T

#### **Resistive Load**



#### **Inductive Load**




#### 65M-3600-CT-T




#### **NOTE**

LS1 should be wired with AI1-AI8 and LS2 should be wired with AI9-AI16.


#### 2-Wire Current Sensor



#### **3-Wire Current Sensor**




#### **4-Wire Current Sensor**




#### 65M-3610-CT-T

#### 4-Wire Voltage Sensor




#### 65M-3800H-CT-T


#### 2-wire Current Sensor (Internal Loop Power)




#### 2-wire Current Sensor (External Loop Power)



#### **3-wire Current Sensor**




#### **4-wire Current Sensor**




# 65M-4820-CT-T

#### **Voltage Output**




## **Current Output**




## 65M-5801-CT-T


#### RS-232



#### **RS-422**




#### RS-485-2w



# Inserting the microSD™ Card


The ioPAC 6500 CPU module offers a microSD slot. This function is currently reserved. Open the cover on the CPU module, you can see the microSD slot inside.



# **Powering on the Unit**

When all the installation and wiring are complete, you can turn on the power to boot up the system. After turning on the system power supply, it will take 90 seconds for the operating system to boot up. The green Ready LED will illuminate continuously until the operating system is ready.

# **Mode Switch**



Open the cover on the CPU module, you can see the mode switch inside. The ioPAC 6500 CPU module offers a mode switch for you to change the system status.

**Remote:** the device is allowed to download the program and change the device setting remotely. The authorized user with secure access is required.

**Run:** The device is actively running the program. It rejects any attempt to interrupt the device running, either locally or over the network. The device information is set to read only.

**Stop:** The device will not execute the program in any condition. The authorized user is allowed to download the program and change the device setting.

The table shows which action can be performed in each mode.

	STOP	RUN	REMOTE - Run	REMOTE - STOP			
IDE							
<b>Configuration Download</b>	Yes	No	Yes	Yes			
Online Change	Yes	No	Yes	Yes			
Firmware Upgrade	Yes	No	No	Yes			
Warm / Cold Reboot	Yes	No	Yes	Yes			
Force Output	Yes	Yes	Yes	Yes			
Reset Warm, Reset Cold,	Yes	No	No	Yes			
Reset Origin	103	110	140	103			
STOP COMMAND	No	No	Yes	No			
Factory Default/ Device	Yes	No	No	Yes			
Decommission	103	110	140	103			
Backup	Yes	Yes	Yes	Yes			
Restore	Yes	No	Yes	Yes			
Security Hot Plug	Yes	Yes	No	No			
Web	Web						
System Settings	Yes	View/Export only	Yes	Yes			
Maintenance	Yes	View/Export only	Yes	Yes			
Diagnostic	Yes	View/Export only	Yes	Yes			
Certificate	Yes	View/Export only	Yes	Yes			
Security	Yes	View/Export only	Yes	Yes			

# **Reset Button: Reset Origin Device**


Open the cover on the CPU module; you can see the reset button inside. Follow the steps to perform **Reset Origin Device**, which will reset the whole system to its original status.

- 1. Keep pressing the reset button for **15 seconds**; the STATUS LED starts double blinking RED.
- Releasing the reset button when the STATUS LED is double blinking RED, the ioPAC 6500 system will start to reset the system to its original status.



#### **NOTE**

Except for the system logs, all other data and settings of the system will be reset once Reset Origin Device is performed successfully.



# 4. Software Configuration

In this chapter, we introduce the web interface and serial console of the ioPAC 6500 CPU module.

# **Connecting the Web Interface**

The Web Console is already embedded in the ioPAC 6500 system. Use the web console to check the device status, configure network settings, or update the firmware of the device. Follow the steps below to connect to the web interface.


- 1. Connect the system to your PC through an Ethernet cable.
- Power on the unit
- 3. Open a web browser (Chrome is recommended) on your PC and type the default IP address shown on the model label of the unit.



#### **INFORMATION**

Type in the IP address (if the IP address is not set by default). If the IP address is not available, use the IINxpress utility to search for the device, or load the factory default settings by holding down the RESET button to access the device through the default IP address.

When you log into the system successfully, you will see the product page is composed of three parts.



- 1. **Title panel:** Provides the log out function. The login account will be shown at the top right corner.
- 2. Menu panel: Provides the access monitor the device status to configure functions or services.
- 3. Information panel: The device information associated with the functions selected in the menu panel.



#### **NOTE**

For security reasons, select Logout when no longer accessing this device. DO NOT leave the web interface unattended.

#### **Dashboard**

#### **System Dashboard**

System Dashboard is the first page when you log in the device. The dashboard provides information about the module information, panel status, service status, protocol status, and IEC 61131-3 program status.

On the top of the system dashboard, the system combination will be displayed. Select the Control Unit, Expansion Unit 1, etc. to check the system combination of each unit.



On the bottom of the system dashboard, the information will be displayed.

#### **System Information**

The system information will be displayed here. For example, device name, system status, Ethernet status, time status, etc.

#### **Module Information**

The information of the selected module will be displayed here. For example, model name, firmware version, serial number, etc.



#### **NOTE**

For detailed information on the switch module, check in the built-in web of the switch module.

#### **LED Status**

The LED status of all modules will be displayed here. For the LED definition, refer to the LED definition section.



#### NOTE

For the LED status of the switch module, check in the built-in web of switch module.

#### **Mode Switch Status**

The mode switch status will be displayed here. There are three statuses of mode switch.

**Remote:** The device is allowed to download the program and change the device setting remotely. An authorized user with secure access is required.

**Run:** The device is actively running the program. It rejects any attempt to download the program or change the device settings. The device information is set to read only.

**Stop:** The device will not execute the program in any condition. The authorized user is allowed to download the program and change the device setting.

#### Protocol Status

The status of all protocol services will be displayed here. There are three statuses.

Run: the service is running.

Stop: the service is stopped.

**Disable:** the service is currently disabled.

#### IEC 61131-3 Program Status

The IEC engine status will be displayed here. **RUN** and **STOP** are two statuses for you to identify if the engine is running or not.

# **System Configuration**

# System Settings—General




Go to **System Settings > General > System** to specify a new device name and enter a description for the device

**Device Name:** Set enter a name to identify the whole ioPAC 6500 system. The maximum length is 64 characteristics, alphanumeric, and special characteristics are allowed.

**Description:** Extra information for you to better identify the device.

Go to **System Settings > General > Time** to set up the time of the device.




The current data and time will be displayed here.



#### **NOTE**

The current date and time are based on the system setting.

**Time Zone:** Specify the time zone where the devices is located.




**Daylight Saving Time:** Enable and enter the daylight-saving time of the device.





#### **NOTE**

0 to 6 in Day represents Sunday to Saturday, respectively.



**Sync Mode:** How to sync up the device time. In **Auto** mode, the device will sync with the time server you specified automatically. In Manual mode, select  $^{\diamondsuit}$  Sync with browser icon to sync with the browser, or input a specific time.






**NTP Authentication:** The device supports NTP Authentication for a secured connection between NTP servers. If you want to use the NTP authentication, follow the steps to enable the NTP authentication.

- Select Create, enter the key ID and password in the pop out window, and then Save to close the window.
- 2. Choose the created key, then **Save** to enable the NTP Authentication.

## System Settings—IP Address




Go to **System Settings > IP Address** to set up the device IP.

LAN mode: The device supports Dual IP mode currently.


 $\textbf{Port Enable/Disable:} \ \textbf{Enable or disable port by selecting LAN1 or LAN2}$ 

LAN1/LAN2: Set up the IP for LAN1 or LAN2. The device supports DHCP or Static mode.

**DNS Server:** Need to input the DNS server.




# **System Settings—Switch Information**



Go to **System Settings > Switch Information** to check the switch information. If any switch module is installed in the system, the IP information will be displayed here. For the switch module setup, select  $\underline{\mathsf{Open}}$  and set up in the web of the switch module.


#### **SNMP Settings**

**SNMP Agent:** The SNMP agent continuously gathers information about the device. When an SNMP manager sends a request, the agent responds with the requested data. **Versions:** v1v2c, v3only, v1v2cv3.




#### **SNMPv3 Account and Account Protection**


Click "Create" to configure the SNMPv3 Account and you could decide whether to disable the SNMPv3 Account if authentication failed.




**SNMP Trap:** The agent proactively sends a notification to the server without waiting for a request, should a critical event occur.




Click "Create" to configure the Trap Server.





#### **Maintenance**

# General Operation—Config. Backup/Restore




Go to **General Operation > Config. Backup/Restore** to back up the system settings to the encrypted configuration file or restore the system settings from an encrypted configuration file.

**Backup:** Input a password first, then select **Backup** to save the configuration file which is encrypted with the password specified by you. The maximum length of password is 40 characteristics, alphanumeric, and special characteristics are allowed.

**Restore:** Restore the system with an encrypted configuration file. Select **Browse** to choose the file and input the password. You can choose to restore the networking, account, and group setting from the backup file by selecting the checkbox or not. Once all the information is ready, select the **Restore** to restore the system.

# **General Operation—Firmware Update**



Go to **General Operation > Firmware Update** to update the firmware to the system. The page provides three steps to guide you in updating the firmware.

- 1. **Select Firmware File:** Select **Browse** to choose the firmware file that needs to be updated to the system. Select the release note to check the details.
- 2. **Select Module on List:** Select the modules that need to be updated on the **Module List**. Use the module filter to speed up the module selection. Module information will be displayed in the module list.
  - > **Slot:** It shows the slot that the module is installed in. The slot number is calculated based on the current system combination. The number 1 shows the leftmost module of each unit. The slot of the backplane module will be displayed with a number in square brackets, e.g., [1].
  - > **Type:** It shows the module type. E.g. CPU, DI, Backplane, etc.
  - > Model Name: The model name of the module will be displayed here.
  - > Current Version: Current firmware version of the module will be displayed here.
  - > Update Version: The firmware version included in this firmware file will be displayed here.




## **NOTE**

Update the switch module's firmware on the web page of the switch module.

- > **Progress(%):** The progress of the update will be here
- > Note: Any other information that cannot be categorized will be displayed here.
- 3. **Update:** Select **Update** to start the system firmware update. Choose **Update Firmware One by One** to update the firmware module by module.

# **Diagnostic**

# **Event Log-Log View**




Go to **Event Log > Log View** to check all logs generated by the system. The following information of the logs will be displayed in the table.

- **ID:** The orders of the logs in the list
- **Severity:** The severity of the event; three severities (alert, warning, information).
- Category: The category from which the log is generated. Check the categories in the Policy Settings
  page.
- **Event Name:** Event name shows why the log was generated.
- **Source:** If the log is generated by an external source, the information will be displayed here.
- **Message:** The message included in the log.
- Timestamp: When the log is generated.

**Export**, **Clear**, and **Refresh** the log list based on the requirement.


# **Event Log—Policy Settings**




Go to **Event Log > Policy Settings** to check the policy settings of the log.

The log will be stored locally as the default. The modification can be done in the **Channels**.

**Local Log:** Select the **to** change the settings. **Event Log Overwrite Policy** and **Log Capacity Warning** can be configured.




**Remote Log:** Select the \( \ \ \) to change the settings. The system supports two syslog servers and can deliver the log to two syslog servers simultaneously. Enable the server and key in the IP to activate the syslog server. The system supports TLS authentication. Remember to complete the settings in the **Certificate Center**.



The logs supported by systems are listed in the **Events** section. The events are enabled and stored locally in default. Change the logs based on the application.

# **OpenVPN Settings**




Go to **OpenVPN Settings** to configure the OpenVPN settings. Follow the steps to enable the OpenVPN

- 1. Import the OpenVPN config file. The file is generated in an OpenVPN server.
- 2. Enable the OpenVPN.
- 3. If connected successfully, the status will become Green.

# **Certificate**

# **Certificate Center**




Go to **Certificate Center > My Certificates** to check the search, view the status, and download the system certificates.


**Create Certificate Signing Request:** This function will generate a .csr file based on current system status. Use the .csr file to obtain a signed certificate from Root CA.

**Import Signed Certificate:** The signed Certificate generated by Root CA in the previous step should be imported here.

**Create Self-signed Certificate:** If the Root CA is not available, the system also provides the self-signed certificate for you to download.








Go to **Certificate Center > Protocol Mapping Table** to link the saved My Certificates and Trusted Root CA to a protocol. Note that not all protocols need My Certificate and Trusted Root CA.


- Only My Certificate: HTTPS, MQTT
- Only Trusted Root CA: OPC UA 2/3/4, LDAPS, RadSec

# **Security**


# **Account Manager**



Go to **Account Manager > Password Policy Settings** to set up the password policy of the device. The <u>length</u>, <u>letter combination</u>, <u>and uniqueness</u> of the password can be set up. Besides the password policy, change the welcome and login-failed message on this page.




Go to **Account Manager > Login Session Settings** to set up the login sessions. The maximum connection and logout time.



Go to **Account Manager > Authentication, Authorization and Accounting Settings** to set up the AAA settings. Several authentication modes are available.

- Local Only: Use the accounts that have been set up in the system.
- RADIUS Only: Link to the RADIUS server to verify the login account.
- TACACS+ Only: Link to the TACACS+ server to verify the login account.
- LDAP Only: Link to the LDAP server to verify the login account.
- **RADIUS Then Local:** Link to the RADIUS server to verify the login account first. If a timeout happens, use the accounts set up in the system as an alternative.
- **TACACS+ Then Local:** Link to the TACACS+ server to verify the login account first. If a timeout happens, use the accounts set up in the system as an alternative.
- **LDAP Then Local:** Link to the LDAP server to verify the login account first. If a timeout happens, use the accounts set up in the system as an alternative.

### RADIUS Settings



The ioPAC 6500 supports RADIUS. Here are detailed descriptions of the RADIUS server settings:

- **Secure:** Enabling the system to communicate encrypted data with the RADIUS server. The certificate will be specified in the Certificate Center.
- **RADIUS Server:** Input the IP of the RADIUS server here.
- RADIUS Key: Input the key of the RADIUS server here.
- **Port:** The port that communicates with the RADIUS server.
- **Authentication Type:** The authentication type used in the RADIUS server. The ioPAC 6500 supports PAP, CHAP, MSCHAP, and EAP-MD5, offering a total of four authentication types.
- **Timeout:** How long the ioPAC 6500 will wait for the response from the RADIUS server.
- **Group Mapping:** It listed the Filter-ID and Group mapping in the ioPAC 6500 system. The current groups will be displayed here. The table shows the authority of each default group of users.




### NOTE

- 1. The ioPAC 6500 system supports a maximum of 16 groups, eight are default and another eight are user-defined.
- 2. The group's modification should be done in IINxpress.

Group	Monitor and Diagnostic	Operational Activities	Configu- ration	IEC Code	System Log	Security Configu- ration and Secure Log	Upgrade and Rollback	Account Management
Viewer	R	R		R	R			
Operator	R	R/W		R/W	R			
Engineer	R/W	R/W	R/W	R/W	R			
Installer	R/W	R	R/W	R/W	R	R	R/W	
Secure Admin	R/W	R	R/W	R	R/W	R/W	R/W	R/W
Secure Auditor	R	R	R		R	R		R
Account Manager	R					R/W		R/W
Admin	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

### **TACACS+ Settings**




The ioPAC 6500 supports TACACS+. Here are detailed descriptions of the TACACS+ server settings:

- TACACS+ Server: Input the IP of TACACS+ server here.
- Shared Secret: Input the key of TACACS+ server here.
- **Port:** The port used to communicate with the TACACS+ server.
- **Authentication Type:** The authentication type used in the TACACS+ server. The ioPAC 6500 supports PAP, CHAP, ASCII, three authentication types in total.
- **Timeout:** How long the ioPAC 6500 will wait for the response from the TACACS+ server.
- **Group Mapping:** The privilege level and group mapping in the ioPAC 6500 system. The current groups will be displayed here. The authority of each default group of users is the same as RADIUS.

### **NOTE**

- 1. The ioPAC 6500 system supports a maximum of 16 groups; eight are default and another eight are user-defined.
- 2. The group modification should be done in IINxpress.

## **LDAP Settings**




The ioPAC 6500 supports LDAP. Here are the detailed descriptions of the LDAP server settings:

- **Secure:** Enabling the system to communicate encrypted data with the LDAP server. The certificate will be specified in the Certificate Center.
- LDAP Server: Input the IP of LDAP server here.
- Search Base DN: The LDAP DN (Distinguished name) that serves as a starting point for the search for users over all child nodes.
- Search Filter: The LDAP search filter used for the search for users
- **Bind DN:** Enter the Distinguished Name of the user to search in the LDAP directory.

- **Port:** The port used to communicate with the LDAP server.
- **Authentication Type:** The authentication type used in the server. The ioPAC 6500 supports Group Attributes and DN, two authentication types.
- **Timeout:** How long the ioPAC 6500 will wait for the response from the LDAP server.
- **Group Mapping:** Listing the Group Attributes and Group mapping in the ioPAC 6500 system. The systems consist of eight groups. The authority of each group of users is the same as RADIUS.


### **Allowlist**

All communications are only allowed for the enabled IPs on the list after enabling this allowlist. Select **Add Rule** to edit the IP and subnet mask.



### **DoS Defense**

This section configures protections against **Denial-of-Service attacks**, which are attempts to make a device or network service unavailable by overwhelming it with traffic.



# Configuration

Items	Description
Null Scan	TCP scan with no flags set; used in stealth attacks to probe for open ports
NMAP-Xmas Scan	TCP scan with FIN, URG, PSH flags; used to bypass simple detection methods
SYN/FIN Scan	Sends TCP packets with both SYN and FIN flags set; non-standard combination
FIN Scan	Sends TCP packets with only the FIN flag; used for stealth port scanning
NMAP-ID Scan	Detects IP ID-based scans used in host discovery and fingerprinting

#### **SYN Flood**

When enabled, it activates protection against SYN flood attacks. The packet limit can be set from 50 to 4000.

### **ICMP-Death**


When enabled, it activates protection against ICMP flood attacks. The packet limit can be set from 50 to 4000

# **Services**

This section allows you to supervise and configure the software and hardware services, including the service and its corresponding port.

Software services: Console, System, Industrial Data.


Hardware services: CPU module.



# **Logging in by Console Port**

The ioPAC 6500 Series offers a serial console port, allowing you to reboot and reset to default. Followed the steps to use the console port.

**Step 1:** Open the cover on the CPU module to see the console port inside.



**Step 2:** Connect the 4-pin serial console cable to the console port. The following diagram shows the 4-pin serial connector and pin connections.

### Pin Assignment for the Serial Console Port



Pin	Definition
1	TxD
2	RxD
3	NC
4	GND

### **Serial Console Default Settings**

Parameter	Value
Baudrate	115200 bps
Parity	None
Data bits	8
Stop bits	1
Flow Control	None


# **NOTE**

Contact the sales representative in your region for the console cable.

We recommend you use PComm Terminal Emulator for serial communication. Download the software free from Moxa's website.

After installing PComm Terminal Emulator, access the Moxa switch's console:


1. From the Windows desktop, select **Start > Moxa > PComm Terminal Emulator**.




2. Select **Open** under the **Port Manager** menu to open a new connection.




The Property window will open. On the Communication Parameter tab for Ports, select the COM port that is being used for the console connection. Set the other fields: 115200 for Baud Rate, 8 for Data Bits, None for Parity, and 1 for Stop Bits.



4. On the **Terminal** tab, select **VT100** for **Terminal Type**, and then select **OK** to continue.



5. The console will prompt you to log in. The default login name is **admin**, and the default password is **moxa**. This password will be required to access any of the consoles (web, serial, Telnet).



6. After successfully connecting to the switch by serial console, start configuring the switch's parameters by using command line instructions. Refer to the **Moxa Command-line Interface Manual** for details.



### **NOTE**

By default, the password assigned to the Moxa switch is **moxa**. Be sure to change the default password after you first log in to help keep your system secure.

In this chapter, we introduce how to configure the ioPAC 6500 by IINxpress. IINxpress is a Moxa utility, which is the integrated development environment (IDE) software for the Moxa ioPAC 6500 Series. IINxpress provides easy access to all status information, ready-to-run service settings, and IEC 61131-3 programming ability. IINxpress requires a paid license, but it can be upgraded for free when future basic functions are available.




### **NOTE**

Avoid installing IINxpress on ARM-based CPUs. To ensure a smooth user experience, the recommended specifications are: x86-64 CPU (i5 or above), 8 GB RAM or higher, and make sure enough storage is reserved for installation and the project; project file size varies depending on the application.




### **NOTE**

Download the IINxpress software from Moxa's official website (<a href="https://www.moxa.com/">https://www.moxa.com/</a>) to do the installation. Once the installation is completed, the following window will appear to ask you to activate the IINxpress. The window will display a 21-digit encrypted user code. Use this code to register on the Moxa Licensing Portal (<a href="https://license.moxa.com/">https://license.moxa.com/</a>) and get an activation code. Then, activate IINxpress.



When IINxpress is launched successfully, you see the following windows. The IINxpress user interface can be divided into three blocks.



**Menu and Toolbar:** The settings related to the device can be found here.

**Project Tree:** The functions of the projects will be listed here hierarchical.

**Main window:** The detailed parameters of each function will be displayed here, switch between each function by the tab.



### **NOTE**

When logging in for the first time into IINxpress, follow the iinstructions in the **Build New Project** section to create a new project.


# **Menu and Toolbar**

IINxpress' menu and toolbar provide the functions for you to develop the program. We will now discuss functions related to the device's configuration and program execution.



- New Project: Built a new project. Refer to the Build New Project section for details.
- **Open project:** Opens an existing project.
- Device helper: Provides the device scan, mapping functions, and performs some basic settings.
- Open ioPAC 6500 Configuration: Opens the ioPAC 6500 configuration page where you configure all the device settings. Refer to the ioPAC 6500 Configuration section for details.
- **Open ioPAC 6500 Web page:** Opens the ioPAC 6500 webpage where you configure IT-related device settings.

Connect device: Used to connect the ioPAC 6500 devices. When connecting the device for the first time, IINxpress will show the warning message about the certificate. Choose the preference option to accept the certificate once or put the certificate into a local store. The log-on window will show. Key in the username and password to log into the device. After a successful connection, monitor the real-time device status on the ioPAC 6500 Configuration page.



- Login application: When you log in the application, you can control the device to run and stop the program remotely. Note: The mode switch should be switched to "REMOTE" to allow the control from the remote side.
- Logout application: Logs out the application to close the remote control session.
- Online change: You can use this command to initiate an online change on the current application. When this is done, CODESYS re-downloads only the changed parts of an application that is already running on the PLC
- Download: Downloads the compiled program to the device.
- Run: Runs the program remotely.
- **Stop:** Stops the program remotely.
- $\odot$  Single cycle: Asks the device to run one cycle.
- **C** Reset warm: Resets the program with warm-start condition.
- **© Reset cold:** Resets the program with cold-start condition.
- Generate code: Compiles the code on completing the program.
- Step over: The command executes the statement where the program is currently located and stops before the next statement in the POU. For details, check **Help**.
- **Step into:** The command executes the statement where the program is currently located and stops before the next statement. For details, check **Help**.
- Step out: The command executes the program until the next return and stops afterwards. For details, check **Help**.
- \*\* Run to cursor: The command executes a program until a specified position as marked by the cursor. For details, check Help.

- Set next statement: The command determines which statement is executed next. For details, check Help.
- Show next statement: The command displays the program statement that is processed in the next step. For details, check **Help**.
- Write values: This command sets a predefined value to a variable on the controller once. For details, check Help.
- Force values: The command sets a permanent predefined value to a variable on the controller. For details, check Help.
- Unforce values: This command resets the forcing of all variables. The variables receive their current values from the PLC. For details, check **Help**.
- Display mode: The value in the project is displayed in Binary, Decimal, and Hexadecimal.

# **Build New Project**


Selecting the New project button allows you to select from three ways to create a new project.

# ioPAC 6500 Project


If there are no ioPAC 6500 devices on hand, we suggest using this option to start a project.

**Step 1:** Choose ioAPC 6500 Project icon and select **Next**.





**Step 3:** Finally, review the project information, and then select **Create** to create a project.



# **Network Scan**

When powering up the device and connecting it to the Ethernet, use the scan function to find the device.


**Step 1:** Choose Network Scan icon and select **Scan Network**.




**Step 2:** Choose one from Scan all network, scan an IP range, and appoint a specific IP.



**Step 3:** The scanned device(s) will be displayed in the table. Choose the device, input the **Username** and **Password**, then select **Next**.



**Step 4:** Input the project information. Set up the mapping of the global variable in this step. When the setup is completed, select **Next**.



Step 4 of 4

Project Type

Project Sammary

Step 4 of 4

Project Type

Project Sammary

Step 4 of 4

Project Type

Project Sam

Project Name

Region2 project

Location

C:Users/Chase\_Shim/Documents/lift/press/Project\_2

Auto Mapping Type

Selected Devices

Model Name

Host Name

LANT MACAddress

LANT IPAddress

LANT IPADRess

LANT IPADRess

LANT IPADRess

LANT IPA

**Step 5:** Finally, review the project and device information, and then select **Create** to create a project.


# **Empty Project**

The process to open an empty project is the same as opening an ioPAC 6500 project. The only difference is there will be no pre-loaded ioPAC 6500 in the project file.

# ioPAC 6500 Configuration

The ioPAC 6500 Configuration is one of the most important parts of IINxpress. Double-click the ioPAC 6500 (ioPAC 6500) in the project tree or the icon on the toolbar to open it.

The ioPAC 6500 configuration page can be categorized into the following parts.




System Menu: The function related to the devices are listed here.

**System Status:** The diagnostic status (error or not), application status (run or stop), and connection status (which connection is established) are displayed here.

**Function Settings Detail:** The settings detail of each function is displayed here once the function was selected in the system menu.

# Home

On the home page, the function settings detail window is categorized into the following parts.



### **System Combination**

The module list of the system will be displayed here. There are some operations can be done in the system combination window.

- 1. Left select on the module: The module details will be displayed in the module detail window.
- 2. Right select on the module: You can remove and remap the variables supported by the module and import/export the module configuration.
- 3. Drag and drop the module: The module can be moved to the empty slot or be deleted.
- 4. For frequently used system combinations, select **Save as Template** ( ) to save the combination in the Template List.
- 5. Add/Remove expansion unit:

Select **Add Expansion** ( to add an expansion unit. The ioPAC 6500 Series supports up to four expansion units.

Select **Remove Expansion** ( ) to remove the expansion unit.

## 6. Mass configuration:

Select **Mass Configuration** ( ) to export/import configuration.

### > Export Configuration:


☐ Export module file (csv.)—supports only single module






☐ Export module file (xlsx.)—supports multiple modules







- $\hfill\Box$  Export Service file—see details in Service Settings
- ☐ Export POU file (xml. or xlsx.)—POU and GVL





> **Import Configuration:** Reverse the process of exporting. Choose the file that's meant to be imported, drag and drop the configuration from right to left.





7. When connecting device, please ensure there is no topology or configuration mismatch between projects and devices. If a mismatch occurs, please address it promptly (See top left yellow exclamation mark)






### **Module Detail**


The selected module details will be displayed here. The details can be grouped into three sections: **Global Variables, Module Settings, Module Information**.

### General information and settings for all modules:

• Before dragging and dropping the module into the desired slot, be sure to check the firmware version on the bottom right to avoid any incompatible issues.



• Right-select on the module to update module firmware when deemed necessary.




# 1

# NOTE


Be aware that an old project (configuration) must be updated to be compatible with hardware preloaded with newer firmware to enable the use of new functions (if applicable).

**Global Variables:** The Global Variables supported by the module will be displayed here. The module and channel will be listed as global variables, which can be used in POUs. When the device is connected, the value of variables can also be monitored as well.


• Double-click the default name to rename the Global Variable based on the application's context, which can be useful when later called in the POU.



Right-select on the module and select "Remapping Variables" to customize in a batch the affix naming
of the Global Variables.




• After renaming the Global Variables, they can simply be dragged and dropped into the POU.



**Module Settings:** The diagnostic variable and module configuration will be displayed here. See below for more detailed module information.

#### 65M-CPU14-IEC CPU module:


Configuration: There are two serial ports on the CPU module with DB9 interfaces. The parameters for serial communication can be configured as shown below.



#### 65M-1900 DI module Settings:


Enable/Disable Diagnostics:

- Field Circuit Supply Loss: To detect if field power supplying for DI contacts fails.
- Wirebreak: To detect if the wiring between the DI contact to the channel is broken.




### Configuration:

• Enable counter mode: Only Channel 1 to 8 can be configured in counter mode, while the triggering condition can be defined as rising, falling, or both.




• Filter: The filter can be set to ignore the spurious signals by waiting for a certain period before registering a valid state change.



#### 65M-2900 DO module Settings:


Enable/Disable Diagnostics:

- DO Common Power Loss: To detect if external power supplying for DO contacts fails.
- Wirebreak: To detect if the wiring between the DO unit to the channel is broken.
- Short Circuit: To detect if there is a short circuit on the DO channel.




# Configuration:

- Enable Pulse Mode: Only Channel 1 to 8 can be configured in Pulse mode. Scroll down in configuration, set the following parameters for counter mode.
- Pulse Count: Set the number of counts to output after the start.
- Low Width: Set the time of the low state in the pulse.
- High Width: Set the time of the high state in the pulse.



#### Failsafe configuration:


- Failsafe Trigger Timeout: Set timeout failsafe will be triggered after DO module communication loss.
- Failsafe Action: Set the action of each DO channel after DO module communication loss. The action of the DO channel can be OFF/ON/Hold Last.



### 65M-3600 AI (mA) module Settings:


Enable/Disable AI (mA) diagnostics:

- Loop Power Supply Loss: To detect if field power supplying for AI fails.
- Wirebreak: To detect if the wiring between the sensor to the channel is broken, which means the current value is smaller than the wirebreak threshold.
- Underflow: To detect if the current value is smaller than the underflow threshold.
- Under Range: To detect if the current value is below the range of the AI (mA) channel.
- Over Range: To detect if the current value is over the range of the AI (mA) channel.
- Overflow: To detect if the current value is larger than the overflow threshold.
- Short Circuit: To detect if there is a short circuit on the AI (mA) channel, which means the current value
  is larger than the short-circuit threshold.



#### Configuration:


- Range: 0 to 20 (mA), 4 to 20 (mA)
- The Diagnostics threshold for Wirebreak, Underflow, Over Range and Short Circuit can be adjusted.



### 65M-3610 AI (V) module Settings:


Enable/Disable AI (V) diagnostics:

- Wirebreak: To detect if the wiring between the sensor to the channel is broken, which means the voltage value is smaller than the wirebreak threshold.
- Underflow: To detect if the voltage value is smaller than the underflow threshold.
- Under Range: To detect if the voltage value is below the range of the AI (V) channel.
- Over Range: To detect if the voltage value is over the range of the AI (V) channel.
- Overflow: To detect if the voltage value is larger than the overflow threshold.



### Configuration:


- Range: 1 to 5 (V), 0 to 10 (V)
- The Diagnostics threshold for Wirebreak, Underflow, and Overflow can be adjusted.



### 65M-4820 AO module Settings:


Enable/Disable AO diagnostics:

- Wirebreak: To detect if the wiring between the AO unit to the channel is broken.
- Short Circuit: To detect if there is a short circuit on the AO channel.




### Configuration:

• Configure the Range of the AO channel. Choose 0 to 0 VDC / 1 to 5 VDC / 0 to 20 mA / 4 to 20 mA.



· Set the parameters for Failsafe.

**Failsafe Trigger Timeout:** Set timeout failsafe will be triggered after AO module communication loss. **Failsafe Action:** Set the action of each AO channel after AO module communication loss. The action of the AO channel can be Zero Output / User-defined Value / Hold Last.



### 65M-3800H HART AI (mA) module Settings:


Global Variable:

PV, SV, TV, QV Setting—After configuring PV, SV, TV, and QV via PACTware, these data will also be sent to IINxpress (ioPAC 6500 IDE Utility Software) and can be accessed in the POU. Make sure the HART is enabled.




### **NOTE**

For detailed PACTware configuration guidance, refer to "ioPAC 6500 Series HART Module Configuration Manual—PACTware"




Enable/Disable AI (mA) diagnostics:

- Loop Power Supply Loss: To detect if field power supplying for AI fails.
- Wirebreak: To detect if the wiring between the sensor to the channel is broken, which means the current value is smaller than the wirebreak threshold.
- Underflow: To detect if the current value is smaller than the underflow threshold.
- Under Range: To detect if the current value is below the range of the AI (mA) channel.
- Over Range: To detect if the current value is over the range of the AI (mA) channel.
- Overflow: To detect if the current value is larger than the overflow threshold.
- Short Circuit: To detect if there is a short circuit on the AI (mA) channel, which means the current value is larger than the short-circuit threshold.



#### Configuration:


- Channel Enable/Disable (Default Enabled): The disabled channel will be skipped when polling.
- HART Enable/Disable (Default Disabled): The disabled channel is used as a regular 4-20 (mA) AI. Check "enable" box if HART field device is used.
- The range is set to be 4-20 (mA) and can't be adjusted.
- The threshold for Wirebreak, Underflow, Overflow, and Short Circuit can be adjusted.



#### 65M-5801 Serial module Settings:

#### Configuration:

• Interface, Baud rate, Parity, Data bits, Stop bits and Flow control can be adjusted in configuration.



**Module Information:** The module information (e.g., firmware version, module serial number, LED status, serial status, mode switch, etc.) will be displayed here. IINxpress shows product specifications here for reference. **Connect the device** to access information.



#### **NOTE**

All the information and settings of the switch module can be completed in the web interface of the switch module. Select the link in the module detail page, and the web interface of the switch module will open in the default browser.

#### **Module Selector**

The available modules are listed here. Drag and drop the selected module to the system combination window for the system setup. Follow the steps to set up the system combination.

- Choose the backplane module: The ioPAC 6500 is fully modular design. Drag and drop the needed backplane module in designated order.
- Choose the other modules: Drag and drop other modules to the designated slot. The module can only be placed on the corresponding backplane. The restricted sign will appear when you drag a module to an unsupported backplane, reminding you not to place it in the slot.

IINxpress also supports the template list. Drag and drop the whole system combination and make some minor changes to meet your application's requirements. IINxpress provides small, medium, and large scale as template. You can also reuse a system combination that you saved previously.

#### **Module Property Selector**


When you select an available module, you will see its properties displayed here. Choose the property version here to match the combination you need.

## **System**

All the system information, settings, and configuration can be found on the system page.


#### **System Information**

System identification (model name, serial number, device name), device information (system uptime, CPU/memory usage), runtime/OS version, network information, and time can be found here. All the information is read-only.



#### **Service Status**

It shows the status of all supported services, which include the Modbus TCP/RTU Server/Client, DNP3 outstation, OPC UA, etc.



#### Reset/Restart

There are several reset/restart types supported by ioPAC 6500, and all of them are listed on the page. Select an action first, then select Run. A pop-up warning message will appear. Follow the instructions to complete the reset/restart process.




#### **NOTE**

Resetting or restarting the system will clear different system information. Make sure to read the table before performing the rest/restart process.




#### **NOTE**

Push the reset button to complete the **Reset Factory Default** and **Device Decommission**. Follow the instructions to complete the process.



#### Backup/Restore

Back up and restore the system configuration on this page.



Follow these steps to back up the system configuration.

- 1. Key in the password.
- 2. Select the **Backup** button and choose where you want to save the configuration file. The password length is required to be between 8 and 63 characteristics.

Follow these steps to restore the system configuration.

- 1. Key in the password
- 2. Choose to overwrite the network and account settings or not.
  - > Overwrite the network settings: The restore process will overwrite the network settings. The system's Ethernet connection might be lost during the restoration.
  - > Overwrite the account settings: The restore process will overwrite the account settings. The account you are using might not be available anymore.
- 3. Select the **Restore** button and choose the configuration file which you want to restore.


# **Diagnostic**

The diagnostic information will be displayed on the Diagnostic page. The error and warning messages that are persistent can be found in the Error and Warning tab, respectively.



#### **NOTE**

Diagnostics will not display the error and warning messages that occur once.




# Log Manager

All the logs will be stored inside the ioPAC 6500 system. Use IINxpress to retrieve the log and show in IINxpress. IINxpress can perform five actions in a log.

- **Retrieve:** Retrieves the log from the device and shows it in IINxpress.
- Delete: Deletes the log stored in the device.
- Backup: Back ups the displayed log to the file.
- Open: Opens the backup log file.
- Clear: Clears the log list in IINxpress. This action will not clear the log inside the device.

For the detailed log list, refer to the log section of the web interface.




# **Account Manager**

The account and its authority can be managed on the Account Manager page. Account manager settings consist of three main parts.

#### **Users and Groups**

On this page, make changes related to the users and groups. All user accounts will be displayed on this page. Choose to show in User view and Group view. In the ioPAC 6500 system, the login property of account belongs to the user group.




#### Add User

When you want to create a new user account, select the **Add User** and a window will pop up. Once you confirmed all the account property and group assignments, select OK to complete the account creation.




#### **NOTE**

Before editing the users and groups, make sure the login account has permission to change the account settings.




#### **Add Group**

When you want to create a new user group, select the **Add Group** and a window will pop up. Specify the group name and assign the user accounts to the group. For the group property, change in Access Rights tab.




#### **Access Rights**

Change the property of the group on the Access Rights page. You cannot change the authority of the default 8 groups. You can only change the authority of the user-created group.



#### **Information**

The information will display the current password policy. It can only be modified on the system webpage. When IINxpress connects the device, the latest password policy will be loaded automatically. For the details about the password policy, refer to the Account Manager section on the webpage.



## **Firmware Update**


IINxpress also allows you to update the firmware to the system. Follow the following three steps to complete the firmware update.

- 1. **Select Firmware File:** Select to choose the firmware file that needs to be updated to the system. The firmware file can be chosen from the local disk or a SFTP from a remote site. You can also select the Release Notes button to check the release details.
- 2. **Select Module on List:** Select the modules that need to be updated on the **Module List**. Use the module filter to speed up the module selection. The module list will display module information.
  - ➤ **Slot:** Shows the slot where the module is installed. The system combination determines the slot number. The number 1 shows the left-most module of each unit. The slot of the backplane module will be displayed with a number in square brackets, e.g., [1].
  - > **Type:** It shows the module type. E.g., CPU, DI, backplane, etc.
  - > Model Name: The model name of the module will be displayed here.
  - > Current Version: The current firmware version of the module will be displayed here.
  - > **Update Version:** The firmware version included in this firmware file will be displayed here.
  - > **Progress(%):** The updated progress will be here.
  - Note: Any other information that cannot be categorized will be displayed here.
- Update: Select Update to start the system firmware update. Choose Update Firmware One by One to update the firmware module by module.



#### **NOTE**

Update the switch module's firmware on the web page of the switch module.



# **Service Settings**

The ioPAC 6500 system provides a protocol service to lower your programming effort. Use the protocol service to collect data from other devices and use the collected data in the program or deliver to the upper-level system.


#### **General Information for All Services**

**Import, Export, and POU Helper:** They can be seen in each of the service pages, prompting easier mass configuration and better service management.




**Export:** Drag and drop the service from Service Tree to Export Service. The configuration will be stored as .xlsx file.





**Import:** Select the desired .xlsx file. Drag and drop from import service to service tree. Blue text indicates the services that are expected to be imported





#### **NOTE**


When importing the service configuration, the system checks the following:

- 1. When a new variable is specified, the system checks whether the variable name already exists. If a duplicate is found, the variable cannot be created, and the importing operation will be blocked.
- 2. When an existing variable is specified, the system checks whether it is an I/O variable. If so, the system will attempt to generate the corresponding IOGVL. If the generation fails, the importing operation will also be blocked.

Uncheck the "Global Variable" in import Configurations, if variables importing is not needed.




**POU Helper:** POU Helper shows detailed information on how sources and variables are mapped, as the data exchange between service and I/O points are carried out via POU. Select **Load** to get the status. Select **Clear** to delete everything.





#### **NOTE**


If "Remove", "Rename" or "Recreate" appears in the suggestion, revisit the configuration within your application or select **Repair**.





#### **NOTE**

When mapping the variables, a message tells you that a variable was automatically created. Select OK to proceed.



#### **Modbus TCP Client**

Modbus TCP Client can collect data from up to 32 Modbus TCP servers. To add a Modbus TCP client, clselectick the Add button and a new Modbus client profile will be added to the Service List. All properties of the Modbus TCP client are categorized into **Basic Settings**, **Command Settings**, and **Tag Settings**.

**Basic Settings:** Enable the service, set up the Server IP Address, Server ID, Server port, and response timeout on this page.







#### **NOTE**

Double-click the Name (ModbusTCPClient\_1) on the Service list to rename.

**Command Settings:** Create command profiles to read from or write to Modbus TCP Server devices. Select **Add** and configure the command property on the right-hand side, e.g., Function Code, Start Address, Read Quantity, etc.




**Tag Settings:** The data array created on the Command Settings page will automatically appear on the Tag Settings page. Select **Set** to map the variables. Alternatively, follow the steps below to create tags manually.




#### **Modbus TCP Server**

Modbus TCP Server services can provide data to other Modbus TCP Client systems. All properties of the Modbus TCP Client are categorized into **Basic Settings**, **Function Settings**, **Variable Mapping**, and **Tag Summary**.


Basic Settings: Enable Service, Listen Port, Keep Alive Time and Server ID can be configured here.




**Function Settings:** The ioPAC 6500 supports the function types: Coil, Discrete Input, Holding Register, and Input Register. Set up the tag quantity in the Function Settings based on the application. Follow the steps below to configure the functions.



**Variable Mapping:** The tag quantity defined in Function Settings will appear here automatically. Sort the variables in the Variable List, then drag and drop them into the array to complete data mapping.




Tag Summary: Overview of all tags




#### **Modbus RTU Client**

The ioPAC 6500 system also supports the Modbus RTU client service. The only difference between Modbus TCP and RTU client service is the COM Port settings, which can be found on the basic setting page.


**Basic Settings:** Select **Add**, Enable Service, COM Port, Server ID, and Response Timeout can be configured here.



**Command Settings:** Create command profiles to read from or write to Modbus RTU Server devices. Select **Add** and configure the command property on the right-hand side, e.g., Function Code, Start Address, Read Quantity, etc.




**Tag Settings:** The data array created on the Command Settings page will automatically appear on the Tag Settings page. Select **Set** to map the variables. Alternatively, follow the steps below to create tags manually.



#### **DNP3 Outstation**

DNP3 Outstation services can be used to provide data to other systems via DNP3 protocol. All properties of the DNP3 Outstation are categorized into **Basic Settings**, **Advanced Settings**, and **Tag Settings**.


**Basic Settings:** The basic settings page provides the essential functions, such as port, Network Type, etc., for you to set up. Multi-master can be enabled on this page as well. The ioPAC 6500 Series supports up to 2 clients. When the DNP 3 Outstation service is enabled, the first client is set to enabled.



#### **Advanced settings**


**Security settings:** These settings configure DNP3 Secure Authentication (SA) to protect communication between master and outstation from spoofing, tampering, or replay attacks.

**Authenticated User List:** This list defines who may operate or view. Please type the authentication update key before checking the "Enable User" box.



Item	Description	
Enable Secure Authentication	Enables DNP3 Secure Authentication. Required to authenticate	
Litable Secure Authentication	control commands or data exchanges.	
Authenticated Response Timeout (ms)	Time (in milliseconds) the outstation waits for a "challenge"	
Authenticated Response Timeout (IIIs)	response from the client. If exceeded, the request is rejected.	
Support Aggressive Mode	When enabled, the outstation proactively initiates challenge.	
Max Session Key Change Count	The number of authenticated operations before a new session key	
Max Session key change count	must be generated. Enhances security by limiting key reuse.	
Session Key Change Interval (ms)	Minimum time interval (in milliseconds) between session key	
Session key Change Interval (IIIs)	changes. Prevents overly frequent updates.	
Event Class of Authentication	Defines the class of authentication events.	
	Specifies the Message Authentication Code (MAC) algorithm.	
MAC Algorithm	3 options are available: SHA1_Oct10, SHA256_Oct16 and	
	AES_GMAC.	

#### **Unsolicited and event settings:**




Item	Description		
Unsolicited Confirm Timeout (ms)	Timeout for waiting for an application layer confirmation (ACK) from		
onsolicited Commit Timeout (ms)	the client after the outstation sends an unsolicited message.		
Unsolicited Response Retry	Number of retries if the unsolicited message is not confirmed.		
Unsolicited Class (X) Max Delay (ms)	Maximum delay allowed before the outstation sends an unsolicited		
Unsuicited Class (A) Max Delay (IIIs)	message if any events are waiting in each class.		
Uncelligited Class (V) May Events	Limits how many events of each class are bundled into a single		
Unsolicited Class (X) Max Events	unsolicited response.		
Event Buffer Overflow	What would be dropped if buffer overflows? Two options are		
Event Burier Overnow	available: Drop Oldest or Drop Latest.		
BI Event Buffer Size	Number of Binary Input events stored		
BO Event Buffer Size	Number of Binary Output events stored		
Counter Event Buffer Size	Number of Counter events (e.g., pulse count changes) stored		
Frozen Counter Buffer Size	Number of frozen counters (e.g., snapshots) values stored		
AI Event Buffer Size	Number of Analog Input changes stored		
AO Event Buffer Size	Number of Analog Output feedback or confirmation events stored		

#### **Data Link Layer Settings:**




Item	Description	
Enable Data Link Layer	Enables data link layer functions	
Data Link Layer Confirm Timeout (ms)	Time to wait for data link acknowledgment before retrying	
II)ata Link Laver ("onfirm Max Refry	Number of times the outstation will retry a message if the link-	
	layer acknowledgment isn't received	

#### Other Settings:




Item	Description	
Application Confirm Timeout	The time the outstation waits for an application-layer confirmation (APPL-	
Application Committee Timeout	CONFIRM) after sending a message that requires one.	
Keepalive Period	Interval at which the outstation sends an idle test message. If no activity	
Reepailve Period	has occurred, to keep the session alive.	
Enable Time Sync	Whether the outstation allows the client to synchronize its internal clock.	
Time Sync Period	How often does the outstation expect a time sync.	
Select Control Timeout	Time allowed between the Select and Operate commands in a Select-	
Select Control Timeout	Before-Operate (SBO) control.	

Tag settings: Follow the steps below to configure Tags



**Local Mode:** The DNP3 Outstation service in ioPAC 6500 system supports Local Mode. It prevents all output categories, including TYPE\_BO and TYPE\_AO, from being remotely controlled when the ioPAC 6500 is connected locally, ensuring the safety of field site personnel. To enable/disable the Local Mode, steps are as follows: Download Application (Connect the device) > Select **Get Status > Select Point > Enable/Disable Local Mode.** 



Flag: Log in to application to see the flag status.

OL	RS	CL	RF	LF	CF	RE	ST
Online	Restart	Comm Lost	Remote	Local	Chatter	Reserved	State
Offilitie	Restart	Comm Lost	Forced	Forced	Filter	Reserveu	State




#### **OPC UA Server**

OPC UA Server services can be used to provide data to other systems via the OPC UA protocol. All properties of the OPC UA are categorized into **Basic Settings**, **Tag Settings**, and **Variable Mapping**.

**Basic Settings:** The Basic Function Settings page provides the essential functions setup, including General Settings, Session Settings, and Subscription Settings.

#### **General Settings:**




#### Session Settings:




Items	Description	
Max Session	Maximum number of concurrent client sessions allowed	
Min Lifetime (ms)	Minimum time (in milliseconds) a session is held before being eligible for termination.	
Max Lifetime (ms)	Maximum duration a session can stay active without being renewed by the client.	

#### **Subscription Settings:**




Items	Description			
Number of Subscriptions	Maximum number of concurrent OPC UA subscriptions the server will allow.			
Max number of notifications per	Limits how many data change events are sent in a single publish			
publish	response.			
Min Publish Interval (ms)	Minimum interval for sending published responses.			
Max Publish Interval (ms)	Maximum interval for sending published responses.			
Number of Monitored Items	Max number of variables (tags) that can be monitored across all			
Number of Monitored Items	subscriptions.			
Min Sampling Interval (ms)	Fastest rate at which a monitored item is sampled.			
Max Sampling Interval (ms)	The slowest rate at which a monitored item is sampled.			
Max size of monitored item's queue	The number of historical values stored in the queue per monitored			
linax size of monitored item's queue	item.			
Min number of subscription lifetime	Minimum amount of time a subscription remains valid without			
(ms)	interaction.			
Max number of subscription lifetime	Maximum allowable time a subscription can exist before it's deleted.			
(ms)	inaximum anowable time a subscription can exist before it's deleted.			

**Tag Settings:** The ioPAC 6500 supports multiple data types to suit various applications. Each type allows up to 200 tags, with a total limit of 2,000 tags. Up to three names can be assigned to each tag for identification purposes. Follow the steps below to configure tags.



**Variable Mapping:** The tag quantity defined in Tag Settings will appear here automatically. Sort the variables in the Variable List, then drag and drop them into the array to complete data mapping. Follow the step below to map variables.



# **System Status**

In the ioPAC 6500 Configuration page, the system status is at the left-bottom corner. The Diagnositc Status, Application Status, and Connection Status will be displayed here. Log in the system and all status will be displayed here.

**Diagnostic Status:** Diagnostic Status: Warnings and errors will trigger an alert here, reminding you to check the status. Select the icon and open the Diagnostic page to review the status.


**Application Status:** Shows the system is in run or stop mode.

Connection Status: Shows which accounts are logged into the system.




# **Library Manager**

Double-click the Library Manger in the project tree, and the Library Manager page will show in the main window. The libraries supported by IINxpress can be found here. Besides the standard library, Moxa also provides the AGA3, 5, 8 libraries for oil-and-gas applications.




# **POU**

POU stands for Programming Organization Unit, where you can develop your application. Add the POU by the path **Application (right-select) > Add Objects > POU**.



Once opening the POU, you will see the following window. Specify the information you need, then select **Add** to create the POU.



Name: The name to identify the program.

Type: You can choose from three different types.

- Program: These POUs contain logical control or function block calls.
- **Function Block:** These are POUs with multiple input and output parameters and can be called into other programs.
- Function: These are POUs with multiple input parameters and only one output parameter.

**Implemented language:** You can choose the familiar IEC 61131-3 language to develop the program. The following languages are supported.


- Continuous Function Chart (CFC)
- Function Block Diagram (FBD)
- Ladder Logic Diagram (LD)
- Sequential Function Chart (SFC)
- Structured Test (ST)

After selecting **Add**, one POU page will be created. You will see the following page.


The POU window can be separated into two parts. You can define the local variable on the upper side. The lower side is where you develop your own program.

# **GVL**

If you have the global variable demand, you can create the global variables by the path **Application** (right-select) > Add Objects > GVL.



Define the global variable in the window, and these global variables can be used in the program. Add an "GVL." prefix to distinguish the variables are local or global.



# **6. Switch Module Configuration**

# **About this Chapter**

In this chapter, learn how to connect your switch module with various interfaces and how to configure all settings and parameters via the user-friendly web interface.

# **Meanings of the Symbols in the Web Interface Configurations**

The Web Interface Configuration includes various symbols. Refer to the following table for the meanings of the symbols.

Symbols	Meanings
+	Add
	Read detailed information
=	Clear all
=,	Column selection
G	Refresh
8	Enable/Disable Auto Save When Auto Save is disabled, users need to select this icon to save the configurations.
•	Export*
ľ	Edit
\$	Re-authentication
Ì	Delete
K X K Y	Panel View
~	Expand
^	Collapse
0	Hint Information
主	Settings
→←	Data Comparison
:	Menu icon
<b>\$</b> 1	Change mode
•	Locator
ф	Reboot

Symbols	Meanings
Ð	Reset to default
€	Logout
<b>1</b>	Increase
$\downarrow$	Decrease
<b>*</b>	Equal
=	Menu
Q	Search
Ø	Hide text that is typed into a text box (usually used when typing a password)
0	Show text typed into a text box (usually used when providing password)


<sup>\*</sup>The **Export** function helps you save the current configurations or information for the specific functions. It is on the upper part of the configuration area. Two formats are available: CVS or PDF. Select the format and save it on your local computer.



# **Configuration Reminders**

In this section, several examples will remind you when configuring the settings for a switch module.

### **A: About Mandatory Parameters**




- 1. The items with asterisks mean they are mandatory parameters that must be provided. In the figure above, the parameters for VLAN, Version, and Query Interval need to be provided, or it will not be created or applied.
- 2. If the item is marked with red, it means this item has been skipped. Fill in the parameters or you cannot apply or create the function.

In addition, some parameter values will be limited to a specific range. If the values exceed the range, they cannot be applied or created.

#### **B: Configurations before Enable/Disable**

In another situation, some settings can be configured first but remain disabled. Enable them, when necessary, without configuring the same settings again. This is particularly convenient and user-friendly when configuring various settings. For example, on the **DHCP Server** configuration page, configure the **DHCP** settings first, but later select to disable the **DHCP** settings in the **General** tab. When enabling the **DHCP** settings, only select **Enable** in **General** settings, so that the **DHCP** settings (either **MAC-based IP Assignment** or **Port-based IP Assignment** as shown as an example in the following figure) can be enabled at the same time.



# **Getting Started**


In this section, we explain how to log in a switch module for the first time. There are three ways to access the switch module's configuration settings: RS-232 console, Telnet (disabled by default) or web-based interface.

# Log in by Web Interface

Directly connect the switch module to your computer with a standard network cable or install your computer at the same intranet as your switch. Then you need to configure your computer's network setting. The default IP address for the switch module is based on the slot index value:

#### 192.168.127.101-102

For example, configure the computer's IP setting as **192.168.127.99**, and the subnet mask as 255.255.255.0.



Select **OK** when finished.

## **Connecting to the Switch**

Open a browser, such as Google Chrome, Internet Explorer 11, or Firefox, and connect to the following IP address based on the corresponding slot index value.

#### 1-slot Communication Module Backplane

Index Value		0	
	IP Address	192.168.127.101	

#### 2-slot Communication Module Backplane

Index Value	0	1
IP Address	192.168.127.101	192.168.127.102



#### **NOTE**

For network security consideration, all HTTP connections will be automatically redirected to HTTPS connections. The web browser will display a warning message if the device uses a certificate which isn't signed by the certification authority. You may add an exception rule for the certificate in the web browser to continue. We recommend using a certificate signed by a certification authority for security reasons. Refer to "Security > Device Security > SSH & SSL > SSL" for the configuration steps.

The default username and password are:

Username: **admin** Password: **moxa** 

Select **LOG IN** to continue. If you have logged in before, you will see a screen showing the previous login records. Select **CLOSE**.

#### **Login Records**

Welcome admin

The last successful login time was 2018-12-27 18:00:03.

CLOSE

Another system message will appear, reminding you to change the default password. We recommend you change your password, or a message will appear whenever you log in. Change the password in the **Account Management** section. Select **CLOSE** to continue.




# Log In by RS-232 Console

The ioPAC 6500 Layer 2 Managed Ethernet Switch Module offers a serial console port, allowing you to connect to the switch and configure the settings. Do the following steps for the serial connection and configuration.


- 1. Prepare an RS-232 serial cable with an RJ45 interface.
- 2. Connect the RJ45 interface to the console port on the switch, and the other end to the computer.
- 3. We recommend you use **PComm Terminal Emulator** for serial communication. Download the software free from Moxa's website.

After installing PComm Terminal Emulator, open the switch module's console:


1. From the Windows desktop, select **Start > Moxa > PComm Terminal Emulator**.




2. Select **Open** under the **Port Manager** menu to open a new connection.




The Property window will open. On the Communication Parameter tab for Ports, select the COM port that is being used for the console connection. Set the other fields: 115200 for Baud Rate, 8 for Data Bits, None for Parity, and 1 for Stop Bits.



4. On the **Terminal** tab, select **VT100** for **Terminal Type**, and then select **OK** to continue.



5. The console will prompt you to log in. The default login name is **admin**, and the default password is **moxa**. This password will be required to access any of the consoles (web, serial, Telnet).



6. After successfully connecting to the switch by serial console, start configuring the switch parameters by using command line instructions. Refer to the **Moxa Command Line Interface Manual**.



#### **NOTE**

By default, the password assigned to the switch module is **moxa**. Be sure to change the default password after you first log in to help keep your system secure.

# Log In by Telnet



## NOTE

The Telnet protocol is disabled by default. Go to the **Security > Device Security > Management Interface** section to enable the telnet function first.

Opening the switch module's Telnet or web console over a network requires that the PC host and switch module are on the same logical subnet. You might need to adjust your PC host's IP address and subnet mask. By default, the switch module's IP is based on the slot index value:(192.168.127.101-102) and the switch module's subnet mask is 255.255.255.0. If the subnet mask is 255.255.0.0, you must set your PC's IP address to 192.168.xxx.xxx. If the subnet mask is 255.255.255.0, you must set your PC's IP address to 192.168.127.xxx.



#### NOTE

When connecting to the switch module's Telnet or web console, first connect one of the switch module's Ethernet ports to your Ethernet LAN, or directly to your PC's Ethernet port. Use either a straight-through or crossover Ethernet cable.




## **NOTE**


The Moxa switch's default IP address is 192.168.127.101-102 (by slot index).

After making sure that the switch module is connected to the same LAN and logical subnet as your PC, open the switch module's Telnet console:

1. Select **Start > Run** from the Windows Start menu and then Telnet to the switch module's IP address from the Windows **Run** window. You can also issue the Telnet command from a DOS prompt.



2. Next, use Telnet to connect the switch module's IP address (192.168.127.101~104) from the Windows **Run** window. You can also issue the Telnet command from a DOS prompt.



3. The Telnet console will prompt you to log in. The default login name is **admin**, and the password is **moxa**. This password will be required to access any of the consoles (web, serial, Telnet).

```
moxa login: admin
Password:
Welcome to MOXA command shell
Current time is Friday, December 21, 2018, 08:51 PM

Please change the default username and password in order to enhance security.

moxa# _
```

4. After successfully connecting to the switch by Telnet, start configuring the switch parameters by using command line instructions. Refer to the **Moxa Command-line Interface Manual**.



## **NOTE**


By default, the password assigned to the switch module is moxa. Be sure to change the default password after you first log in to help keep your system secure.

# **Web Interface Configuration**

The ioPAC 6500 Layer 2 Managed Ethernet Switch Module offers a user-friendly web interface for easy configurations. It is easy to configure various settings over the web interface. All configurations for the switch module can be easily set up and done via this web interface, essentially reducing system maintenance and configuration effort.

#### **Function Introduction**


This section describes the web interface design, providing a basic visual concept for users to understand the main information or configuration menu for the web interface pages.



- 1. Login Name: It shows the role of the login name.
- 2. Configuration Mode: Two modes can be shown: Standard Mode and Advanced Mode.
  - Standard Mode: Some features and parameters will be hidden to make the configurations simpler (default).
  - > **Advanced Mode:** More features and parameters will be shown for you to configure detailed settings.
- 3. **Search Bar:** Type the items you want to search for in the function menu tree.
- Function Menu: Functions of the switch are shown here. Select the function you want to view or configure.
- 5. Device Summary: Important device information of the functions will be shown here.

# **Device Summary**


After successfully connecting to the switch, the **Device Summary** will automatically appear. View the whole web interface on the screen. If you are in the middle of performing configurations, select Device Summary on the Function Menu and you can view the detailed information of the switch.



See the following sections for detailed descriptions of the specific items.


# **System Information**

This shows the system information, including the product model name, product revision, serial number, firmware version, system uptime, etc.




## **Panel Status**

This section illustrates the panel status. For example, the connecting ports will be shown in green, while the disconnected ports will be shown in gray. Select **EXPAND** to view more detailed information on the panel status and select **Collapse** to return.



Select EXPAND to view more detailed information on the panel status and select COLLAPSE to return.




# **Panel View**

This appearance of the panel view figure depends on which model is being used. So, what you see might differ from the panel view shown below.




# **Event Summary (Last 3 Days)**

This section shows the event summary for the past three days.




Select **VIEW ALL EVENTS LOGS** to go to the Event Log page, where you can view the event logs.



For Event Log settings, refer to **Event Log** under the **Diagnosis** section.


# **CPU Utilization History**

This section shows the CPU usage. The data will be shown as a percentage over time. Select the refresh icon on the page to show the latest information.




# **System**

Select **System** on the function menu. Configure the **System Management, Account Management, Network,** and **Time** configurations.




# **System Management**

Select **System Management**, four functions can be configured under this section: **Information Setting**, **Firmware Upgrade**, **Configure Backup and Restore**, and **Event Log Backup**.



# **Information Setting**

Define **Information Setting** items to make it easier to identify different switches that are connected to your network.



#### Device Name

Setting	Description	Factory Default
1 to 64 characters	This option is useful for differentiating between the roles or applications of different units. Note that the device name cannot be empty.	moxa



# **NOTE**

The Device Name field follows the PROFINET I/O naming rule. The name can only include the following characters,  $\mathbf{a}$ - $\mathbf{z}$ / $\mathbf{0}$ - $\mathbf{9}$ /-.

## Location

Setting	Description	Factory Default
Max. 255 characters	This option is for differentiating between the locations of	None
Max. 233 Characters	different switches. Example: production line 1.	None

# Description

Setting	Description	Factory Default
Max. 255 characters	This option is for recording a more detailed description of the unit.	None

## **Contact Information**

Setting	Description	Factory Default
Max. 255 characters	Input contact information, such as email address, or telephone	None
Max. 255 Characters	number when problems occur.	None


When finished, select **APPLY** to save your changes.

# Firmware Upgrade

There are three ways to update your switch module's firmware: from a local \*.rom file, by remote SFTP server, and remote TFTP server.

#### Local

Select **Local** tab.




#### Select File

Before performing firmware upgrade, download the updated firmware (\*.rom) file first from Moxa's website (www.moxa.com).

Setting	Description	Factory Default
Isoloct the tirmware tile	Select the icon on the right and select the firmware file from the location where the updated firmware is located.	None
Browse for the (*.rom)	This option allows you to select the undated firmware file and	None

## **SFTP**

Select **SFTP** tab.



#### Server IP Address

Setting	Description	Factory Default
Input the IP address of	Input the server IP address of the computer where the new	None
the SFTP server.	firmware file (*.rom) is located.	

#### Account

Setting	Description	Factory Default
Input the account of	The account must be authorized for the SFTP Server to have a	None
the SFTP server	secure connection.	None

#### Password

Setting	Description	Factory Default
Input the password for	The account must be specified to authorize the SFTP Server	None
the SFTP server	for secure connection.	None

## File Name

Setting	Description	Factory Default
Input the filename of	Input the filename of the new firmware.	None
the firmware	input the illename of the new firmware.	None

When finished, select **UPGRADE** to perform the firmware upgrade. The switch will reboot automatically and perform the firmware upgrade.

#### **TFTP Server**

Upgrade firmware via the TFTP server. Select **TFTP** tab first.



#### Server IP Address

Setting	Description	Factory Default
Input the IP address of	Input the IP address of the TFTP server where the new	None
the TFTP server	firmware file (*.rom) is located.	None


# File Name

Setting	Description	Factory Default
Input the filename of	Input the filename of the new firmware.	None
the firmware	input the mename of the new firmware.	None

When finished, select  ${\bf UPGRADE}$  to perform the firmware upgrade.

## **USB**

Upgrade the firmware via Moxa's USB-based ABC-02 configuration tool. Connect the ABC-02 to the switch and select **USB** from the drop-down list under **Method**.



#### Select File

Before performing the firmware upgrade, download the latest firmware (\*.rom) file first from Moxa's website (www.moxa.com).

Setting	Description	Factory Default
Select the firmware file	Select the firmware file from the location where the updated	None
Select the infilware me	firmware is located.	
Browse for the (*.rom)	This option allows you to select the updated firmware file and	None
file	perform the firmware upgrade.	None

When finished, select **UPGRADE** to perform the firmware upgrade.



#### **Note**


If you have difficulty using the ABC-02 configuration tool, check if the **USB Function** has been enabled in the **Hardware Interface** section.

# **Configuration Backup and Restore**

Back up the configurations of your switch module in five ways: using a local configuration file, a remote SFTP server, a remote TFTP server, or a USB tool.

#### Local

Select **Local** tab first.



#### **Configuration Selection**

Setting	Description	Factory Default
Running Configuration	Back up the running configuration.	Running
Startup Configuration	Back up the start-up configuration.	Configuration

## **Default Configuration**


Setting	Description	Factory Default
Not Included	Back up the configuration without default settings.	Not Included
Included	Back up the configuration with default settings.	Not Included

## Select File

Setting	Description	Factory Default
Select the Backup button to back up the configuration file to a local drive.	Back up the system file to your local computer.	None
Browse for a configuration file on a local disk, and then select the <b>RESTORE</b> button.	Select the configuration file and perform system restoration.	None

# **SFTP Server**

Select **the SFTP** tab first.



## Server IP Address

Setting	Description	Factory Default
Input the IP address of	Input the IP address of the SFTP server where the new	None
the SFTP server	firmware file (*.rom) is located.	NOTIE

#### Account

Setting	Description	Factory Default
Input the account of	An account must be provided to authorize the SFTP server for	None
the SFTP server	a secure connection.	

#### Password

Setting	Description	Factory Default
Input the passwords for	The password has to be specified to authorize the SFTP Server	Nono
the SFTP server	for secure connection.	None


## File Name

Setting	Description	Factory Default
Input the	Input the filename of the configuration backup or restoration No file.	None
backup/restore file		
Iname (support up to 54)		
characters, including		
the .ini file extension).		

When finished, select **BACKUP** or **RESTORE** to back up or restore the system configuration file.

#### **TFTP Server**

Select TFTP tab first.



#### Server IP Address

Setting	Description	Factory Default
Input the IP address of	Input the IP address of the TFTP server.	None
the TFTP server	imput the ir address of the H IP server.	INOTIC


#### File Name

Setting	Description	Factory Default
Input the		
backup/restore file	Input the filename to back up or restore the system	
name (supports up to	configuration file.	None
54 characters, including		
the .ini file extension).		

When finished, select **BACKUP** or **RESTORE** to perform the firmware upgrade.

#### **USB**

Select **USB** from the drop-down list under **Method**.



Insert Moxa's ABC-02 USB-based configuration tool into the USB port of the switch, select **BACKUP** to back up the system configuration file.




# Note

If you have difficulty using the ABC-02 configuration tool, check if the **USB Function** has been enabled in the **Hardware Interface** section.

# **File Encryption**

To encrypt the configuration file, select the **File Encryption** tab first.



#### Enable Configuration File Encryption

Setting	Description	Factory Default
Enabled	Enable the configuration file to be encrypted.	
Disabled	Disable the feature that allows the configuration file to be	Disabled
Disableu	encrypted.	


#### Password

Setting	Description	Factory Default
4 to 16 characters,	Input the password when you encrypt the configuration file.	None
numbers only.	Imput the password when you entrypt the configuration file.	None

When finished, select **APPLY** to save your changes.

## File Signature

Select **File Signature** tab to see additional configuration options. Enabling the file signature can ensure file integrity and authenticity.




## **Enable Signed Configuration**

Setting	Description	Factory Default
Enabled	Enable the configuration file signature.	Disabled
Disabled	Disable the configuration file signature	

Select **APPLY** to save your changes.

Select + icon to add customer key.



#### Label

Setting	Description	Factory Default
0 to 16 characters	Provide the name for the certificate and the key.	None

#### Certificate

Setting	Description	Factory Default
Select the import file		
icon to select the file	Import the certificate file.	None
from your computer		

#### Key

Setting	Description	Factory Default
Select the import file		
icon to select the file	Import the key file.	None
from your computer		


When finished, select **CREATE** to save your changes.

# **Event Log Backup**

Three methods exist for backing up switch module's log files: using a local drive, through a remote SFTP server, or via remote TFTP.

## Local


Select Local tab.



Select **BACKUP** to back up the log file to a local drive.

# **SFTP Server**

Select **SFTP** tab.



# Server IP Address

Setting	Description	Factory Default
Input the IP address of	Input the IP address of the SFTP server.	None
the SFTP server	input the 1P address of the SFTP server.	None

## Port

Setting	Description	Factory Default
Input the port of the		
SFTP server, 1 to	Specify the port used in the SFTP server.	None
65535		

#### Account

Setting	Description	Factory Default
Input the account of	An account must be specified to authorize the SFTP server for	None
the SFTP server	a secure connection.	

#### Password

Setting	Description	Factory Default
Input the password for	The password must be entered to authorize the SFTP server	None
the SFTP server	for a secure connection.	None


## File Name

Setting	Description	Factory Default
Input the file name for	Input the filename of the event log.	None
event log backup	input the mename of the event log.	INOTIC

When finished, select **BACKUP** to back up the event log file.

## **TFTP Server**

Select **TFTP** tab.



#### Server IP Address

Setting	Description	Factory Default
Input the IP address of	Input the IP address of the TFTP server.	None
the TFTP server		

#### Port

Setting	Description	Factory Default
Input the port of the		
TFTP server, 1 to	Input the port used in the TFTP server.	None
65535		


#### File Name

Setting	Description	Factory Default
Input the file name for	Input the filename of the event log.	None
event log backup		

When finished, select  $\ensuremath{\mathbf{BACKUP}}$  to back up the event log file.


# **Account Management**

The **Account Management** feature allows you to manage the accounts of the switch. Enable different accounts with different roles to facilitate convenient management and safe access.



#### **User Account**

This section describes how to manage the existing accounts of the switch. Here, you can add, edit, and delete user accounts for the switch. Only one account, admin, exists by default. To enhance security, we suggest you create a new account with the user authority.




The User Account page features a search function on the upper right. Type the username you want to search for.




## **Editing Existing Accounts**

Select the account you want to edit and select the edit icon.



Configure the following settings.



## Enabled

Setting	Description	Factory Default
Enabled	This enables the user account.	Enabled
Disabled	This disables the user account.	

#### Authority


Setting	Description	Factory Default
admin	This account has read/write access for all configuration	
aumm	parameters.	
supervisor	This account has read/write access for some specific	admin
super visor	configuration parameters.	
user	This account can only view some specific configuration	
usei	parameters.	

#### Email

Setting	Description	Factory Default
Input an email address	Input an email address for the account if required.	None

When finished, select **APPLY** to save your changes.

To change the password for the user, select **CHANGE PASSWORD**.



#### New Password

Setting	Description	Factory Default
4 to 63 characters	Enter the password to use for this account.	None

#### Confirm Password

Setting	Description	Factory Default
4 to 63 characters	Reenter the password to confirm it.	None

When finished, select **APPLY** to save your changes.




# **NOTE**


Refer to **Appendix B** for detailed descriptions for read/write access privileges for the admin, supervisor, and user authority levels.

## **Creating a New Account**

Create a new account by selecting the + icon on the Configuration page.



Configure the following settings.



#### Enabled

Setting	Description	Factory Default
Enabled	This enables the account.	Enabled
Disabled	This disables the account.	

#### Username

Setting	Description	Factory Default
Input a username, 4 to	Input a new username for this account.	None
32 characters	input a new username for this account.	None

#### Authority

Setting	Description	Factory Default
admin	This account has read/write access of all configuration	None
aumm	parameters.	None
supervisor	This account has read/write access for some specific	
super visor	configuration parameters.	
ucor	This account can only view some specific configuration	
user	parameters.	

To enhance security, we suggest you create a new account with the user authority.

## New Password

Setting	Description	Factory Default
4 to 63 characters	Input a new password for this account.	None

#### Confirm Password

Setting	Description	Factory Default
4 to 63 characters	Reenter the password to confirm.	None


#### Email

Setting	Description	Factory Default
Input an email address	Input an email address for the account if required.	None


When finished, select **CREATE** to complete.

# **Delete an Existing Account**

To delete the existing account, simply select the account you want to delete, and then select the delete icon on the configuration page.




Select **DELETE** to delete the account.



# **Password Policy**

To prevent hackers from cracking weak passwords, a password policy can be set. The password policy can enforce users to create passwords with a minimum length and complexity, and it can also establish a maximum lifetime for the password to ensure it is changed periodically.



#### Minimum Length

Setting	Description	Factory Default
Input from 4 to 63	This sets the minimum length of the password.	4

#### Password Complexity Strength Check

Setting	Description	Factory Default
digit, letter cases,	These determine the required complexity for the password.	Nono
special characters	Multiple options may be checked.	None


## Password Max-life-time (day)

Setting	Description	Factory Default
LINDUIT FROM U TO 365	This determines how long the password can be used before it must be changed.	0


When finished, select **Apply** to save your changes.

#### **Online Accounts**

The **Online Accounts** function allows you to view who has connected to the device. You may immediately remove the user who is currently online.




Select the remove icon and select **REMOVE** to disconnect the user.




# **Network**

This section describes how to configure the switch's network settings, including **IP Configuration** and the **DHCP Server**.



# **IP Configuration**

You can configure the IP settings of the switch.



#### Get IP From

Setting	Description	Factory Default
Manual	The IP address of the switch must be set manually.	
DHCP	The IP address of the switch will be assigned automatically by	
БПСР	the network's DHCP server.	Slot Index
Slot Index	The IP address of the switch will be assigned automatically by	
Slot Index	the slot index.	

#### IP Address

Setting	Description	Factory Default
Innut the IP address for		IP address is based
the switch	Specify the IP address to use for the switch.	on the slot index
the switch		value.

#### Subnet Mask

Setting	Description	Factory Default
Input the subnet mask	Specify the subnet mask to use for the switch.	24 (255.255.255.0)
for the switch	Specify the subhet mask to use for the switch.	24 (233.233.233.0)

## Default Gateway

Setting	Description	Factory Default
'	Specify the IP address of the gateway that connects the LAN to a WAN or another network.	None

#### DNS Server 1

Setting	Description	Factory Default
	Specify the IP address of the first DNS server used by your	
Input the IP address of	network. After specifying the DNS server's IP address, you can	None
the first DNS server	use the switch's URL (e.g., www.mymoxaswitch.com) to open	None
	the web console instead of entering the IP address.	

#### DNS Server 2

Setting	Description	Factory Default
the second DNS server	Inetwork The switch will lise the secondary DNS server it the	

# IPv6 Global Unicast Address Prefix (Prefix Length: 64 bits) Default Gateway

Setting	Description	Factory Default
Global Unicast Address Prefix	The prefix value must be formatted according to the RFC 2373 IPv6 Addressing Architecture, using 8 colon-separated 16-bit hexadecimal values. One double colon can be used in the address to show the number of zeros required to fill the undefined fields.  Note: This feature is only available in Advanced Mode.	None

#### IPv6 DNS Server 1

Setting	Description	Factory Default
	Specify the IPv6 address of the first DNS server used by your	
Input the IPv6 IP	network. After specifying the DNS server's IP address, you can	
address of the first DNS	use the switch's URL (e.g., www.mymoxaswitch.com) to open	None
server	the web console instead of entering the IP address.	
	Note: This feature is only available in Advanced Mode.	

#### IPv6 DNS Server 2

Setting	Description	Factory Default
of the second DNS	Specify the IPv6 address of the second DNS server used by your network. The switch module will use the secondary DNS server if the first DNS server cannot connect.  Note: This feature is only available in Advanced Mode.	None

## IPv6 Global Unicast Address

Setting	Description	Factory Default
None	Displays the IPv6 Global Unicast address. The network portion	None
	of the Global Unicast address can be configured by specifying	
	the Global Unicast Prefix and using an EUI-64 interface ID in	
	the low order 64 bits of the address. The host portion of the	
	Global Unicast address is automatically generated using the	
	modified EUI-64 form of the interface identifier (the switch's	
	MAC address).	
	<b>Note:</b> This feature is only available in <b>Advanced Mode</b> .	

## IPv6 Link-Local Address

Setting	Description	Factory Default
	The network portion of the Link-Local address is FE80, and the	
	host portion of the Link-Local address is automatically	
None	generated using the modified EUI-64 form of the interface	None
	identifier (the switch's MAC address).	
	Note: This feature is only available in Advanced Mode.	

When finished, select **APPLY** to save your changes.

## **DHCP Server**

This section describes how to configure the DHCP server settings for switch module. First, select the **General** tab.



Then, select DHCP/MAC-based IP Assignment and select APPLY.




# **NOTE**


The DHCP server will use UDP port 67 to send messages to the DHCP client.

#### **DHCP**

Select the **DHCP** tab and then select the + icon on the configuration page to create a new DHCP server pool.



Configure the following parameters.



# **NOTE**

You can only create one IP pool. It can be connected to different network subnets with the Management IP of the switch.

#### Enable

Setting	Description	Factory Default
Enabled	Enables the DHCP server pool.	-Disabled
Disable	Disables the DHCP server pool.	

## Start IP Address

Setting	Description	Factory Default
Input the first IP	Specify the first IP address for the pool.	None
address	Specify the first IP address for the pool.	None

#### Subnet Mask

Setting	Description	Factory Default
Select from the drop-	Specify the subnet mask for the pool.	None
down list	Specify the subflet mask for the pool.	None

## End IP Address

Setting	Description	Factory Default
Input the last IP	Specify the last IP address for the pool.	None
address	Specify the last if address for the poor.	None

#### Default Gateway

Setting	Description	Factory Default
Input the IP address of	Specify the default gateway for clients to use.	None
the default gateway		

#### Lease Time (sec.)

Setting	Description	Factory Default
Input the lease time for		
the DHCP, from 10 to	Charles the lease time for DUCD ID againments	86400
604,800 seconds (up to	Specify the lease time for DHCP IP assignments.	00400
7 days)		

#### DNS Server 1

Setting	Description	Factory Default
Input the IP address of	Specify the IP address of the first DNS server for clients to	None
the first DNS server	use.	None

#### DNS Server 2

Setting	Description	Factory Default
Input the IP address of	Specify the IP address of the second DNS server for clients to	None
the second DNS server	use.	none

#### NTP Server


Setting	Description	Factory Default
Input the address of the NTP server	Specify the NTP server clients will use.	None

When finished, select **CREATE**.


## **MAC-based IP Assignment**

Assign an IP address for a specific MAC address. This can be useful if you always want the same IP address to be assigned to a specific device, even if it is reconnected or connected to a different port.

Select the **MAC-based IP Assignment** tab, and then select the + icon on the configuration page.



Configure the following parameters.



## Enable

Setting	Description	Factory Default
Enabled	Enables the MAC-based IP assignment entry.	-Enabled
Disabled	Disables the MAC-based IP assignment entry.	

#### Hostname

Setting	Description	Factory Default
Enter a host name		
between 0 and 63	Specify a host name to use for the DHCP client.	None
characters		

## IP Address

Setting	Description	Factory Default
Input the assigned IP	Specify the IP address to assign to the client.	None
address	specify the 1P address to assign to the cheft.	Notice

#### Subnet Mask

Setting	Description	Factory Default
Select from the drop-	Specify the subnet mask to use for the client.	None
down list	Specify the subhet mask to use for the cheft.	None

#### MAC Address

Setting	Description	Factory Default
	Specify the MAC address of the device you want to assign an	
Input the assigned MAC	IP address to. Make sure the MAC address is entered in the	None
address	correct format. Here is an example:	None
	28-d2-44-D3-e3-f2 or 28:d2:44:D3:e3:f2.	

#### Default Gateway

		Factory Default
Input the IP address of	Specify the default gateway for the client to use.	None
the default gateway	Specify the default gateway for the client to use.	None

## Lease Time (sec.)

		Factory Default
Input the lease time for	Define how long before the IP address needs to be reassigned.	
the DHCP, from 10 to	Define flow long before the 1r address fleeds to be reassigned.	86400
604800.		

#### DNS Server 1

		Factory Default
Input the IP address of	Specify the IP address of the first DNS server for the client to	None
the first DNS server	use.	

#### DNS Server 2

	Description	Factory Default
Input the IP address of	Specify the IP address of the second DNS server for the client	None
the second DNS server	to use.	

#### NTP Server


Setting	Description	Factory Default
Input the address of	Specify the NTP server the client will use.	None
the NTP server	specify the NTP server the cheft will use.	None

When finished, select **CREATE**.


# **Port-based IP Assignment**

Assign an IP to a device based on what switch port it is connected to. This can be useful if you want to always use the same IP for a device connected to a specific port, even if it is replaced with a different device.


On the **General** tab, select **Port-based IP Assignment**. Select **APPLY**.



Next, select the **Port-based IP Assignment** tab, and then select the **+** icon on the configuration page.



Configure the following parameters.



#### Enable

Setting	Description	Factory Default
Enabled	Enables the port-based IP assignment entry.	Enabled
Disabled	Disables the port-based IP assignment entry.	

## Port

Setting	Description	Factory Default
Select from 1 to 28	Select which switch port the DHCP server will assign an IP address for.	None

#### IP Address

Setting	Description	Factory Default
Input the assigned IP address	Specify the IP address to assign to the client.	None

#### Subnet Mask

Setting	Description	Factory Default
Select from the drop-	Charify the subject most to use for the client	None
down list	Specify the subnet mask to use for the client.	None

#### Default Gateway

Setting	Description	Factory Default
Input the IP address of	Specify the default gateway for the client to use.	None
the default gateway	specify the default gateway for the chefit to use.	None

## Lease Time (sec.)

Setting	Description	Factory Default
Input the lease time for		
the DHCP, from 10 to	Define how long before the IP address needs to be reassigned.	86400
604800		

## DNS Server 1

Setting	Description	Factory Default
Input the IP address of	Specify the IP address of the first DNS server for the client to	None
the first DNS server	use.	

#### DNS Server 2

	Description	Factory Default
Input the IP address of	Specify the IP address of the second DNS server for the client	None
the second DNS server	to use.	


#### NTP Server

Setting	Description	Factory Default
Input the address of	Specify the NTP server the client will use.	None
the NTP server		

When finished, select **CREATE**.

## **Lease Table**


Select **Lease Table** to view detailed information for the host name, IP address, MAC address, and time left for each port.



Item	Description
Host name	The Host name of the client.
IP Address	The IP address of the client.
MAC Address	The MAC address of the client.
Time Left	The time left on the DHCP lease for the client.

## **Time**

This section describes how to configure the **Time Zone** and **System Time** settings for the switch. The switch has a time calibration function based on information from an NTP server or a user-specified time and date, allowing functions such as automatic warning emails to include a time and date stamp.






## **NOTE**

Update the Current Time and Current Date after the switch has been powered off for an extended period (e.g., three days). Pay particular attention to this when there is no NTP server or Internet connection available.

## **Time Zone**

Configure the time zone for the switch.



## System Uptime

Setting	Description	Factory Default
System-specified time	This shows how long the switch has been running since the	N/A
System specified time	last cold start.	N/ A

#### Current Time


Setting	Description	Factory Default
User-specified time	Shows the current system time.	None

#### Time Zone

Setting	Description	Factory Default
Select from the drop-	Specify the time zone to use for the switch	GMT (Greenwich
down list		Mean Time)

# **Daylight Saving Time**

The Daylight Saving Time settings are used to automatically adjust the time according to regional standards.



Configure the following settings.

#### **Daylight Saving Time**

Setting	Description	Factory Default
Enabled	Enables Daylight Saving Time.	Disabled
Disabled	Disables Daylight Saving Time.	

#### Start Date

Setting	Description	Factory Default
User-specified date	Specify the date that Daylight Saving Time begins.	None

#### End Date

Setting	Description	Factory Default
User-specified date	Specify the date that Daylight Saving Time ends.	None

### Offset

Setting	Description	Factory Default
User-specified hour	Specify the offset (in HH:MM format) to use during Daylight Saving Time.	None


When finished, select **APPLY** to activate the time zone settings.

# **System Time**

This section describes how to configure the **Time**, **NTP Server**, and **NTP Authentication** settings.

#### Time

The section describes how to configure the system's time. Select the Time tab.



#### **Current Time**

Setting	Description	Factory Default
None	This automatically shows the current time according to your default settings.	Local


#### Clock Source

Setting	Description	Factory Default
Select from the drop-	Specify whether to set the time manually (Local), from an	Local
down list	SNTP server, or from an NTP server.	Local

# **Clock Source is from Local**

# Date

Setting	Description	Factory Default
Select the date	Select the current date.	Local



#### Time

Setting	Description	Factory Default
	Specify the current time. Manually input the time or select	
Input the current time	Sync from Browser to set the time based on the time used by	None
	your web browser.	

## **Clock Source is from SNTP**

#### Time Server 1

Setting	Description	Factory Default
Input the address of	Specify the IP or domain address of the first SNTP server to	
the first SNTP time	use (e.g., 192.168.1.1, time.stdtime.gov.tw, or	Time.nist.gov
server	time.nist.gov).	

#### Time Server 2

Setting	Description	Factory Default
Ithe second SNIP time	Specify the IP or domain address of the secondary SNTP server to use if the first SNTP server cannot connect.	None

Select **APPLY** to complete.

#### **Clock Source is from NTP**

If the switch is connected to an NTP server that requires authentication, refer to the **NTP Authentication** section to configure the NTP key to use.

#### Time Server 1

Setting	Description	Factory Default
Input the address of the first NTP time server	Specify the IP or domain address of the first NTP server to use (e.g., 192.168.1.1, time.stdtime.gov.tw, or time.nist.gov).	Time.nist.gov

#### Authentication

Setting	Description	Factory Default
Disabled	Enable or disable NTP authentication for Time Server 1.	Disabled

## Time Server 2

Setting	Description	Factory Default
Input the address of	Specify the IP or domain address of the secondary NTP server	None
the second time server	to use if the first NTP server cannot connect.	


#### Authentication

Setting	Description	Factory Default
Disabled	Enable or disable NTP Authentication for Time Server 2.	Disabled

Select **APPLY** to complete.

## **NTP Server**

Select the **NTP Server** Tab to perform further configuration.



#### Enable

Setting	Description	Factory Default
Enabled	Enable the NTP server.	Disabled
Disabled	Disable the NTP server.	

#### **Client Authentication**

Setting	Description	Factory Default
Enabled	Enable NTP authentication.	-Disabled
Disabled	Disable NTP authentication.	

When finished, select **APPLY** to save your changes.




# **NOTE**


The NTP server will use TCP port 123 to send messages to the NTP client.

## **NTP Authentication**

This section describes how to configure NTP Authentication. Select the **NTP Authentication** tab, and then select the **+** icon on the page.



Configure the following settings.



#### Key ID

	Setting	Description	Factory Default
- 1	Input the Key ID from	Input the Key ID to use for NTP authentication.	None
	1 to 10		

# Туре

Setting	Description	Factory Default
Input the	Input the authentication type.	MD5
authentication type		

# Key String

Setting	Description	Factory Default
Input the key string for		
authentication, from 0	Input the password to use for the authentication key.	None
to 32 characters.		

When finished, select **CREATE**.


# **Port**

This section describes how to configure the **Port Interface** and **Link Aggregation** functions for the switch.




# **Port Interface**

Two functions are included in this section:  $\mbox{\bf Port Setting}$  and  $\mbox{\bf Linkup Delay}.$ 




# **Port Setting**

Under Port Setting, select the Setting tab and then select the edit icon on the port you want to configure.



Configure the following parameters.



#### Admin Status

Setting	Description	Factory Default
Enable	Allows data transmission through this port.	-Enabled
Disabled	Disables data transmission through this port.	

## Media Type

Setting	Description	Factory Default
Media type	Displays the media type for each module's port.	1000TX,RJ45,PTP

#### Description

Setting	Description	Factory Default
May 63 characters	Specify an alias for the port to help differentiate between	None
	different ports (e.g., PLC1).	

## Speed/Duplex

Setting	Description	Factory Default
Auto	Allows the port to use the IEEE 802.3u protocol to negotiate with connected devices. The port and connected devices will determine the best speed for that connection.	
10M Half		Auto
10M Full	Choose a fixed speed option if the connected Ethernet device	
100M Half	has trouble auto-negotiating line speed.	
100M Full		

## Flow Control

This setting enables or disables flow control for the port when the port's speed is set to Auto. The result will be determined by the Auto process between the switch and connected devices.

Setting	Description	Factory Default	
Enable	Enables flow control for this port when the port's speed is set		
	to Auto.	-Disabled	
Disable	Disables flow control for this port when the port's speed is set		
	to Auto.		

## MDI/MDIX

Setting	Description	Factory Default
Auto	Allows the port to auto-detect the port type of the connected	
Auto	Ethernet device and changes the port type accordingly.	Auto
MDI	Choose MDI or MDIX if the connected Ethernet device has	Auto
MDIX	trouble auto-detecting the port type.	


## Copy Config to Ports

Setting	Description	Factory Default
Select the port(s) from	Allows you to copy the configuration to other port(s).	None
the drop-down list	Allows you to copy the configuration to other port(s).	None

When finished, select **APPLY** to save your changes.

#### **Port Status**

To view the status of the ports, select the **Status** tab.



# **Linkup Delay**

## **Linkup Delay Overview**

Linkup delay is used to prevent a port alternating between link up and link down. It is also sometimes called link flap prevention. This feature is useful when the link connection is unstable. An unstable connection might be caused by a faulty cable, faulty fiber transceiver, duplex mismatch, etc. This feature helps administrators to mitigate the risk of an unstable network, particularly when the topology changes frequently.


## **Linkup Delay Settings**

This section describes how to configure the linkup delay for the ports. Select the **Linkup Delay** menu. The default setting disables linkup delay for all ports.



## **NOTE**

Only ports 1 to 10 support Linkup Delay Setting. SW1, SW2, CPU1, CPU2 are internal communication ports. This function cannot be edited in these ports.



# Enable


Setting	Description	Factory Default
Enable	Enables linkup delay.	Disabled
Disabled	Disables linkup delay.	

When finished, select **APPLY** to save your changes.

To configure the linkup delay for a port, select the edit icon on the port you want to configure.

	Port	Enable	Delay Time	Remaining Time
1	1	Disabled	2	0
1	2	Disabled	2	0
1	3	Disabled	2	0
1	4	Disabled	2	0
j	5	Disabled	2	0
j	6	Disabled	2	0
1	7	Disabled	2	0
i	8	Disabled	2	0
j	9	Disabled	2	0
j	10	Disabled	2	0
1	SW1			-
1	SW2		-	
1	CPU1			
1	CPU2	-	_	

Some parameters need to be configured.



#### Linkup Delay

Setting	Description	Factory Default
Enable	Enables linkup delay for the port.	Disabled
Disable	Disables linkup delay for the port.	Disabled

#### Delay Time (sec.)

Setting	Description	Factory Default
1 to 1000	Specify the linkup delay time from 1 to 1000 seconds.	2

#### Copy Config to Ports

Setting	Description	Factory Default
Select the port(s) from	Allows you to copy the configurations to other port(s).	None
the drop-down list		

When finished, select **APPLY** to save your changes.

# **Link Aggregation**

## Link Aggregation (Port Channel) Overview

Link Aggregation helps balance, optimize, and facilitate the switch's throughput. This method can combine multiple network communications in parallel to maximize data throughput, increasing data communication efficiency for each port. In addition, it also acts as a useful method for network redundancy when a link fails. In general, Link Aggregation supports combining multiple physical switch ports into a single, efficient bandwidth data communication route. This can improve network load sharing and increase network reliability.

#### **Static Trunk**


For some networking applications, a situation can arise where traffic from multiple ports is required to be filtered through one port. For example, if there are 30 UHD IP surveillance cameras deployed and connected in a ring, the traffic can reach up to 1 Gbps, causing a surge in traffic that can increase network loading by up to 50%. Hence, the uplink port needs to use the static trunk function to provide more bandwidth and redundancy protection.

## **LACP**


The Link Aggregation Control Protocol (LACP) allows a network device to negotiate an automatic bundling of several ports by sending LACP packets to the peer, a directly connected device that also uses LACP.

# **Link Aggregation Settings**

This section describes how to configure link aggregation for each port. Select **Link Aggregation** on the menu and then select the + icon on the configuration page.



To create a link aggregation group, configure the following parameters.



#### LA Group Status

Setting	Description	Factory Default
Enable	Enable link aggregation grouping.	None
Disable	Disable link aggregation grouping.	None

## Туре


Setting	Description	Factory Default	
Manual	Configure the link aggregation type manually.	None	
LACP	Configure the link aggregation type by LACP.	None	

#### **Config Member Port**

Setting	Description	Factory Default
Select from the ports	Select the ports you want to create for link aggregation	None
Select Iron the ports	grouping.	None

When finished, select CREATE to continue.

View the current Link Aggregation or Port Channel (Trunk) status on the configuration page. Edit or delete by selecting the edit or delete icon on the page.




# **Editing Port Setting for Link Aggregation**

To edit each port's setting for Link Aggregation, select the edit icon on the port name. You can also check the port and then select the edit icon for editing the port settings for Link Aggregation.




## **NOTE**

Only port 1 to 10 support Link Aggregation setting. SW1, SW2, CPU1, CPU2 are internal communication ports. This function cannot be edited in these ports.



Edit the following port settings.



### LA Group Status

Setting	Description	Factory Default
Enable	Enable link aggregation grouping.	None
Disable	Disable link aggregation grouping.	None

#### Type

Setting	Description	Factory Default
Manual	Configure link aggregation manually.	None
LACP	Configure link aggregation by LACP.	


# Config Member Port

Setting	Description	Factory Default
Select from the ports	Select the ports you want to create link aggregation grouping for.	None


When finished, select  $\ensuremath{\mathbf{APPLY}}$  to save your changes.

## **Deleting the Port for Link Aggregation**

To delete the port for Link Aggregation, check the port and then select the delete icon.




Select **DELETE** to finish. Note that some features, such as RSTP and VLAN, will be set to default values once you delete the Link Aggregation setting.



# **Layer 2 Switching**

This section describes how to configure various parameters, such as **VLAN**, **GARP**, **MAC**, **QoS**, and **Multicast**, for switch module. Select **Layer 2 Switching** on the function menu.



### **VLAN**

This section includes IEEE802.1Q configurations.



# **IEEE 802.1Q Overview**


The IEEE 802.1Q is a network communication protocol that falls under the IEEE 802.1 standard regulation, allowing various segments to use a physical network at the same time to block broadcast packets by different segmentations. It specifies the VLAN tagging for Ethernet frames on switches that can control the path process.

#### **How A VLAN Works**

#### What is a VLAN?

A VLAN is a group of devices that can be located anywhere on a network, but which communicate as if they are on the same physical segment. With VLANs, you can segment your network without being restricted by physical connections—a limitation of traditional network design. With VLANs you can segment your network into:

- **Departmental groups**—You could have one VLAN for the marketing department, another for the finance department, and another for the product development department.
- Hierarchical groups—You could have one VLAN for directors, another for managers, and another for general staff.
- Usage groups—You could have one VLAN for email users and another for multimedia users.



#### **Benefits of VLANs**

The main benefit of VLANs is that they provide a network segmentation system that is far more flexible than traditional networks. Using VLANs also provides you with three other benefits:

- VLANs ease the relocation of devices on networks: With traditional networks, network administrators spend much of their time dealing with changes. If you move to a different subnetwork, the addresses of each host must be updated manually. With a VLAN setup, if a host originally on the Marketing VLAN is moved to a port on another part of the network, and retains its original subnet membership, you only need to specify that the new port is on the Marketing VLAN. You do not need to do any recalling.
- VLANs provide extra security: Devices within each VLAN can only communicate with other devices on the same VLAN. If a device on the Marketing VLAN needs to communicate with devices on the Finance VLAN, the traffic must pass through a routing device or Layer 3 switch.
- VLANs help control traffic: With traditional networks, congestion can be caused by broadcast traffic
  that is directed to all network devices, regardless of whether they need it. VLANs increase the efficiency
  of your network because each VLAN can be set up to contain only those devices that need to
  communicate with each other.

#### VLANs and the Switch Module

Your switch module includes support for VLANs using IEEE Std 802.1Q-2005. This standard allows traffic from multiple VLANs to be carried across one physical link. The IEEE Std 802.1Q-2005 standard allows each port on your switch module to be placed:

- · On a single VLAN defined in the switch
- On several VLANs simultaneously using 802.1Q tagging

The standard requires that you define the 802.1Q VLAN ID for each VLAN on your switch module before the switch can use it to forward traffic:

## Managing a VLAN

A new or initialized switch module contains a single VLAN—the Default VLAN. This VLAN has the following definition:

- Management VLAN ID 1 can be changed
- 802.1Q VLAN default ID 1 cannot be deleted

All the ports are initially placed on this VLAN, and it is the only VLAN that allows you to access the management software of the switch module over the network.

#### **Communication Between VLANs**

If devices connected to a VLAN need to communicate with devices on a different VLAN, a router or Layer 3 switching device with connections to both VLANs needs to be installed. Communication between VLANs can only take place if they are all connected to a routing or Layer 3 switching device.

# **VLANs: Tagged and Untagged Membership**

Switch module supports 802.1Q VLAN tagging, a system that allows traffic for multiple VLANs to be carried on a single physical link (backbone, trunk). When setting up VLANs you need to understand when to use untagged or tagged membership of VLANs. Simply put, if a port is on a single VLAN it can be an untagged member, but if the port needs to be a member of multiple VLANs, a tagged membership must be defined.

A typical host (e.g., clients) will be an untagged member of one VLAN, defined as an **access port** in a switch module, while an inter-switch connection will be a tagged member of all VLANs, defined as a **trunk port** in a switch module.


The IEEE Std 802.1Q-2005 defines how VLANs operate within an open packet-switched network. An 802.1Q compliant packet carries additional information that allows a switch to determine which VLAN the port belongs to. A frame is called a tagged frame if it carries additional information.

To carry multiple VLANs across a single physical link (backbone, trunk). Each packet must be tagged with a VLAN identifier so that the switches can identify which packets belong to which VLAN. To communicate between VLANs, a router must be used.

Switch module supports three types of VLAN port settings:

- Access Port: The port connects to a single device that is not tagged. You must define the default port PVID that assigns which VLAN the device belongs to. Once the ingress packet of this access port egresses to another trunk port (the port needs all packets to carry tag information), the switch will insert this PVID into this packet so the next 802.1Q VLAN switch can recognize it.
- **Trunk Port:** The port connects to a LAN that comprises untagged devices and tagged devices. In general, the traffic of the trunk port must have a tag. You can also assign a PVID to a trunk port. The untagged packet on the trunk port will be assigned the default port PVID as its VID.
- Hybrid Port: The port is like a trunk port, except users can explicitly assign tags to be removed from egress packets.

The following section illustrates how to use these ports to set up different applications.



#### In this application:

- Port 1 connects a single untagged device and assigns it to VLAN 5; it should be configured as an access port with PVID 5.
- Port 2 connects a LAN with two untagged devices belonging to VLAN 2. One tagged device with VID 3 and one tagged device with VID 4. It should be configured as a **hybrid port** with PVID 2 for untagged devices and Fixed VLAN (Tagged) with 3 and 4 for tagged device. Since each port can only have one unique PVID, all untagged devices on the same port must belong to the same VLAN.
- Port 3 connects with another switch. It should be configured as a **trunk port**. GVRP protocol will be used through the trunk port.
- Port 4 connects a single untagged device and assigns it to VLAN 2; it should be configured as an access port with PVID 2.
- Port 5 connects a single untagged device and assigns it to VLAN 3; it should be configured as an access port with PVID 3.
- Port 6 connects a single untagged device and assigns it to VLAN 5; it should be configured as an access port with PVID 5.
- Port 7 connects a single untagged device and assigns it to VLAN 4; it should be configured as an access port with PVID 4.

After the application is properly configured:


- Packets from Device A will travel through **Trunk Port 3** with tagged VID 5. Switch B will recognize its VLAN, pass it to port 6, and then remove tags received successfully by Device G, and vice versa.
- Packets from Devices B and C will travel through Hybrid Port 2 with tagged VID 2. Switch B recognizes
  its VLAN, passes it to port 4, and then removes tags received successfully by Device F, and vice versa.
- Packets from Device D will travel through **Trunk Port 3** with tagged VID 3. Switch B will recognize its VLAN, pass to port 5, and then remove tags received successfully by Device H. Packets from Device H will travel through **Trunk Port 3** with PVID 3. Switch A will recognize its VLAN and pass it to port 2, but will not remove tags received successfully by Device D.
- Packets from Device E will travel through Trunk Port 3 with tagged VID 4. Switch B will recognize its VLAN, pass it to port 7, and then remove tags received successfully by Device I. Packets from Device I will travel through Trunk Port 3 with tagged VID 4. Switch A will recognize its VLAN and pass it to port 2, but will not remove tags received successfully by Device E.

# **VLAN Settings**

To configure VLAN, select **VLAN** on the function menu, then select **IEEE 802.1Q**. Select **Global** tab.

GVRP (Generic VLAN Registration Protocol) is an IEEE 802.1Q standard protocol that helps specify how to define a method of tagging frames with VLAN configuration data. It essentially facilitates the management of VLAN within a larger network of data communication.

To edit the GVRP function, select the Global tab.



Configure the following setting.


#### **GVRP**

Setting	Description	Factory Default
Disabled	Disables GVRP.	-Disabled
Enabled	Enables GVRP.	

Select **APPLY** to finish.

## **VLAN Management Port Quick Settings**

In the lower part of the configuration page, you can quickly configure the VLAN settings.



Configure the following settings.

# Management VLAN

Setting	Description	Factory Default
Select the Management		
VLAN from the drop-	Show the list of selectable VLANs.	1
down list		


#### Management Port

Setting	Description	Factory Default
Select the port(s) as		
the VLAN port(s) from	To select the port(s) as the VLAN port(s).	None
the drop-down list		


When finished, select **APPLY** to save your changes.

# **Detailed VLAN Settings**

On the IEEE 802.1Q page, first select the Setting tab, and then select the edit icon.



Configure the following parameters.



## VID

Setting	Description	Factory Default
Input a VLAN ID, (10	Input a VLAN ID.	None
VLANs max.)	Input a VLAN ID.	None

#### Name

Setting	Description	Factory Default
Input a name for the		
VLAN, (32 characters	Specify a name for the VLAN.	None
max.)		

### Member Port

		Factory Default
Select the port from the drop-down list.	Specify the ports that are the member ports for the VLAN.	None


When finished, select CREATE.

#### Forbidden Port (in Advanced Mode only)


		Factory Default
Select the port from the drop-down list	Specify the ports that are forbidden for the VLAN.	None

# **Editing the Existing VLAN Settings**

To edit the exiting VLAN settings, select the edit icon of the VLAN you want to edit.



Configure the following settings.



### VID

Setting	Description	Factory Default
Show the VLAN ID	Display the VLAN ID.	None

#### Name

Setting	Description	Factory Default
Show the name of the	Display the VLAN name.	None
VLAN		

#### **Member Port**

		Factory Default
Select the port from the drop-down list	Specify the ports that are member ports for the VLAN.	None


When finished, select **APPLY** to save your changes.

## Forbidden Port (in Advanced Mode only)


		Factory Default
Select the port from the	Specify the ports that are forbidden for the VLAN.	None
drop-down list		

# **Editing the Port Settings**

To edit the port settings, in the **VLAN** tab, select the edit icon on the port you want to configure on the lower part of the page.



Configure the following settings.



## Mode

Setting	Description	Factory Default
Access	When this port is connected to a single device, without tags.	-Access
Trunk	When this port is connected to another 802.1Q VLAN aware switch.	
Hybrid	When this port is connected to another Access 802.1Q VLAN aware switch or another LAN that combines tagged and/or untagged devices.	Access

### PVID

Setting	Description	Factory Default
11 to 4094	Sets the default VLAN ID for untagged devices connected to the port.	None

#### **GVRP**

Setting	Description	Factory Default
Enabled	Enables GVRP.	Disabled
Disabled	Disables GVRP.	

#### Tagged VLAN

Setting	Description	Factory Default
	This field will be active only when selecting the trunk or hybrid	
1 to 4094	port type. Set the other VLAN ID for tagged devices that	None
	connect to the port.	

#### Untagged VLAN

Setting	Description	Factory Default
VID range from 1 to	This field is only active when the hybrid port type is selected.  Set the other VLAN ID for tagged devices that connect to the port and tags that need to be removed in egress packets.	1

#### Copy Config to Ports

Setting	Description	Factory Default
Select the port(s) from	Copy the configuration to other port(s).	None
the drop-down list		

When finished, select **APPLY** to save your changes.

#### **GARP Overview**


GARP stands for **Generic Attribute Registration Protocol**, which is a communication protocol defined by IEEE 802.1, offering a generic framework for bridges to register and de-register an attribute value. In a VLAN structure, two applications can be applied: **GARP VLAN Registration Protocol (GVRP)** is used to register VLAN trunking between multilayer switches, and **GARP Multicast Registration Protocol (GMRP)** to provide a constrained multicast flooding facility.

# **GARP Settings**

Select GARP on the menu page and then select the edit icon on the port you want to configure.



Configure the following settings.



#### Join Time (sec.)

Setting	Description	Factory Default
10 to 499999980	Input the join time from 10 to 499999980 seconds.	200

#### Leave Time (sec.)

Setting	Description	Factory Default
30 to 499999980	Input the leave time from 30 to 499999980 seconds.	600

#### Leave All time (sec.)

Setting	Description	Factory Default
30 to 499999990	Input the leave all time.	10000

### Copy Config to Ports

Setting	Description	Factory Default
Select the port(s) from	Copy the configurations to other port(s).	None
the drop-down list		

When finished, select **APPLY** to save your changes.

## **MAC**

This section explains Independent VLAN learning and describes how to configure **Static Unicast** and the **MAC Address Table**.



## Independent VLAN Learning

The switch module uses the **Independent VLAN Learning (IVL)** mode.


In an **IVL Mode**, a MAC table will be created in each VLAN, which will make up many MAC tables. However, the same VID record will be selected and put in a table. A MAC table will be stored in the format of MAC + VID, the same MAC will be stored in different tables with different VIDs.

#### **Static Unicast**

Select **Static Unicast** on the function menu page and select the + icon on the configuration page.



Configure the following settings.



#### VID

Setting	Description	Factory Default
Input a VLAN ID	Input a VLAN ID.	None

#### MAC Address

Setting	Description	Factory Default
MAC address of the	Input the MAC address of the port	None
port	Input the MAC address of the port.	None


#### Port

		Factory Default
Select the port from the drop-down list	Specify the port you want to create a VLAN for.	None

When finished, select CREATE.

# **MAC Address Table**

Select **MAC Address Table and** configure the following settings.



# MAC Learning Mode

Information	Description	Factory Default
Independent VLAN	IShow the current MAC Learning Mode.	Independent VLAN
learning		learning

## Aging Time

Setting	Description	Factory Default
10 to 300	Input a VLAN ID.	None

When finished, select **APPLY** to save your changes.


View the current MAC Address Table on the bottom part of the configuration page.



Item Name	Description
Index	The number of the MAC address.
VLAN	The VLAN number
MAC Address	The MAC address on this device.
Туре	Learnt Unicast, Learnt Multicast, Static Unicast, Static: Multicast
Port	The forwarding port of this MAC address.

# QoS

This section describes how QoS works and how to configure the settings.



# **QoS Overview**

The switch's traffic prioritization capability provides Quality of Service (QoS) to your network by making data delivery more reliable. Prioritize traffic on your network to ensure that high priority data is transmitted with minimum delay. Traffic can be controlled by a set of rules to obtain the required Quality of Service for your network. The rules define different types of traffic and specify how each type should be treated as it passes through the switch. The switch can inspect both IEEE 802.1p/1Q layer 2 CoS (Class of Service) tags, and even layer 3 DSCP (Differentiated Services Code Point) information to provide a consistent classification of the entire network. The switch's QoS capability improves the performance and determinism of industrial networks for mission-critical applications.

# The Traffic Prioritization Concept

Traffic prioritization allows you to prioritize data so that time-sensitive and system-critical data can be transferred smoothly and with minimal delay over a network. The benefits of using traffic prioritization are:

- Improve network performance by controlling a wide variety of traffic and by managing congestion.
- Assign priorities to different categories of traffic. For example, set higher priorities for time-critical or mission-critical applications.
- Provide predictable throughput for multimedia applications, such as videoconferencing or voice over IP, and minimize traffic delay and jitter.
- Optimize the network utilization depending on application usage and usage needs. Hence, asset owners do not always need to expand their backbone bandwidth as the amount of traffic increases.

Traffic prioritization uses eight traffic queues to ensure that higher priority traffic can be forwarded separately from lower priority traffic, which guarantees Quality of Service (QoS) to your network.

Switch module traffic prioritization is based on two standards:

- IEEE 802.1p—a layer 2 QoS marking scheme
- **Differentiated Services (DiffServ)**—a layer 3 QoS marking scheme.

#### **IEEE 802.1p Class of Service**

The IEEE Std 802.1D 2005 Edition marking scheme, which is an enhancement to IEEE Std 802.1D, enables Quality of Service on the LAN. Traffic service levels are defined in the IEEE 802.1Q 4-byte tag, which is used to carry VLAN identification and IEEE 802.1p priority information. The IEEE 802.1p occupying 3 bits of the tag follows the destination MAC address and Source MAC address.

The IEEE Std 802.1D 2005 Edition priority marking scheme assigns an IEEE 802.1p priority level between 0 and 7 to each frame, which specifies the level of service that the associated packets shall be handled. The table below shows an example of how different traffic types can be mapped to the eight IEEE 802.1p priority levels.

IEEE 802.1p Priority Level	IEEE 802.1D Traffic Type
0	Best Effort
1	Background (lowest priority)
2	Reserved
3	Excellent Effort (business critical)
4	Controlled Load (streaming multimedia)
5	Video (interactive media)
6	Voice (interactive voice)
7	Network Control Reserved traffic

Even though the IEEE 802.1p standard is the most widely used prioritization scheme for LAN environments, it still has some restrictions:

- It requires an additional 4-byte tag in the frame, which is normally optional for Ethernet networks. Without this tag, the scheme cannot work.
- The tag is part of the IEEE 802.1Q header, so to implement QoS at layer 2, the entire network must implement IEEE 802.1Q VLAN tagging.
- It is only supported within a LAN and does not cross the WAN boundaries, since the IEEE 802.1Q tags will be removed when the packets pass through a router.

#### Differentiated Services (DiffServ) Traffic Marking

DiffServ is a Layer 3 marking scheme that uses the DiffServ Code Point (DSCP) field in the IP header to specify the packet priority. DSCP is an advanced intelligent method of traffic marking that allows you to choose how your network prioritizes different types of traffic. The DSCP field can be set from 0 to 63 to map to user-defined service levels, enabling you to regulate and categorize traffic by applications with different service levels.

The advantages of DiffServ over IEEE 802.1Q are:

- Prioritize and assign different traffic with appropriate latency, throughput, or reliability by each port.
- No extra tags are required.
- The DSCP priority tags are carried in the IP header, which can pass the WAN boundaries and through the Internet.
- DSCP is backwards compatible with IPv4 ToS (Type of Service), which allows operation with legacy devices that use IPv4 layer 3.

#### **Traffic Prioritization**

Switch module classifies traffic based on layer 2 of the OSI 7 layer model, and the switch prioritizes outbound traffic according to the priority information defined in the received packet. Incoming traffic is classified based upon the IEEE 802.1p service level field and is assigned to the applicable egress priority queue. The traffic flow through the switch is as follows:

- A packet received by the switch module may or may not have an 802.1p tag associated with it. If it
  does not, then it is given a default CoS value (according to the port settings in the classification
  section). Alternatively, the packet might be marked with a new 802.1p value, which will cause all
  knowledge of the previous 802.1p tag being lost.
- Each egress queue has associated 802.1p priority levels, and can be defined by users, the packet will be placed in the appropriate priority queue. When the packet reaches the head of its queue and is about to be transmitted, the device determines whether the egress port belongs to the VLAN group. If it is, then the new 802.1p tag is used in the extended 802.1D header.

## **Traffic Queues**

The hardware of switch module has multiple traffic queues that allow packet prioritization to occur. Higher priority traffic can pass through the switch module without being delayed by lower priority traffic. As each packet arrives in the switch module, it undergoes ingress processing (which includes classification, marking/re-marking), and is then sorted into the appropriate queue. The switch then forwards packets from each queue.

Switch modules support two different queuing mechanisms:


- **Weight Fair:** This method services all the traffic queues, giving priority to the higher priority queues. Under most circumstances, the Weight Fair method gives high priority precedence over low priority, but if high priority traffic does not reach the link capacity, lower priority traffic is not blocked.
- **Strict:** This method services high traffic queues first; low priority queues are delayed until no more high priority data needs to be sent. The Strict method always gives precedence to high priority over low priority.

#### Classification

This section includes three parameters: **DSCP Mapping, CoS Mapping,** and **Port Setting**. The three parameters are described below.

#### **DSCP to CoS Mapping**

In the Classification menu, select the DSCP Mapping tab, and then select the edit icon.



Configure the priority setting from the drop-down list for this port.




#### DSCP Value and Priority

Setting	Description	Factory Default
0 to 7		0
8 to 15	Different DSCP values map to one of eight different priorities from 0 to 7.  5 6 7	1
16 to 23		2
24 to 31		3
32 to 39		4
40 to 47		5
48 to 55		6
56 to 63		7

When finished, select **APPLY** to save your changes.

# **CoS to Queue Mapping**

In the **Classification** menu, select the **CoS Mapping** tab, and then select the edit icon.



Configure the Queue priority setting for the port.




## Queue Priority

Setting	Description	Factory Default
0	Different 802.1p values map to one of the eight different queues from 1 (lowest priority) to 8 (highest).	1
1		2
2		3
3		4
4		5
5		6
6		7
7		8


When finished, select **APPLY** to save your changes.

# **Port Settings**

In the Classification menu, select the Port Setting tab, and then select the edit icon.



Configure the following settings.



#### Trust Type

Setting	Description	Factory Default
CoS	Enables the port with CoS-based traffic classification.	CoS
DSCP	Enables the port with DSCP-based traffic classification.	C03

#### **Untag Default Priority**

Setting	Description	Factory Default
IU to /	802.1p tag (CoS) can be ranged from 0 (lowest) to 7 (highest).	3



## **NOTE**

Certain functions such as redundancy mechanisms use the highest traffic class. Therefore, assign another traffic class to application data for the 65M-5011M Series.

#### Copy Config to Ports

Setting	Description	Factory Default
Select from the drop-	Convitte settings to other ports you select	None
down list	Copy the settings to other ports you select.	None

When finished, select **APPLY** to save your changes.


## **Ingress Rate Limit**

#### **Exceed Rate Limit Threshold Port Shutdown**

In general, any user shall not consume unlimited bandwidth and influence others' access. One scenario is that a malfunctioning switch or mis-configured network might cause "broadcast storms". ioPAC 6500 Layer 2 Managed Ethernet Switch Module not only prevents broadcast storms but also regulates ingress packet rates, giving administrators full control of their limited bandwidth to prevent undesirable effects caused by unpredictable faults.

### **Editing Port Shutdown**

To edit the port shutdown configurations, select the **Port Shutdown** tab.



Configure the following settings.

#### Enable

Setting	Description	Factory Default
Enable	Enable the port to be shut down.	Disabled
Disable	Disable the ability for the port to be shut down.	Disabled


## Release Interval (min.)

Setting	Description	Factory Default
0 to 10080	Specify the release interval for the port to shut down. 0	60
0 to 10060	means this port will be shut down until manually enabled.	00


When finished, select **APPLY** to save your changes.

## **Editing the Port for Port Shutdown**

Edit the specific port you want to edit the port shutdown configurations for.



Configure the following settings.



#### Enable

Setting	Description	Factory Default
Enable	Enable port shutdown for this port.	Disable
Disable	Disable port shutdown for this port.	

## Threshold (Mbps)

Setting	Description	Factory Default
1 to 100 or 1000 for	Specify the threshold for port shutdown	100 or 1000
Gigabit ports	specify the threshold for port shutdown	100 01 1000

## Copy Config to Ports

Setting	Description	Factory Default
Select the port(s) from	Copy the configurations to other port(s).	None
the drop-down list	copy the configurations to other port(s).	None

When finished, select **APPLY** to save your changes.

## **Scheduler**

## **Scheduler Overview**

Scheduler is an arbiter in a switch forwarding path to prioritize traffic flows by users' defined criteria. This essentially enhances data transmission efficiency and guarantees that critical packets can be transmitted earlier. Switch modules support two scheduling algorithms: Strict Priority and Weighted Round Robin.

## **Strict Priority**


The **Strict Priority** type allows you to determine to transmit packets in the highest priority queue first, while packets with lower priority will be transmitted later. This guarantees that traffic with the highest level of priority for data transmission will go first.

## **Weighted Round Robin**


The **Weighted Round Robin** type allows tou to give priority to specific packets in the higher weighted queue to ensure those packets will be sent first. Switch modules now have eight queues, and the weights from highest to lowest are 8:8:4:4:2:2:1:1.

## **Scheduler Settings**

Select Scheduler in the menu and then select the edit icon on the port you want to configure.



Configure the following settings.



#### Type

Setting	Description	Factory Default
Strict Priority	Set scheduler algorithm as Strict Priority.	
Weighted Round Robin	Set the scheduler algorithm as Weighted Round Robin: The	Strict Priority
Weighted Round Robin	queued packet will be forwarded by its associated weight.	

#### Copy Config to Ports

		Factory Default
Select the port from the	Copy the same settings to other ports.	None
drop-down list	Copy the same settings to other ports.	None

When finished, select **APPLY** to save your changes.

#### **Multicast**

Multicast filtering improves the performance of networks that carry multicast traffic. This section will explain the Layer 2 multicast settings, such as IGMP Snooping, GMRP, and Static Multicast.



# **IGMP Snooping**

## **IGMP Snooping Overview**


IGMP stands for **Internet Group Management Protocol**, which is a network communication protocol that hosts nearby routers on networks to construct multicast group memberships.

IGMP snooping allows a network switch to listen in on the IGMP conversation between hosts and routers. By listening to these conversations, the switch maintains an association mapping table between port(s) and multicast group.


### **How IGMP Snooping Works**

A switch will, by default, flood multicast traffic to all the other ports, aside ingress, in a broadcast domain (or the VLAN equivalent). Multicast can cause unnecessary loading for host devices by requiring them to process packets they have not solicited. IGMP snooping prevents hosts on a local network from receiving traffic for a multicast group they have not joined. It provides switches with a mechanism to forward multicast traffic to specific ports that receive IGMP hosts. Hence, IGMP snooping can use the network bandwidth more efficiently.

### Without IGMP Snooping



## With IGMP Snooping



## Differences Between IGMP Snooping V1, V2, and V3

IGMP protocols regulate the communication mechanism between querier and listener. IGMP Snooping has three different versions. Refer to the following table for the detailed differences.

IGMP Version	Main Features	Reference
V1	The IGMPv1 querier will periodically send out a "query". Listeners can solicit a "report" of their interested group. However, IGMPv1 does not have a "leave group" message, and the querier might need to implement a timeout mechanism for each registered group.	RFC-1112
V2	Compatible with V1 and the following functions:  a. Group-specific query  b. Leave group messages  c. Resends specific queries to verify leave message was the last one in the group  d. Querier election if multiple capable queries are present.	RFC-2236
V3	Compatible with V1, V2, and the following functions: Source filtering enables hosts to specify: - the multicast traffic from a specified source - the multicast traffic from any source except a specified source	RFC-3376

# **IGMP Snooping Settings**

First, select IGMP Snooping on the menu and then the General tab on the configuration page.





#### Enable

Setting	Description	Factory Default
Enabled	Enable IGMP Snooping on a specific VLAN.	Disabled
Disabled	Disable IGMP Snooping on a specific VLAN.	

# **Configuring VLAN Setting**

Select the **VLAN Setting** tab, and then select the edit icon to configure the VLAN settings.





# Enable

Setting	Description	Factory Default
Enabled	Enable IGMP Snooping on a switch.	Disabled
Disabled	Disable IGMP Snooping on a switch.	

### Version

Setting	Description	Factory Default
11 / 3	Specify the IGMP version of the packets that the switch listens to and sends queries for.	2

## Query Interval (sec)

Setting	Description	Factory Default
20 to 600	Specify the query interval for the Querier function globally	125
20 to 600	(Querier must be enabled.)	123

#### Static Router Port

Setting	Description	Factory Default
Check the port from the drop-down list	The router port is the port that connects to the upper-level router (or IGMP querier), or to the upper-level router of downstream multicast streams. All of the received IGMP signaling packets or multicast streams will be forwarded to those static router ports.	None

## Config Role

Setting	Description	Factory Default
Querier	The switch will act as the Querier role.	-Querier
Non-querier	The switch will not act as the Querier role.	

When finished, select **APPLY** to save your changes.




## **NOTE**

To ensure stable multicast stream transmission during topology changes with redundant protocols, it is recommended to configure a static router port.

# **Viewing the Group Table**

Select the **Group Table** tab, which allows you to view the current Group Table status.




Refer to the following table for the detailed description for each item.

Item	Description
VLAN	The VLAN ID.
Group Address	The registered multicast group.
	Only applicable to IGMPv3. (v1 and v2 will display "N/A")
Filter Mode	Include: source-specific multicast address group
	Exclude: source-specific exclusive multicast address group
Port	The forwarded port.
Source Address	Only applicable to IGMPv3. (v1 and v2 will display N/A)

## Viewing the Forwarding Table

Select the **Forwarding Table** tab to view the current forwarding table.



Refer to the following table for a description of each item.


Item	Description
VLAN	The VLAN ID.
Group Address	The associated multicast group address of the streaming data.
Source Address	The source address of the streaming data.
Port	The forwarded port.

#### **GMRP**

GMRP stands for GARP Multicast Registration Protocol, which is a Generic Attribute Registration Protocol (GARP) application that can be used to prevent multicast from data flooding. Both GMRP and GARP are defined by the IEEE 802.1P, and widely used as a standard protocol in various industrial-related applications. GMRP allows bridges and the devices at the edge of the network to perform a dynamic group membership information registration with the MAC bridges connected to the same LAN section. The information can be transmitted among all bridges in the Bridge LAN that is implemented with extended filtering features. To operate GMRP, the GARP service must be established first.

## **Configuring GMRP Setting**

To configure the GMRP settings, select **GMRP** on the menu.



Configure the following settings.

#### Enable

Setting	Description	Factory Default
Enabled	Enable GMRP.	-Disabled
Disabled	Disable GMRP.	


When finished, select APPLY to save your changes.

# **Configuring GMRP Settings for Each Port**

Next, select the edit icon on the port you want to configure.



Configure the following settings.



### Enable

Setting	Description	Factory Default
Enabled	Enable GMRP for this port.	Disabled
Disabled	Disable GMRP for this port.	

### **Group Restrict**

Setting	Description	Factory Default
lEnabled	Enable Group Restrict on the port. This specific port will not	-Disabled
	process any GMRP control packets.	
II)isahled	Disable Group Restrict on the port. The specific port will	
	receive and process incoming GMRP control packets.	

### Copy Config to Ports

Setting	Description	Factory Default
Select the port(s) from the drop-down list	Allows you to copy the configurations to other port(s).	None


When finished, select **APPLY** to save your changes.

# **Static Multicast**


Select Static Multicast on the menu to view the current multicast table.

# **Adding Static Multicast Entry**

To add more tables, select the + icon.



Configure the following settings.



# VID (VLAN ID)

Setting	Description	Factory Default
Input the VID	Specify the multicast group's associated VLAN ID.	None

### MAC Address

Setting	Description	Factory Default
Input the MAC address	Specify the multicast MAC address.	None

### Egress Port

Setting	Description	Factory Default
Input the port from the	Set the port(s) as an egress port(s) so that multicast streams	Nono
drop-down list	can be forwarded to this port.	None

### Forbidden Port

		Factory Default
Input the port from the	Set the port as forbidden so that packets cannot be forwarded	None
drop-down list	to this port.	None

When finished, select **CREATE**.

# **Network Redundancy**


Setting up the Redundancy Protocol on your network helps protect critical links against failure, protects against network loops, and keeps network downtime to a minimum.

The Redundancy Protocol allows you to set up redundant paths on the network to provide a backup data transmission route if a cable or one of the switches is inadvertently disconnected or damaged. This is a particularly important feature for industrial applications, since it can take several minutes to address the link down port or failed switch. For example, if a switch module is used as a key communications device for a production line, several minutes of downtime can cause a big loss in production and revenue. Switch modules support the following Redundancy Protocol functions:

- Spanning Tree
- Turbo Ring V2
- Turbo Chain
- Dual Homing

# **Layer 2 Redundancy**

First select Network Redundancy on the menu and then select Layer 2 Redundancy.



# **Spanning Tree**

### Spanning Tree Overview


Spanning Tree Protocol (STP) helps construct a loop-free logical typology on an Ethernet network and provides an automatic means of avoiding any network loops. This is particularly important for networks that have a complicated architecture, since unintended loops in the network can cause broadcast storms. Switch modules' STP feature is disabled by default. To be completely effective, enable STP/RSTP on every switch module connected to your network.

STP (802.1D) is a bridge-based system that is used to implement parallel paths for network traffic. STP uses a loop-detection process to:


- Locate and then disable less efficient paths (e.g., paths that have lower bandwidth).
- Enable one of the less efficient paths if a more efficient path fails.

### **How STP Works**


The figure below shows a network made up of three LANs separated by three bridges. Each segment uses at most two paths to communicate with the other segments. Since this configuration can give rise to loops, the network will overload if STP is not enabled.



If STP is enabled, it will detect duplicate paths or block one of the paths from forwarding traffic. In the following example, STP determined that traffic from segment 2 to segment 1 flows through switches C and A since this path is in a forwarding state and is processing BPDUs. However, switch B on segment 1 is in a blocking state.



What happens if a link failure is detected? As shown in the figure below, the STP will change the blocking state to a forwarding state so that traffic from segment 2 flows through switch B to segment 1 through a redundant path.



STP will determine which path between each segment is most efficient and then assign a specific reference point on the network. When the most efficient path has been identified, the other paths are blocked. In the previous three figures, STP first determined that the path through switch C was the most efficient, and as a result, blocked the path through switch B. After the failure of switch C, STP re-evaluated the situation and opened the path through switch B.

### **Difference Between STP and RSTP**

RSTP is like STP but includes additional information in the BPDUs that allows each bridge to confirm that it has taken action to prevent loops from forming when it decides to enable a link to a neighboring bridge. Adjacent bridges connected via point-to-point links will enable a link without waiting to ensure that all other bridges in the network have had time to react to the change. The main benefit of RSTP is that the configuration decision is made locally rather than network-wide, allowing RSTP to carry out automatic configuration and restore a link faster than STP.


STP and RSTP spanning tree protocols operate without regard to a network's VLAN configuration and maintain one common spanning tree throughout a bridged network. Thus, these protocols map one loop-free, logical topology on a given physical topology.

### STP/RSTP Settings and Status

This section describes how to configure **Spanning Tree** settings.

### General

Select Spanning Tree on the menu and then the General tab.




Configure the following settings.

### STP Mode

Setting	Description	Factory Default
Disabled	Disable Spanning Tree.	
STP/RSTP	Specify STP/RSTP as the STP mode.	Disabled
MSTP	Specify MSTP as the STP mode.	

Select **APPLY** to save your changes. When **STP/RSTP** has been selected, configure the following settings.



### STP Mode

Setting	Description	Factory Default
STP/RSTP	Use the STP/RSTP mode as the Spanning Tree protocol.	STP/RSTP

# Compatibility

Setting	Description	Factory Default
STP	To be compatible with STP mode only	RSTP
RSTP	To be compatible with RSTP and STP modes	

## **Bridge Priority**

Setting	Description	Factory Default
0 to 61440	Increase this device's bridge priority by selecting a lower number. A device with a higher bridge priority has a greater chance of being established as the root of the Spanning Tree	32768
	topology.	

# Forwarding Delay Time (sec.)

Setting	Description	Factory Default
14 to 30	The time the device waits before checking to see if it should	15
	change to a different state.	

### Hello Time (sec.)

Setting	Description	Factory Default
1 or 2	The root of the Spanning Tree topology periodically sends out a "hello" message to other devices on the network to check if	
	the topology is healthy. The "hello time" is the time the root waits between sending hello messages.	_

### Max Age (sec.)


Setting	Description	Factory Default
	If this device is not the root, and it has not received a hello message from the root in the time equal to "Max. Age," then	
6 to 40	this device will reconfigure itself as a root. Once two or more	20
	devices on the network are recognized as a root, the devices	
	will renegotiate a new Spanning Tree topology.	

### Error Recovery Time (sec.)

Setting	Description	Factory Default
	If the BPDU guard is triggered on a port, it will automatically recover to the normal state after the Error Recovery Time.	300

When finished, select **APPLY** to save your changes.

If you select **MSTP** as the STP mode, configure the following settings.



### STP Mode

Setting	Description	Factory Default
MSTP	Use the MSTP mode as the Spanning Tree protocol.	MSTP

# Compatibility

Setting	Description	Factory Default
MSTP	Only compatible with MTP mode.	
STP	Only compatible with STP mode.	MSTP
RSTP	Compatible with RSTP and STP modes.	]

# Forwarding Delay Time (sec.)

Setting	Description	Factory Default
4 to 30	The amount of time the device waits before checking to see if	15
	it should change to a different state.	13

# Hello Time (sec.)

Setting	Description	Factory Default
1 or 2	The root of the Spanning Tree topology periodically sends out	
	a "hello" message to other devices on the network to check if the topology is healthy. The "hello time" is the amount of time	
	the root waits between sending hello messages.	

# Max Age (sec.)

Setting	Description	Factory Default
	If this device is not the root, and it has not received a hello	
	message from the root in the amount of time equal to "Max.	
6 to 40	Age," then this device will reconfigure itself as a root. Once	20
	two or more devices on the network are recognized as a root,	
	the devices will renegotiate a new Spanning Tree topology.	

### Error Recovery Time (sec.)

Setting	Description	Factory Default
	If the BPDU guard is triggered on a port, it will automatically	300
30 to 03333	recover to the normal state after the Error Recovery Time.	300

## Region Name

Setting	Description	Factory Default
0 to 32 characters	Provides the region's name.	MSTP

# **Region Revision**

Setting	Description	Factory Default
0 to 65535 (characters)	Provides the regional revision.	0

### Max. Hops

Setting	Description	Factory Default
6 to 40	Provides the maximum hops value.	20


When finished, select  $\ensuremath{\mathbf{APPLY}}$  to save your changes.

# **Editing Spanning Tree for a Port**

To edit the spanning tree settings for a specific port, select the edit icon on the port you want to configure.

	Port	Enable	Edge	Priority	Path Cost	Link Type
	2	Disabled	Auto	128	0	Auto
	3	Disabled	Auto	128	0	Auto
/	4	Disabled	Auto	128	0	Auto
•	po1	Disabled	Auto	128	0	Auto

Configure the following settings.



### Enable

Setting	Description	Factory Default
Enabled	Enables Spanning Tree.	Disabled
Disabled	Disables Spanning Tree.	Disableu

# Edge

Setting	Description	Factory Default
Auto	Automatically detects to be the edge port.	
Yes	Set as an edge port.	Auto
No	Does not set as an edge port.	

# Priority

Setting	Description	Factory Default
III to 255 (militiples of	Increases the priority of a port by selecting a lower number. A port with a higher priority has a greater chance of being a root port.	

## Path Cost

Setting	Description	Factory Default
0 to 20000000	The path cost value will be automatically assigned according	0
0 to 20000000	to the different port speed if the value is set to zero.	U

# Link Type

Setting	Description	Factory Default
Force True	Set to Force True when port operating in full-duplex mode,	
roice irue	such as a switch.	Auto
Force False	Set to Force False when port operating in half-duplex mode,	
roice raise	such as a hub.	
Auto	Automatically select Force True or Force False mode.	

# Copy Config to Ports

Setting	Description	Factory Default
Select the port(s) from	Copy the configurations to other port(s).	None
the drop-down list	copy the configurations to other port(s).	None

Select **APPLY** to finish.

### **BPDU Overview**

BDPUs (Bridge Protocol Data Units) are the network communication frames used in the STP (Spanning Tree Protocol). When two switches exchange messages, BDPUs are used to calculate the STP topology and determine the network communication route. A BDPU filter is often used to screen sending or receiving BPDUs on a specific port of the switch.

#### **BPDU Guard**

BDPU Guard is a protection mechanism that prevents a port from receiving BPDUs. When an RSTP-enabled port receives BPDUs, it will automatically be in the error-disable state, which means the port will in turn switch to Block state. When STP is enabled, all ports are involved in the STP domain, sending and receiving BPDUs. However, when BPDU Guard is enabled, all ports will not receive or send any BPDUs, as all computers and unmanaged switches do not support STP. When BPDU Guard is enabled, all communications will be treated as error-disabled, and the related ports will be blocked, therefore no more data will be sent or received, protecting the network from a loop chain.

### **Root Guard**

**Root Guard** prevents a designated port role in changing to a root port role on reception of superior information.

### **Loop Guard**


**Loop Guard** prevents temporary loops in a network caused by **non-designated ports** changing to the spanning-tree **forwarding** state because of a link failure in the topology.

### **BPDU Filter**


**BPDU Filter** prevents a port from sending and processing BPDUs. A BPDU filter enabled port cannot transmit any BPDUs and drop all received BPDUs.

# Configuring BPDU Filter, BPDU/Root/Loop Guard Settings

First select **Spanning Tree** on the menu and then the **Guard** tab. Next, select the edit icon on the port you want to configure.



Configure the following settings.



# **BDPU** Guard

Setting	Description	Factory Default
Enabled	Enables BDPU Guard.	Disabled
Disabled	Disables BDPU Guard.	Disabled



# **NOTE**

To establish a redundant port, e.g., it is highly recommended that you do not enable the BPDU filter.

### Root Guard

Setting	Description	Factory Default
Enabled	Enables Root Guard.	Disabled
Disabled	Disables Root Guard.	Disableu

# Loop Guard

Setting	Description	Factory Default
Enabled	Enables Loop Guard.	Disabled
Disabled	Disables Loop Guard.	Disabled

### **BDPU Filter**

Setting	Description	Factory Default
Enabled	Enables BDPU Filter.	Disabled
Disabled	Disables BDPU Filter.	Disabled


# Copy Config to Port

		Factory Default
Select the port(s) from	Copies the same settings as other port(s).	None
the drop-down list	copies the same settings as other port(s).	None


When finished, select **APPLY** to save your changes.

# **Viewing Current Spanning Tree Status**

Select the Status tab to view the current Spanning Tree status.



In addition, the status for each port will also be shown below.



Refer to the following table for a detailed description of each item.


Item	Description
Port	The port number on this device.
Edge	Shows if this port is connected to an edge device.
	Root: The port is connected directly or indirectly to the root device.
	Designated: The port is designated if it can send the best BPDU on the segment to
	which it is connected.
Port Rule	Alternate: The alternate port receives more useful BPDU from another bridge and is
l ort Kule	a blocked port.
	Backup: The backup port receives more useful BPDU from the same bridge and is
	the blocked port.
	Disabled: The function is disabled.
	Forwarding: The traffic can be forwarded through this port.
Port State	Blocked: The traffic will be blocked.
	Disabled: The function is disabled.
Root Path Cost	The total path cost to the root bridge.
Path Cost	The path cost on this link.
	Edge Port: The port is connected to an edge device.
Link Type	Point-to-Point Non-edge Port: The port is connected to another bridge and is full
Ешк туре	duplex.
	Shared Non-edge Port: The port is connected to another bridge and is half duplex.
BPDU Inconsistency	BPDU is received in a port enabled by a BPDU guard.
Root Inconsistency	A port is changed to a root port when enabled by a loop guard.
Loop Inconsistency	A loop is detected on this port by a loop guard.

# Turbo Ring v2

## **Turbo Ring v2 Overview**

Moxa Turbo Ring is a proprietary self-healing technology that enables fast fault recovery of under 20 ms for Fast Ethernet, and 50 ms for Gigabit Ethernet. Turbo Ring supports two topology expansions—ring coupling and dual-ring—to reduce redundant network cabling and network planning costs and to ensure high reliability of your industrial network applications.

The Turbo Ring v2 protocols identify one switch as the client of the network, and then automatically block one port beside the client on the ring (red line) to avoid network's redundant loops. If one branch of the ring gets disconnected from the rest of the network, the protocol automatically readjusts the ring so that the part of the network that was disconnected can reestablish contact with the rest of the network.




## **How Turbo Ring v2 Works**

Turbo Ring v2 is an advanced technology for network redundancy, which ensures recovery times of less than 20 ms for Fast Ethernet, and 50 ms for Gigabit Ethernet when the network is down. In addition, it allows more switches within the network rings. You can select different network typologies for Turbo Ring redundancy to allow more network reliability and reduce cabling costs. Below are three examples of how Turbo Ring v2 works.


### **Ring Coupling**

Ring Coupling helps you separate distributed devices into different smaller redundant rings, but in such a way that the smaller rings at different remote sites will be able to communicate with each other. This is useful for applications where some devices are at remote sites.



# **Dual-Ring**


Dual-ring adds reliability by using a single switch module to connect two separate rings for applications that present cabling difficulties. It provides another ring coupling configuration where two adjacent rings can share one switch. This typology is an ideal solution for applications that have inherent cabling difficulties.




### **How to Determine the Redundant Path**

For Turbo Ring v2, the client is determined by two methods: one is a system MAC address election, the smallest MAC address will play the client role; the other is user manual configuration to enable the client role on the switch.

The redundant path is determined by "Ring Port 2", which means the port set on "Ring Port 2" will become the blocking port.



# Ring Coupling for a "Turbo Ring V2" Ring



For Turbo Ring V2, Ring Coupling is enabled by configuring the **Coupling Port (Primary)** on Switch B, and the **Coupling Port (Backup)** on Switch A only.

The **Coupling Port (Backup)** on Switch A is used for the backup path, and connects directly to an extra network port on Switch C. The **Coupling Port (Primary)** on Switch B monitors the status of the main path, and connects directly to an extra network port on Switch D. With ring coupling established, Switch A can activate the backup path as soon as it detects a problem with the main path.



## **ATTENTION**

Ring Coupling needs to be enabled on one coupling primary switch and one coupling backup switch as the Ring Coupler. The Coupler must designate different ports, such as the two Turbo Ring ports and the coupling port.



## **NOTE**

- 1. You do not need to use the same switch for both Ring Coupling and Ring Master.
- 2. To achieve optimal redundancy performance, it is recommended to use 1G fiber for Turbo Ring.


# **Turbo Ring V2 Settings and Status**



# **NOTE**

If you connect the EDR-G9010 Series in your topology, ensure it is not set as the client.

Select Turbo Ring V2 on the menu, and then select the Setting tab.



Configure the following setting.

### Enable

Setting	Description	Factory Default
Enabled	Enable Turbo Ring V2.	-Disabled
Disabled	Disable Turbo Ring V2.	


When finished, select **APPLY** to save your changes.

# **Ring Settings**

In Ring Setting, select the edit icon.



Configure the following settings. When finished, select **Apply** to save your changes.



### Enable

Setting	Description	Factory Default
Enabled	Enables Ring Setting.	Disabled
Disabled	Disables Ring Setting.	

### Master

Setting	Description	Factory Default
Enabled	Enables this Ring as the client.	-Disabled
Disabled	Disables this Ring as the client.	

### Ring Port 1

		Factory Default
Select the port from the	Specifies this port as the first redundant port.	1/1
list		

### Ring Port 2

		Factory Default
Select the port from the	Specifies this port as the second redundant port.	1/2
list		

# **Ring Coupling Overview**


Ring Coupling helps you separate distributed devices into different smaller redundant rings, but in such a way that the smaller rings at different remote sites will be able to communicate with each other. This is useful for applications where some devices are at remote sites.

# **Ring Coupling Settings and Status**

In the  ${\bf Ring\ Coupling\ Setting},$  select the edit icon.



Configure the following settings.



### Enable

Setting	Description	Factory Default
Enabled	Enables Ring Coupling.	-Disabled
Disabled	Disables Ring Coupling.	

# Coupling Mode

Setting	Description	Factory Default
Counting Backup Path	Selects Coupling Mode to assign the coupling port as the backup path.	Coupling Primary Path
If alining Primary Path	Selects Coupling Mode to assign the coupling port as the primary path.	


### **Coupling Port**

		Factory Default
Select the port from the	Selects the port as the coupling port. 2/	2/1
list		2/1

When finished, select **APPLY** to save your changes.

# **Ring Settings and Ring Coupling Setting Status**

Select **Status** in the Turbo Ring V2 menu to view the current Ring settings and the Ring Coupling Status.



Refer to the following table for a detailed description of each item of the Ring status.

Item	Description
Ring ID	The ID number of the Ring.
Master ID	The MAC address of the Ring client.
Status	Healthy: The Ring and the ports are working properly.
Status	Break: One or more rings has been broken.
Master	The device is a client/server on this ring.
Ring Port 1	The port of the first ring port.
Ring Port 2	The port of the second ring port.

Refer to the following table for a detailed description of the status of Coupling Mode and Coupling Port.

Item	Description
Coupling Mode	Primary: The main path of Ring Coupling.
Coupling Mode	Backup: The backup path of Ring Coupling.
Coupling Port	The port of the Ring Coupling.

### **Turbo Chain**

### **Turbo Chain Overview**


Moxa's Turbo Chain is an advanced software technology that gives network administrators the flexibility of constructing any type of redundant network topology. In addition, it offers system recovery time under 20 ms for Fast Ethernet, and 50 ms for Gigabit Ethernet for member port link environments. When using the "chain" concept, you first connect the Ethernet switches in a chain and then simply link the two ends of the chain to an Ethernet network.

Turbo Chain can be used on industrial networks that have a complex topology. If the industrial network uses multi-ring architecture, Turbo Chain can be used to create flexible and scalable topologies with a fast media-recovery time.

### **How Turbo Chain Works**

Moxa's Turbo Chain outperforms traditional ring topologies by providing great flexibility, unrestricted expansion, and cost-effective configurations when connecting separate redundant rings together—in a simplified manner. With Turbo Chain, you can create any complex redundant network that corresponds to your needs, while still ensuring great reliability and availability for your industrial Ethernet network applications.

With Moxa's Turbo Chain, network engineers have the flexibility to construct any type of redundant topology with minimum effort by simply linking Turbo Chain to the Ethernet Network. Turbo Chain allows for unrestricted network expansion. Network engineers no longer need to go through the hassle of reconfiguring the existing network and can simply use Turbo Chain to scale up their redundant networks.




### **How to Determine the Redundant Path**

Here is an example of how to set up Turbo Chain and determine the redundant path.

- 1. Select the head switch, tail switch, and member switches.
- 2. Configure one port as the head port and one port as the member port in the head switch, configure one port as the tail port and one port as the member port in the tail switch, and configure two ports as Member ports in each of the member switches.
- 3. Connect the head switch, tail switch, and member switches, as shown in the diagram below.

The path connecting to the head port is the main path, and the path connecting to the tail port is the backup path of Turbo Chain. Under normal conditions, packets are transmitted through the head port to the LAN network. If any Turbo Chain path is disconnected, the Tail Port will be activated so that packet transmission can continue.




There are two points to note:

- 1. Two chain ports must have the same PVID.
- 2. Chain ports must join the untagged members of PVID VLAN before being assigned to be a chain port.

### **Turbo Chain V2 Settings and Status**

First select Turbo Chain on the menu and then Setting.



Configure the following settings.

### Enable

Setting	Description	Factory Default
Enabled	Enables Turbo Chain.	-Disabled
Disabled	Disables Turbo Chain.	

### Chain Role

Setting	Description	Factory Default
Head	Enables chain role as the head.	
Member	Enables chain role as a member.	Member
Tail	Enables chain role as the tail.	

### Head/Member/Tail Port


		Factory Default
Select the port from the	Specifies the port as the head/member/tail port.	1/1
list	Specifies the port as the flead/fileffiber/tail port.	1/1

### Member Port

		Factory Default
Select the port from the list	Specifies the port as the member port.	1/2

When finished, select **APPLY** to save your changes.

Select **Turbo Chain** on the menu and then **Status** to view the current Turbo Chain status.



Refer to the following table for a detailed description of each item.

Item	Description	
	Head: The device is the head of this chain.	
Turbo Chain	Member: The device is a member of this chain.	
	Tail: The device is the tail of this chain.	
Chain Role	Healthy: The Chain and the ports are working properly.	
Chain Role	Break: The chain or the ports are broken.	
Head/Member/Tail 1 Port Status	The status of the first Head/Member/Tail port.	
Head/Member/Tail 2 Port Status	The status of the second Head/Member/Tail port.	

# **Dual Homing**


### **Dual Homing Overview**

Dual Homing is a layer 2 function, which uses a single Ethernet switch to connect two network topologies, both of which can run any redundancy protocols. It involves coupling two separate devices or even coupling to two separate rings with a single switch connecting to two independent connection points. The secondary path will be activated if the primary path fails.

## **How Dual Homing Works**

Dual Homing is a redundant path technology that allows a single switch to connect to any topology.

The primary and secondary paths require manual configuration: Select a primary port as the primary path and the secondary port as the secondary path. The default path switching mode is "primary path always first", which means when failover occurs, the primary path will switch to the secondary path, but if the primary path recovers, the path will switch back to the primary path again even if the secondary path is healthy.



# **Path Switching Mode**


There are two path switch modes that you can configure:

**Primary path always first:** Always select the path switching mode as the primary path first. When path switching occurs, the primary path will always be the first path for data communication.

**Maintain current path:** Select the path switching mode to maintain the current path. When path switching occurs, maintain the current path to keep the network stable and do not change paths for data communication.

### **Dual Homing Settings and Status**

Select **Dual Homing** in the menu and then **Setting**.



Configure the following settings.

### Enable

Setting	Description	Factory Default
Enabled	Enables Dual Homing.	Disabled
Disabled	Disables Dual Homing.	Disabled

# **Primary Port**

		Factory Default
Select the port from the	Specifies the port as the primary port.	1/1
list	specifies the port as the primary porti	-/ -

### Secondary Port


		Factory Default
Select the port from the	Specifies the port as the secondary port.	1/1
list	Specifies the port as the secondary port.	1/1

### Path Switching Mode

Setting	Description	Factory Default
Primary path always first	Always select path switching mode as the primary path first.	Primary path always
Maintain current path	Always select the path switching mode to maintain the current path.	first

When finished, select **APPLY** to save your changes.

First, select **Dual Homing** in the menu and then **Status** to view the current Dual Homing Settings.



Refer to the following table for a detailed description of each item.

Item	Description	
Path	Primary: The primary path of dual homing.	
ratii	Secondary: The secondary path of dual homing.	
Port	The port that is used as the primary/secondary path.	
Link Status	Link Up: The port is connected.	
LINK Status	Link Down: The port is disconnected.	
Port State	Forwarding: The port is forwarding traffic.	
Port State	Blocking: The port is blocking traffic.	

# Management

This section describes how to configure Network Management including SNMP and SNMP Trap/Inform.



# **Network Management**

This section demonstrates how to configure **SNMP** and **SNMP Trap/Inform** settings.

### **SNMP**

The ioPAC 6500 Layer 2 Managed Ethernet Switch Module support SNMP V1, V2c, and V3. SNMP V1 and SNMP V2c use a community string match for authentication, so SNMP servers access all objects with read-only or read/write permission using the community strings public and private by default. SNMP V3 requires that you select an authentication level of MD5 or SHA. You can also enable data encryption to enhance data security.

Supported SNMP security modes and levels are shown in the table below. Select the security mode and level that will communicate between the SNMP agent and manager.

Protocol Version	UI Setting	Authentication	Encryption	Method
SNMP V1,	V1, V2c Read Community	Community string	No	Uses a community string match for authentication.
V2c	V1, V2c Write/Read Community	Community string	No	Uses a community string match for authentication.
	None	No	No	Uses an account with admin or user to access objects.
SNMP V3	MD5 or SHA	Authentication based on MD5 or SHA	Disabled	Uses authentication based on HMAC-MD5, or HMAC-SHA algorithms. 8-character passwords are the minimum requirement for authentication.
	MD5 or SHA	Authentication based on MD5 or SHA	Data encryption key: DES, AES	Uses authentication based on HMAC-MD5 or HMAC-SHA algorithms, and data encryption key. 8-character passwords and a data encryption key are the minimum requirements for authentication .and encryption.




### **NOTE**

SNMPv3 enhances security, as it includes authentication and data privacy. If you require a higher level of security, it is recommended to install additional security mechanisms, such as a firewall, to protect critical infrastructure.

# **General Settings**

First select **SNMP** on the menu and then **General**.



Configure the following settings.

### SNMP Version

Setting	Description	Factory Default
V1, V2c, V3	Specify V1, V2c, and V3 as the SNMP version.	
V1, V2c	V2c Specify V1 and V2c as the SNMP version.	
V3 only	Specify V3 as the SNMP version.	

### Read Community

Setting	Description	Factory Default
Max. 30 characters	Specifies the community string to authenticate the SNMP agent for read-only access. The SNMP agent will access all objects with read-only permissions using this community string.	Public


# Read/Write Community

Setting	Description	Factory Default
Max. 30 characters	Specifies the community string to authenticate the SNMP agent for read/write access. The SNMP server will access all objects with read/write permissions using this community string.	Private


When finished, select **Apply** to save your changes.

# **Creating an SNMP Account**

Select **SNMP** on the menu and then **SNMP Account**. Next, select the **+** icon on the page.



Configure the following settings.



### Username

Setting	Description	Factory Default
At least 4 characters,	Input a ucornamo	None
(max. 32 characters)	Input a username.	None

### Authority

Setting	Description	Factory Default
Read Write	The user has read/write access.	None
Read Only	The user only has read access.	None

# Authentication type

Setting	Description	Factory Default
None	No authentication will be used.	
MD5	MD5 is the authentication type.	None
SHA	SHA is the authentication type.	

### Authentication password

•		
Setting	Description	Factory Default
8 to 64 characters	Input the authentication password.	None

### **Encryption Method**

Setting	Description	Factory Default
Disabled	Disables the encryption method.	
DES	DES is the encryption method.	None
AES	AES is the encryption method.	]

### Encryption Key

Setting	Description	Factory Default
8 to 30 characters	Enables data encryption.	None

When finished, select **CREATE**.



# **NOTE**


SNMPv3 enhances security management by using authentication and ensuring data privacy. If you intend to pursue a higher level of security, it is recommended to install additional security mechanisms, such as a firewall, to protect critical infrastructure.

# **Deleting an Existing SNMP Account**

To delete an existing SNMP account, select the delete icon on the account.




Select **DELETE** to delete the SNMP account.



# **SNMP Trap/Inform**

# **General Settings**

First select **SNMP Trap/Inform** on the menu and then **General**.



Configure the following settings.


### Retry

Setting	Description	Factory Default
1 to 99	Input the retry value.	3
Timeout		
Setting	Description	Factory Default
1 to 300	Input the timeout value.	10


When finished, select **APPLY** to save your changes.

# **SNMP Trap Host Settings**

SNMP Trap allows an SNMP agent to notify the NMS of a significant event. The switch supports two SNMP modes: **Trap** mode and **Inform** mode. Select **SNMP Trap/Inform** on the menu and then **SNMP Trap Host**. Then select the **+** icon on the page.



Configure the following settings.



## Host IP/Name

Setting	Description	Factory Default
Iname, (max. 32	Specify the name of the primary trap server used by your network.	None

### Mode

Setting	Description	Factory Default
Trap V1	Set the trap version to Trap V1.	
Trap V2c	Set the trap version to Trap v2c.	
Inform V2c	Set the inform version to Inform V2c.	None
Trap V3	Set the trap version to Trap V3.	
Inform V3	Set the inform version to Inform V3.	


# Trap Community

Setting	Description	Factory Default
At least 4 characters,	Specify the community string that will be used for	None
(max. 30 characters)	authentication.	None


When finished, select CREATE.

# **SNMP Trap Account Settings**

Select **SNMP Trap/Inform** on the menu and then **SNMP Trap Account**. Next, select the + icon on the page.



Configure the following settings:



### Username

Setting	Description	Factory Default
At least 4 characters,	Input a username.	None
(max. 30 characters)	input a asemanic.	None

# Authentication type

Setting	Description	Factory Default
None	No authentication type will be used.	
MD5	MD5 is the authentication type.	None
SHA	SHA is the authentication type.	

# **Authentication Password**

Setting	Description	Factory Default
8 to 64 characters	Input the authentication password.	None

# **Encryption Method**

Setting	Description	Factory Default
Disabled	Disable the encryption method.	
DES	DES is the encryption method.	None
AES	AES is the encryption method.	

## **Encryption Key**

Setting	Description	Factory Default
8 to 64 characters	Enable data encryption.	None

When finished, select **CREATE**.

# Security

This section describes how to configure **Device Security, Network Security,** and **Authentication**.



# **Device Security**

This section includes information about the **Management Interface, Login Policy, Trusted Access,** and **SSH and SSL** configurations.




# **Management Interface**

Select Management Interface to configure the settings for User Interface.



# **User Interface**



Configure the following settings.

### HTTP

Setting	Description	Factory Default
Enabled	Enable the HTTP connection.	-Enabled
Disabled	Disable the HTTP connection.	



# **NOTE**

An HTTP session will be redirected to HTTPs if both HTTP and HTTPs are enabled.

# HTTP - TCP Port

Setting	Description	Factory Default
0 to 47808	Specify the HTTP connection port number.	80

## HTTPS

Setting	Description	Factory Default
Enabled	Enable the HTTPS connection.	-Enabled
Disabled	Disable the HTTPS connection.	

### HTTPS - TCP Port

Setting	Description	Factory Default
1 to 65535	Specify the HTTP connection port number.	443

## Telnet

Setting	Description	Factory Default
Enabled	Enable a Telnet connection.	-Disabled
Disabled	Disable a Telnet connection.	

### Telnet - TCP Port

Setting	Description	Factory Default
1 to 65535	Specify the Telnet connection port number.	23

### SSH

Setting	Description	Factory Default
Enabled	Enable the SSH connection.	Enabled
Disabled	Disable the SSH connection.	

### SSH - TCP Port

Setting	Description	Factory Default
1 to 65535	Input the SSH connection port number.	22

### SNMP

Setting	Description	Factory Default
Enabled	Enable the SNMP connection.	Disabled
Disabled	Disable the SNMP connection.	

### SNMP - Port

Setting	Description	Factory Default
0 to 47808	Input the SNMP connection port number.	161

### Moxa Service

Setting	Description	Factory Default
Enabled	Enable Moxa Service.	-Enabled
Disabled	Disable Moxa Service.	

When you enable a non-secure protocol, such as Telnet, a warning screen will appear. Select **CONFIRM** to make sure you want to enable the protocol.





# **NOTE**

Moxa Service is only for Moxa network management software suite.

### Moxa Service (Encrypted)—TCP Port

Setting	Description	Factory Default
443 (read only)	Enable a Moxa Service TCP port.	443

# Moxa Service (Encrypted)—UDP Port

Setting	Description	Factory Default
40404 (read only)	Enable a Moxa Service UDP port.	40404

# Maximum number of Login Sessions for HTTP+HTTPS

Setting	Description	Factory Default
11 t∩ 1()	Specify the maximum amount of HTTP and HTTPS login	5
	sessions that can happen simultaneously.	


### Maximum number of Login Sessions for Telnet+SSH

Setting	Description	Factory Default
11 to 5	Specify the maximum amount of Telnet and SSH login sessions that can happen simultaneously.	1

When finished, select **APPLY** to save your changes.

# **Login Policy**

Select Login Policy on the menu.



Configure the following settings.

# Login Message

Setting	Description	Factory Default
0 to 500 characters	Input the message that will be displayed to users when they log in.	None

### Login Authentication Failure Message

Setting	Description	Factory Default
0 to 500 characters	Input the message that will be displayed when users cannot log in.	None

### Account Login Failure Lockout

Setting	Description	Factory Default
Enabled	Enables the lockout function when a user cannot log in. Note that this will work on web, command-line interface, and SNMP V3 protocols.	Disabled
Disabled	Disables the lockout function when a user cannot log in.	

# Retry Failure Threshold (times)

Setting	Description	Factory Default
1 to 10	Input the maximum number of retry failure times.	5

# Lockout Time (min.)

Setting	Description	Factory Default
1 to 60	Specifies the time (in minutes) that a user cannot log in after the retry failure threshold is achieved.	5

# Auto Logout Setting (min.)

Setting	Description	Factory Default
10 to 1440	Specify how long a user must be inactive before getting	5
	logged out.	J

When finished, select **APPLY** to save your changes.


### **Trusted Access**

### **Trusted Access Overview**

Trusted Access is a mechanism that provides a secure connection to the switch module. Use this method to allow the connection from the assigned IP address to ensure safe data transmission.

## **Trusted Access Settings and Status**

Select Trusted Access on the menu.



Configure the following settings.

### Enable

Setting	Description	Factory Default
Enabled	Enables Trusted Access.	Disabled
Disabled	Disables Trusted Access.	




## **NOTE**


- 1. Trusted Access must be added before it can be enabled.
- 2. To avoid being disconnected after you enable Trusted Access, you must first add the current IP subnet to Trusted Access. To use this function, you should use an RS-232 console to log in or set the device to factory default.

When finished, select **APPLY** to save your changes.

Next, select the + icon.



Configure the following settings.



### IP Address

Setting	Description	Factory Default
Input IP address	Specifies the IP address that is allowed to connect to switch module.	None

### Netmask


Setting	Description	Factory Default
IInput Netmask	Specifies the Netmask that is allowed to connect to switch module.	None

When finished, select **CREATE**.


View the Trusted Access status in the figure below.



To delete the trusted access source, select the item and then delete the icon on the top of the page.




Select **DELETE** to delete the item.



### SSH & SSL

## **SSH Key Regeneration**


Select **SSH & SSL** on the menu and then the **SSH** tab.



Select **REGENERATE** to regenerate the key.

# **SSL Certification Regeneration**

Select SSH & SSL on the menu and the SSL tab. The Certificate Information is shown on this screen.



We recommend using a certificate that is signed by the certification authority to enhance security. Configure the following settings and use the steps below to import the certificate.

- 1. Export the CSR file from the switch and provide it to the certification authority to generate the certificate.
- 2. Import the certificate signed by the certification authority to the switch.

### Export SSL Certificate Request

Setting	Description	Factory Default
Export	Export the SSL certificate to your local computer.	None

### Regenerate SSL Certificate


Setting	Description	Factory Default
Regenerate	Regenerates the SSL certificate.	None

#### Import Certificate

Setting	Description	Factory Default
Select the file	Imports the SSL certificate from the location where the SSL	None
	certificate is located.	None

# **Network Security**

This section shows how to configure network security settings, including IEEE802.1X, MAC Authentication Bypass, Port Security, Traffic Storm Control, Access Control List, and Loop Protection.



### **IEEE 802.1X**

# Port-based IEEE 802.1X Overview

The IEEE 802.1X standard defines a protocol for client/server-based access control and authentication. The protocol restricts unauthorized clients from connecting to a LAN through ports that are open to the Internet, and which otherwise would be readily accessible. The purpose of the authentication server is to check each client that requests access to the port. The client is only allowed access to the port if the client's permission is authenticated.

Three components are used to create an authentication mechanism based on 802.1X standards: Client/Supplicant, Authentication Server, and Authenticator.

**Client/Supplicant:** The end station that requests access to the LAN and switch services and responds to the requests from the switch.

Authentication Server: The server that performs the actual authentication of the supplicant.


**Authenticator:** Edge switch or wireless access point that acts as a proxy between the supplicant and the authentication server, requesting identity information from the supplicant, verifying the information with the authentication server, and relaying a response to the supplicant.

The switch module acts as an authenticator in the 802.1X environment. A supplicant and an authenticator exchange EAPOL (Extensible Authentication Protocol over LAN) frames with each other. We can either use an external RADIUS server as the authentication server or implement the authentication server in the switch module by using a Local User Database as the authentication look-up table. When we use an external RADIUS server as the authentication server, the authenticator and the authentication server exchange EAP frames.

Authentication can be initiated either by the supplicant or the authenticator. When the supplicant starts the authentication process, it sends an **EAPOL-Start** frame to the authenticator. When the authenticator starts the authentication process or when it receives an **EAPOL Start** frame, it sends an **EAP Request/Identity** frame to ask for the username of the supplicant.

### **How IEEE 802.1X Works**

802.1X authentication requires three parties: a supplicant, an authenticator, and an authentication server. The supplicant is a client device that wishes to connect to the LAN or WLAN. The supplicant can also use the software to run on the client that offers credentials to the authenticator. Network administrators usually use an Ethernet switch or wireless access point as the authenticator and running software supporting RADIUS and EAP protocols in the authentication server.



The authenticator serves as a security guard to a protected network. The supplicant is not allowed access through the authenticator to the protected side of the network unless the supplicant's identity has been validated and authorized. With 802.1X port-based authentication, the supplicant provides credentials, such as username/password or digital certificate, to the authenticator, and the authenticator transmits the credentials to the authentication server for verification. If the authentication server approves the credentials as valid, the supplicant (client device) is allowed to access resources located on the protected side of the network.

## IEEE 802.1X Settings

Select IEEE802.1X on the menu and then the General tab.



# **NOTE**

Only ports 1 to 10 support 802.1X setting. SW1, SW2, CPU1, CPU2 are internal communication ports. This function cannot be edited in these ports.



Configure the following settings.

### IEEE 802.1X


Setting	Description	Factory Default
Enabled	Enables IEEE 802.1X.	-Disabled
Disabled	Disables IEEE 802.1X.	

## Authentication Mode

Setting	Description	Factory Default
Local Database	Uses the local database as the authentication mode.	Local Database
RADIUS	Uses the RADIUS as the authentication mode.	

When finished, select **APPLY** to save your changes.

To configure the IEEE 802.1X settings for the specific port, select the edit icon on the port.



Configure the following settings.



### Enable

Setting	Description	Factory Default
Enabled	Enables IEEE 802.1X.	-Disabled
Disabled	Disables IEEE 802.1X.	

### Port Control

Setting	Description	Factory Default
Force Unauthorized	The controlled port must be held in the Unauthorized state.	
Auto	The controlled port is set to the authorized or unauthorized	
	state in accordance with the outcome of an authentication	Auto
	exchange between the Supplicant and the Authentication	
	Server.	
Force Authorized	The controlled port is required to be held in the authorized	
	state.	

### Max Request (times)

Setting	Description	Factory Default
1 to 10	Enables re-authentication request time.	2

## Quiet Period (sec.)

Setting	Description	Factory Default
	Specifies the duration of time that the switch remains in the	
0 to 65535	muted state following a failed authentication exchange with	60
	the client.	

### Reauthentication

Setting	Description	Factory Default
Enabled	Enables re-authentication.	Disabled
Disabled	Disables re-authentication.	

## Reauth Period (sec.)

Setting	Description	Factory Default
11 to 65535	Input the duration of time between re-authentication	3600
	attempts.	

### Server Timeout (sec.)

Setting	Description	Factory Default
1 to 65535	Input the duration of time that the switch will re-transmit the	20
	packets from the switch to the authentication server.	30

### Supp (Supplicant, such as Client PC) Timeout (sec.)

Setting	Description	Factory Default
1 to 65535	Input the duration of time that the switch will re-transmit the	20
	packets from the switch to the client.	30

### Tx Period (sec.)

Setting	Description	Factory Default
1 to 65535	Input the duration of time that the switch will re-transmit the	30
	data to the client.	

### Copy Config to Ports

Setting	Description	Factory Default
Select the port(s) from	Allows users to copy configurations to other port(s).	None
the drop-down list	Allows users to copy configurations to other port(s).	None

When finished, select  $\ensuremath{\mathbf{APPLY}}$  to save your changes.


#### IEEE 802.1X Database

#### **RADIUS**

RADIUS **Remote Authentication Dial in User Service** is a protocol that involves three services in one network protocol: Authentication, Authorization, and Accounting (AAA). The protocol operates in port 1812, and the AAA management for users connecting to a network service.

RADIUS is based on a client/server protocol that runs in the application layer and can use either TCP or UDP as the mode of transport. The network access servers that contain the RADIUS protocol can allow the client to communicate with the RADIUS server. Through Authentication, Authorization, and Accounting, RADIUS is used to monitor access to the network.

To configure RADIUS settings, select the **RADIUS** tab.



Configure the following settings.

### Server Address 1

		Factory Default
To input server address 1	Specifies the first server address.	None

### Auth Port

Setting	Description	Factory Default
1 to 65535	Specifies the authentication port number for the first server address.	None

### Share Key

Setting	Description	Factory Default
Input the share key for		
the first server, (0 to	Specifies the share key for the first server.	None
46)		

## Timeout (sec.)

Setting	Description	Factory Default
1 to 120	Specifies the duration of time before a device is logged out.	None

## Retransmit (sec.)

Setting	Description	Factory Default
1 to 254	Specifies the time for data retransmission.	None

### Server Address 2

		Factory Default
To input server address 2	Specify the second server address.	None

### **Auth Port**

Setting	Description	Factory Default
1 to 65535	Specifies the authentication port number for the first server address.	None

#### Share Key

Setting	Description	Factory Default
Input the share key for		
the second server (0 to	Specifies the share key for the second server.	None
46)		

## Timeout

Setting	Description	Factory Default
1 to 120	Specifies the duration of time before the device is timed out.	None

### Retransmit (sec.)

Setting	Description	Factory Default
1 to 254	Specifies the time for data re-transmission.	None

When finished, select **APPLY** to save your changes.



## **NOTE**


The RADIUS service will be operated via the first server first; if it fails, it will be run on the second server.

### **Local Database**

First, select the **Local Database** tab and then the + icon.



Configure the following settings.



#### Username

Setting	Description	Factory Default
0 to 20 characters	Specifies the username for the local database.	None

#### Password

Setting	Description	Factory Default
At least 4 characters,	Charifies the password for the local database user	None
(max. 64 characters)	Specifies the password for the local database user.	None

#### Confirm Password

Setting	Description	Factory Default
At least 4 characters,	Confirms the password for the local database user	None
(max. 64 characters)	Confirms the password for the local database user.	NOTIE

When finished, select **APPLY** to save your changes.

## **MAC Authentication Bypass**

Select MAC Authentication Bypass on the function menu.




## **NOTE**

Only ports 1 to 10 support MAC Authentication Bypass setting. SW1, SW2, CPU1, and CPU2 are internal communication ports. This function cannot be edited in these ports.

#### **General**

Select the **General** tab for general settings.



### MAC Authentication Bypass

Setting	Description	Factory Default
Enabled	Enables the MAC authentication bypass function.	None
Disabled	Disables the MAC authentication bypass function.	None


#### **Authentication Mode**

Setting	Description	Factory Default
RADIUS	Selects RADIUS as the authentication mode.	None
Local Database	Selects local database as the authentication mode.	

When finished, select **APPLY** to save your changes.

## **RADIUS**

Select the **RADIUS** tab to perform further configurations.



Configure the following settings.

### Server Address 1

		Factory Default
To input server address 1	Specifies the first server address.	None

#### Auth Port

Setting	Description	Factory Default
11 to 65535	Specifies the authentication port number for the first server address.	None

### Share Key

Setting	Description	Factory Default
Input the share key for		
the first server, (0 to	Specifies the share key for the first server.	None
46)		

### Timeout (sec.)

Setting	Description	Factory Default
1 to 120	Specifies the duration of time before a device is logged out.	None

### Retransmit (sec.)

Setting	Description	Factory Default
1 to 254	Specifies the time for data retransmission.	None

### Server Address 2

		Factory Default
To input server address 2	Specifies the second server address.	None

#### **Auth Port**

Setting	Description	Factory Default
1 to 65535	Specifies the authentication port number for the first server address.	None

## Share Key

Setting	Description	Factory Default
Input the share key for		
the second server (0 to	Specifies the share key for the second server.	None
46)		

### Timeout

Setting	Description	Factory Default
1 to 120	Specifies the duration of time before the device is timed out.	None

### Retransmit (sec.)

Setting	Description	Factory Default
1 to 254	Specifies the time for data retransmission.	None

When finished, select  $\ensuremath{\mathbf{APPLY}}$  to save your changes.




## **NOTE**

The RADIUS service will be operated via the first server first. If it fails, it will be run on the second server.

## **Local Database**

Select **Local Database** tab and then select **!** icon for further configurations.



Configure the following setting.



#### MAC Address

Setting	Description	Factory Default
MAC Address	Specifies the MAC address used for MAC authentication	None
	bypass.	

When finished, select CREATE to complete.

### **Port Security**



#### NOTE

Only port 1 to 10 support Port Security setting. SW1, SW2, CPU1, CPU2 are internal communication ports. This function cannot be edited in these ports.

## **MAC Sticky Overview**


MAC Sticky is a function that allows users to configure the maximum number of MAC addresses (the Limit) that a port can "learn". Users can configure what action should be taken (under Secure Action) when a new MAC address tries to access a port after the maximum number of MAC addresses have already been learned. The total number of allowed MAC addresses cannot exceed 1024.

### **How MAC Sticky Works**

In MAC Sticky mode, administrators can set a proper limit number and then configure trust devices manually, or let the system configure trust devices automatically. Except for dropping packets as a response to any violations, administrators can set 'port shutdown' on a port and achieve a strict security guarantee. When a violation is registered on a port, the port will shut down and an administrator will receive a notification to perform a check.

## **MAC Sticky Settings and Status**

To configure the MAC Sticky settings, select the **General** tab in **Port Security**.



Configure the following settings.

#### Enable

Setting	Description	Factory Default
Enabled	Enables port security.	Enabled
Disabled	Disables port security.	

### Port Security Mode

Setting	Description	Factory Default
MAC Sticky	Specifies MAC Sticky as the port security mode.	Static Port Lock
Static Port Lock	Specifies Static Port Lock as the port security mode.	Static Port Lock

Select MAC Sticky and then APPLY.




## **NOTE**

When you change the Port Security Mode, the settings in the table will be deleted.

Select the edit icon on the port you want to edit.



Configure the following settings.



### MAC Sticky

Setting	Description	Factory Default
Enabled	Enables Static Port Lock for this port.	Disabled
Disabled	Disables Static Port Lock for this port.	Disabled

### Address Limit


Setting	Description	Factory Default
1 to 1017	Specifies the maximum numbers of the learned MAC address.	1

### Secure Action


Setting	Description	Factory Default
Port Shutdown	Enables port shutdown when a violation occurs.	Packet Drop
Packet Drop	Drops the packets when a violation occurs.	

When finished, select  $\ensuremath{\mathbf{APPLY}}$  to save your changes.

Next, select the **MAC Sticky** tab and then the + icon to add the MAC Sticky entries.



Configure the following settings.



#### Port

Setting	Description	Factory Default
Select the port from the	Selects the port(s) that will be used with the MAC Sticky	None
drop-down list	function.	None

#### **VLAN ID**


Setting	Description	Factory Default
Input the VLAN ID	Specifies the VLAN ID that will be used with MAC Sticky.	None

#### MAC Address

Setting	Description	Factory Default
Input the MAC address	Specifies the MAC Address of the device that will be used as	None
that will be used	the reliable source for network access.	None

When finished, select CREATE.

You can view the MAC Sticky settings in the figure below.




#### Static Port Lock Overview

To provide a port-based security function, switch modules have implemented Static Port Lock function; the main idea is to allow configured devices, 128 at most, to access the network through a specific port. Packets sent from unknown devices or from configured devices with mismatching ports will be dropped. In other words, only the packets from the devices pre-configured with the specific MAC addresses can be sent to the specific port to ensure a secure network data transmission scenario.

### Static Port Lock Settings and Status

To configure these settings, first select the **Port Security** tab and then **General**.



Configure the following settings.

### Enable


Setting	Description	Factory Default
Enabled	Enables port security.	Enabled
Disabled	Disables port security.	

#### Port Security Mode

Setting	Description	Factory Default
MAC Sticky	Selects MAC Sticky as the port security mode.	Static Port Lock
Static Port Lock	Selects Static Port Lock as the port security mode.	

Select Static Port Lock and then APPLY.

Select the edit icon on the port you want to edit.



Configure the following settings.




#### Enable


Setting	Description	Factory Default
Enabled	Enables Static Port Lock.	Disabled
Disabled	Disables Static Port Lock.	

When finished, select **APPLY** to save your changes.

Next, select the **Static Port Lock** tab and then the + icon to perform further settings.



Configure the following settings.



#### Port

		Factory Default
Select the port from the	Specifies the port(s) that will be used with Static Port Lock.	None
drop-down list	Specifies the port(s) that will be used with Static Port Lock.	INOTIC

#### VLAN ID


Setting	Description	Factory Default
Input the VLAN ID	Specifies the VLAN ID that will use Static Port Lock.	None

#### MAC Address

Setting	Description	Factory Default
Input the MAC address	Specifies the MAC Address of the device that will be used as	None
that will be used	the reliable source for network access.	

When finished, select CREATE.

View the Static Port Lock setting status from the following figure.



## **Traffic Storm Control**


A traffic storm can happen when packets flood the network; this causes excessive traffic and slows down the network performance. To counter this, Traffic Storm Control provides an efficient design to prevent the network from flooding caused by a broadcast, multicast, or unicast traffic storm on a physical network layer. The feature can handle packets from both ingress and egress data.

First select **Traffic Storm Control** on the menu and then the edit icon on the specific port you want to configure.




### **NOTE**

Only ports 1 to 10 support Traffic Storm Control setting. SW1, SW2, CPU1, CPU2 are internal communication ports. This function cannot be edited in these ports.



Configure the following settings.



Three methods that can be used for traffic storm control: Broadcast, Multicast, and Destination Lookup Failure (DLF).

### Broadcast

Setting	Description	Factory Default
Enabled	Enables Broadcast when a traffic storm occurs.	Disabled
Disabled	Disables Broadcast when a traffic storm occurs.	

### Multicast

Setting	Description	Factory Default
Enabled	Enables multicast when a traffic storm occurs.	Disabled
Disabled	Disables multicast when a traffic storm occurs.	

## DLF

Setting	Description	Factory Default
Enabled	Enables DLF when a traffic storm occurs.	Disabled
Disabled	Disables DLF when a traffic storm occurs.	

### Threshold (fps)

Setting	Description	Factory Default
1 to 1488100	Define the threshold for a traffic storm.	12700


### Copy Config to Ports


Setting	Description	Factory Default
Select the port(s) from	Select the port(s) you want to have the same configurations	None
the drop-down list	for.	

When finished, select **APPLY** to save your changes.

## **Access Control List**

Select **Access Control List** on the function menu and then **t** to perform further configurations.





Configure the following settings.

### Access List Type

Setting	Description	Factory Default
IP-based	Specify IP-based as the access list type.	None
MAC-based	Specify MAC-based as the access list type.	

### Index (For IP-based type)

Setting	Description	Factory Default
Select from IP-1 to IP- 16	Select from the drop-down list for index.	None

### Index (For MAC-based type)

Setting	Description	Factory Default
Select from MAC-1 to	Select from the drop-down list for index.	None
MAC-16	Select from the drop-down list for index.	None

### Name

Setting	Description	Factory Default
0 to 127 characters	Provide a name for this access list.	None

## **IP-based ACL Table Configurations**

Configure the following settings for the IP-based access list.



### Active Interface Type

Setting	Description	Factory Default
Port-based	Specify Port-based as the active interface type.	None
VLAN-based	Specify VLAN-based as the active interface type.	

### Active Ingress Ports (For Port-based type)

Setting	Description	Factory Default
Select the port(s) from	Select the port(s) as the active ingress port(s).	None
the drop-down list	3 · · · · · · · · · · · · · · · · · · ·	

## Active Ingress VLAN (For VLAN-based type)


Setting	Description	Factory Default
Select the port(s) from	Select the port(s) as the active ingress VLAN.	None
the drop-down list	Select the port(s) as the active ingress viant.	NOTIC

When finished, select  $\ensuremath{\mathbf{APPLY}}$  to save your changes.

# **IP-based Rule Index Settings**

Select the ## icon for Rule Index settings.





Configure the following settings.

### Rule Index 1

Setting	Description	Factory Default
Enabled	Enable Rule Index 1 settings.	Enabled
Disabled	Disable Rule Index 1 settings.	Lilableu

## Rule Type

Setting	Description	Factory Default
Permit	Permit the rule type.	None
Deny	Deny the rule type.	

#### Protocol

Setting	Description	Factory Default
Select the port(s) from	Select the protocol used for this rule index.	Anv
the drop-down list	Select the protocol used for this full index.	Ally

## Source IP Address

Setting	Description	Factory Default
IP address	Provide the IP address as the source IP address.	Any

## Source IP Mask

Setting	Description	Factory Default
Select the port(s) from	Select the source IP mask from the list.	None
the drop-down list		

### **Destination IP Address**

Setting	Description	Factory Default
IP address	Provide the IP address as the destination IP address.	Any

#### Destination IP Mask

Setting	Description	Factory Default
Select the port(s) from	Select the destination IP mask from the list.	None
the drop-down list		

### DSCP

Setting	Description	Factory Default
0 to 63	Specify the DSCP value.	Any


When finished, select **CREATE** to complete.

Note that the following system packets are not included in the ACL operation.

Item	Destination/Source Port Number
DHCP Server	67
DHCP Client	68
Moxa Service	40404

## **MAC-based ACL Table Configurations**

Configure the following settings for MAC-based access list.



### Active Interface Type

Setting	Description	Factory Default
Port-based	Specify Port-based as the active interface type.	None
VLAN-based	Specify VLAN-based as the active interface type.	

### Active Ingress Ports (For Port-based type)

Setting	Description	Factory Default
Select the port(s) from the drop-down list	Select the port(s) as the active ingress port(s).	None

### Active Ingress VLAN (For VLAN-based type)

5	Setting	Description	Factory Default
- 1	Select the port(s) from the drop-down list	Select the port(s) as the active ingress VLAN.	None

When finished, select  $\ensuremath{\mathbf{APPLY}}$  to save your changes.

## **MAC-based Rule Index Settings**

Select the **±** icon for Rule Index settings.





Configure the following settings.

### Rule Index 1

Setting	Description	Factory Default
Enabled	Enable Rule Index 1 settings.	Enabled
Disabled	Disable Rule Index 1 settings.	Lilabled

## Rule Type

Setting	Description	Factory Default
Permit	Permit the rule type.	Nono
Deny	Deny the rule type.	None

## EtherType

Setting	Description	Factory Default
User defined	Select User defined as the Ethernet type.	Any

### EtherType Value (For User defined type only)

Setting	Description	Factory Default
In hex digit	Provide the Ethernet type value for the user defined type.	0x

#### Source MAC Address

Setting	Description	Factory Default
MAC address	Provide the MAC address as the source MAC address.	Any

### Source MAC Mask

Setting	Description	Factory Default
Select the port(s) from	Select the source MAC mask from the list.	None
the drop-down list	Select the source MAC mask from the list.	None

## **Destination MAC Address**

Setting	Description	Factory Default
MAC address	Provide the MAC address as the destination MAC address.	Any

### **Destination MAC Mask**

Setting	Description	Factory Default
Select the port(s) from	Select the destination MAC mask from the list.	None
the drop-down list	select the destination MAC mask from the list.	None

### VLAN ID

Setting	Description	Factory Default
Select the VLAN ID by		
using the up/down	Select the VLAN ID.	Any
arrows		

### CoS

Setting	Description	Factory Default
Select the CoS value by		
using the up/down	Specify the DSCP value.	Any
arrows		

When finished, select  $\ensuremath{\mathbf{CREATE}}$  to complete.


Note that the following system packets are not included in the ACL operation.

Item	MAC Address
IEEE reserved Multicast MAC address	01:80:C2:XX:XX
IP Multicast MAC address	01:00:5E:XX:XX
Broadcast MAC address	FF:FF:FF:FF:FF
L2 Multicast MAC address	01:XX:XX:XX

Item	Ether Type
LLDP	0x88CC
EAPOL	0x888E
LACP	0x8809
LLC Jumbo Frame	0x8870
ARP	0x0806
MRP	0x88E3
PROFINET	0x8892
PTP	0x88B5
PTP	0x88F7
GOOSE	0x88B8
SMV	0x88BA
Ethernet Configuration Testing Protocol	0x9000

### **Access Control List Status**

Select **Status** to view the Access Control List status.




# **Loop Protection**

Select **Loop Protection** on the function menu.

## **Settings**

Select **Settings** for further configurations.



Configure the following settings.

#### **Loop Protection**

Setting	Description	Factory Default
Enabled	Enable the Loop Protection function.	Disabled
Disabled	Disable the Loop Protection function.	Disabled


### Detect Interval

Setting	Description	Factory Default
1 to 30	Specify the detect interval value.	10

When finished, select **APPLY** to complete.

#### **Status**

Select **Status** tab to view the Loop Protection status.




### **Authentication**

This section describes how to configure system authentication including RADIUS and TACACS+. Switch modules have three different user login authentications: TACACS+ (Terminal Access Controller Access-Control System Plus), RADIUS (Remote Authentication Dial In User Service), and Local. The TACACS+ and RADIUS mechanisms are centralized "AAA" (Authentication, Authorization, and Accounting) systems for connecting to network services. The fundamental purpose of both TACACS+ and RADIUS is to provide an efficient and secure mechanism for user account management.

Five combinations are available to choose from.

- 1. **TACACS+, Local:** Check the TACACS+ database first. If checking the TACACS+ database fails, then check the Local database.
- 2. **RADIUS, Local:** Check the RADIUS database first. If checking the RADIUS database fails, then check the Local database.
- 3. **TACACS+:** Only check TACACS+ database.
- 4. **RADIUS:** Only check the RADIUS database.
- 5. **Local:** Only check the Local database.


This section includes the configurations for Login Authentication, RADIUS, and TACACS+.



# **Login Authentication**

This section allows you to select the login authentication protocol.

Select Login Authentication.



Configure the following settings.


#### **Authentication Protocol**

Setting	Description	Factory Default
Local	Select Local as the authentication protocol.	
RADIUS	Select RADIUS as the authentication protocol.	
TACACS+	Select TACACS+ as the authentication protocol.	Local
RADIUS, Local	Select RADIUS and Local as the authentication protocol.	
TACACS+, Local	Select TACACS+ and Local as the authentication protocol.	

When finished, select **APPLY** to save your changes.

## **RADIUS**

Select RADIUS on the menu and configure the following settings.



## Server Address 1

Setting	Description	Factory Default
Input the server	Specify the first server address as the authentication	0.0.0.0
address	database.	0.0.0.0

## **UDP** Port

Setting	Description	Factory Default
Input the port number	Specify the UDP port.	1812

### Share Key

Setting	Description	Factory Default
Input the key	Input the share key for first server authentication verification.	None

## Authentication Type

Setting	Description	Factory Default
PAP	PAP is the authentication type.	
CHAP	CHAP is the authentication type.	СНАР
MS-CHAPv1	MS-CHAPv1 is the authentication type.	

## Timeout (sec.)

Setting	Description	Factory Default
15 to 180	When waiting for a response from the server, set the time	E
	before timeout.	5

### Retry (sec.)

Setting	Description	Factory Default
0 to 5	Define the retry interval when reconnecting to a server.	1

### Server Address 2

Setting	Description	Factory Default
Input the server	Specify the second server address as the authentication	0.0.0.0
address	database.	0.0.0.0

### **UDP Port**

Setting	Description	Factory Default
Input the port number	Specify the UDP port.	1812

### Share Key

Setting	Description	Factory Default
Unnut the key	Specify the share key for second server authentication verification.	None

### Authentication Type

Setting	Description	Factory Default
PAP	PAP is the authentication type.	
CHAP	CHAP is the authentication type.	CHAP
MS-CHAPv1	MS-CHAPv1 is the authentication type.	

## Timeout (sec.)

Setting	Description	Factory Default
15 to 180	When waiting for a response from the server, set the time	5
	before the device is timed out.	

### Retry (sec.)

Setting	Description	Factory Default
0 to 5	Set the retry interval when reconnecting to a server.	1

When finished, select **APPLY** to save your changes.




## **NOTE**

The RADIUS service will be operated via the first server; if it fails, it will run on the second server.

## TACACS+

Select **TACACS+** on the menu and then configure the following settings.



### Server Address 1

Setting	Description	Factory Default
Input the server	Specify the first server address as the authentication	0.0.0.0
address	database.	0.0.0.0

## TCP Port

Setting	Description	Factory Default
Input the port number	Specify the UDP port.	49

## Share Key

Setting	Description first	Factory Default
Unnut the key	Specify the share key for first server authentication	None
	verification.	

## Authentication Type

Setting	Description	Factory Default
ASCII	ASCII is the authentication type.	
PAP	PAP is the authentication type.	СНАР
CHAP	CHAP is the authentication type.	

## Timeout (sec.)

Setting	Description	Factory Default
Unnut the value	When waiting for a response from the server, set the time	5
	before the device is timed out.	

#### Retry

Setting	Description	Factory Default
Input the value	Set the retry interval when reconnecting to a server.	1

### Server Address 2

Setting	Description	Factory Default
Input the server	Specify the second server address as the authentication	0.0.0.0
address	database.	0.0.0.0

### TCP Port

Setting	Description	Factory Default
Input the por	number Specify the UDP port.	49

### Share Key

Setting	Description	Factory Default
Unnut the key	Specify the share key for second server authentication verification.	None

## Authentication Type

Setting	Description	Factory Default
ASCII	ASCII is the authentication type.	
PAP	PAP is the authentication type.	CHAP
СНАР	CHAP is the authentication type.	

## Timeout (sec.)

Setting	Description	Factory Default
Input the value	When waiting for a response from the server, set the time	E
Input the value	before the device is timed out.	3

### Retry

Setting	Description	Factory Default
Input the value	Set the retry interval when reconnecting to a server.	1

When finished, select **APPLY** to save your changes.




## **NOTE**

The TACACS+ service will be operated via the first server; if it fails, it will run on the second server.


# **Diagnostics**

This section describes the diagnostics functions of the switch module. Select **Diagnostics** from the function menu.



## **System Status**

This section allows you to view the current system status, including **Utilization**, **Statistics**, and **Module Information**.



### **Utilization**

Select **Utilization** on the function menu to view the current utilization status, including CPU utilization, memory history, power consumption, and power history. All the information is displayed via graphics, making it easier for you to view the system's status. In addition, a refresh icon is available on the upper right corner of each figure, which allows you to view the latest status for each function.




### **CPU Utilization**

Setting	Description	Factory Default	
Read-only	Displays the current utilization of the CPU.	None	

### CPU Usage History

Setting	Description	Factory Default
Read-only	Displays the CPU usage history trend in a chart.	None




## Memory Utilization

Setting	Description	Factory Default	
Read-only	Displays the memory status.	None	

### Memory Usage History

Setting	Description	Factory Default
Read-only	Displays the history of memory usage.	None



## Power Consumption (watt)


Setting	Description	Factory Default
Read-only	Displays the power consumption status.	None

## Power Usage History


Setting	Description	Factory Default	
Read-only	Displays the history of power usage.	None	

### **Statistics**

Select **Statistics** on the function menu. The first figure shows the packet counter status.



The status of the different ports will be shown in different colors. A maximum of five ports will have their information displayed.



There are four icons on the right upper corner of the page. The table below describes each one.

Item	Name	Description
G	Refresh	All statistical data will be refreshed.
Ē	Reset Statistics Graph	The packet counter will be cleared, and the graphs will be reset.
≡,	Display Setting	All selected setting items will be shown here.
47	Data Comparison	Select the data you want to compare.

## **Refreshing the Statistics**

Select the **Refresh** button and all statistical data will be refreshed immediately.


## **Resetting Statistics Graph**

Select the **Reset** button and then **CLEAR** to clear the packet counter and reset the graph.



## **Display Setting**

Select the **Display Setting** icon and all settings will be displayed. Select the display mode from the drop-down list.



The Monitoring Port is the port you want to view or monitor. The sniffer port is the port you can choose to view its receiving or transmission status, or both.

### Display Mode

Setting	Description	Factory Default
Packet Counter	The packet statistics will be displayed.	Packet Counter
Bandwidth Utilization	The bandwidth statistics will be displayed.	Packet Counter

Select **APPLY** to complete.


### **Comparing Data**

Select the **Data Comparison** icon and then select the items from the relevant fields.





Select **CLOSE** to complete.

The data comparison figure will be shown. Select **Close** to finish.



The detailed packet transmission activity for each port can be seen in the table below.





Port: port number

**Tx Total Octets:** Number of octets transmitted, including bad packets and FCS octets. Framing bits are not included.

**Tx Total Packets:** Number of packets transmitted.

Tx Unicast Packets: Number of Unicast packets transmitted.

**Tx Broadcast Packets:** Number of good Broadcast packets transmitted. Multicast packets are not included.

**Rx Total Octets:** Number of octets received, including bad packets and FCS octets. Framing bits are not included.

Rx Unicast Packets: Number of Unicast packets received.

Rx Multicast Packets: Number of Multicast packets received.

**Rx Broadcast Packets:** Number of good Broadcast packets received. Multicast packets are not included.

**Rx Pause Packets:** Number of pause packets received.

**Collision Packets:** Number of collisions received. If Jumbo Frames are enabled, the threshold of Jabber

Frames is raised to the maximum size of Jumbo Frames.

Late Collision Packets: Number of late collision packets.

**Excessive Collision Packets:** Number of excessive collision packets.

CRC Align Error Packets: Number of CRC and Align errors that have occurred.

**Drop Packets:** Number of packets that were dropped.

Undersize: Number of undersized packets (less than 64 octets) received.


Oversize Packets: Number of oversized packets (over 1518 octets) received.

**Fragment Packets:** Number of fragments (packets with less than 64 octets, excluding framing bits, but including FCS octets) received.

**Jabber Packets:** Number of received packets that were longer than 1632 octets. This number excludes frame bits but includes FCS octets that had either a bad FCS (Frame Check Sequence) with an integral number of octets (FCS Error) or a bad FCS with a non-integral octet (Alignment Error) number.

### **Event Notification**


This section includes the information regarding **Event Notification**, **Email Notification**, and **Syslog**.




### **Event Notification**

Event Notification includes two functions: System and Function, and Port.

In the **Event Notification** menu, select the **System and Function** tab and then the edit icon on the specific event you want to configure. For example, select the edit icon for warm start when the switch reboots.



Configure the following settings.



### Enable

Setting	Description	Factory Default
Enabled	Enable Event Notification for this event.	Enabled
Disabled	Disable Event Notification for this event.	Lilabieu


### Registered Action

Setting	Description	Factory Default
Trap	Send SNMP Trap for event notifications.	Trap/Email
Email	Send an email for event notifications.	i i ap/Liliali


When finished, select **APPLY** to save your changes.

In addition, use the same method to edit other events, such as login lockout, warm start, password changed, etc.

Next, in the **Event Notification** menu, select the **Port** tab, and then select the edit icon on the specific port status on **Event Name**. For example, select the edit icon for event notifications when the port status is on.



Configure the following settings.



#### Enable

Setting	Description	Factory Default
Enabled	Enable Event Notification for this event.	Enabled
Disabled	Disable Event Notification for this event.	Lilableu

#### Registered Action

Setting	Description	Factory Default
Trap	Send SNMP Trap for event notifications.	Tran/Email
Email	Send an email for event notifications.	Trap/Email

### Registered Port

Setting	Description	Factory Default
Select port(s) from the	Specify the port(s) that use the registered action.	All Ports
drop-down list	Specify the port(s) that use the registered action.	All Forts

When finished, select **APPLY** to save your changes.

In addition, use the same method to edit other events such as, port status is off, port shutdown by port security, and port recovery by rate limit, etc.


Check the following table for the severity degree of each event.

System & Function	
Event Name	Severity
Cold start	Critical
Warm start	Notice
Configuration changed	Notice
Login success	Notice
Login fail	Warning
Login lockout	Warning
Account setting changed	Notice
Configuration imported	Notice
SSL certification changed	Notice
Log capacity threshold	Warning
Password changed	Notice
PWR Off->On	Notice
PWR On->Off	Notice
Topology changed	Warning
Coupling changed	Warning
Master changed	Warning
Master mismatch	Warning
RSTP topology changed	Warning
RSTP root changed	Warning
RSTP migration	Warning
RSTP invalid BPDU	Warning
RSTP new port role	Warning
Redundant port health check fail	Error
Dual homing path changed	Warning
Dot1X auth fail	Warning
LLDP table changed	Information
RMON raising alarm	Warning
RMON failing alarm	Warning

Port		
Event Name	Severity	
Port On	Notice	
Port Off	Notice	
Port shutdown by Port Security	Warning	
Port shutdown by Rate Limit	Warning	
Port recovery by Rate Limit	Warning	

## **Email Notification**

Select **Email Notification** on the function menu and configure the following settings.



#### Mail Server

Setting	Description	Factory Default
IP address or URL	The IP Address or URL of the email server.	0.0.0.0

### TCP Port

Setting	Description	Factory Default
1 to 65535	The TCP port number of your email server.	25

## User Name

Setting	Description	Factory Default
Max. of 60 characters	Your email account name.	None

## Password

Setting	Description	Factory Default
Max. of 60 characters	Your email account password.	None

## TLS Enable

Setting	Description	Factory Default
Enabled	Enable TLS (Transport Layer Security).	Disabled
Disabled	Disable TLS (Transport Layer Security).	

#### Sender Address

Setting	Description	Factory Default
Max. 60 characters	The sender's email address.	admin@localhost


## First to Fifth Email Addresses

Setting	Description	Factory Default
Max. of 60 characters	Set up maximum five email addresses to receive alert emails	None
Max. 01 60 Characters	from the switch module.	None

When finished, select **APPLY** to save your changes.

## **Syslog Settings**

Select the **General** tab on the function menu and configure the following settings.



## Logging Enable

Setting	Description	Factory Default
Enabled	Enable logging.	-Disabled
Disabled	Disable logging.	

## Syslog Server 1

Setting	Description	Factory Default
Enabled	Enable the first log server.	Dicablod
Disabled	Disable the first log server.	Disabled

## Address 1

IIP Address	ut the IP address of the Syslog first server that is used by r network.	None

## **UDP** Port

Setting	Description	Factory Default
1 to 65535	Input the UDP port number.	514

## Syslog Server 2

Setting	Description	Factory Default
Enabled	Enable the second syslog server.	-Disabled
Disabled	Disable the second syslog server.	

#### Address 2

Setting	Description	Factory Default
IIP Address	Input the IP address of Syslog second server that is used by your network.	None

## **UDP** Port

Setting	Description	Factory Default
1 to 65535	Input the UDP port number.	514

## Syslog Server 3

Setting	Description	Factory Default
Enabled	Enable the third syslog server.	-Disabled
Disabled	Disable the third syslog server.	

## Address 3

		Factory Default
IP Address	Input the IP address of the Syslog third server that is used by your network.	None

#### **UDP Port**

Setting	Description	Factory Default
1 to 65535	Input the UDP port number.	514


When finished, select **APPLY** to save your changes.




## **NOTE**

If the syslog server cannot receive the previous logs, it is possible that the receiving port of the syslog server is not ready. We suggest you enable the Linkup Delay function to delay the log delivery time.

Select **Authentication** tab and add the icon in the function menu.



Configure the following settings.



#### Client Certificate

Setting	Description	Factory Default
Select the import icon		
and then the file from	Import the client certificate file.	None
your computer.		

#### Client Key

Setting	Description	Factory Default
Select the import icon		
and then the file from	Import the client key file.	None
your computer.		


## CA Key

Setting	Description	Factory Default
Select the import icon		
and then select the file	Import the CA key file.	None
from your computer.		

When finished, select **CREATE** to save your changes.

## **Diagnosis**


This section explains the configurations for system diagnoses, such as LLDP, Port Mirror, Ping, ARP Table, and Event Log.



#### **LLDP Overview**


LLDP is an OSI Layer 2 protocol defined by IEEE 802.11AB. LLDP standardizes the self-identification advertisement method, and allows each networking device, such as a Moxa managed switch, to periodically send its system and configuration information to its neighbors. Because of this, all LLDP devices are kept informed of each other's status and configurations. With SNMP, this information can be transferred to Moxa's MXview for auto-topology and network visualization.

From the switch's web interface, enable or disable LLDP, and set the LLDP transmit interval. In addition, you can view each switch's neighbor-list, which is reported by its network neighbors. Most importantly, enabling the LLDP function allows Moxa's MXview to automatically display the network's topology and system setup details, such as VLAN and trunking for the entire network.



## **LLDP Settings and Status**

Select LLDP on the menu and then the Setting tab to configure the following settings.



#### Enable

Setting	Description	Factory Default
Enabled	Enable LLDP.	Disabled
Disabled	Disable LLDP.	

## LLDP Version

Setting	Description	Factory Default
Show the LLDP version	Show the LLDP version automatically.	2005

## Transmit Interval (sec.)

Setting	Description	Factory Default
5 to 32768	Set the transmit interval of LLDP messages	30

## Notification Interval (sec.)

Setting	Description	Factory Default
5 to 3600	Specify the notification interval.	5

## Tx Delay (sec.)

Setting	Description	Factory Default
1 to 8192	Specify the Tx delay interval.	2

## Reinitialization Delay (sec.)

Setting	Description	Factory Default
1 to 10	Specify the LLDP reinitialization delay interval.	2

#### Holdtime Multiplier


Setting	Description	Factory Default
2 to 10	Specify the holdtime multiplier value.	4

## Chassis ID Subtype


Setting	Description	Factory Default
Chassis-Component	Select Chassis-Component as Chassis ID subtype.	
If-Alias	Select If-Alias as Chassis ID subtype.	
Port-Component	Select Port-Component as Chassis ID subtype.	
MAC-Addr	Select MAC-Address as Chassis ID subtype.	Mac-Addr
Network Address	Select Network Address as Chassis ID subtype.	
If-Name	Select If-Name as Chassis ID subtype.	
Local	Select Local as Chassis ID subtype.	

When finished, select **APPLY** to save your changes.

Each port for the LLDP settings can also be configured. Select the edit icon for the port you want to configure.



Configure the following settings.



#### Port Status

Setting	Description	Factory Default
Tx Only	Set Tx as the port status.	
Rx Only	Set Rx as the port status.	Tx and Rx
Tx and Rx	Set both Tx and Rx as the port status.	

## Subtype

Setting	Description	Factory Default
If-Alias	Select If-Alias as the subtype.	
Port-Component	Select Port-Component as the subtype.	
MAC-Addr	Select MAC-Address as the subtype.	If-Alias
If-Name	Select If-Name as the subtype.	
Local	Select Local as the subtype.	

## TLV

Setting	Description	Factory Default
Basic	Set TLV as Basic.	
802.1	Set TLV as 802.1.	Basic
802.3	Set TLV as 802.3.	

## Transmit TLVs


Setting	Description	Factory Default
Port Description	Add a port description for the TLV.	
System Name	Add a system name for the TLV.	Port Description
System Description	Add a system description for the TLV.	System Name
System Capability	Add a system capability for the TLV.	

## Copy Config to Port

Setting		Factory Default
Select the port from th list	Copy the same configurations to other port(s).	None

When finished, select **APPLY** to save your changes.

To view the LLDP status, select the **Status** tab on the LLDP page, and the status of all LLDP will be shown on the page.




Refer to the following table for the detailed description of each item.

Local Information	
Enable	Show if LLDP has been enabled or disabled.
LLDP Version	Show the LLDP version.
Chassis ID Subtype	Show the chassis ID subtype.
Chassis ID	Show the chassis ID.

Local Timer	
Transmit Interval (sec.)	The interval between regular LLDP packet transmissions.
Notification Interval (sec.)	The interval that notifications will be sent.
Tx Delay (sec.)	The delay period between successive LLDP frame transmissions initiated by
	changes.
Reinitialization Delay (sec.)	The interval of an LLDP port waits before re-initializing an LLDP packet
	transmission.
Holdtime Multiplier	The time that the receiving device holds an LLDP packet before discarding it.

Remote Table Statistics	
Last Change Time (ms.)	The last time the remote table changed.
Inserts	How many inserts have occurred.
Drop	How many drops have occurred.
Delete	How many deletes have occurred.
Age-outs	How many age-outs have occurred.

To view the LLDP status for a specific port, select the detailed information icon on the port. All information will be shown on the right side of the page.




## **Port Mirroring**

## **Port Mirroring Overview**

The Port Mirroring function can be used to monitor data being transmitted through a specific port. This is done by setting up another port (the mirror port) to receive the same data being transmitted from, or both to and from, the port under observation. Using a mirror port allows the network administrator to sniff the observed port to keep tabs on network activity.


## **How Port Mirror Works**

Port Mirroring can configure to copy one or more packets from various ports to a single port, so that you can check if there are problems occurring in these ports. For example, the following figure demonstrates how the packets transmitted in the four mirrored ports (marked in orange) are copied (mirrored) to a single mirroring port (marked in green). These packets will be sent to a monitoring computer and then software is used to check if there is something wrong with these packets. It is a useful function to troubleshoot or debug a network data transmission issue.



## **Port Mirror Settings and Status**

Select Port Mirror on the menu and then configure the settings.




#### Enable


Setting	Description	Factory Default
Enabled	Enable Port Mirror.	Enabled
Disabled	Disable Port Mirror.	Lilableu

When finished, select **APPLY** to save your changes.

To configure the specific port, select the edit icon next to the port.



Configure the following settings.



#### Enable

Setting	Description	Factory Default	
Enabled	Enable Port Mirror for this session.	Disabled	
Disabled	Disable Port Mirror for this session.	Disabled	

#### Tx Source Port

Setting	Description	Factory Default
Select the port from the	Select this option to monitor only those data packets being	None
list	sent out through the switch's port.	None

#### Rx Source Port

Setting	Description	Factory Default
Select the port from the	Select this option to monitor only those data packets coming	None
list	into the switch's port.	None

#### Destination Port

		Factory Default
Select the port from the list	Specify this port as the destination port.	None

When finished, select **APPLY** to save your changes.



## **NOTE**

The RSTP ports and Port Mirror destination port cannot be enabled on the same port.

The Port Mirror status can be seen in the figure below.

	Session ID	Enable	Tx Source Port(s)	Rx Source Port(s)	Destination Port
/	1	Enabled	1, 2	1, 4	3
<i>&gt;</i>	2	Disabled			

## **Ping**

The **Ping** function uses the ping command to give you a simple but powerful tool for troubleshooting network problems. The unique feature of the function is that even though the ping command is entered from the your PC, the actual ping command originates from the switch module itself. This allows you to essentially sit on top of the switch module and send ping commands out through its ports.

To use the Ping function, select **Ping** on the menu, and enter the IP address or domain name you want to ping. After selecting **Ping**, the result will be shown.




## **ARP Table**

To view the ARP Table, select **ARP Table** and the information will be displayed.



## **Event Log**

To edit the event log oversize-action, select **Event Log** on the menu and then **Event Log** on the page.



Configure the following settings when the event log file is full.

### Oversize-action

Setting	Description	Factory Default
Overwrite the oldest event log	Overwrite the oldest event log.	Overwrite the oldest
Stop recording event		event log
log	·	


Select APPLY to finish.

To view all the event formation, check the lower part of the event log page.

Index	Bootup Number	Severity	Timestamp	Uptime	Message
1	16	Notice	2018-12-27 21:47:10	0d4h52m3s	Configuration ['Account'] changed by admin.
2	16	Notice	2018-12-27 21:41:20	0d4h46m13s	Configuration ['Port Security'] changed by admin.
3	16	Notice	2018-12-27 21:36:48	0d4h41m41s	Configuration ['Port Security'] changed by admin.
4	16	Notice	2018-12-27 21:21:34	0d4h26m27s	Configuration ['Trusted Access'] changed by admin.
5	16	Notice	2018-12-27 21:12:24	0d4h17m17s	Configuration ['Mgmt Interface'] changed by admin.
6	16	Notice	2018-12-27 21:05:41	0d4h10m34s	Configuration ['SNMP'] changed by admin.
7	16	Notice	2018-12-27 21:04:13	0d4h9m6s	Configuration ['SNMP'] changed by admin.
8	16	Notice	2018-12-27 20:57:08	0d4h2m1s	Configuration ['L2 Redundancy'] changed by admin.
9	16	Notice	2018-12-27 20:56:09	0d4h1m2s	Port 1/2 has restarted by Turbo Chain.
10	16	Notice	2018-12-27 20:56:08	0d4h1m1s	Port 1/1 has restarted by Turbo Chain.
11	16	Notice	2018-12-27 20:56:06	0d4h0m59s	Configuration ['L2 Redundancy'] changed by admin.
12	16	Warning	2018-12-27 20:55:11	0d4h0m4s	Topology has been changed by Turbo Chain.
13	16	Notice	2018-12-27 20:55:11	0d4h0m4s	Port 1/2 has restarted by Turbo Chain.
14	16	Notice	2018-12-27 20:55:11	0d4h0m4s	Port 1/1 has restarted by Turbo Chain.
15	16	Notice	2018-12-27 20:55:08	0d4h0m1s	Configuration ['Turbo Chain'] changed by admin.
16	16	Notice	2018-12-27 20:54:54	0d3h59m47s	Configuration ['L2 Redundancy'] changed by admin.

## **Threshold Settings**

To configure the event log threshold, select the **Threshold Setting** tab on the Event Log Page. The event log threshold can be set up to send an early warning when the event log entries have reached the percentage of the threshold. The maximum recorded event log entries are 10,000.



Configure the following settings.

## Capacity Warning

Setting	Description	Factory Default
Enabled	Enable capacity warning event log.	Disabled
Disabled	Disable capacity warning event log.	Disabled

## Warning Threshold (%)

Setting	Description	Factory Default
50 to 100	Set the warning threshold as a percentage.	80


## **Industrial Applications**

This section introduces the settings for the MMS of the IEC 61850 standard. Select **MMS** in the function menu under **Industrial Application** and **IEC 61850**.



## **General Settings**

Select the **General** tab for further configurations.



Configure the following settings.

### MMS

Setting	Description	Factory Default
Enabled	Enable the MMS function on the switch.	Disabled
Disabled	Disable the MMS function on the switch.	Disableu


#### IED Name

Setting	Description	Factory Default
		RKS-G4000 (Will
0 to 20 characters	Provide the IED name for your switch.	vary depending on
		the switch models)


When finished, select **APPLY** to save your changes.

## **CID File Settings**

Select the edit icon 
on the page.



Configure the following settings.



## Data Change

Setting	Description	Factory Default
Enabled	Enable the Data Change function.	-Enabled
Disabled	Disable the Data Change function.	

#### Data Update

Setting	Description	Factory Default
Enabled	Enable the Data Update function.	Disabled
Disabled	Disable the Data Update function.	Disabled

## Quality Change

Setting	Description	Factory Default
Enabled	Enable the Quality Change function.	Disabled
Disabled	Disable the Quality Change function.	Disabled

## Integrity

Setting	Description	Factory Default
Enabled	Enable the Integrity function.	Enabled
Disabled	Disable the Integrity function.	

#### **Buffer Time**

Setting	Description	Factory Default
1 to 4294967295 (ms)	Provide the buffer time value.	1000

## Integrity Period

Setting	Description	Factory Default
1 to 4294967295 (ms)	Provide the integrity period value.	5000

When finished, select **APPLY** to save your changes.

## **Exporting CID File**


To export the CID file, select **EXPORT CID FILE**.



The file will be downloaded to your local computer.

## **Security Settings**

Select the **Security** tab, where you can view the information for **T-Profile** and **A-Profile** Certificates.



## **T-Profile Security Settings**

Configure the following settings for T-Profile Security.



## T-Profile Security

Setting	Description	Factory Default
Enabled	Enable T-Profile Security.	-Disabled
Disabled	Disable T-Profile Security.	

### Import Client CA

Setting	Description	Factory Default
Select the import icon on the right.	Import Client CA file from your local computer	None

## Import Client Certificate

Setting	Description	Factory Default
Select the import icon on the right.	Import Client Certificate file from your local computer	None

When finished, select **APPLY** to complete.

## **Export Server CA**

To export the Server CA, select **EXPORT SERVER CA**, the file will be downloaded to your local computer.

**EXPORT SERVER CA** 


## **Export Server Certificate**

To export the Server Certificate, select **EXPORT SERVER CERTIFICATE**, the file will be downloaded to your local computer.

EXPORT SERVER CERTIFICATE

## **A-Profile Security Settings**

Configure the following settings for A-Profile Security.



## A-Profile Security

Setting	Description	Factory Default
Enabled	Enable A-Profile Security	Disabled
Disabled	Disable A-Profile Security	

### Import Client CA

Setting	Description	Factory Default
Select the import icon on the right	Import Client CA file from your local computer	None

## Import Client Certificate

Setting	Description	Factory Default
Select the import icon on the right	Import Client Certificate file from your local computer	None

When finished, select **APPLY** to complete.

## **Exporting Server CA**

To export Server CA, select **EXPORT SERVER CA**. The file will be downloaded to your local computer.

**EXPORT SERVER CA** 


## **Exporting Server Certificate**

To export Server Certificate, select **EXPORT SERVER CERTIFICATE**. The file will be downloaded to your local computer.

**EXPORT SERVER CERTIFICATE** 

## **Maintenance and Tool**

This section explains how to maintain the switch module and the tools that help you operate the switch. Select the icon on the upper right corner of the page.



## Standard/Advanced Mode


Two configuration modes are available: Standard Mode and Advanced Mode.

- 1. In **Standard Mode**, some of the features/parameters will be hidden to make it easier to perform configurations (this is the default setting).
- 2. In **Advanced Mode**, some advanced features/parameters will be available for you to adjust these settings.

To switch to Advanced Mode, select the change mode icon on the upper right corner of the page and then **Change Mode**.




Select CHANGE to change to Advanced Mode.



Advanced Mode offers more detailed system configurations for specific functions. Use the same process if you want to return to Standard Mode.

## **Disable Auto Save**


Auto Save allows you to save the settings to the start-up configurations; all parameters will be effective when applied immediately, even when the switch has restarted. When you select **Disable Auto Save**, all parameters will be temporarily stored in the running config (memory), and a disk icon will appear on the upper right corner of the page. You need to save the running-configuration to the startup-configuration when changing any parameters or function after selecting **Apply**.




It is highly recommended that you always manually save all configurations by selecting the Save Disk icon when **Disable Auto Save** is applied, or all information will have disappeared after the switch has restarted.

When **Disable Auto Save** is applied, only the configurations that are running will be saved; you can unplug the power or perform a warm recovery to the network before manually saving the configurations. When Auto Save is enabled, the start-up configurations will be saved in the switch.

To disable the **Auto Save** function, select **Disable Auto Save** in the menu.




#### Select **DISABLE**.



## Locator

You can trigger the device locator by selecting this icon. This will cause the LED indicators on the switch to flash for one minute. This helps you easily find the location of the switch on a field site.



## Select **LOCATE**.



## Duration (sec.)

Setting	Description	Factory Default
30 to 300	Specify the time the indicators will remain flashing.	60


Select **LOCATE** to activate the switch locator.

The LED indicators are on the top of the front panel of the switch, as shown in the following figure.




## **Reboot**

To reboot the device, select **Reboot**.




Select **REBOOT** to reboot the device.



## **Reset to Default**

To reset the switch to the default status, select **Reset to Default**.




To return the switch to factory default settings, select **Reset**.




## Log Out of the Switch

To log out of the switch, select **Log Out**.



Select **LOG OUT** to log out of the switch.




# A. Activate and Transfer the IINxpress

In this appendix, we demonstrate how to activate the IINxpress and transfer the activation code between the IINxpress.

## **Activate the IINxpress**


The activation code is needed to activate the IINxpress. Follow the steps to complete the activation in your computer.


- **Step 1:** Contact Moxa sales representatives or Moxa official distributors to purchase the license of IINxpress. One computer is required for one license. Once the license procurement is complete, the **Registration Code** will be mailed to you.
- **Step 2:** Download the IINxpress from the Moxa website (<a href="https://www.moxa.com/">https://www.moxa.com/</a>) and install in the computer. When a first-time user opens IINxpress, the user can find the **User Code** in the popup window.




**Step 3:** Create an account on Moxa Software Licensing System. (https://netsecuritylicense.moxa.com/Account/Login)

Step 4: Go to Products and Licenses > Activate a Product License and select the IINxpress.





**Step 5:** Enter the Registration Code and User Code. Select the **Activate**.




- **Step 6:** If activated successfully, you will receive a mail notice with the **Activation Code**.
- **Step 7:** Activate the IINxpress with the Activation Code.


# **Transfer the Activation Code Between IINxpress**

When you want to change the development environment to a new computer, the IINxpress can transfer to a new computer accordingly. Follow the steps to complete the transfer between the IINxpress.


- **Step 1:** Download the IINxpress and complete the installation on the new computer. Get the <u>new</u> **User Code** from the IINxpress on the new computer.
- **Step 2:** Open the IINxpress on the old computer, go to **Help > License Information**, and launch the license management tool.



**Step 3:** Select the **Deactivate** button, the IINxpress will ask you to reconfirm again. Select OK and the IINxpress will provide a **Deactivation Code**.




**Step 4:** Go to Moxa Software Licensing System and find the Transfer page via **Products and Licenses > Transfer a Product License**.



**Step 5:** Select the IINxpress.



**Step 6:** Enter the <u>Deactivation Code</u> and <u>New User Code</u>. Then, select the **Product Transfer**.



- **Step 7:** If the transfer is successful, you will receive a mail notice with <u>new</u> **Activation Code**.
- **Step 8:** Activate the IINxpress on a new computer with the <u>new</u> Activation Code.

# B. Account Privileges List of 65M-5011M (Managed Switch Module)

This appendix describes the read/write access privileges for different accounts on the ioPAC 6500 Layer 2 Managed Ethernet Switch Module.

## **Account Privileges List**

This appendix lists the privileges for different account roles.

Note, R stands for Read and W stands for Write.

Function	Account Privilege			
System	Admin	Supervisor	User	
Information Setting	R/W	R/W	R/W	
Firmware Upgrade	Execute	No Access	No Access	
Configuration Backup and Restore	F	N - A	N	
(including File Signature)	Execute	No Access	No Access	
Event log backup	Execute	Execute	Execute	
User Account	R/W	No Access	No Access	
Password Policy	R/W	No Access	No Access	
Online Accounts	R/w	No Access	No Access	
IP Configuration	R/W	R/W	R	
DHCP Server	R/W	R/W	R	
Time Zone	R/W	R/W	R	
System Time	R/W	R/W	R	
Port		<u>'</u>	'	
Port Setting	R/W	R/W	R	
Linkup Delay	R/W	R/W	R	
Link Aggregation (Port Channel)	R/W	R/W	R	
VLAN		<u>'</u>	'	
IEEE 802.1Q	R/W	R/W	R	
GARP	R/W	R/W	R	
MAC	•		•	
Static Unicast	R/W	R/W	R	
MAC Address Table	R/W	R/W	R	
QoS		<u>'</u>	'	
Classification	R/W	R/W	R	
Ingress Rate Limit (port shutdown only)	R/W	R/W	R	
Scheduler	R/W	R/W	R	
Multicast	•		•	
IGMP Snooping	R/W	R/W	R	
Static Multicast	R/W	R/W	R	
GMRP	R/W	R/W	R	
Layer 2 Redundancy			•	
Spanning Tree	R/W	R/W	R	
Turbo Ring v2	R/W	R/W	R	
Turbo Chain	R/W	R/W	R	
Dual Homing	R/W	R/W	R	
Network Management	·	•	·	
SNMP	R/W	No Access	No Access	
SNMP Trap/Inform	R/W	No Access	No Access	

Function	Account Privilege			
Security	Admin	Supervisor	User	
Management Interface	R/W	R/W	R	
Login Policy	R/W	R	R	
Trusted Access	R/W	R/W	R	
SSH & SSL	Execute	Execute	No Access	
IEEE802.1X	R/W	R/W	R	
Port Security	R/W	R/W	R	
Traffic Storm Control	R/W	R/W	R	
Authentication			·	
RADIUS	R/W	No Access	No Access	
TACACS+	R/W	No Access	No Access	
Login Authentication	R/W	No Access	No Access	
Diagnostics			·	
Event Notification	R/W	R/W	R	
Email Notification	R/W	R	R	
Syslog (including authentication)	R/W	R	R	
Event Log	R/W	R/W	R	
LLDP	R/W	R/W	R	
Port Mirror	R/W	R/W	R	
Ping	Execute	Execute	Execute	
ARP Table	R	R	R	
Utilization	R	R	R	
Statistics	R/W	R/W	R	
Maintenance and Tool			·	
Standard/Advance Mode	Execute	Execute	Execute	
Disable Auto Save	R/W	R/W	R	
Locator	R/W	R/W	Execute	
Reboot	Execute	Execute	No Access	
Reset to Default	Execute	Execute	No Access	
Logout	Execute	Execute	Execute	

# C. Event Log Description of 65M-5011M (Managed Switch Module)

This appendix describes all the information for the event logs. When an event occurs, it will be recorded in the event log files. Check the event log name and its event log description.

## **Event Log Description**

<b>Event Name</b>	Severity	Event Description	
802.1X Auth Failed	Warning	802.1x authentication failed on port	
802.1X Addi i alied	waiting	{{index}}/{{number}} with {{buffer}}	
ABC-02 is inserted or unplugged	Notice	ABC-02 is {{inserted/unplugged}}.	
Account log out	Notice	[Account:{{user_name}}] logged out.	
Account removed	Notice	[Account:{{user_name}}] has been removed by admin.	
Account settings changed	Notice	Account settings of [Account:{{user_name}}] has been updated. Account settings of [Account:{{user_name}}] has been deleted. Account settings of [Account:{{user_name}}] has been created.	
Announce message with different	Warning	An Announce message with a different interval has	
interval		been received from port {{index}}/{{number}}	
Check if hardware revision is valid	Notice	The hardware revision of Power Module {{index}} is not allowed.	
Cold start	Critical	System has performed a cold start.	
Configuration changed	Notice	Configuration {{modules}} changed by {{username}}.	
Configuration exported	Notice	Configurations exported {{successful /failed}} by {{username}} via {{method}}.	
Configuration imported	Notice	Configuration import {{successful /failed}} by {{username}} via {{method}}.	
Coupling changed	Warning	Turbo Ring v2 coupling path status has changed.	
dhcpsnp untrust mac discards	Warning	VLAN {{Vlan Id}} dropped packets due to violation of DHCP Snooping rule. Total mac discards: {{number}}.	
dhcpsnp untrust server discards	Warning	VLAN {{Vlan Id}} dropped packets due to a violation of the DHCP Snooping rule. Total server discards: {{number}}.	
Dual homing path changed	Warning	Dual Homing path has switched.	
Event log export	Notice	Event Log export {{successful /failed}} by {{username}} via {{method}}.	
Firmware upgrade failed	Warning	Firmware failed to upgrade.	
Firmware upgrade successful	Notice	Firmware successfully upgraded	
Hardware revision is not allowed	Error	The hardware revision of Line Module %d is not allowed.	
Interface link down	Notice	Interface{{number}} down.	
Interface link up	Notice	Interface {{number}} up.	
LLDP table changed	Info	LLDP remote table has changed.	
Log capacity threshold	Warning	Number of event log entries {{logEntryNum}} has reached the threshold.	

Event Name	Severity	Event Description	
		Port-Channel {{channel id}} has restarted by	
Log Turbo Chain Dort Bostort	Notice	Turbo Chain.	
Log Turbo Chain Port Restart	Notice	Port {{index}}/{{number}} has restarted by	
		Turbo Chain.	
Login failed	Warning	[Account {{user_name}}] log in failed via	
Login railed	warning	{{interface}}.	
Login lockout	Warning	[Account {{user_name}}] locked due to	
Logii lockout	Warning	{{failed_times}} failed login attempts.	
Login successful	Notice	[Account {{user_name}}] successfully logged in	
		via {{interface}}.	
Master changed	Warning	Ring {{Index}} client has changed.	
Master mismatch	Warning	Ring {{Index}} client setting does not match.	
MSTP new port role	Warning	MSTP (MST{{Index}}) port {{number}} role	
The first partition		changed from {{role}} to {{role}}.	
MSTP root changed	Warning	MSTP (MST{{Index}}) new root has been elected	
	, ,	in topology.	
MSTP topology changed	Warning	Topology (MST{{Index}}) has been changed by	
1 3, 3	3	MSTP.	
Packet dropped by Port Security	Warning	Port {{index}}/{{number}} dropped packets due	
, , ,		to violation of Port Security rule.	
Password changed	Notice	Password of [Account: {{user_name}}] has been	
-		changed.	
Port Link Down	Notice	Port {{index}}/{{number}} link down.	
		Port-channel {{Channel id}} link down.	
Port Link Up	Notice	Port {{index}}/{{number}} link up.	
		Port-channel {{Channel id}} link up.	
Port recovery by Rate Limit	Warning	Port {{index}}/{{number}} has recovered by rate	
		limit.  Port {{index}}/{{number}} looping and	
Port shutdown by Loop	Critical	shutdown.	
		Port {{index}}/{{number}} has shut down due to	
Port shutdown by Port Security	Warning	a violation of the Port Security rule.	
		Port {{index}}/{{number}} has excessive traffic	
Port shutdown by Rate Limit	Warning	and shutdown.	
Power Off->On	Notice	Power {{index}} has turned off.	
Power On->Off	Notice	Power {{index}} has turned on.	
		Redundant port {{index}}/{{number}} health	
Redundant port health check failed	Error	check fail.	
RMON failing alarm	Warning	{{user defined}}.	
RMON raising alarm	Warning	{{user defined}}.	
The state of the s		RSTP Port-Channel {{channel id}} received an	
		invalid BPDU (type: {{type}}, value: {{value}}).	
RSTP invalid BPDU	Warning	RSTP port {{index}}/{{number}} received an	
		invalid BPDU (type: {{type}}, value: {{value}}).	
		Port-Channel {{channel id}} changed to	
		{{rstp/stp}}.	
RSTP migration	Warning	Port {{index}}/{{number}} changed to	
		{{rstp/stp}}.	
		RSTP Port-Channel {{channel id}} role changed	
		from {{role}} to {{role}}.	
RSTP new port role	Warning	RSTP port {{index}}/{{number}} role changed	
		from {{role}} to {{role}}.	
RSTP root changed	Warning	RSTP new root has been elected in topology.	
RSTP topology changed	Warning	Topology has been changed by RSTP.	
SSH Key generated	Notice	SSH key has been regenerated.	
		SSL certificate has been changed.	
SSL certification changed	Notice	SSL certificate has been regenerated.	
Topology changed (RSTP)	Warning	Topology has been changed by RSTP.	
Topology changed (Turbo Chain)	Warning	Topology has been changed by Turbo Chain.	
ropology changed (ruibo chaiii)	warning	ropology has been changed by furbo chain.	

<b>Event Name</b>	Severity	Event Description
Topology changed (Turbo Ring)	Warning	Topology change has been detected on Ring
repensely enumber (caree canage		{{RingIndex}} of Turbo Ring v2.
Topology changed (MSTP)	Warning	Topology (MST{{Index}}) has been changed by
Topology changed (MSTF)	waitiiig	MSTP.
Warm start	Notice	System has performed a warm start.
		A trust host, MAC is {{mac address}} with VLAN
When the trust host moves, it will send	Warning	{{Vlan Id}}, moved from port
a log to Moxa log handler.	waitiiig	{{index}}/{{number}} to port
		${\{index\}}/{\{number\}\}}$ .

# D. SNMP MIB File of 65M-5011M (Managed Switch Module)

This appendix contains the SNMP MIB file for the managed switch.

## **Standard MIB Installation Order**

If you need to import the MIB one-by-one, install the MIBs in the following order.

- 1. RFC1213-MIB.mib
- 2. SNMP-FRAMEWORK-MIB.mib
- 3. SNMPv2-SMI.mib
- 4. SNMPv2-TC.mib
- 5. SNMPv2-CONF.mib
- 6. SNMPv2-MIB.mib
- 7. IANAifType-MIB.mib
- 8. IEEE8023-LAG-MIB.mib
- 9. IF-MIB.mib
- 10. EtherLike-MIB.mib
- 11. IEEE8021-PAE-MIB.mib
- 12. BRIDGE-MIB.mib
- 13. P-BRIDGE-MIB.mib
- 14. RFC1271-MIB.mib
- 15. RMON-MIB.mib
- 16. TOKEN-RING-RMON-MIB.mib
- 17. RMON2-MIB.mib
- 18. Q-BRIDGE-MIB.mib
- 19. INET-ADDRESS-MIB.mib
- 20. IEEE8021-TC-MIB.mib
- 21. IEEE8021-SPANNING-TREE-MIB.mib
- 22. IANA-ADDRESS-FAMILY-NUMBERS-MIB.mib
- 23. LLDP-MIB.mib
- 24. LLDP-EXT-DOT1-MIB.mib
- 25. LLDP-EXT-DOT3-MIB.mib

## **MIB Tree**

```
Refer to the following content for the MIB Tree structure.
iso(1)
|-std(0)-iso8802(8802)-ieee802dot1(1)-ieee802dot1mibs(1)
   |-ieee8021paeMIB(1): IEEE8021-PAE-MIB.mib
   |-ieee8021SpanningTreeMib(3): IEEE8021-SPANNING-TREE-MIB.mib
|-org(3)
 |-dod(6)-internet(1)
  |-mgmt(2)-mib-2(1): SNMPv2-MIB.mib
          |-system(1): RFC1213-MIB.mib
             |-interface(2): RFC1213-MIB.mib
          |-at(3): RFC1213-MIB.mib
          |-snmp(11): RFC1213-MIB.mib
          |-rmon(16): RMON-MIB.mib
          |-dot1dBridge(17): BRIDGE-MIB.mib, P-BRIDGE-MIB.mib, Q-BRIDGE-MIB.mib
          |-ifMIB(31): IF-MIB.mib
          |-etherMIB(35): EtherLike-MIB.mib
  |-private(4)-moxa(8691)
          |-product(600): mxGeneralInfo.mib, mxProductInfo.mib,
          |-general(602): mxGeneral.mib, mxDeviceIo.mib, mxDhcpSvr.mib, mxEmailC.mib,
                    mxEventLog.mib,
                   : mxGene.mib, mxLocator.mib, mxManagementIp.mib, mxPorte.mib,
                   : mxSnmp.mib, mxSwe.mib, mxSysLoginPolicySvr.mib,
                   : mxSyslogSvr.mib, mxSysPasswordPolicySvr.mib, mxSystemInfo.mib,
                   : mxSysTrustAccessSvr.mib, mxSysUtilSvr.mib, mxTimeSetting.mib,
                   : mxTimeZone.mib, mxTrapC.mib, mxUiServiceMgmt.mib
          |-switching(603): mxSwitching.mib
             |- portInterfacce : mxPort.mib, mxLa.mib
             |- basicLayer2: mxLhc.mib, mxQos, mxVlan.mib
             |- layer2Redundancy: mxRstp.mib, mxTrv2.mib, mxTurboChain.mib,
               mxDualHoming.mib
             |- layer2Security: mxStcl.mib, mxRlps.mib, mxPssp.mib, mxPsms.mib, mxDot1x.mib,
               mxRadius.mib
             |- layer2Diagnosic: mxLldp.mib, mxTcst.mib, mxPortMirror.mib, mxRmon.mib
             |- layer2Multicast: mxIgmpSnp.mib
  |-snmpV2(6)-snmpModules(3)
             |-snmpFrameworkMIB(10): SNMP-FRAMEWORK.mib
|-ieee(111)-standards-association-numbers-series-standards(2)-lan-man-stds(802)-ieee802dot1(1)-
    ieee802dot1mibs(1)-ieee8021SpanningTreeMib(3): IEEE8021-SPANNING-TREE-MIB.mib
```

# E. Security Guidelines of 65M-5011M (Managed Switch Module)

This appendix explains security practices for installing, operating, maintaining, and decommissioning the device. We strongly recommend that our customers follow these guidelines to enhance network and equipment security.

## **Installation**

## **Physical Installation**

- 1. The device MUST be installed in an access-controlled area, where only the necessary personnel have physical access to the device.
- 2. The device MUST NOT be directly connected to the Internet, which means switches MUST be installed within a security perimeter, which can be implemented by a firewall at the border since the device is not classified as zone/boundary equipment.
- 3. Follow the instructions in the Quick Installation Guide, which is included in the package, to ensure you install the device correctly in your environment.
- 4. The device has anti-tamper labels on the enclosures. This allows an administrator to tell whether the device has been tampered with.
- 5. The ports that are not in use should be deactivated. Refer to **Port Interface** section for detailed instructions.

## **Account Management**

Follow these best practices when setting up an account.

- 1. Each account should be assigned the correct privileges: Only allow the minimum number of people to have admin privilege so they can perform device configuration or modifications, while other users should only have read access privilege. The device supports both local account authentication and remote centralized mechanism, including Radius and TACACS+.
- 2. Change the default password, and strengthen the account password complexity by:
  - a. Enabling the "Password Policy" function.
  - b. Increasing the minimum password length to at least eight characters.
  - Defining a password policy to ensure that it contains at least an uppercase and lowercase letter, a digit, and a special character.
  - d. Setting user passwords to expire after a certain period.
- 3. Enforce regulations that ensure that only a trusted host can access the device. Refer to the **Trusted Access** section for detailed instructions.

## **Vulnerable Network Ports**

- For network security concerns, we strongly recommend that you change the port numbers, such as TCP port numbers for HTTP, HTTPS, Telnet, and SSH, for the protocols that are in use; ports that are not in use but are still reachable pose an unacceptable security risk and should be disabled. Refer to the Management Interface section for detailed instructions.
- 2. To avoid eavesdropping from snooping confidential information, you should adopt encryption-based communication protocols, such as HTTPS instead of HTTP, SSH instead of Telnet, SFTP instead of TFTP, SNMPv3 instead of SNMPv1/v2c, etc. In addition, the maximum number of sessions should be kept to an absolute minimum. Refer to **Management Interface** section for detailed instructions.
- 3. Generate the SSL certificate for the device before commissioning HTTPS or SSH applications. Refer to **SSH & SSL** section for detailed instructions.

## **Operation**

1. To ensure that communications are properly protected, use a strong cryptographic algorithm for key exchange or encryption protocols for HTTPS/SSH applications. The device follows the NIST SP800-52 and SP800-131 standards and supports TLS v1.2 and v1.3 with the following cipher suites:

TLS V1.2				
Cipher suite name	Key exchange	Authentication	Encryption	Hash function
TLS_ECDHE_RSA_WITH_CHACHA20_PO LY1305_SHA256	ECDHE	RSA	CHACHA20- POLY1305	SHA256
TLS_ECDHE_ECDSA_WITH_AES_128_G CM_SHA256	ECDHE	ECDSA	AES128	SHA256
TLS_ECDHE_RSA_WITH_AES_128_GCM _SHA256	ECDHE	RSA	AES128	SHA256
TLS_ECDHE_RSA_WITH_AES_256_GCM _SHA384	ECDHE	RSA	AES256	SHA384
TLS_DHE_RSA_WITH_AES_128_GCM_S HA256	Ephemeral DH	RSA	AES128	SHA256
TLS_DHE_RSA_WITH_AES_256_GCM_S HA384	Ephemeral DH	RSA	AES256	SHA384
TLS_DHE_RSA_WITH_CHACHA20_POLY 1305_SHA256	Ephemeral DH	RSA	CHACHA20- POLY1305	SHA256
TLS_ECDHE-RSA_WITH_AES256- SHA384	ECDHE	RSA	AES256	SHA384
TLS_ECDHE_RSA_WITH_AES_128_CBC _SHA256	ECDHE	RSA	AES128	SHA256
TLS_ECDHE_ECDSA_WITH_CHACHA20_ POLY1305_SHA256	ECDHE	ECDSA	CHACHA20- POLY1305	SHA256
TLS_ECDHE_RSA_WITH_AES_256_CBC _SHA384	ECDHE	RSA	AES256	SHA384
TLS_ECDHE_ECDSA_WITH_AES_256_C BC_SHA384	ECDHE	ECDSA	AES256	SHA384
TLS_ECDHE_ECDSA_WITH_AES_128_C BC_SHA256	ECDHE	ECDSA	AES128	SHA256

TLS V1.3				
Cipher suite name	Key exchange	Encryption	Mode	Hash function
TLS_AES_256_GCM_SHA384	any	AES256	GCM	SHA384
TLS_CHACHA20_POLY1305_SHA256	any	CHACHA20- POLY1305	N/A	SHA256
TLS_AES_128_GCM_SHA256	any	AES128	GCM	SHA256

2. Below is a list of the recommended secure browsers that support TLS v1.2 or above:

Browser	Version
Microsoft Edge	All
Microsoft Internet Explorer	v11 or above
Mozilla Firefox	v27 or above
Google Chrome	v38 or above
Apple Safari	v7 or above

Reference: https://support.globalsign.com/ssl/general-ssl/tls-protocol-compatibility#Browsers

- 3. The device supports event logs and syslog for SIEM integration:
  - a. Event log: Because of limited storage capacity, the event log can only accommodate a maximum of 10,000 entries. Administrators can set a warning for a pre-defined threshold. We recommend that youregularly back up system event logs. Refer to **Event Log** section for detailed instructions.
  - b. Syslog: the device supports syslog, and advanced secure TLS-based syslog for centralized SIEM integration. Refer to **Syslog Settings** section for detailed instructions.
- 4. The device can provide information for control system inventory:
  - a. SNMPv1, v2c, v3: We recommend administrators use SNMPv3 with authentication and encryption to manage the network. Refer to the **MIB File** for detailed instructions.
  - b. Telnet/SSH: We recommend that administrators use SSH with authentication and encryption to retrieve device properties.
  - c. HTTP/HTTPS: We recommend that administrators use HTTPS with a certificate that has been granted by a Certificate Authority to configure the device.
- 5. Denial of Service protection: To avoid disruption of normal operation of the switch, administrators should configure the QoS function. The device supports the ingress rate limit and egress shaped. Administrators can decide how to deal with excess data flow and configure the device accordingly. This process will regulate the resulting data rate per port. Refer to **QoS** section for detailed instructions.
- 6. Time synchronization with authentication: Time synchronization is crucial for process control. To prevent malicious attacks, whereby the settings are changed without permission, authentication must be in place between the NTP server and client. The device supports NTP with a pre-shared key. Refer to **NTP** section for detailed instructions.
- Periodically regenerate the SSH and SSL certificates: Even though the device supports RSA 2048-bit and SHA-256 to ensure sufficient complexity, we strongly recommend that you frequently renew their SSH key and SSL certificate in case the key is compromised. Refer to SSH & SSL section for detailed instructions.
- 8. Below is the list of the protocol port numbers used for all external interfaces.

Protocol	Service Type	Port Number
	SSH	22
TCP	Telnet	23
TCF	HTTP	80
	HTTPS	443
	DHCP	67
UDP	NTP	123
ODP	SNMP	161
	Moxa Service	40404

## **Maintenance**

- 1. Perform firmware upgrades frequently to enhance features, deploy security patches, or fix bugs.
- 2. Frequently back up the system configurations: In order to properly protect the system configuration files from being tampered with, the device supports password encryption and signature authentication for backup files.
- 3. Examine event logs frequently to detect any anomalies.
- 4. To report vulnerabilities of Moxa products, submit your findings on the following web page: <a href="https://www.moxa.com/en/support/product-support/security-advisory/report-a-vulnerability">https://www.moxa.com/en/support/product-support/security-advisory/report-a-vulnerability</a>.

# **Decommission**

To avoid any sensitive information such as your account password or certificate from being disclosed, always reset the system settings to factory default before decommissioning the device.

# F. SFP Module List of 65M-5011M (Managed Switch Module)

This appendix lists the supported SFP module for the managed switch module

Model	Description
SFP-1GLHLC-T	SFP module with 1 1000BaseLH port with LC connector for 30 km transmission, -40 to 85°C operating temperature
SFP-1GLSXLC-T	SFP module with 1 1000BaseLSX port with LC connector for 1km/2km transmission, -40 to 85°C operating temperature
SFP-1GLXLC-T	SFP module with 1 1000BaseLX port with LC connector for 10 km transmission, -40 to 85°C operating temperature
SFP-1GSXLC-T	SFP module with 1 1000BaseSX port with LC connector for 300m/550m transmission, - 40 to 85°C operating temperature
SFP-1GZXLC-T	SFP module with 1 1000BaseZX port with LC connector for 80 km transmission, -40 to 85°C operating temperature
SFP-1G10ALC-T	WDM-type (BiDi) SFP module with 1 1000BaseSFP port with LC connector for 10 km transmission; TX 1310 nm, RX 1550 nm, -40 to 85°C operating temperature
SFP-1G10BLC-T	WDM-type (BiDi) SFP module with 1 1000BaseSFP port with LC connector for 10 km transmission; TX 1550 nm, RX 1310 nm, -40 to 85°C operating temperature
SFP-1G20ALC-T WDM-type (BiDi) SFP module with 1 1000BaseSFP port with LC connector for 20 km transmission; TX 1310 nm, RX 1550 nm, -40 to 85°C operating temperature	
SFP-1G20BLC-T	WDM-type (BiDi) SFP module with 1 1000BaseSFP port with LC connector for 20 km transmission; TX 1550 nm, RX 1310 nm, -40 to 85°C operating temperature
SFP-1G40ALC-T	WDM-type (BiDi) SFP module with 1 1000BaseSFP port with LC connector for 40 km transmission; TX 1310 nm, RX 1550 nm, -40 to 85°C operating temperature
SFP-1G40BLC-T	WDM-type (BiDi) SFP module with 1 1000BaseSFP port with LC connector for 40 km transmission; TX 1550 nm, RX 1310 nm, -40 to 85°C operating temperature
SFP-1FELLC-T	SFP module with 1 100Base single-mode with LC connector for 80 km transmission, -40 to 85°C operating temperature
SFP-1FEMLC-T	SFP module with 1 100Base multi-mode with LC connector for 2/4 km transmission, -40 to 85°C operating temperature
SFP-1FESLC-T	SFP module with 1 100Base single-mode with LC connector for 40 km transmission, -40 to 85°C operating temperature