

DA-820E Series Win10 LTSC 21H2 User Manual

Version 1.0, January 2025

www.moxa.com/products

MOXA[®]

© 2025 Moxa Inc. All rights reserved.

DA-820E Series Win10 LTSC 21H2 User Manual

The software described in this manual is furnished under a license agreement and may be used only in accordance with the terms of that agreement.

Copyright Notice

© 2025 Moxa Inc. All rights reserved.

Trademarks

The MOXA logo is a registered trademark of Moxa Inc.
All other trademarks or registered marks in this manual belong to their respective manufacturers.

Disclaimer

- Information in this document is subject to change without notice and does not represent a commitment on the part of Moxa.
- Moxa provides this document as is, without warranty of any kind, either expressed or implied, including, but not limited to, its particular purpose. Moxa reserves the right to make improvements and/or changes to this manual, or to the products and/or the programs described in this manual, at any time.
- Information provided in this manual is intended to be accurate and reliable. However, Moxa assumes no responsibility for its use, or for any infringements on the rights of third parties that may result from its use.
- This product might include unintentional technical or typographical errors. Changes are periodically made to the information herein to correct such errors, and these changes are incorporated into new editions of the publication.

Technical Support Contact Information

www.moxa.com/support

Table of Contents

1. Introduction	5
Moxa Computers and Windows	5
2. System Initialization	6
Initializing User Settings	6
Initializing System	10
3. BitLocker	11
Enabling the BitLocker	11
Disabling the BitLocker	15
4. RAID	18
Intel® RAID: Changing the RAID Mode	18
Intel® RAID: Creating a RAID Disk in BIOS	20
Intel® RAID: Removing a RAID Volume From the BIOS	24
SW RAID: Creating the RAID 0 or RAID 1 From Disk Management	27
SW RAID: Creating the RAID 5 From Storage Spaces	32
SW RAID: Creating the RAID 10 From Storage Spaces	36
5. Teaming	46
Intel® Net Team	46
Creating an Intel® Net Team	46
Modifying an Intel® Net Team Member	49
6. Intel® Active Management Technology	53
Turning on Intel® AMT on PC	53
Access the Intel® AMT From Website	59
7. Unified Write Filter	62
Turning on UWF on a Running PC	62
Installing UWF Using WMI	64
8. Driver	65
9. Utility	67
Where to Find Windows Utility	67
Dependent Packages	68
Moxa IO Controller Utility	69
Setting the DIO Status	69
Setting the UART Mode	70
Setting the Relay Status	71
Setting the LED Status	72
Moxa Serial Interface Utility	73
Setting the Serial Port Mode	73
Moxa Sort Net Name Utility	74
Moxa Power Temperature Detect Utility	75
10. IO Control API	76
Downloading the API	76
mxdgio	77
GetDinCount	77
GetDoutCount	78
GetDinStatus	78
GetDoutStatus	79
SetDoutStatus	79
mxsp	80
GetUartCount	80
GetUartMode	81
SetUartMode	81
mxrelay	82
GetRelayData	82
SetRelayData	83
mxled	84
GetLedData	84
SetLedData	85
mxwdg	86
mxwdg_open	86

mxwdg_refresh	86
mxwdg_close.....	87
11. System Backup and Restore	88
WindowsRecovery	88
Preparing the USB device	88
Booting From the USB Disk.....	90
System Image Backup	91
Restoring the System From a Backup.....	95

1. Introduction

This Windows 10 IoT Enterprise LTSC 2021(21H2) user manual is applicable to Moxa's x86-based computers listed below and covers the complete set of instructions for these series. Detailed instructions on configuring advanced settings are covered in the following chapters of the manual. Before referring to sections in these chapters, confirm that the hardware specification of your computer model supports the functions/settings covered in this manual.

Moxa Computers and Windows

Moxa computers are integrated with Windows drivers and I/O controller utilities based on the recent up-to-date version of Microsoft Windows so that you can use the most compatible hardware-software combination in your application fields.


2. System Initialization

In this chapter, we describe how to initialize the system settings when you boot up the computer for the first time. When you turn on the computer, you will see the Windows Out of Box Experience (OOBE) wizard. OOBE consists of a series of screens that require customers to accept the license agreement, connect to the internet, log in with or sign up for a Microsoft Account, and share information with the OEM.


Initializing User Settings

The following is a non-exhaustive list of OOBE screens that you will see in the order that they are listed here:


1. Select a region.





2. Select a keyboard.




3. Select a second keyboard.




4. Connect to a network or continue with limited setup.




5. Sign in to or create a local account or a Microsoft account (MSA).



6. Set a password.



7. Choose your privacy settings.



Initializing System

After the OOB settings, you will be redirected to the device desktop of the device. Wait until the process is complete. The device will reboot, and the new settings will take effect after the system restarts.

```
SetupComplete
C:\Windows\system32>start/wait c:\windows\system32\SetOEMModel.exe
C:\Windows\system32>start/wait c:\windows\system32\SortNetName.exe
C:\Windows\system32>reg delete "HKEY_LOCAL_MACHINE\Software\Microsoft\Windows\CurrentVersion\Run" /v "SetupComplete" /f
The operation completed successfully.
```

3. BitLocker


BitLocker is a Windows disk encryption feature, designed to protect data by providing encryption for entire volumes. BitLocker addresses the threats of data theft or exposure from lost, stolen, or inappropriately decommissioned devices. For more information about BitLocker, go to:

<https://learn.microsoft.com/en-us/windows/security/operating-system-security/data-protection/bitlocker/>


This chapter describes the BitLocker setup process.

Enabling the BitLocker


1. In the **Windows Devices and drives**, right-click on the drive and select **Turn on BitLocker**.





2. Select an option to back up the recovery key. For example, select **Save to a file**.




3. Select the path to store the file in.




4. Follow the onscreen instructions to specify the drive encryption options.




5. Click **Continue**.



6. Restart the computer.




7. Wait for the encryption process to complete and then click **Close**.




Disabling the BitLocker



1. In the **Windows Devices and drives**, right-click on the drive and select **Manage BitLocker**.




2. Click on **Turn off BitLocker**.



3. Wait for the decryption process to complete and click **Close** to exit the program.



4. Check the disk status after the decryption process is completed.



4. RAID

RAID is the acronym for **Redundant Array of Independent Disk** which indicates the use of combining multiple disks into one or more logical units for data redundancy, performance improvement, or both. This chapter describes the setup process for Intel® RAID (Intel® RST) and SW RAID.




NOTE


Use hard disks of the same brand, same model, and same capacity to create a RAID for best performance.

Intel® RAID: Changing the RAID Mode

1. Power on the computer and press **F2** to enter the BIOS menu.
2. Select the **Setup Utility** option.



3. Select the **Chipset Configuration** option.



4. Select the **Map SATA Root Port under VMD** and **Enable** this option.




5. Press **F10** to save the settings and Exit, and then select **Yes** to save the settings.




Intel® RAID: Creating a RAID Disk in BIOS


1. Power on the computer and press **F2** to enter the BIOS menu.
2. Select the **Device Management** option.





3. Select **Intel® Rapid Storage Technology**.




4. Select **Create RAID Volume**.




- Select the **RAID Level** option and then press **Enter** to select the raid level; for example, **RAID1 (Mirror)**.




- Select the target disk.




- Enter **X** and then press **Enter**.




- The disk is now marked with an **X** next to it to indicate the selection.



- Select the **Create Volume** option.




10. A RAID volume is created based on the settings specified.




11. Press **F10** to save the settings.

Intel® RAID: Removing a RAID Volume From the BIOS


1. Power on the computer and press **F2** to enter the BIOS menu.
2. Select **Device Management**.




3. Select the **Intel® Rapid Storage Technology** option.




4. Select the RAID volume that you want to remove.



5. Select **Delete** and then press **Enter**.



6. Select **Yes** to confirm and then press **Enter**.



7. Press **F10** to save the settings.



NOTE

Using hard disks of the same brand, same model and same capacity to create RAID for best performance.

SW RAID: Creating the RAID 0 or RAID 1 From Disk Management



NOTE

Use hard disks of the same brand, same model, and same capacity to create a RAID for best performance.

1. Run the **Disk Management**.

All connected disks should have the disk status **Unallocated**. If the disk status is not **Unallocated**, you can right-click on the disk and select **Delete Volume**.

The screenshot shows the Windows Disk Management console. At the top, a table lists the volumes on Disk 0:


Volume	Layout	Type	File System	Status	Capacity	Free Sp...	% Free
(Disk 0 partition 2)	Simple	Basic		Healthy (E...	100 MB	100 MB	100 %
Recovery	Simple	Basic	NTFS	Healthy (...)	500 MB	179 MB	36 %
Windows (C:)	Simple	Basic	NTFS	Healthy (B...	29.21 GB	13.97 GB	48 %

Below the table, the physical disks are shown:


- Disk 0** (Basic, 29.80 GB, Online): Contains three partitions: Recovery (500 MB NTFS, Healthy OEM Partition), 100 MB (Healthy EFI System Partit), and Windows (C:) (29.21 GB NTFS, Healthy (Boot, Page File, Crash Dump, Primary Partition)).
- Disk 1** (Basic, 238.46 GB, Online): Entirely Unallocated.
- Disk 2** (Basic, 238.46 GB, Online): Entirely Unallocated.

A legend at the bottom indicates that black represents Unallocated space and blue represents Primary partition.


2. Right-click the target disk. Select the target volume type. For example: **RAID1(Mirror)**.




3. To continue, click **Next**




4. Select the disks you want to use, and then click **Add**.




5. Click **Next**.




6. Assign the drive letter, click **Next**.




7. Format the volume using **Quick Format**, click **Next**.




8. Checking the RAID1(Mirror) information. Click **Finish** to create the RAID1 volume.



9. System will show the warning message about SW RAID volume, click **Yes** to continue.




10. Checking the RAID1(Mirror) information from disk management.




SW RAID: Creating the RAID 5 From Storage Spaces


1. Open **Control Panel > System and Security**, run **Storage Spaces**.




2. Click **Create a new pool and storage space**.




3. Select target drives to create a storage pool. RAID 5 requires at least three disks. Click **Create pool**.



4. Changing the **Resiliency type to Parity**. Click **Create storage space**.



5. Checking the RAID 5 volume status.



6. Checking the storage space from disk management.

The screenshot shows the Windows Disk Management console. At the top, a table lists the volumes on the system:

Volume	Layout	Type	File System	Status	Capacity	Free Sp...	% Free
(Disk 0 partition 2)	Simple	Basic		Healthy (E...	100 MB	100 MB	100 %
Recovery	Simple	Basic	NTFS	Healthy (...)	500 MB	179 MB	36 %
Storage space (...)	Simple	Basic	NTFS	Healthy (P...	469.87 GB	469.75 GB	100 %
Windows (C:)	Simple	Basic	NTFS	Healthy (B...	29.21 GB	14.00 GB	48 %


Below the table, the details for three disks are shown:

- Disk 0:** Basic, 29.80 GB, Online. Contains Recovery (500 MB NTFS, Healthy (OEM Partition)), 100 MB Healthy (EFI System), and Windows (C:) (29.21 GB NTFS, Healthy (Boot, Page File, Crash Dump, Primary Pa)).
- Disk 4:** Basic, 223.56 GB, Online. Contains 223.56 GB Unallocated space.
- Disk 5:** Basic, 469.88 GB, Online. Contains Storage space (D:) (469.87 GB NTFS, Healthy (Primary Partition)). This section is highlighted with a red border.


A legend at the bottom indicates that black represents Unallocated space and blue represents Primary partition.

SW RAID: Creating the RAID 10 From Storage Spaces


1. Run the **Disk Management**. Connecting the new disks and checking all the disk status are **Unallocated**. If the disk status is not **Unallocated**, you can right-click the target disk and select **Delete Volume**.




2. Open **Control Panel > System and Security**, run **Storage Spaces**.




3. Click **Create a new pool and storage space.**




4. RAID 10 requires at least four disks. Select **Disk 1** and **Disk 2** to create a storage pool. Click **Create a pool.**




5. Changing the **Resiliency type** to **Two-way mirror**. Click **Create storage space**. Follow the step 4 to run the same steps on **Disk 3** and **Disk 4**.




6. Checking the storage space status.




- After the creating steps, the **Storage space (D:)** and **Storage space (E:)** will be shown on **Disk Management**.




- Right-click the **Storage space (D:)**, select **Delete Volume**.




- The warning messages will show on screen, click **Yes** to delete the volume.




- The storage space status will change to **Unallocated**, run the same steps on **Storage space (E:)**.




11. All the storage space status are **Unallocated**.




12. Right-click on the **Disk 5**, select **New Striped Volume**.




13. To continue, click **Next**.




14. Select the disks you want to use, and then click **Add**.




15. Click **Next**.




16. Assign the drive letter, click **Next**.




17. Format the volume using the **Quick Format**, click **Next**.




18. Checking the volume information. Click **Finish** to create the striped volume.



19. System will show the warning messages about SW RAID volume, click **Yes** to continue.



20. Checking the striped volume information from disk management.



5. Teaming

NIC Teaming, also known as load balancing and failover (LBFO), allows multiple network adapters on a computer to be placed into a team for bandwidth aggregation or traffic failover to prevent connectivity loss in the event of a network component failure.


For more information about Teaming : [https://learn.microsoft.com/en-us/previous-versions/windows/itpro/windows-server-2012-r2-and-2012/hh997031\(v=ws.11\)](https://learn.microsoft.com/en-us/previous-versions/windows/itpro/windows-server-2012-r2-and-2012/hh997031(v=ws.11))

Intel® Net Team


This chapter describes the setup process for the Intel® Teaming function.

Creating an Intel® Net Team


1. Run **Intel® PROSet Adapter Configuration Utility** as administrator.



2. In the **Teaming/VLANs** tab, click **Create Team**.



3. Select the adapter to include in this team and click **Next**. An Intel ANS team can contain a maximum of eight members.



4. Name the team and select a team type. Click **Next** to continue.

New Team Wizard

Step 1
Select Member Adapters

Step 2
Provide Team Information

Step 3
Configure Member Adapters

Please name the team and select a type:

Name:

Type:

- Adapter Fault Tolerance
- Adaptive Load Balancing
- IEEE 802.3ad Dynamic Link Aggregation
- Static Link Aggregation
- Switch Fault Tolerance

Note: All fields are required

Back Next Cancel



NOTE

You cannot use an Intel® AMT enabled adapter in a Dynamic Link Aggregation (DLA) team or in a Static Link Aggregation (SLA) team.

1. Select the primary and secondary adapters for the team and click **Finish** to create an Intel net team.

New Team Wizard

Step 1
Select Member Adapters

Step 2
Provide Team Information

Step 3
Configure Member Adapters

Select Primary and Secondary Adapters for the team


Primary Adapter:

Secondary Adapter:

- None Selected
- Intel(R) Ethernet Connection (2) I219-LM
- Intel(R) I210 Gigabit Network Connection

Back Finish Cancel


2. Check the **Network adapters** in the **Windows Device Manager**.




Modifying an Intel® Net Team Member

Adding an Intel® Net Team Member


1. Select an Intel® Net team and click **Modify Members**.



2. Select the adapters to include in this team and click **Apply Changes**.




3. Click **Yes** to continue.



NOTE


Modifying team members will cause the members to momentarily lose connectivity.

4. Check the **Network adapters** in the **Windows Device Manager**.




Removing an Intel® Net Team Member


1. Select an Intel® Net team and click **Modify Members**.




2. Uncheck the adapters you want to remove in this team and click **Apply Changes**.



3. Click **Yes** to continue.



4. Check the **Network adapters** in the **Windows Device Manager**.



6. Intel® Active Management Technology

Intel® AMT is part of the Intel® vPro technology offering. Platforms equipped with Intel® AMT can be managed remotely, regardless of its power state or if it has a functioning OS or not. The Intel® Converged Security and Management Engine (Intel® CSME) powers the Intel® AMT system. As a component of the Intel® vPro platform, Intel® AMT uses several elements in the Intel® vPro platform architecture. This chapter describes the setup process for the Intel® Active Management Technology.

For more information about Intel® Active Management Technology :

<https://www.intel.com/content/www/us/en/developer/articles/guide/getting-started-with-activemanagement-technology.html?wapkw=AMT>




NOTE

Intel® AMT is not supported in models with Intel® Celeron® and Intel® Core™ i3 processors.

Turning on Intel® AMT on PC


1. Power on the computer and press **F2** to enter the BIOS menu.
2. Select **Intel(R) Management Engine BIOS Extension**.




3. Select **MEBx Login**.




4. Type the Intel® ME default password: "**admin**".



5. Type the new password. The new Intel® MEBX password must meet the following requirements for strong passwords:
 - a. **Password Length:** At least 8 characters, and no more than 32.
 - b. **Password Complexity:** Password must include the following:
 - i. At least one digit character ('0', '1', ... '9')
 - ii. At least one 7-bit ASCII non alphanumeric character (e.g., '!', '\$', ';'), but excluding ':', ',' and '"' characters.
 - iii. At least one lower-case letter ('a', 'b'...'z') and at least one upper case letter ('A','B'...'Z').



6. Select **OK** to save and exit.



7. Select **Intel(R) AMT Configuration**.



8. Select **Network Setup**.



9. Select **TCP/IP Settings**.



10. Select **Wired LAN IPV4 Configuration**.



11. Select **DHCP Mode** and **Disable** DHCP mode.



12. Type the network settings for Intel® Active Management Technology.




- Go back to the **Intel(R) AMT Configuration** page and select **Network Activate Access > Network Active**. Enter **Y** to continue.




- Press **F10** to Save and Exit.

Access the Intel® AMT From Website


- Open the web browser and type the URL: **Intel® AMT IP Address:16993** (ex: 192.168.111.10:16993)




- The browser would show the sign in message box. Type the **Username** and **Password** of Intel® AMT. The default username is **admin**.




- After signing in, you can check the system status and hardware information of your managed device.




- The Intel® AMT website provides the basic remote power control feature for the managed device. The advanced remote power control and the remote KVM feature please reference to next chapter.



5. The Event Manager deals with internal alerts that occur in both the host platform and the Intel® AMT device, regardless of the power state.



6. You can configure the managed device network settings from the website.



NOTE

You can also use AMT management tool to remotely manage devices.

7. Unified Write Filter

Unified Write Filter (UWF) is an optional feature that helps to protect your drives by intercepting and redirecting any writes to the drive (app installations, settings changes, saved data) to a virtual overlay. The virtual overlay is a temporary location that is usually cleared during a reboot or when a guest user logs off.

UWF provides a clean experience for thin clients and workspaces that have frequent guests, like school, library, or hotel computers. Guests can work, change settings, and install software. After the device reboots, the next guest receives a clean experience. It increases security and reliability for kiosks, IoT-embedded devices, or other devices where new apps are not expected to be frequently added.

This chapter describes how to use the Unified Write Filter (UWF).

To use the UWF, you must first install the feature and enable it; the default is disabled.

The first time you enable UWF on your device, UWF makes the following changes to your system to improve its performance:


- **Paging files are disabled.**
- **System restore is disabled.**
- **SuperFetch is disabled.**
- **File indexing service is turned off.**
- **Fast boot is disabled.**
- **Defragmentation service is turned off.**
- **BCD setting bootstatuspolicy is set to ignoreallfailures.**

After UWF is enabled, you can select a drive that you want to protect and start using UWF. UWF can help you manage PCs and devices remotely using WMI.

Turning on UWF on a Running PC


- Install UWF.
 - a. In the Windows **Start** window, type **Turn Windows features on or off**.
 - b. Open the **Windows Features** window and expand the **Device Lockdown** node.
 - c. Select **Unified Write Filter** and click **OK**.
 - d. Windows searches for the required files and displays a progress bar.

Once the files are found, Windows applies the changes. When the changes are complete, a message to this effect is displayed.
 - e. Click **Close**.



- Enable the following filter as an Administrator:

cmd uwfmgr filter enable




```
Administrator: Command Prompt
C:\Windows\system32>uwfmgr filter enable
Unified Write Filter Configuration Utility version 10.0.17763
Copyright (C) Microsoft Corporation. All rights reserved.

Unified Write Filter will be enabled after system restart.

C:\Windows\system32>
```

- Enable write protection for a drive:

cmd uwfmgr.exe volume protect C:



```
Administrator: Command Prompt
C:\Windows\system32>uwfmgr filter enable
Unified Write Filter Configuration Utility version 10.0.17763
Copyright (C) Microsoft Corporation. All rights reserved.

Unified Write Filter will be enabled after system restart.


C:\Windows\system32>uwfmgr.exe volume protect C:
Unified Write Filter Configuration Utility version 10.0.17763
Copyright (C) Microsoft Corporation. All rights reserved.

The volume C: will be protected by Unified Write Filter after system restart.

C:\Windows\system32>
```

- Restart your computer.
- Confirm that UWF is running:

cmd uwfmgr.exe get-config



```
Administrator: Command Prompt
C:\windows\system32>uwfmgr.exe get-config
Unified Write Filter Configuration Utility version 10.0.17763
Copyright (C) Microsoft Corporation. All rights reserved.

Current Session Settings

FILTER SETTINGS
  Filter state: ON
  Pending commit: N/A
  Shutdown pending: No

SERVICING SETTINGS
  Servicing State: OFF

OVERLAY SETTINGS
  Type: RAM
  Maximum size: 1024 MB
  Warning Threshold: 512 MB
  Critical Threshold: 1024 MB
  Freespace Passthrough: OFF
  Persistent: OFF
  Reset Mode: N/A
```

Installing UWF Using WMI

If you have already installed Windows on your computer and you do not want to use a provisioning package, you can configure UWF by using Windows Management Instrumentation (WMI) providers.

To turn on UWF using WMI, use the **UWF_Filter** function, specifically the **UWF_Filter.Enable** method in one of the following ways:

- Use the WMI providers directly in a PowerShell script
- Use the WMI providers directly in an application
- Use the command line tool, uwfmgr.exe



NOTE

You must restart your computer after you turn on or turn off UWF for the changes to take effect.

You can also change the settings after you turn on UWF. For example, you can move the page file location to an unprotected volume and re-enable paging files.



IMPORTANT!

If you add UWF to your image by using SMI settings in the unattend.xml file, turning on UWF only sets the bootstatuspolicy BCD setting and turns off the defragmentation service. You must manually turn off the other features and services if you want to increase the performance of UWF.

After the device is restarted, UWF maintains configuration settings for the current session in a registry. UWF automatically excludes these registry entries from its filter. Static configuration changes do not take effect until after a device restarts; the changes are saved in registry entries for use in the next session. Dynamic configuration changes occur immediately and persist after a device restarts.

8. Driver

Moxa provides verified drivers for each device on the official website. Please access the Moxa support page(<https://www.moxa.com/en/support>) and search for the device from the search window (For Example: DA-820C).

The screenshot shows the Moxa Support website interface. At the top, the Moxa logo is on the left, and search and shopping cart icons are on the right. Below the logo, the breadcrumb "Home > Support" is visible. The main heading "Support" is prominently displayed, followed by the subtext "Find product resources, request support, or send in your product for repair." A red rectangular box highlights a "Select a Product Series" section. This section contains a dropdown menu currently set to "--Select--", a search input field with "DA-820C" entered, and a list of search results: "DA-820C Series" and "DA-820C-Ethernet Series Expansion Modules". To the right of this section, there are three columns of content: "Warranty" with a "Repair" link, "Resources" with a "Literature Library" section, and "Documentation" with a download icon and text "Easily find drivers, software, and documentation for a specific product." Below the "Warranty" section is a "Service/MA" section with a gear icon and text "Moxa's product repair service centers provide quick, quality service with complete".

From the **Software & Documentation** page filtered by **Driver** and download the driver package. The driver packages are categorized by OS version, with separate sections for **Peripheral** and **Expansion modules**.

Software & Documentation Product FAQs Security Advisories

Related Software, Firmware, and Drivers

FILTER Operating System All **Driver(6)** Firmware(2) Software Package(7) Utility(6)

NAME	TYPE	CHECKSUM	VERSION	OPERATING SYSTEM	RELEASE DATE
Driver for DA-820C Series (Windows 10 IoT Enterprise LTSC 2019 and Windows Server 2019 peripherals) 1.2 GB	Driver	SHA-512	v1.2	- Windows 10 IoT Enterprise LTSC 2019 - Windows Server 2019	Jul 18, 2024 Release notes
Driver for DA-820C Series (Windows 10 IoT Enterprise LTSC 2021 peripherals) 1.9 GB	Driver	SHA-512	v1.1	- Windows 10 IoT Enterprise LTSC 2021	Jul 18, 2024 Release notes
Driver for DA-820C Series (Windows 10 IoT Enterprise LTSC 2021 for DA-IRIG-B module) 3.2 MB	Driver	SHA-512	v1.0	- Windows 10 IoT Enterprise LTSC 2021	Apr 13, 2022 Release notes
Driver for DA-820C Series (Linux for DA-IRIG-B module) 10.8 KB	Driver	SHA-512	v1.3	- Debian 9.x	Jul 27, 2021 Release notes
Driver for DA-820C Series (Windows 10 IoT Enterprise LTSC 2019/2021 and Windows Server 2019 for DN-SP08 module) 2.5 MB	Driver	SHA-512	v1.0	- Windows 10 IoT Enterprise LTSC 2019 - Windows 10 IoT Enterprise LTSC 2021 - Windows Server 2019	Sep 02, 2019 Release notes
Driver for DA-820C Series (Windows 10 IoT Enterprise LTSC 2019 and Windows Server 2019 for DN-LN04 module) 276.4 KB	Driver	SHA-512	v1.0	- Windows 10 IoT Enterprise LTSC 2019 - Windows Server 2019	Sep 02, 2019 Release notes


9. Utility

This chapter describes the usage of the following:

- **Moxa IO Controller Utility**
- **Serial Interface Utility**
- **Moxa Sort Net Name Utility**
- **Moxa Power Temperature Detect Utility**

Where to Find Windows Utility

The utilities will be preinstalled on the device if Moxa provides the Windows 10 OS. However, if you install Windows 10 independently, visit Moxa's support page (<https://www.moxa.com/en/support>) to download the required utilities. Simply search for your device model (e.g., DA-820C) on the support page to find the appropriate files.



From the **Software & Documentation** page, filter by **Utility** and download the installation *.zip file.

Software & Documentation Product FAQs Security Advisories

Related Software, Firmware, and Drivers

FILTER Operating System All Driver(6) Firmware(2) Software Package(7) **Utility(6)**

NAME	TYPE	CHECKSUM	VERSION	OPERATING SYSTEM	RELEASE DATE
Utility for DA-820C Series (Windows 10 IoT Enterprise LTSC 2019 and Windows Server 2019) 3.3 MB	Utility	SHA-512	v1.1	- Windows 10 IoT Enterprise LTSC 2019 - Windows Server 2019	Jul 18, 2024 Release notes
Utility for DA-820C Series (Windows 10 IoT Enterprise LTSC 2021) 3.3 MB	Utility	SHA-512	v1.1	- Windows 10 IoT Enterprise LTSC 2021	Jul 18, 2024 Release notes
Utility for DA-820C Series (Windows 10 IoT Enterprise LTSC 2021 for DA-PRP-HSR-I210 module) 2.3 MB	Utility	SHA-512	v1.5	- Windows 10 IoT Enterprise LTSC 2021	Feb 16, 2023 Release notes
Utility for DA-820C Series (DN-PRP-HSR-I210 module) 2.3 MB	Utility	SHA-512	v1.5	- Windows 10 IoT Enterprise LTSC 2021	Feb 16, 2023 Release notes
Utility for DA-820C Series (Linux for DA-PRP-HSR-I210 module) 15.6 KB	Utility	SHA-512	v1.0	- Debian 9.x	Mar 22, 2021 Release notes
Utility for DA-820C Series (Linux for DA-IRIG-B module) 38.9 KB	Utility	SHA-512	v1.0	- Debian 9.x	Sep 02, 2019 Release notes

Dependent Packages

After completing the installation of Windows 10 LTSC 2021 and the necessary drivers, you must install the required (dependency) packages to ensure the utility functions correctly. Use the following link to download and install the packages:


- Microsoft Visual C++ Redistributable:
<https://learn.microsoft.com/en-us/cpp/windows/latest-supported-vc-redist?view=msvc-170>
- Microsoft .NET Framework 4.8:
<https://support.microsoft.com/en-us/topic/microsoft-net-framework-4-8-offline-installer-for-windows-9d23f658-3b97-68ab-d013-aa3c3e7495e0>

Moxa IO Controller Utility

The Moxa IO Controller Utility is designed to manage the device's peripheral I/O and expansion module interfaces. This section provides an overview of how to use the utility, covering the following topics:

- **Setting the DIO Status**
- **Setting the UART Mode**
- **Setting the Relay Status**
- **Setting the LED Status**

Use the pre-installed utility or install the **MoxaIOControllerSetup** utility from the Moxa support page. To use the Moxa IO Controller utility, first install the utility and enable the utility to configure the DIO, UART, Relay, and LED mode. After the installation process is complete, run the Windows command prompt as an Administrator and change the path to C:\Program Files\Moxa\Moxa IO Controller.



```
Administrator: Command Prompt
Microsoft Windows [Version 10.0.26100.2161]
(c) Microsoft Corporation. All rights reserved.

C:\Windows\System32>cd /d C:\Program Files\Moxa\Moxa IO Controller

C:\Program Files\Moxa\Moxa IO Controller>
```


Setting the DIO Status

Run the **mx-dio-ctl --help** command to view instructions for using this utility. Follow the displayed guidelines to get or set the DIO status.



IMPORTANT!

The DIN and DOUT indices start at 0. Even though the console output starts at 1, the indices still start at 0.



```
Administrator: Command Prompt

C:\Program Files\Moxa\Moxa IO Controller>mx-dio-ctl.exe --help
mx-dio-ctl 2.0.2307.10000
Copyright (C) 2019 Moxa Inc. All rights reserved.

-i      -i <#DIN index> (Start from 0)
-o      -o <#DOUT index> (Start from 0)
-m      -m <status>
        0 --> LOW
        1 --> HIGH
-c      -c <#DIN:0 /DOUT:1>

--help  Display this help screen.
--version Display version information.

C:\Program Files\Moxa\Moxa IO Controller>
```

Example:

```
Administrator: Command Prompt
C:\Program Files\Moxa\Moxa IO Controller>mx-dio-ctl.exe -c 0
DIN port count: 6

C:\Program Files\Moxa\Moxa IO Controller>mx-dio-ctl.exe -c 1
DOUT port count: 2

C:\Program Files\Moxa\Moxa IO Controller>mx-dio-ctl.exe -i 0
DIN port 0 status: 1

C:\Program Files\Moxa\Moxa IO Controller>mx-dio-ctl.exe -o 0
DOUT port 0 status: 1

C:\Program Files\Moxa\Moxa IO Controller>mx-dio-ctl.exe -o 0 -m 0
DOUT port 0 status: 0

C:\Program Files\Moxa\Moxa IO Controller>mx-dio-ctl.exe -i 0
DIN port 0 status: 1

C:\Program Files\Moxa\Moxa IO Controller>_
```

Setting the UART Mode

Run the **mx-uart-ctl --help** command to view instructions for using this utility. Follow the displayed guidelines to get or set the UART status.



IMPORTANT!

The UART index starts from 0. Even though the console output starts at 1, the index still starts at 0.

```
Administrator: Command Prompt
C:\Program Files\Moxa\Moxa IO Controller>mx-uart-ctl.exe --help
mx-uart-ctl 2.1.2409.10000
Copyright (C) 2024 Moxa Inc. All rights reserved.

-p      -p <#port index> (Start from 0)

-m      -m <#uart mode>
        0 --> set to RS232 mode
        1 --> set to RS485-2W mode
        2 --> set to RS485-4W mode
        3 --> set to RS422 mode

-c      -c

--help  Display this help screen.
--version Display version information.

C:\Program Files\Moxa\Moxa IO Controller>
```

Example:

```
Administrator: Command Prompt
C:\Program Files\Moxa\Moxa IO Controller>mx-uart-ctl.exe -c
COM port count: 2

C:\Program Files\Moxa\Moxa IO Controller>mx-uart-ctl.exe -p 0
Current uart mode is RS232 interface.

C:\Program Files\Moxa\Moxa IO Controller>mx-uart-ctl.exe -p 0 -m 1
Set OK.

Current uart mode is RS485-2W interface.

C:\Program Files\Moxa\Moxa IO Controller>
```

Setting the Relay Status

Run the **mx-relay-ctl --help** command to view instructions for using this utility. Follow the displayed guidelines to get or set the Relay status.



IMPORTANT!

The relay index starts from 0. Even though the console output starts at 1, the index still starts at 0.

```
Administrator: Command Prompt
C:\Program Files\Moxa\Moxa IO Controller>mx-relay-ctl.exe --help
mx-relay-ctl 1.0.1905.0
Copyright (C) 2019 Moxa Inc. All rights reserved.
USAGE:
Get value from relay index 1:
  mx-relay-ctl -i 1
Turn on relay index 2:
  mx-relay-ctl -i 2 -m 1

-i      Required. -i <#Relay index> (Start from 0)

-m      -m <status>
        0 --> turn off
        1 --> turn on

--help  Display this help screen.

--version Display version information.

C:\Program Files\Moxa\Moxa IO Controller>
```

Example:

```
Administrator: Command Prompt
C:\Program Files\Moxa\Moxa IO Controller>mx-relay-ctl.exe -i 0
Relay index 0 data: 1

C:\Program Files\Moxa\Moxa IO Controller>mx-relay-ctl.exe -i 0 -m 0
Relay index 0 data: 0

C:\Program Files\Moxa\Moxa IO Controller>mx-relay-ctl.exe -i 0
Relay index 0 data: 0

C:\Program Files\Moxa\Moxa IO Controller>mx-relay-ctl.exe -i 0 -m 1
Relay index 0 data: 1

C:\Program Files\Moxa\Moxa IO Controller>
```

Setting the LED Status

Run the **mx-led-ctl --help** command to view instructions for using this utility. Follow the displayed guidelines to get or set the LED status.



IMPORTANT!

The LED index starts from 0. Even though the console output starts at 1, the index still starts at 0.

```
Administrator: Command Prompt
C:\Program Files\Moxa\Moxa IO Controller>mx-led-ctl.exe --help
mx-led-ctl 1.0.1905.0
Copyright (C) 2019 Moxa Inc. All rights reserved.
USAGE:
Get value from LED index 1:
  mx-led-ctl -i 1
Turn on LED index 2:
  mx-led-ctl -i 2 -m 1
Set LED index 3 to blink mode:
  mx-led-ctl -i 3 -m 2

-i      Required. -i <#LED index> (Start from 0)

-m      -m <status>
        0 --> led off
        1 --> led on
        2 --> led blink

--help  Display this help screen.

--version  Display version information.

C:\Program Files\Moxa\Moxa IO Controller>
```

Example:

```
Administrator: Command Prompt
C:\Program Files\Moxa\Moxa IO Controller>mx-led-ctl.exe -i 1
LED index 1 data: 0

C:\Program Files\Moxa\Moxa IO Controller>mx-led-ctl.exe -i 1 -m 1
LED index 1 data: 1

C:\Program Files\Moxa\Moxa IO Controller>mx-led-ctl.exe -i 1
LED index 1 data: 1

C:\Program Files\Moxa\Moxa IO Controller>mx-led-ctl.exe -i 1 -m 0
LED index 1 data: 0


C:\Program Files\Moxa\Moxa IO Controller>
```

Moxa Serial Interface Utility


This section explains how to use the Moxa Serial Interface Utility to configure the UART mode on your computer's serial interface.

Setting the Serial Port Mode

1. Install the Moxa Serial Interface utility
2. From the Windows Start menu, run the **Moxa Serial Interface utility**.




3. Select the target COM port and UART mode and click **Apply** to save the settings.




Moxa Sort Net Name Utility

This section explains how to use the **Moxa Sort Net Name** utility to rename Ethernet adapters. This utility helps map the physical LAN port order on the chassis to the corresponding adapter names in the system.


1. Use the pre-installed utility or install the **MoxaSortNetName** utility from the Moxa support page.
2. The initial order of network names may be random.



3. After the installation process is complete, run the **SortNetName.exe** from **C:\Program Files\Moxa\Moxa Sort Net Name** as an Administrator.



4. If you want to rename the Ethernet adapter, wait for the installation process to complete. The order of the Ethernet adapter will correspond to the order of the label (e.g., **LAN 2** of the computer is mapped to **Ethernet 2** in Windows).




Moxa Power Temperature Detect Utility


Moxa Power Temperature Detect Utility is developed to detect power temperature as a monitoring tool.

This section describes how to use the Moxa Power Temperature Detect Utility


1. Use the pre-installed utility or install the **MxPowerTemperatureDetect** utility from the Moxa support page.
2. Run the **mx-pwrtemp-ctl.exe** from C:\Program Files\Moxa\MxPowerTemperatureDetect\ as an Administrator.




3. Type the **mx-pwrtemp-ctl.exe --help** command to see instructions on using this utility and follow the onscreen instructions to get the power temperature.



4. Example (two power installed):



Example (only one power installed, display N/A for empty power slot):




10. IO Control API

This chapter describes how to use the IO Control API.


Downloading the API

1. Go to <https://www.moxa.com/en/support>
2. Select your product series (e.g., DA-820).



The screenshot shows the Moxa website's support page. The navigation bar includes 'Products', 'Solutions', 'Support', 'How to Buy', and 'About Us'. The main heading is 'Support' with the subtext 'Find product resources, request support, or send in your product for repair.' Below this is a 'Select a Product Series' section with a dropdown menu set to '--Select--'. A search input field contains 'DA-820'. A dropdown menu is open, showing 'DA-820 Series' and 'DA-820-Ethernet Series Expansion Modules'. To the right, there are sections for 'Warranty' and 'Resources', including 'Literature Library' and 'Service/RMA'.

3. Download the related files.



The screenshot shows the Moxa DA-820 Series product page. It features a product image of a 3U 19-inch IEC 61850 native PRP/HSR computer. The product description includes 'Intel® Celeron®, Core™ i3 or i7 CPU'. There is a 'GO TO PRODUCT PAGE' button and a 'Save' button. Below the product information, there are tabs for 'Software & Documentation', 'Product FAQs', and 'Security Advisories'. The 'Software & Documentation' tab is active, showing a section for 'Related Software, Firmware, and Drivers'. A filter dropdown is set to 'Operating System'. The table below lists the following items:

NAME	TYPE	VERSION	OPERATING SYSTEM	RELEASE DATE
Library for DA-820 Series (Windows 7 Example) 459.9 KB	Library	v1.0		Jan 29, 2015
Driver for DA-820 Series (Peripheral for Linux) 651.6 KB	Driver	v1.0		Jan 22, 2015
Driver for DA-820 Series (Linux) 318.5 KB	Driver	v1.0		Jan 22, 2015

At the bottom of the table, there is a 'SHOW ALL' button.

mxdgio

The mxdgio library operates on the digital I/Os and consists of the following:

- **GetDinCount**
- **GetDoutCount**
- **GetDinStatus**
- **GetDoutStatus**
- **SetDoutStatus**

GetDinCount

Syntax

```
int GetDinCount();
```

Description

Get the numbers of a digital input port.

Parameters

N/A.

Return Value

The numbers of the digital input port.

Error codes

The following error codes can be retrieved using the **DIO_STATUS** function.

Name	Value	Meaning
LIB_INITIALIZE_FAIL	-1	The mxdgio library initialization failed. Cannot open json profile.

Requirements

Name	Items
Header	mxdgio.h
Library	mxdgio.lib
DLL	mxdgio.dll
Profile	MxdgioProfile[ModelName].json

GetDoutCount

Syntax

```
int GetDoutCount();
```

Description

Get the numbers of a digital output port.

Parameters

N/A.

Return Value

The numbers of the digital output port.

Error codes

The following error codes can be retrieved using the **DIO_STATUS** function.

Name	Value	Meaning
LIB_INITIALIZE_FAIL	-1	The mxdgio library initialization failed. Cannot open json profile.

Requirements

Name	Items
Header	mxdgio.h
Library	mxdgio.lib
DLL	mxdgio.dll
Profile	MxdgioProfile[ModelName].json

GetDinStatus

Syntax

```
int GetDinStatus(int port);
```

Description

Gets the status of a digital input port.

Parameters

port: The index of the digital input port; starts at 0.

Return Value

The status of the digital input port; 0 for low and 1 for high.

Error codes

The following error codes can be retrieved using the **DIO_STATUS** function.

Name	Value	Meaning
LIB_INITIALIZE_FAIL	-1	The mxdgio library initialization failed. Cannot open json profile.
PORT_OUTOF_INDEX	-2	Target port index is out of range.

Requirements

Name	Items
Header	mxdgio.h
Library	mxdgio.lib
DLL	mxdgio.dll
Profile	MxdgioProfile[ModelName].json

GetDoutStatus

Syntax

```
int GetDoutStatus(int port);
```

Description

Gets the status of a digital output port.

Parameters

port: The index of the digital output port; starts at 0.

Return Value

The status of the digital output port; 0 for low and 1 for high.

Error codes

The following error codes can be retrieved using the **DIO_STATUS** function.

Name	Value	Meaning
LIB_INITIALIZE_FAIL	-1	The mxdgio library initialization failed. Cannot open json profile.
PORT_OUTOF_INDEX	-2	Target port index is out of range.

Requirements

Name	Items
Header	mxdgio.h
Library	mxdgio.lib
DLL	mxdgio.dll
Profile	MxdgioProfile[<i>ModelName</i>].json

SetDoutStatus

Syntax

```
int SetDoutStatus(int port, int status);
```

Description

Sets the status of a digital output port.

Parameters

port: The index of the digital output port; starts at 0.

status: The status of the digital output port; 0 for low and 1 for high.

Return Value

Returns the value 0 if the digital output status is successfully set.

Error codes

The following error codes can be retrieved using the **DIO_STATUS** function.

Name	Value	Meaning
LIB_INITIALIZE_FAIL	-1	The mxdgio library initialization failed. Cannot open json profile.
PORT_OUTOF_INDEX	-2	Target port index is out of range.
SET_STATUS_ERR	-3	Status setting failed or is defined with a bad format.

Requirements

Name	Items
Header	mxdgio.h
Library	mxdgio.lib
DLL	mxdgio.dll
Profile	MxdgioProfile[<i>ModelName</i>].json

mxsp

The mxsp library operates on the serial port and consists of the following:

- **GetUartCount**
- **GetUartMode**
- **SetUartMode**

GetUartCount

Syntax

```
int GetUartCount();
```

Description

Gets the numbers of the UART port.

Parameters

N/A

Return Value

The numbers of the UART port.

Error codes

The following error codes can be retrieved using the **UART_STATUS** function.

Name	Value	Meaning
LIB_INITIALIZE_FAIL	-1	The mxsp library initialization failed. Cannot open json profile.

Requirements

Name	Items
Header	mxsp.h
Library	mxsp.lib
DLL	mxsp.dll
Profile	MxspProfile[<i>ModelName</i>].json

GetUartMode

Syntax

```
int GetUartMode(int port);
```

Description

Gets the status of the UART port.

Parameters

port: The index of the UART port; starts at 0.

Return Value

The mode of a UART interface; 0 for RS-232, 1 for RS-485-2W, 2 for RS-485-4W and 3 for RS-422.

Error codes

The following error codes can be retrieved using the **UART_STATUS** function.

Name	Value	Meaning
LIB_INITIALIZE_FAIL	-1	The mxsp library initialization failed. Cannot open json profile.
PORT_OUTOF_INDEX	-2	Target port index is out of range.

Requirements

Name	Items
Header	mxsp.h
Library	mxsp.lib
DLL	mxsp.dll
Profile	MxspProfile[<i>ModelName</i>].json

SetUartMode

Syntax

```
int SetUartMode(int port, int mode);
```

Description

Sets the status of the UART port.

Parameters

port: The index of the UART port; starts at 0.

mode: The mode of a UART interface; 0 for RS-232, 1 for RS-485-2W, 2 for RS-485-4W and 3 for RS-422.

Return Value

Returns 0 if the UART mode is successfully set.

Error codes

The following error codes can be retrieved using the **UART_STATUS** function.

Name	Value	Meaning
LIB_INITIALIZE_FAIL	-1	The mxsp library initialization failed. Cannot open json profile.
PORT_OUTOF_INDEX	-2	Target port index is out of range.
SET_STATUS_ERR	-3	Status setting failed or is defined with a bad format.
NOT_SUPPORT_MODE	-4	Target mode is not supported for this port.

Requirements

Name	Items
Header	mxsp.h
Library	mxsp.lib
DLL	mxsp.dll
Profile	MxspProfile[<i>ModelName</i>].json

mxrelay

The mxrelay library operates on the relay output and consists of the following:

- **GetRelayData**
- **SetRelayData**

GetRelayData

Syntax

```
int GetRelayData(int port);
```

Description

Gets the status of the relay output port.

Parameters

port: The index of the relay output port; starts at 0.

Return Value

The status of a relay output port; 0 for OFF, 1 for ON.

Error codes

The following error codes can be retrieved by the **RELAY_STATUS** function.

Name	Value	Meaning
LIB_INITIALIZE_FAIL	-1	The mxrelay library initialization failed. Cannot open json profile.
PORT_OUTOF_INDEX	-2	Target port index is out of range.

Requirements

Name	Items
Header	mxrelay.h
Library	mxrelay.lib
DLL	mxrelay.dll
Profile	MxrelayProfile[<i>ModelName</i>].json

SetRelayData

Syntax

```
int SetRelayData(int port, int status);
```

Description

Sets the status of the relay output port.

Parameters

port: The index of the relay output port; starts at 0.

status: The status of a relay output; 0 for OFF, 1 for ON.

Return Value

Returns 0 if the status of the relay output is successfully set.

Error codes

The following error codes can be retrieved by the **RELAY_STATUS** function.

Name	Value	Meaning
LIB_INITIALIZE_FAIL	-1	The mxrelay library initialization failed. Cannot open json profile.
PORT_OUTOF_INDEX	-2	Target port index is out of range.
SET_STATUS_ERR	-3	Status setting failed or is defined with a bad format.

Requirements

Name	Items
Header	mxrelay.h
Library	mxrelay.lib
DLL	mxrelay.dll
Profile	MxrelayProfile[ModelName].json

mxled

The mxled library operates on the relay output and consists of the following:

- **GetLedData**
- **SetLedData**

GetLedData

Syntax

```
int GetLedData(int port);
```

Description

Gets the status of the LED port.

Parameters

port: The index of the LED port; starts at 0.

Return Value

The status of a LED port; 0 for OFF, 1 for ON.

Error codes

The following error codes can be retrieved by the **LED_STATUS** function.

Name	Value	Meaning
LIB_INITIALIZE_FAIL	-1	The mxled library initialization failed. Cannot open json profile.
PORT_OUTOF_INDEX	-2	Target port index is out of range.

Requirements

Name	Items
Header	mxled.h
Library	mxled.lib
DLL	mxled.dll
Profile	MxledProfile[<i>ModelName</i>].json

SetLedData

Syntax

```
int SetLedData(int port, int status);
```

Description

Sets the status of the LED port.

Parameters

port: The index of the LED port; starts at 0.

status: The status of the LED; 0 for OFF, 1 for ON, and 2 for blinking.

Return Value

Returns 0 if the LED status is set successfully.

Error codes

The following error codes can be retrieved by the **LED_STATUS** function.

Name	Value	Meaning
LIB_INITIALIZE_FAIL	-1	The mxled library initialization failed. Cannot open json profile.
PORT_OUTOF_INDEX	-2	Target port index is out of range.
SET_STATUS_ERR	-3	Status setting failed or is defined with a bad format.

Requirements

Name	Items
Header	mxled.h
Library	mxled.lib
DLL	mxled.dll
Profile	MxledProfile[<i>ModelName</i>].json

mxwdg

The mxwdg library operates on the watchdog and consists of the following:

- **mxwdg_open**
- **mxwdg_refresh**
- **mxwdg_close**

mxwdg_open

Syntax

```
PVOID mxwdg_open(unsigned long time);
```

Description

Initializes the watchdog timer.

Parameters

time: The interval at which the watchdog timer is refreshed; the unit is seconds.

Return Value

Returns the pointer to the watchdog handle; returns -1 on failure to initialize the watchdog timer.

Requirements

Name	Items
Header	mxwdg.h
Library	mxwdg.lib
DLL	mxwdg.dll

mxwdg_refresh

Syntax

```
int mxwdg_refresh(PVOID fd);
```

Description

Refreshes the watchdog timer.

Parameters

fd: The handle of the watchdog timer.

Return Value

Returns 0 on success. If not, the function has failed.

Requirements

Name	Items
Header	mxwdg.h
Library	mxwdg.lib
DLL	mxwdg.dll

mxwdg_close

Syntax

```
void mxwdg_close(PVOID fd);
```

Description

Disables the watchdog timer.

Parameters

fd: The handle of the watchdog timer.

Return Value

This function does not return a value.

Requirements

Name	Items
Header	mxwdg.h
Library	mxwdg.lib
DLL	mxwdg.dll

11. System Backup and Restore

This chapter describes the usage of the following for system backup and restoration.


- **WindowsRecovery**

WindowsRecovery


WindowsRecovery is an OS image backup and restore program for system deployment, backup, and recovery. You will first need to create a WindowsRecovery USB disk. This WindowsRecovery disk can only be used to boot a **UEFI BIOS** machine. This chapter describes the setup process of the Windows Recovery function.

Preparing the USB device


1. Contact a Moxa technical staff and get the required file.





2. Run the **BuildWindowsRecoveryUSB_V1.2.0.exe**.




3. Select the USB drive to format.




- Click ... to select .wim file from the folder.





- Click **Start** and make sure the selected USB can be formatted. Click **Yes** to start creating the recovery USB.



- Wait for the process to finish. The program will format the USB device and create a UEFI bootable volume and a WinPE volume. You may see additional windows about folder information; do not close these. You can close the windows after the process finishes.




- To create a recovery USB disk with the Windows 10 image, copy the **os_image_ModelName** directory to the **\home\partimag** folder in the USB drive.




Booting From the USB Disk

- Turn on the computer and press **F2** when you hear the beep sound to enter the BIOS setup menu, select **Boot Manager** and press **Enter** to continue.



- Select the **EFI USB Device** on the computer and press **Enter** to continue to boot from the USB device.




System Image Backup

To back up the image from the USB disk, run **Windows Preinstallation Environment(WinPE)** and the **Windows Recovery utility** will display. Follow these steps.


1. Click **Backup**.




2. Select the **Source disk** to backup and **Destination USB** to store the OS image, also give an image name and description. Click **Start to backup**.



3. Click **Yes** to continue.



4. Wait for the backup process to complete.




- When the process is done, click **OK**.




- Click **OK**, the computer will shut down.



7. The OS image will be saved in USB disk at **home\partimag**.



8. In the **os_image** folder you can view the backup information and the image files.




Restoring the System From a Backup

To restore the image, run the **Windows Preinstallation Environment(WinPE)** and the **Windows Recovery utility** will display. Follow these steps.

1. Click **Recovery**.



2. Select the **Source USB Device**, Image Folder File and check the image information, select the **Destination Drive** to restore. Click **Apply**.







NOTE

If dual operating systems are required, it is recommended that you restore the image to the destination drive with the PCIe interface (if available) first.

3. Click **Yes** to continue the process.



4. Click **Yes** to overwrite the destination drive.



5. Wait for the process to complete.



6. Click **OK**.



NOTE

When you restart the computer, you will need to wait about 5 minutes for the computer to go through two cycles of the reboot process. The system configuration files will be initiated during the first boot-up process. Do not turn off or shut down the computer while the system is restarting.