

NPort 5600-DT-G2 Series User Manual

Version 1.0, May 2026

www.moxa.com/products

MOXA[®]

© 2026 Moxa Inc. All rights reserved.

NPort 5600-DT-G2 Series User Manual

The software described in this manual is furnished under a license agreement and may be used only in accordance with the terms of that agreement.

Copyright Notice

© 2026 Moxa Inc. All rights reserved.

Trademarks

The MOXA logo is a registered trademark of Moxa Inc.
All other trademarks or registered marks in this manual belong to their respective manufacturers.

Disclaimer

- Information in this document is subject to change without notice and does not represent a commitment on the part of Moxa.
- Moxa provides this document as is, without warranty of any kind, either expressed or implied, including, but not limited to, its particular purpose. Moxa reserves the right to make improvements and/or changes to this manual, or to the products and/or the programs described in this manual, at any time.
- Information provided in this manual is intended to be accurate and reliable. However, Moxa assumes no responsibility for its use, or for any infringements on the rights of third parties that may result from its use.
- This product might include unintentional technical or typographical errors. Changes are periodically made to the information herein to correct such errors, and these changes are incorporated into new editions of the publication.

Technical Support Contact Information

www.moxa.com/support

Table of Contents

1. Introduction	6
Overview	6
Package Checklist	7
NPort 5600-DT-G2 Models	7
2. Getting Started	8
Panel Layout	8
NPort 5600-8-DT-G2	8
NPort 5600-16-DT-J-G2	9
NPort 5600-8-DTS-J-G2	9
Connecting the Hardware	10
Wiring Requirements	10
Powering the NPort 5600-DT-G2	11
LED Indicators	11
Pin Assignments of the Serial Ports	12
Mounting Options	13
Connecting to the Network	14
3. First-time Setup.....	15
Finding the Device	15
Search Device.....	16
First-time Login With Device Search Utility	16
Unlock	18
Assigning IPs	18
COM Mapping	20
Console.....	20
Locate	20
First-time Login Process	21
4. Mapping COM Ports.....	24
Mapping COM Ports on Windows Platforms	24
Mapping COM Ports With Real COM Mode	24
Mapping COM Ports on Linux Platforms.....	26
Mapping TTY Ports.....	27
Removing Mapped TTY Ports.....	27
Removing Linux Driver Files.....	27
Mapping COM Ports on macOS Platforms	28
Installing macOS TTY Driver Files	28
Mapping macOS TTY Port	31
Uninstalling the macOS Driver	33
Mapping COM Ports on UNIX-like Platforms	34
Installing the UNIX Fixed TTY Driver	34
Configuring the UNIX Driver	35
5. Cybersecurity Considerations	36
Updating Firmware	36
Turn Off Unused Service and Ports.....	36
Turn On Services That Are Necessary	37
Limited IP Access.....	37
Account and Password.....	37
System Log.....	38
Deployment of the Device.....	38
Testing the Security Environment	39
6. Management Consoles	40
Configuration Options.....	40
Device Search Utility.....	40
Web Console.....	40
Serial Console.....	40
7. Configuration with the Web Console.....	42
Factory Default IP Address.....	42
Using Your Web Browser.....	42
Opening the Web Console.....	42

Web Console Navigation	44
Dashboard Introduction	45
System Settings	46
General	46
Notification	48
SNMP Agent	53
Network Settings	55
IP Address	55
Port Speed	57
Routing Table	57
Serial Port Settings	59
Operation Modes	59
Serial Parameters	90
Secure Connection	93
Security	95
Services	95
Allowlist	97
Certificate	97
DoS Defense	99
Login Settings	99
Account Management	101
Accounts	101
Groups	102
Password Policy	104
Maintenance	105
Config. Import/Export	105
Firmware Upgrade	106
Reset to Default	108
Restart	108
Diagnostics	109
Quick System Check	109
Support	110
System Log	112
Operation Mode Statistics	115
Network Monitor	118
Ping	119
Traffic Monitor	119
8. Mass Deployment/Maintenance	121
Mass Configuration With GUI Tool: Device Search Utility v3.0 or Later	121
Import/Export Configuration	121
Import Certificate	122
Firmware Upgrade	123
Mass Configuration with CLI tool: MCC Tool	123
Import/Export Configuration	123
Firmware Upgrade	125
Change Password	126
9. Advanced Settings of NPort Windows Driver Manager	127
Configure the mapped COM ports	127
Change the Number of a Mapped COM Port	127
COM Splitting	128
Advanced Setting	130
Security	132
Importing/Exporting COM mapping	133
Port Sniffer Wizard	134
10. Frequently Asked Questions	142
Q1. If I disable the Web console, how can I change the settings?	142
Q2. Can different users use the same account to log in to the device server?	142
Q3. Why Device Search Utility v3.0 and later cannot be executed on my Windows 7 or Windows 2008 R2?... ..	142
Q4. How can I check the CRC value of the runtime settings?	143
Q5. Is there an easier way to copy the settings of an NPort 5600-DT device server to an NPort 5600-DT-G2?	143

Q6. If there is a power outage during a firmware upgrade, how can I recover the device?	143
Q7. Before calling Moxa customer service, is there anything I can prepare to save both of us time?.....	143
A. Pinouts and Cable Wiring.....	144
Cable Wiring Diagrams	145
Ethernet Cables	145
Serial Cables	145
B. Accessory Introduction.....	147
Convert the DB9 Connector to Other Connectors	147
Convert the 8-pin RJ45/10-pin RJ50 Connector to Other Connectors	148
Selecting Suitable Power Adapter Depends on the Environment.....	151
C. Well-known Port Numbers.....	153
D. SNMP MIB List	155
RFC1213 MIB-II Supported SNMP Variables	155
RFC1317 RS-232-like Groups	156
Moxa-NP5600-DT-G2-MIB.....	157
E. Event List.....	162
F. Command List of the Serial Console.....	165
G. How to Become a Registered User	167

1. Introduction

By leveraging the IEC 62443-4-1 secure development life-cycle process, Moxa has created a new line of secure device servers. The NPort 5600-DT-G2 Series secure device servers follow the IEC 62443-4-2 design and guidelines to connect your legacy serial devices to industrial networks securely. Furthermore, Moxa's 35 years of experience in serial-connectivity contributes to an enhanced user experience with flexible installation options and a convenient troubleshooting tool for maintenance.

The NPort 5600-DT-G2 Series of serial device servers has many exceptional features. What distinguishes the models apart are the number of ports and the type of network connection they employ. The NPort 5600-DT-G2 Series shares the same instructions and information across all its models. We will specify any variations between models. To learn more about the variations between models in the series, refer to the Product Selection Chart section in this chapter.

Overview

The NPort 5600-DT-G2 device servers can conveniently and transparently connect 8 or 16 serial devices to an Ethernet network, allowing you to network your existing serial devices with only basic configuration. You can both centralize the management of your serial devices and distribute management hosts over the network. As the NPort 5600-DT-G2 device servers have a smaller form factor compared to our 19-inch models, they are a great choice for applications that need additional serial ports but for which mounting rails are not available.

NPort 5600-DT-G2 enables the connection of serial devices to Ethernet networks and supports multiple operation modes. In particular, the NPort 5600-DT-G2 has support for Secure Real COM, Secure TCP Server, Secure TCP Client, and Secure Pair Connection modes. This makes it ideal for security-critical applications like banking, telecom, access control, and remote site management. With these secure operation modes, you'll have access to supported protocols, authentication control, advanced data encryption, and more.

The NPort 5600-DT-G2's Any Baudrate feature, which is based on Moxa's UART IC, allows the use of nonstandard baudrates. For example, some special applications may require a baudrate of 500 kbps. Most device servers can only support a baudrate of 460.8 kbps, leading to an error rate of 7.84%. The margin of error allowed for serial communication is just 3%. With the NPort 5600-DT-G2, you can configure the baudrate more precisely and transmit serial data at a rate of 491.5 kbps. This is only a 1.7% margin of error, which is well within the acceptable margin for serial data.

Even when communication is disrupted, reliable data delivery is crucial for certain applications. The NPort 5600-DT-G2 has an exceptional feature that buffers data in case of communication failure. In case of a communication failure, the NPort 5600-DT-G2 stores the data. Upon resumption of communication, the buffered data will be sent to the destination. Each port has a default buffer size of 64 KB.

Package Checklist

Each NPort 5600-DT-G2 serial device server is packaged individually with various standard accessories. When you receive your shipment, check the contents of the box carefully and notify your Moxa sales representative if any of the items are missing or appear to be damaged.

NPort 5600-DT-G2 Models

The supported models of the NPort 5600-DT-G2:

Model Name	No. of Ethernet Ports	No. of Serial Ports	Serial Standards	Serial Isolation	Power Supply Included	Dimensions	Operating Temperature
NPort 5610-8-DT-G2	2	8	RS-232	-	-	197 x 125 x 44 mm	-10 to 60°C
NPort 5610-8-DT-G2-T	2	8	RS-232	-	-	197 x 125 x 44 mm	-40 to 75°C
NPort 5650-8-DT-G2	2	8	RS-232/422/485	-	-	197 x 125 x 44 mm	-10 to 60°C
NPort 5650-8-DT-G2-T	2	8	RS-232/422/485	-	-	197 x 125 x 44 mm	-40 to 75°C
NPort 5650I-8-DT-G2	2	8	RS-232/422/485	✓	-	197 x 125 x 44 mm	-10 to 60°C
NPort 5650I-8-DT-G2-T	2	8	RS-232/422/485	✓	-	197 x 125 x 44 mm	-40 to 75°C
NPort 5610-16-DT-J-G2	2	16	RS-232	-	-	197 x 125 x 44 mm	-10 to 60°C
NPort 5610-16-DT-J-G2-T	2	16	RS-232	-	-	197 x 125 x 44 mm	-40 to 75°C
NPort 5650-16-DT-J-G2	2	16	RS-232/422/485	-	-	197 x 125 x 44 mm	-10 to 60°C
NPort 5650-16-DT-J-G2-T	2	16	RS-232/422/485	-	-	197 x 125 x 44 mm	-40 to 75°C
NPort 5610-8-DTS-J-G2	2	8	RS-232	-	-	210 x 95 x 25 mm	-10 to 60°C
NPort 5610-8-DTS-J-G2-T	2	8	RS-232	-	-	210 x 95 x 25 mm	-40 to 75°C
NPort 5650-8-DTS-J-G2	2	8	RS-232/422/485	-	-	210 x 95 x 25 mm	-10 to 60°C
NPort 5650-8-DTS-J-G2-T	2	8	RS-232/422/485	-	-	210 x 95 x 25 mm	-40 to 75°C

Standard Accessories for the NPort 5600-DT-G2

- Quick installation guide (printed)
- 1 wall-mounting kit (WK-44-04)


2. Getting Started

This chapter covers the hardware installation of the NPort 5600-DT-G2. The software installation is covered in the following chapters.

Panel Layout


NPort 5600-8-DT-G2

Unit: mm (inch)




NPort 5600-16-DT-J-G2

Unit: mm (inch)



NPort 5600-8-DTS-J-G2

Unit: mm (inch)



Connecting the Hardware

This section describes how to connect the power supply to the NPort 5600-DT-G2.

Wiring Requirements



ATTENTION

Disconnect the power before installing and wiring

Disconnect the power cord before installing and/or wiring your NPort 5600-DT-G2.

Do not exceed the maximum current for the wiring

Determine the maximum current for each power wire and common wire. Adhere to electrical codes, which dictate the maximum current allowed for each wire size.

If the current exceeds the maximum rating, the wiring could overheat, causing serious damage to your equipment.

Servers may get hot; use caution when handling

Exercise caution when handling the NPort 5600-DT-G2 after it has been plugged in. The internal components generate heat, and the casing may get too hot to touch.

You should also heed the following guidelines:

- Use separate paths to route wiring for power and devices. If power-wiring and device-wiring paths must cross, make sure the wires are perpendicular at the intersection point.



NOTE


Do not run signal or communication wiring and power wiring in the same wire conduit. To avoid interference, wires with different signal characteristics should be routed separately.

- The type of signal transmitted through a wire should determine which wires should be kept separate. The rule of thumb is that wires sharing similar electrical characteristics may be bundled together.
- Keep the input wiring and the output wiring separately.
- It is good practice to label the wiring of all devices in the system.


Powering the NPort 5600-DT-G2

Unbox the device server and power it up by connecting the proper pin assignment of the terminal block on the bottom or rear side of it. The location and the pin assignment of the terminal block on the device server are shown in the following figures:

The bottom side of NPort 5600-DT-G2



The rear side of NPort 5600-DTS-J-G2




V+	V-	
DC Power	DC Power	Chassis GND

When wiring the power input, we suggest a skilled person using copper (Cu) conductors with American Wire Gauge (AWG) 16 to 20 and a torque value of 0.50 N-m as a cable and the corresponding pin-type cable terminals. We recommend stripping the cable to a length of 8 to 9 mm. The wire temperature rating should be at least 85°C. Use copper conductors only. The shielding ground screw (M4) is near the power connector. When you connect the shielding ground wire (min. 16 AWG), the noise is routed from the metal chassis to the ground.

When you are using a DIN-rail power supply, ensure that the ground pin is properly connected. The ground pin must be connected to the chassis ground of the rack or the system.

After powering up the device, the Ready LED should turn red first. After a couple of seconds, the Ready LED should turn green, and you should hear a beep, which shows that the device is ready. For detailed behavior of the LED indicators, see the *LED Indicators* section.



LED Indicators

The LED indicators on the front panel of the NPort 5600-DT-G2 are described in the following table.

LED Name	LED Color	LED Function
Ready	Red	Steady: Power is on, and the NPort 5600-DT-G2 is booting up. Blinking: Showed an IP conflict occurs, or the DHCP server does not respond properly or the device detects the user pushing the reset button.
	Green	Steady: Power is on, and the NPort 5600-DT-G2 is functioning normally. Blinking: The device server has been located by the Device Search Utility.
	Red and Green (Amber)	Steady: After pushing the reset button for over five seconds shows the user can release the button, and the device will restart with default settings.
	Off	Power is off, or a power error occurred.
LAN1, LAN2	Green	Steady: Ethernet cable is connected. Blinking: Shows that traffic is on the Ethernet port.
	Off	Ethernet cable is disconnected.
P1, P2 ... P16	Yellow	The serial port is receiving data.
	Green	The serial port is transmitting data.
	Off	No data is being transmitted or received through the serial port.


When the device is ready, connect an Ethernet cable to the NPort 5600-DT-G2 directly to the computer's Ethernet port or an Ethernet port of a switch.

To connect the serial device to the serial port of the NPort 5600-DT-G2, follow the pin assignment below.

Pin Assignments of the Serial Ports


NPort 5600-8-DT-G2 models (male DB9):

Pin	RS-232	RS-422/4-wire RS-485	2-wire RS-485
1	DCD	TxD-(A)	-
2	RxD	TxD+(B)	-
3	TxD	RxD+(B)	Data+(B)
4	DTR	RxD-(A)	Data-(A)
5	GND	GND	GND
6	DSR	-	-
7	RTS	-	-
8	CTS	-	-
9	-	-	-




NPort 5600-16-DT-J-G2 models (8-pin RJ45):

Pin	RS-232	RS-422/4-wire RS-485	2-wire RS-485
1	DSR	-	-
2	RTS	TxD+(B)	-
3	GND	GND	GND
4	TxD	TxD-(A)	-
5	RxD	RxD+(B)	Data+(B)
6	DCD	RxD-(A)	Data-(A)
7	CTS	-	-
8	DTR	-	-



NPort 5600-8-DTS-J-G2 models (10-pin RJ50):

Pin	RS-232	RS-422/4-wire RS-485	2-wire RS-485
1	-	TxD-(A)	-
2	DSR	RxD-(B)	Data-(A)
3	RTS	-	-
4	CGND	CGND	CGND
5	TxD	TxD+(A)	-
6	RxD	RxD+(B)	Data+(B)
7	SGND	SGND	SGND
8	CTS	-	-
9	DTR	-	-
10	DCD	-	-




The serial cables needed to connect the NPort 5600-DT-G2 Series to a serial device can be purchased separately. Refer to [Appendix A](#).


Mounting Options

The NPort 5600-DT-G2 can be placed flat on a desktop or other horizontal surface, and it also includes a wall-mounting kit in the box, which can be used to mount the NPort to a wall or the inside of a cabinet. You can order a DIN-rail mounting kit (DK-43-01) separately for different placement options, as illustrated in the following diagrams:


Wall Mounting (WK-44-04)



For attaching the device server to a wall, it requires two screws. The requirements of the screws are listed as below:



DIN-rail Mounting (WK-44-04 + DK-43-01)



The mounting kit packages include screws. However, if you prefer to buy your own, refer to the dimensions below:

- Wall-mounting kit screws: FMS M3 x 5 mm
- DIN-rail mounting kit screws: FTS M3 x 6 mm

Connecting to the Network

Connect one end of the Ethernet cable to the NPort 5600-DT-G2's Ethernet port and the other end of the cable to the Ethernet network.

If the cable is properly connected, the NPort 5600-DT-G2 will show a valid connection to the Ethernet:

LED Name	LED Color	LED Function
High speed of the RJ45 connector	Green	Steady on: The 1000 Mbps Ethernet is connected Blinking: The Ethernet packets are being transmitted or received
	Off	The 1000 Mbps Ethernet is disconnected
Low speed of the RJ45 connector	Yellow	Steady on: The 10/100 Mbps Ethernet is connected Blinking: The Ethernet packets are being transmitted or received
	Off	The 10/100 Mbps Ethernet is disconnected

3. First-time Setup

The NPort 5600-DT-G2 device server allows IP access to traditional serial devices (RS-232/422/485). The device server is a small computer with a CPU and TCP/IP protocols that can convert data between serial and Ethernet formats in both directions. With your computer, you can remotely control, manage, and configure facilities and equipment from any location in the world using the Internet.

Traditional SCADA and data collection systems rely on serial ports to collect data from various kinds of instruments. With the NPort 5600-DT-G2, your SCADA and data collection system can access all instruments on a standard TCP/IP network, whether they are used locally or remotely, thanks to its compatibility with RS-232, RS-422, and RS-485 communication ports.


The NPort 5600-DT-G2 is an external network device that adds more serial ports to a host computer as needed. If your host computer is TCP/IP protocol compatible, bus limitations or lack of drivers won't restrict you for a variety of operating systems.

To combat the rising number and complexity of cyberattacks, network device vendors are including protective functions to secure sensitive business and personal information. Thanks to our dedicated efforts, all Moxa products meet the security standard, allowing customers to use them worry-free.

To accomplish this, the services will be disabled until you set up the first username and password for the unit. The unit can only be configured and made functional using a web console (HTTPS) or Moxa service.

Finding the Device

The default IP address of the NPort 5600-DT-G2 Series is <https://192.168.127.254>. Directly input the IP address in the address bar of a browser to open the web console and set up the first username and password. Or download the **Device Search Utility (DSU) v3.0 or later** and search for the device to access its web console.



DSU is a handy tool for easily finding NPort device servers and deploying single or multiple devices. DSU v3.0 functions as a web-based application that works on Chrome, Firefox, and (Microsoft) Edge.

To use the web-based application DSU v3.0 or later, your browser version and operating system must meet certain minimum requirements:


- Chrome:
 - For Windows 7, 8/8.1, Server 2012 and Server 2012 R2: Chrome 109 and later
 - For Windows 10 and later, Server 2016 and later: All Chrome versions
- Firefox:
 - For Windows 7 and later versions, Server 2012 and later versions: All Firefox ESR versions
- Edge:
 - For Windows 7 and later versions, Server 2012 and later versions: All Firefox ESR versions



NOTE


For detailed instructions on how to use **DSU**, download the user manual from moxa.com.

Search Device



When connecting the NPort device server to the network, use DSU's **Search Device** function to find the target NPort device server. Searching can be done in three different ways. To see the options, select the pull-down menu:

Search	Default button action. It will search for the devices through multicasting.
Search by IP	Search the device by a specific IP
Search by IP range	Search the device within a certain IP range; the search results will only display the corresponding IP type. For example, if you search by IPv4, only IPv4 values will be displayed.






It's possible to stop the search at any stage of the process. A **STOP** button appears on top of the table; select it to halt the search and keep the already searched devices on the list.


The default search time is 10 seconds. DSU will continue searching until time runs out. If your device(s) do not appear, you may change the search timeout limit in **Preferences > Device Search > Timeout limit for device searching**, to give the network a bit more time to respond.

First-time Login With Device Search Utility

To address cybersecurity concerns, the NPort device server found through DSU will prompt for an account name and password during the first login.



Select the target device  and select the unlock button . The login window will remind you to set up the account name and password, and it will show the password minimum requirements as tips below the password field.



New Setup

For the first time to unlock the new device, need to setup the account and password.

Account
moxa





New Password

Confirm Password


CANCEL SETUP

Once you have configured the first account and password successfully, the device may restart. After completing a new search, the lock icon will change to **Advance** type:


Please select device(s)

<input type="checkbox"/>	No.		Device Name	Model Name	Lan1 IPv4	Lan1 MAC	Firmw
<input type="checkbox"/>	1		NP5450L_4850	NPort 5450I	192.168.1.222	00:90:E8:9A:E0:BF	3.14
<input type="checkbox"/>	2		NP6150_15012	NPort 6150	192.168.127.254	00:90:E8:61:50:12	2.2
<input type="checkbox"/>	3		NP6250_15731	NPort 6250	192.168.127.254	00:90:E8:7D:8D:AD	2.2.2





An error message will appear at the bottom right of the screen if the unlocking process fails, for example, because of an incorrect password.



Unlock



When selecting one or multiple NPort device servers, use can select the **Unlock** button to unlock them. Because of different product series, there are four types of login permission types:

	Login Permission Type	Definition
	Default	The device has not completed the first-time login process, which requires setting the first account name and password.
	Basic	The device only has password protection; login requires inputting the password only.
	Advance	The device has username and password protection; the login requires inputting both the account name and password.
	Legacy/Unlocked	The device is unlocked, or does not require any protection to log in.


To unlock multiple devices at once, the devices must be of the same model name.



NOTE

The DSU solely facilitates unlocking the device; for account name or password changes, you must access the web console and find the Account Management function.

Assigning IPs



The device(s) need to be unlocked before the **Assign IP** function can be used.

Assign IPv4 (if supported) to the device. Selecting the button will show you all the options under **Assign IP**:

- Assign IPv4

If your device does not support certain options, they will be disabled.

Assigning IPv4

Mode: Static or DHCP

Select the field of **IP Address, Subnet Mask, Default Gateway – opt**, to manually key in the values.

If you have selected multiple devices and a specific IP is not required for each device, you may consider using **ASSIGN IP SEQUENTIALLY** to set up an IP quickly. The function increments the IP address based on the IP value of the first device in the list.

The screenshot shows a web interface titled "Assign IP". At the top left, it says "3 Device(s)". On the right, there is a button labeled "ASSIGN IP SEQUENTIALLY". Below this is a table with the following columns: "No.", "Model Name & Mac", "IP Address", "Subnet Mask", and "Default Gateway - opt.". The table contains three rows of device information. At the bottom right, there are two buttons: "CANCEL" and "ASSIGN & RESTART".

No.	Model Name & Mac	IP Address	Subnet Mask	Default Gateway - opt.
1	NPort 5450I 00:90:E8:9A:E0:BF	192.168.1.222	255.255.255.0	
2	NPort 5210A 00:90:E8:AD:45:6A	192.168.1.223	255.255.255.0	
3	NPort 5210A 00:90:E8:AD:45:10	192.168.1.224	255.255.255.0	


Clone "Network Mask"/"Default Gateway" to All Devices

This is a quick way to copy and paste Netmask or gateway values to all the selected devices. Edit **Subnet Mask** and **Default Gateway—Opt** out of any device first, and find the options in the menu icon at the end of the list and apply:

The screenshot shows the same table as above, but with a context menu open over the second row. The menu has two options: "Clone 'Network Mask' to all devices" and "Clone 'Default Gateway' to all devices". A "START" button is visible at the bottom right of the menu.


No.	Model Name & Mac	IP Address	Subnet Mask	Default Gateway - opt.
1	NPort 5450I 00:90:E8:9A:E0:BF	192.168.1.222	255.255.255.0	
2	NPort 5210A 00:90:E8:AD:45:6A	192.168.127.254	255.255.255.0	


COM Mapping



After setting up the first user account, password, and IP address, and if the software is to communicate with the serial devices, select the **More** functions to find the COM Mapping function for the next step by opening a COM port/TTY port. Refer to [Chapter 4, Mapping COM Ports](#) for more information.


Console



When you want to configure the More Details settings, select the **Console** button  to connect to the HTTPS console of the NPort 5600-DT-G2 Series.

For how to use the web console for configuration, refer to [Chapter 7, Configuration with the Web Console](#)

Locate



You should unlock the device before you can use the **Locate** function.


This is to locate the device by triggering the buzzer to help you find the target device server easily. Selecting the button would show all the options for **Locate**. If your device does not support certain options, they will be disabled:

- Locate (IPv4)
- Locate (IPv6)

First-time Login Process


When you select the Console button at Device Search Utility or input the default IP address, 192.168.127.254, for the first time logging in to the web console of an NPort 5600-DT-G2 Series, there will be a first-time login wizard to guide you to initialize the device for setting up its first administrator and the network settings.

On seeing this page, select the **START** button to start the process.



If you have an existing configuration file of an NPort 5600-DT or NPort 5600-DT-G2, select the file and import it at the first step. Then the NPort 5600-DT-G2 will be configured as the old unit you have, and the wizard will directly jump to step 5 for you to confirm if the settings are correct?

If the user doesn't have an existing configuration file, select **SKIP** to skip this step.



The default IP address of the NPort 5600-DT-G2 Series is 192.168.127.254/255.255.255.0. Based on your network topology, you can change it to DHCP or a different IP address. Select **NEXT** for the next step.

MOXA

1 Import Configuration
Optional

2 **IP Settings**

3 Create Account

4 Confirmation

IP Settings

Configure the IP settings of the device.

IPv4 Address

Get IP from
Manual

IPv4 Address
192.168.127.254

Subnet Mask
255.255.255.0

IPv4 Gateway - Optional

DNS Server

Customize DNS Server

< BACK NEXT >

As there is no default username/password for NPort 5600-DT-G2 devices, set up the first account for this unit. The first user of the device will have full privileges through this account. Keep the account name and password protected. A minimum of eight characters is required for the default password complexity. The Password Policy function in the Account Management category allows you to change it.

MOXA

1 Import Configuration
Optional

2 IP Settings

3 **Create Account**

4 Confirmation

Create Account

Create the first account of the device.

Account Name
admin

Password
.....

Confirm Password
|

The value is required.

< BACK NEXT >


Double-select the network settings at the "Confirmation" step. If everything is okay, select the **SUBMIT** button and the unit will reboot, affecting the above settings.

The screenshot shows the MOXA web interface during the 'Confirmation' step. On the left, a sidebar lists four steps: '1 Import Configuration Optional', 'IP Settings' (checked), 'Create Account' (checked), and '4 Confirmation' (active). The main area is titled 'Confirmation' and asks the user to confirm their initial settings. An 'Info' box states: 'If you imported the configuration file or modified the network settings, the system will restart automatically.' Below this, a box titled 'IP Settings' displays the following configuration: 'Get IPv4 From: Manual', 'IPv4 Address: 192.168.127.254', 'Subnet Mask: 255.255.255.0', 'IPv4 Gateway: --', and 'Customize DNS Server: Disabled'. At the bottom, there is a '< BACK' button and a green 'SUBMIT' button.


Once you complete the initial login, you'll have various next steps to choose from:

1. Read [Chapter 5, Cybersecurity Considerations](#), for the recommendations from Moxa to securely use the NPort 5600-DT-G2 device server.
2. For using Real COM mode, refer to [Chapter 4, Mapping COM Ports](#), for more information.
3. For other operation modes, refer to [Chapter 7, Configuration With Web Console > Operation Modes](#), for more introductions.
4. For other advanced settings, refer to [Chapter 7, Configuration With the Web Console](#), for more details.


1. Select the **Add** icon.



2. Select the **Search** button to search for NPort device servers. Select the server from the list to map the COM ports before selecting **OK**.



3. Alternatively, select **Input Manually** and then manually enter the **NPort IP Address**, first **Data Port**, first **Command Port**, and **Total Ports** to which COM ports will be mapped. Select **OK** to proceed to the next step. Note that the Add NPort page will automatically fill in the IP address field if a fully qualified domain name (FQDN) is used.



NOTE

In **Real COM mode**, the Data Port number and Command Port number are fixed. The Data Port number starts at **950** for NPort serial port 1, **951** for serial port 2, and so on. The Command Port number starts at **966** for serial port 1, **967** for serial port 2, and so on.

For example, if your NPort device has 8 serial ports and you only want to map **ports 3 to 5**, set **Total Ports** to **3**. The first mapped port will have a Data Port number of **952** and a Command Port number of **968**.

If you need to map serial ports **nonsequentially** (e.g., port 3 and port 5), you must add each port **separately**.

4. COM ports and their mappings will appear in blue until they are activated. Activating the COM ports saves the information in the host system registry and makes the COM ports available for use. The host computer will not use the COM port until the COM ports are activated. Select **Yes** to activate the COM ports or **No** to activate the COM ports later.
5. Activated ports will be displayed in black.

No	COM Port	/	Address 1		Address 2
1	COM9		192.168.1.222	950:966 (Port1)	
2	COM10		192.168.1.222	951:967 (Port2)	
3	COM11		192.168.1.222	952:968 (Port3)	
4	COM27		192.168.1.222	953:969 (Port4)	
5	COM28		192.168.1.201	950:966 (Port1)	
6	COM50		192.168.1.201	951:967 (Port2)	
7	COM51		192.168.127.254	950:966 (Port1)	
8	COM52		192.168.127.254	951:967 (Port2)	
9	COM53		00:90:e8:12:fa:42	(Port1)	

Mapping COM Ports on Linux Platforms

Download the Real TTY Linux driver on Moxa website and install it. Remember to check the kernel version that is suitable for your host PC. Before installing it, make sure you've already configured the device server properly:

- The IP address of the device server must comply with the network topology. The default IP address of the NPort 5600-DT-G2 Series is <https://192.168.127.254>. Log in to the device and change its location to the same subnet as the host PC.
- Make sure the Operation Mode is Real COM mode. Once the first administration user is set up, the default Operation Mode is Real COM mode. You may not need to change this. If you have a device server that has been modified by others, it's a good idea to double-check it.

When the IP address and operation mode settings are confirmed:

1. Get the driver file from Moxa's website.
2. Log in to the console of the host PC as a superuser (root).
3. Execute **# cd /** to go to the root directory.
4. Copy the driver file **npreal2xx.tgz** to the / directory.
5. Execute **# tar xvfz npreal2xx.tgz** to extract all files onto the system.
6. Execute **# /tmp/moxa/mxinst**.
For RedHat AS/ES/WS and Fedora Core1, append an extra argument as follows:
/tmp/moxa/mxinst SP1
The shell script will install the driver files automatically.
7. After installing the driver, you will see several files in the **/usr/lib/npreal2/driver** folder:
 - > **mxaddsvr** (Add Server, mapping tty port)
 - > **mxdelsvr** (Delete Server, unmapping tty port)
 - > **mxloadsvr** (Reload Server)
 - > **mxmknod** (Create device node/tty port)
 - > **mxrmnod** (Remove device node/tty port)
 - > **mxuninst** (Remove tty port and driver files)

You are ready to map the NPort serial ports to the system tty port.

Mapping TTY Ports

Logging in as a superuser, enter the directory `/usr/lib/npreal2/driver` and then execute `mxaddsvr` to map the target NPort serial port to the host tty ports. The syntax of the command `mxaddsvr` is as follows:

```
# mxaddsvr [NPort IP Address] [Total Ports] ([Data port] [Cmd port])
```

The `mxaddsvr` command will perform the following actions:

1. Change `npreal2d.cf`.
The `npreal2d.cf` is the configuration file of the driver.
2. Create tty ports in the directory `/dev` with major and minor numbers configured in `npreal2d.cf`.
3. Restart the driver.

To map the tty ports with default settings, execute `mxaddsvr` with the IP address and the number of ports, as in the following example:

```
# cd /usr/lib/npreal2/driver  
# ./mxaddsvr 192.168.3.4 16
```

This example involves adding 16 tty ports, each with IP 192.168.3.4. The data ports will span from 950 to 965, while the command ports will go from 966 to 981.

To map the tty ports with preferred data ports and command ports, execute `mxaddsvr` with the following example:

```
# cd /usr/lib/npreal2/driver  
# ./mxaddsvr 192.168.3.4 16 4001 966
```

This example involves adding 16 tty ports, each with IP 192.168.3.4. The data ports will span from 4001 to 4016, while the command ports will go from 966 to 981.

Removing Mapped TTY Ports

Log in as root, enter the directory `/usr/lib/npreal2/driver` and then execute `mxdelsvr` to delete a server. The syntax of `mxdelsvr` is:

```
mxdelsvr [IP Address]
```

Example:

```
# cd /usr/lib/npreal2/driver  
# ./mxdelsvr 192.168.3.4
```

The following actions are performed when executing `mxdelsvr`:

1. Change `npreal2d.cf`.
2. Remove the relevant tty ports in the directory `/dev`.
3. Restart the driver.

If the IP address is not provided in the command line, the program will list the installed servers and total ports on the screen. Choose a server from the list for deletion.

Removing Linux Driver Files

A utility is included that will remove all driver files, mapped tty ports, and unload the driver. To do this, you only need to enter the directory `/usr/lib/npreal2/driver`, then execute `mxuninst` to uninstall the driver. This program will perform the following actions:

- Unload the driver.
- Delete all files and directories in `/usr/lib/npreal2`
- Delete directory `/usr/lib/npreal2`
- Change the system initializing script file.

Mapping COM Ports on macOS Platforms

To map an NPort 5600-DT-G2 serial port to a Mac host's tty port, follow these instructions:

1. Download the macOS driver from Moxa website and install the Mac driver files on the host.
2. Set up the NPort 5600-DT-G2. Verify the IP configuration works by using ping, Telnet, etc.
3. Search or manually input the IP address of the NPort to set up a virtual COM port.


Installing macOS TTY Driver Files




NOTE

For the newest information, refer to readme.txt on the Mac TTY Driver. Resource location of product information, release notes, and readme file: /usr/local/share/NportConnect.


1. Get the driver file from Moxa's website at <https://www.moxa.com>. It is in the Resource section under the product page.




2. Execute the installer package 'moxa-macOS-tty-drivers-for-macOS-10.12-or-later-v1.0.pkg'.




3. Press **Continue** when the **Introduction** window opens to proceed with the installation.




4. Press **Continue** in the **Destination Select** window.




5. Select **Install** to start the installation in the default directory or select an alternative location.




6. Enter your system login username and password to confirm the authentication.



7. The installation window reports the progress of the installation.



8. Select **Close** to complete the installation of the NPort macOS tty driver.




Mapping macOS TTY Port


1. In the menu bar, an NPortConnect icon will appear after the installation is completed.




2. Select the **NPortConnect** icon and then **NPort Mapping** for the port mapping function.




3. Select **+ Add** to enter the tty port setup.




4. Select **Search** to find the NPort already set up in the **Hardware Setup** procedure. The **Search** function broadcasts a search to locate NPort units on the LAN that are connected to your Mac. The Broadcast Search function searches by MAC address and not by IP address. The location of all NPort units connected to the LAN will be determined, regardless of their subnet. Alternatively, you can manually enter the IP address to locate the specific NPort.




- Once the search is completed, all the NPort found will appear on the list.




- Select the model types that are for the tty port mapping and select **OK**.




- NPortConnect auto-assigns the tty name and corresponding port number to the IP address of the selected NPort.



8. The tty name and port number are editable. Note that these changed values are only for mapping configuration and would not change the values in the NPort settings.



9. When everything is set, select **Apply** to save the configuration.



Uninstalling the macOS Driver

Run the following command to uninstall the driver:

```
$ sudo bash /usr/local/share/NPortConnect/uninstall.sh
```

Mapping COM Ports on UNIX-like Platforms



NOTE

For the newest information, refer to readme.txt on the fixed TTY Driver.

Installing the UNIX Fixed TTY Driver

1. Log in to UNIX and create a directory for the Moxa TTY driver. To create a directory named `/usr/etc`, execute the command:
mkdir -p /usr/etc
2. Copy `moxattyd.tar` to the directory you created. If you created the `/usr/etc` directory above, execute the following commands:
cp moxattyd.tar /usr/etc
cd /usr/etc
3. Extract the source files from the tar file by executing the command:
tar xvf moxattyd.tar
The following files will be extracted:
README.TXT
moxattyd.c --- source code
moxattyd.cf --- an empty configuration file
Makefile --- makefile
VERSION.TXT --- fixed tty driver version
FAQ.TXT
4. Compile and link
 - For SCO UNIX:
make sco
 - For UnixWare 7:
make svr5
 - For UnixWare 2.1.x, SVR4.2:
make svr42

Configuring the UNIX Driver

Change the configuration:

The configuration used by the **moxattyd program** is defined in the text file **moxattyd.cf**, which is in the same directory that contains the program **moxattyd**. Use **vi** or any text editor to change the file:

```
ttyp1 192.168.1.1 950
```

For more configuration information, view the file **moxattyd.cf**, which contains detailed descriptions of the various configuration parameters.



NOTE

The "Device Name" depends on the OS. See the Device Naming Rule section in README.TXT for more information.

To start the **moxattyd** daemon after system bootup, add an entry into **/etc/inittab**, with the tty name you configured in **moxattyd.cf**, as in the following example:

```
ts:2:respawn:/usr/etc/moxattyd/moxattyd -t 1
```

Device naming rule

For UnixWare 7, UnixWare 2.1.x, and SVR4.2, use:

```
pts/[n]
```

For all other UNIX operating systems, use:

```
ttyp[n]
```

Starting moxattyd

Execute the command **init q** or reboot your UNIX operating system.

Adding an additional server

1. Change the text file **moxattyd.cf** to add an additional server. Use **vi** or any text editor to change the file. For more configuration information, refer to the file **moxattyd.cf**, which contains detailed descriptions of the various configuration parameters.
2. Find the process ID (PID) of the program **moxattyd**.

```
# ps -ef | grep moxattyd
```
3. Update the configuration of **moxattyd** program.

```
# kill -USR1 [PID]
```

(e.g., if **moxattyd** PID = 404, **kill -USR1 404**)

This completes adding an additional server.

5. Cybersecurity Considerations

As cyberattacks increase and become more sophisticated, network device vendors are incorporating features to safeguard sensitive information. Moxa has made it a priority to develop measures that ensure all products meet security standards, so that you can use them with peace of mind. There are certain details that Moxa cannot do alone; you and Moxa need to work together to build up a much-secured environment to defend against all kinds of cyberthreats. This chapter introduces the essential steps to enhance the cybersecurity of Moxa's products. You may need to refer to other sections in the user manual for the exact settings or commands.

Updating Firmware

Customers who buy products from Moxa or a reseller should be aware that Moxa might have already launched a later firmware version with enhanced security features. Check Moxa's support website to see if there is a later version of firmware. If so, we recommend upgrading the firmware to the newest version .

Turn Off Unused Service and Ports

Imagine living in a house that has many entrances. If all the doors and windows are left unlocked or even open, it sends a message of welcome to intruders out there. We always recommend turning off services and ports that are not in use to reduce the chances of being attacked.

Refer to the table below for all the ports, protocols and services that are provided to communicate between the NPort 5600-DT-G2 Series and other devices.

Service Name	Option	Default Settings	Type	Port Number	Description
Moxa services	Enable/Disable	Enable	TCP UDP	443	For Moxa utility communication
DNS_wins	Enable	Enable	UDP	53, 137, 949	Processing DNS and WINS (client) data
SNMP agent	Enable/Disable	Disable	UDP	161	SNMP handling routine
HTTPS server	Enable/Disable	Enable	TCP	443	Secured web console
DHCP client	Enable/Disable	Disable	UDP	68	The DHCP client needs to get the system IP address from the DHCP server
SNTP	Enable/Disable	Disable	UDP	Random port	Synchronize the time settings with a time server

Operation Mode	Option	Default Settings	Type	Port Number
Real COM mode	Enable/Disable	Disable (Changed to Enable after user set username/password)	TCP	949 + (serial port number) 965 + (serial port number)
RFC2217 mode	Enable/Disable	Disable	TCP	4000 + (serial port number)
TCP Server mode	Enable/Disable	Disable	TCP	4000 + (serial port number) 965 + (serial port number)
UDP mode	Enable/Disable	Disable	UDP	4000 + (serial port number)
Pair Connection Server mode	Enable/Disable	Disable	TCP	4000 + (serial port number)
Disable mode	Enable/Disable	Disable	N/A	N/A

Turn On Services That Are Necessary

Some services are recommended to be enabled because they are key functions of the NPort 5600-DT-G2, and they face cybersecurity threats. Encryption protects the communication of these services on the Ethernet network.

- **Web console (HTTPS):** This is the main management console of the NPort 5600-DT-G2 for configuring all the settings, and it also provides some diagnostic tools for an engineer to troubleshoot a problem.
- **SNMPv3:** The Simple Network Management Protocol is a popular tool for remote device monitoring and management. Enable SNMPv3 to encrypt communication data if needed.
- **Moxa services (HTTPS):** The Device Search Utility v3.0 is a good tool for first-time installation on the NPort 5600-DT-G2 Series, and Moxa MXview can easily monitor all the NPorts in a network. All these tools work with Moxa services.




NOTE

If all the HTTPS/Moxa services/Serial consoles are turned off, then there is no other route to access the product. The only way to recover it is to reset the device and start from the beginning. For guidance on resetting the device, refer to the user manual.

Limited IP Access

Limiting the number of IP addresses that can access the product is one of the most effective ways of blocking unwanted intruders. If the product is accessed by a limited number of desktop/notebook/mobile devices, provide access to those IPs.

The NPort 5600-DT-G2 has the Allowlist function to grant an IP address or a range of devices access to the device server. You can **ADD RULE** for those granted IP addresses and then enable the allowlist function to limit access to the specific NPort 5600-DT-G2 only to those IP addresses.



Account and Password

- There is no default username or password for NPort 5600-DT-G2 devices. You may need to follow up the first-time login process to set the username and password for the first user (who will also be the admin user) of this device to enhance the device's security.
- Use strong passwords. The devices support a function called **Password Policy** to check if passwords are strong enough. Enable the function to help you check whether passwords are strong enough.
- Use the account login failure lockout feature to prevent unwelcome access (**Security > Login Settings > Login Lockout**).

System Log


The system log usually records all kinds of activities that are happening on your NPort, such as Login Fail, IP Changed, Password Changed, Config Changed, etc. Check the log regularly to examine any abnormal behavior.

The events will be recorded in the format defined by RFC3164 to read/analyze. Refer to **System Settings > Notifications > Channels Settings** for more information.

Deployment of the Device

Deploy the NPort 5600-DT-G2 Series behind a secure firewall network that has sufficient security features in place to ensure that networks are safe from internal and external threats.

Make sure that the physical protection of the NPort devices and/or the system meets the security needs of your application. Depending on the environment and the threat situation, the form of protection can vary significantly.



Testing the Security Environment

Besides the devices that support these protective functions, network managers can follow several recommendations to protect their networks and devices.

To prevent unauthorized access to a device, follow these recommendations:

- Testing tools for cybersecurity environment checks are available. Some may provide limited free use, for example, Nessus. These tools help identify probable security leaks in the environment.
- The device should be operated inside a secure network, protected by a firewall or router that blocks attacks via the Internet.
- Control access to the serial console as with any physical access to the device.
- Avoid using insecure services such as SNMPv1 or v2; the best way is to disable them completely.
- Limit the number of simultaneous web server sessions allowed. Periodically, change the passwords.
- Back up the configuration files periodically and check the CRC value of the runtime settings to make sure the devices work properly.
- Audit the devices periodically to ensure they comply with these recommendations and/or any internal security policies.
- If there is a need to return the unit to Moxa, make sure that you have already backed up the current configuration before returning it.



NOTE

DISCLAIMER: Note that the above information and guide (the "information") are for your reference only. We do not guarantee a cyberthreat-free environment. These guidelines are intended to increase the security level to defend against cyberintrusions and do not guarantee that the above information will meet your specific requirements. The above information is provided "as-is", and we make no warranties, express, implied or otherwise, regarding its accuracy, completeness, or performance.

6. Management Consoles

If you' are looking to open COM port applications, you can follow the steps in the **First-time Setup** and **Mapping COM Port** chapters to complete the basic settings. The NPort 5600-DT-G2 will work properly at the actual site. If you want to configure more advanced settings, like **Security** or **Account Management**, access the device with the different management consoles introduced in this chapter.

If you use other applications, finish the account and IP settings during the first-time setup process. There are more settings waiting for you. Access the device through the different management consoles introduced in this chapter to complete the configuration.

Configuration Options

Device Search Utility

Configure your NPort 5600-DT-G2 with the bundled Device Search Utility (DSU) v3.0 and above for Windows. When you find the NPort 5600-DT-G2 with the default IP address 192.168.127.254 on DSU, set the username and password for the first user (it will also be the admin user) of this device to enhance the device security. Then **right-select** on the device to change the IP address for your network. Or you can **double-select** on the device to directly open the Web console of the device for configuration.

Web Console


Configure your NPort 5600-DT-G2 using a standard web browser. We recommend using the web console as the device's default management interface. Besides special reasons, we suggest keeping it enabled—not only for the first-time installation but also for maintenance and troubleshooting.

Serial Console


The NPort 5600-DT-G2 supports the serial console as the local access point through serial port 1. The serial console port only supports basic settings, like network settings to change the IP address, or when the Ethernet LAN port cannot be logged into.

The following instructions and screenshots show how to enter the serial console using PComm Terminal Emulator, which is available free as part of the PComm Lite suite. You may use a different terminal emulator utility, although your actual screens and procedures may vary slightly from the following instructions.


1. Turn off the power to the NPort 5600-DT-G2. Use a serial cable to connect the NPort 5600-DT-G2's serial console port to your computer's male RS-232 serial port.
2. From the Windows desktop, select **Start > All Programs > PComm Lite > Terminal Emulator**.
3. The PComm Terminal Emulator window will appear. From the Port Manager menu, select **Open**, or simply select the **Open** icon as shown below:



- The Property window opens automatically. Select the **Communication Parameter** tab; then, select the appropriate COM port for the connection (COM1 in this example). Configure the parameters for **19200**, **8**, **None**, **1** (**19200** for Baud Rate, **8** for Data Bits, **None** for Parity, and **1** for Stop Bits).



- From the Property window's Terminal page, select **ANSI** or **VT100** for **Terminal Type** and select **OK**.
- Hold down the grave accent key (`) while powering it up, as shown below. Note that the grave accent key (sometimes called a backwards apostrophe) is NOT the apostrophe key—it is the key usually found next to the number **1** key.



The NPort 5600-DT-G2 will then automatically switch from data mode to console mode.

- When you see the "Login:" message, enter the username and password. You will be prompted to command-line mode.



- The serial console is a command-line interface. You may need to input commands to view or change the settings. Find the [Appendix F Command List of the Serial Console](#) section for more details.

7. Configuration with the Web Console

To configure the NPort 5600-DT-G2, the web console is the easiest method to use. With a standard web browser, you can effortlessly navigate through all settings and options. Once you've completed the **First-time Setup** or used DSU-G2 to configure a new IP address for an NPort 5600-DT-G2, enter the new IP address to access the web console. This chapter covers the introduction of the web console and explores its configuration options.

Factory Default IP Address

The NPort 5600-DT-G2 is configured with the following default private IP address:

192.168.127.254

Note that IP addresses that begin with "192.168" are referred to as private IP addresses. Devices configured with a private IP address are not directly accessible from a public network. For example, you cannot ping a device with a private IP address from an outside Internet connection.

Using Your Web Browser

Opening the Web Console

Open your web browser and enter the IP address you've changed in the website address line. Press **ENTER** to load the page.



You may find the "Not secure" icon on the website address line. Select it to add the NPort as a trusted device to remove the icon. For more information, refer to the **Security Hardening Guide**. Enter the account name and password you've set to access the device.




ATTENTION


With a forgotten password, the reset button must configure the NPort 5600-DT-G2 by resetting all settings and loading the factory defaults. Even if you disabled the reset button in your NPort 5600-DT-G2 configuration, you can still use it to restore factory defaults within the first minute of powering on the NPort 5600-DT-G2.

Remember to back up your configuration by exporting it to a file. Importing the file to the NPort 5600-DT-G2 will quickly restore your configuration. This will save time if you have forgotten the password and need to reload the factory defaults.


The NPort 5600-DT-G2's web console will appear after logging in, and you may receive the message history, including the **Login Message** (can be configured at **Security > Login Settings > Login Message**) and account login history.





Select the **CLOSE** button, and the Dashboard page will be displayed.



The Header shows who is logged in to the device. Select an account to change your password or log out of the web console.



Select the  icon to hide or show the Navigation Panel.



How many categories you may see on the navigation panel depends on the privilege of the user group you belong to. The administrators will see all of them as in the snapshot above.

Web Console Navigation

On the NPort 5600-DT-G2 web console, the left panel is the navigation panel and contains an expandable menu tree for navigating among the various settings and categories. When you select a menu item in the navigation panel, the main window will display the corresponding options for that item. Configuration changes can then be made in the main window.

Changes will take effect immediately except for the network-related settings. If users add or remove devices after the NPort is online, they would want the new settings to immediately take effect without needing to reboot the device. Support for this function is provided by the NPort 5600-DT-G2 Series.


The IP address change for the NPort 5600-DT-G2 is a separate issue. It may require notifying all network devices and updating their tables. To make the NPort 5600-DT-G2 work after changing its IP address, a reboot is necessary.

Dashboard Introduction

Home > Dashboard

Dashboard

Device Information



Model Name NPort-5650-16-DT-J-G2
Device Name NPort-5650-16-DT-J-G2_0029
Description --
Serial Number TAAAAA000029
Firmware Version v1.0.0 Build 26031205

System Operations

Time
System Time 2026-04-16T16:19:33
Uptime 0 day 00h:25m:57s

System State
CPU Usage 20%
Memory Usage 6%

Network Operations

LAN1 ✔ 1000MB FD
LAN2 🔗 Link down
MAC Address 00:90:E8:56:50:80
IPv4 Address 192.168.127.254/24

System Log

Top 5 critical events within the past 30 days VIEW MORE >

Severity	Category	Event Name	Timestamp
No critical events recently.			

Operation Mode State

VIEW MORE >

Port	Operation Mode	Connection Status	Serial Parameters	Serial Errors (Count)
1	Real COM	🔗 Disconnected	RS-232, 19200, None, 8, 1	0

When you access the web console of an NPort 5600-DT-G2 device, it will take you to the Dashboard page to give you an overview of the unit's status. There are five sections:

Device Information: This section displays the basic/general information of the unit, including the Model Name, Serial Number, MAC address, and firmware version.

System Operations: This section displays unique information about the unit, like when the device is powered up, the CPU, and memory usage.

Network Operations: This section shows the network status of the unit. For example, the IP address and the Ethernet LAN speed.


System Log: You can check whether any critical events have happened since you last logged in to the device. It will remind you of any abnormal events that happened.

Operation Mode State: The key function of an NPort 5600-DT-G2 device is to provide communication between serial port(s) and the Ethernet LAN port(s). You will find the operation mode of each serial port in this section, and you can check the status here to see if it works properly.

System Settings

The first category on the navigation panel is System Settings, which includes three parts. The General page has the Identity and Date & Time settings of the device. The Notification page has system events, emails, and SNMP Trap/Inform settings. The SNMP Agent has the SNMP Agent settings, which will be needed if you want to get information or settings from the NPort 5600-DT-G2 device via the SNMP protocol.


General



Under the General page, the Identity tab provides the Device Name and Description columns for you to identify which unit the NPort 5600-DT-G2 is using.

Device Name: This is an optional free-text field for your own use. It does not affect the operation of the NPort 5600-DT-G2. It will be set as the model name of the device and the last four digits of the serial number. It helps differentiate one NPort 5600-DT-G2 server from another.

Description: This is an optional free-text field for your own use. It does not affect the operation of the NPort 5600-DT-G2. It is useful for assigning or describing the location of an NPort 5600-DT-G2. In a network environment with multiple servers, this can be a valuable aid when performing maintenance.



The NPort 5600-DT-G2 has a built-in real-time clock for time calibration functions. To change the time, switch to the Date & Time tab. Select the **EDIT** button to change the current date and time and the time zone.

Edit Date And Time

Mode
 Manual Sync with NTP server

Date
 07/22/2024

Hour : Minute : Second
 11 : 17 : 29

CANCEL SAVE

The NPort 5600-DT-G2 uses SNTP (RFC-1769) for auto time calibration. Enter a time server IP address or domain name in this optional field. Once the correct time server address is set, the NPort 5600-DT-G2 will regularly request time information from the time server every 10 minutes.

Edit Date And Time

Mode
 Manual Sync with NTP server

Interval (min)
 1440

Time Server

CANCEL SAVE

To change the time zone, select the **EDIT** button and select the location of the device. It will adjust the time zone automatically.

Edit Time Zone

Time Zone
 (GMT+08:00) Taipei

Enable daylight saving time by recurring

CANCEL SAVE

If daylight saving time applies in the summer, enable the checkbox **Enable daylight saving time by recurring**.

Enable daylight saving time by recurring

Offset (hour)
 1

Start/End Date

From
 Month: Jan, Week: First, Day: Sun, Hour: 0

To
 Month: Jan, Week: First, Day: Sun, Hour: 0

CANCEL SAVE

Daylight saving time (also known as **DST** or **summertime** involves advancing clocks (usually one hour) during the summer to provide an extra hour of daylight in the afternoon.

Offset

Setting	Description	Factory Default
User adjustable hour	The clock should be set forward by the number of hours specified in the offset parameter.	1

Start Date

Setting	Description	Factory Default
User adjustable date	The Start Date parameter allows users to enter the date on which daylight saving time begins.	The Sunday of the first week of January

End Date

Setting	Description	Factory Default
User adjustable date	The End Date parameter allows users to enter the date that daylight saving time ends.	The Sunday of the first week of January



ATTENTION

The risk of an explosion if the real-time clock battery is replaced with the wrong type!

A lithium battery powers the NPort 5600-DT-G2's real-time clock. We strongly recommend that you do not attempt replacement of the lithium battery without help from a qualified Moxa support engineer. If you need to change the battery, contact the Moxa RMA service team.

Notification

Notification settings allow you to customize events that are logged by the NPort 5600-DT-G2. Events are grouped into five categories, known as event groups. Select which groups or events you want to log on the NPort 5600-DT-G2 local database. An email or SNMP Trap/Inform can also notify the administrator immediately of some events.

By default, the NPort will enable the event severity as Notice, Warning, and Error under the Security category and save them on the local flash memory. For the local log settings, find the diagnostics section.

Local Log	Keep the log in the flash of NPort 5600-DT-G2 up to 10,000 items.
-----------	---

The Categories of Notifications

Category	Description
System	The events related to the NPort itself, like firmware ready.
Network	The events related to the Ethernet interface, for example, the Ethernet link up.
Security	In the event that may be considered security related; the administrator may need to figure out why it happened. For example, a login fail event.
Maintenance	The events that usually happen during a maintenance process, for example, a firmware upgrade.
Serial	The events related to the serial interface(s), for example, port connect.

The Severity of Events

Based on RFC5424, the severity of different events is categorized according to the following priority and description.

Priority	Severity	Description
1	Error	Events that indicate problems, but in a category that does not require immediate attention.
2	Warning	Events that provide forewarning of potential problems indicate that some further action could result in a critical error.
3	Notice	Events that are not error conditions, but that may require special handling.
4	Informational	Confirmation that the program works as expected.

The logs are essential for troubleshooting in the case of errors. Refer to [Appendix E](#) for a detailed event list.

Event Settings

Home > System Settings > Notification > Events Settings

← Events Settings

Get notified by selecting the events and channels. Events can be sorted by various levels of severity. [Refer to the specifics of the severity.](#)

Severity: Error Warning Notice Informational SEARCH

System (4) Network (5) Security (9) Maintenance (3) Serial (4)

Severity	Event Name	<input type="checkbox"/> Email	<input type="checkbox"/> SNMP Trap/Inform
Notice	User trigger reboot	<input type="checkbox"/>	<input type="checkbox"/>
Warning	NTP fail	<input type="checkbox"/>	<input type="checkbox"/>
Notice	Email service is back	<input type="checkbox"/>	<input type="checkbox"/>
Notice	SNMP inform service is back	<input type="checkbox"/>	<input type="checkbox"/>

When selecting the **EDIT** button in the **Events Settings** column, you will see the event list, separated into different categories. Select the checkbox to enable the event for Email or SNMP Trap/Inform. Only the enabled events will be recorded or trigger an email or SNMP Trap/Inform.

System (4) Network (5) Security (9) Maintenance (3) Serial (4)

Severity	Event Name	<input checked="" type="checkbox"/> Email	<input checked="" type="checkbox"/> SNMP Trap/Inform
Notice	User trigger reboot	<input type="checkbox"/>	<input type="checkbox"/>
Warning	NTP fail	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Notice	Email service is back	<input type="checkbox"/>	<input type="checkbox"/>
Notice	SNMP inform service is back	<input type="checkbox"/>	<input type="checkbox"/>

Channels Settings

Once you choose which events to record, set up whether the device shall notify the administrator on email or SNMP Trap/Inform for immediate notification.

Email

Select the **EDIT** button in the Email column. Enable the SMTP service so that the NPort will send an email if the selected events occur.

Server Settings


Setting	Description	Factory Default
Server Address	The IP address or domain name of the SMTP server.	N/A
TCP port	The TCP port at which the SMTP server receives SMTP messages.	25

If the SMTP server requires a secure connection (encrypting the email), select **Enable secure connection**. There are three options.

Setting	Description	Factory Default
TLS	Encrypts the entire communication channel between the client and the server from the beginning, ensuring that all data transmitted is secure.	N/A
STARTTLS	It is possible to start the connection in plain text and then switch to encrypted mode through STARTTLS. If the upgrade fails, the communication remains in plain text.	N/A
STARTTLS-None	No encryption. STARTTLS-None as an option helps system administrators clearly specify which connections should remain unencrypted.	N/A

Enable authentication

Username

Password 


If the SMTP server requires authentication verification, select **Enable authentication**, and input the username and password used to log into the SMTP server.

Setting	Description	Factory Default
Username	The name used to log into the SMTP server.	N/A
Password	The password is used to log into the SMTP server.	N/A

Contact Information

Setting	Description	Factory Default
Sender Email (From)	The email address that the NPort will use to send the message. The user can easily figure out which NPort sends the message through this account.	N/A
Recipient Email 1 (To)	The email address to which the NPort will send the message. It shall be the administrator/manager of the NPort who manages/monitors the status of the NPort or the serial device connected to the NPort. There are at most four recipient emails.	N/A

SNMP Trap/Inform



Select the **EDIT** button in the SNMP Trap/Inform column and select **ADD SERVER**. Set the server settings and the SNMP settings.

Server Settings

Setting	Description	Factory Default
Server Address	The IP address or domain name of the SNMP server.	N/A
UDP port	The UDP port at which the SNMP server receives SMTP messages.	162

SNMP Settings

Add Server

Server Settings **SNMP Settings**

SNMP Type
-- Select One --

SNMP Version
-- Select One--

CANCEL **SAVE**

SNMP Type	Description	Retry (Count)	Timeout (sec)	SNMP version
Trap	The NPort will send SNMP Trap and will not wait for acknowledgment	N/A	N/A	v1/v2c/v3
Inform	After sending an SNMP Inform, the NPort waits for an acknowledgment. The NPort will resend the Inform message until it gets confirmation or times out.	Number of retries Default=3	The duration before a timeout occurs Default=5	v2c/v3

SNMP Inform messages require acknowledgement of notifications. If you choose SNMP Inform as the SNMP type, you might have to specify the number of retries the NPort should attempt if it doesn't receive acknowledgments. Also, determine the time interval for the NPort to wait before sending the SNMP Inform message.

Server Settings **SNMP Settings**


SNMP Type
Inform

Retry (count)
3

Timeout (sec)
5

SNMP Agent

Simple Network Management Protocol (SNMP) is a widely used protocol/tool for network administrators to manage and monitor network devices. To meet this requirement, the NPort 5600-DT-G2 Series supports SNMPv1/v2c/v3 and includes a private MIB for device management and status monitoring of Ethernet or serial communication. For such purposes, enable the SNMP Agent service here (**System Settings > SNMP Agent**) and configure the proper settings introduced in the following sections.



Select the **EDIT** button under the General column. Select the SNMP version and set the device details.

Setting	Description	Factory Default
SNMP Version	Select the SNMP version. Use only SNMP v3/Use only v1, v2c/Use v1, v2c, and v3.	v3
Contact - Optional	This field usually includes an emergency contact name and telephone or pager number.	N/A
Location - Optional	Use this field to specify the location string for SNMP agents such as the NPort 5600-DT-G2. This string is usually set to the street address where the NPort 5600-DT-G2 is physically located.	N/A

When using SNMP v3, you need to create a V3 Account first. Select the **CREATE** button in the V3 Account column.

Create Account [X]

Account Name

Authority
Read Only

Enable account authentication

Authentication Type
-- Select One --

Authentication Password

Enable account privacy

Privacy Type
-- Select One --

CANCEL SAVE

Account Name: Use this field to identify the username for the specified level of access.

Authority: Select authentication parameters for two levels of access: Read Only(default) and Read/Write.

When enabling account authentication, select the authentication type and input the authentication password.

Authentication Type: Use this field to select MD5 or SHA as the method of password encryption.

Authentication Password: Use this field to set the password.

Privacy Type: Use this field to enable DES_CBC or AES_128 data encryption when you enable account privacy.

V3 Account V3 Account Protection

To enhance the security of the v3 accounts, set the minimum password length for authentication and privacy passwords.

Min. Password Length
8

To prevent hackers from repeatedly logging into your account to crack passwords, you can enable v3 account protection and configure the settings accordingly.

Enable v3 account protection

Max. Authentication Failure Retry(times)
5

Enable reset login failure counter
The login failure counter will reset and be recalculated according to your designated reset period.

Reset Period(min)
10

Lockout Time (min)
5

SAVE


Select the V3 Account Protection to set the minimum password length for authentication and privacy passwords. Enabling v3 account protection can set the maximum authentication failure times and lockout time. Additionally, you can enable the reset login failure counter to automatically reset and recalculate it within your designated reset period.

Network Settings

The second category on the Navigation Panel is Network Settings, which also includes three parts. The IP Address page is where you assign the NPort 5600-DT-G2 IP address, netmask, gateway, and other IP parameters. The Routing Table page allows you to configure the NPort 5600-DT-G2's connection to an external network. The Hosts & WINS page can make entering IP addresses on the NPort 5600-DT-G2 console easier by assigning a Host Name to an IP Address.

IP Address


A network device will need an IP address to communicate with other network devices. The IP address should have already been set up during the first-time login process. When accessing the Network Settings category, you may want to configure the advanced settings or change the existing IP address.



The screenshot shows a web interface for configuring the IP address. At the top, there is a breadcrumb trail: Home > Network Settings > IP Address. The main heading is "IP Address". Underneath, there is a section for "IPv4 Address". A dropdown menu labeled "Get IP from" is set to "Manual". Below this, there are three input fields: "IPv4 Address" with the value "192.168.127.254", "Subnet Mask" with the value "255.255.255.0", and "IPv4 Gateway - Optional" which is currently empty. Below the IP configuration fields, there is a "DNS Server" section with a checkbox labeled "Customize DNS Server" which is unchecked. At the bottom of the form is a green "SAVE" button.

IPv4 Address

Get IP from: DHCP or Manual. If there is a DHCP server on the network that assigns the IP address automatically, then select **DHCP**. If not, select **Manual** and input the IPv4 address, subnet mask, and IPv4 gateway.



IPv4 Address

DHCP

Manual

IPv4 Address

192.168.127.254

Subnet Mask

255.255.255.0

IPv4 Gateway - Optional

DNS Server

Customize DNS Server


SAVE

IPv4 Address (default=192.168.127.254): Enter the IP address that will be assigned to your NPort 5600-DT-G2. All ports on the NPort 5600-DT-G2 will share this IP address. An IP address is a number assigned to a network device (such as a computer) as a permanent address on the network. Computers use IP addresses to identify and talk to each other over the network. Choose a proper IP address that is unique and valid in your network environment.

Subnet Mask (default=255.255.255.0): Enter the subnet mask. A subnet mask represents all the network hosts at one geographic location, in one building, or on the same local area network. When a packet is sent out over the network, the NPort 5600-DT-G2 will use the subnet mask to check if the desired TCP/IP host specified in the packet is on the local network segment. If the address is on the same network segment as the NPort 5600-DT-G2, the NPort 5600-DT-G2 establishes a connection directly. Otherwise, the connection is established through the default gateway.

IPv4 Gateway: Enter the IP address of the gateway, if applicable. A gateway is a network computer or device that acts as an entrance to another network. Usually, the devices that control traffic within the network or at the local Internet service provider are gateway nodes. The NPort 5600-DT-G2 needs to know the IP address of the default gateway device to communicate with hosts outside the local network environment. For the correct gateway IP address information, consult the network administrator.

DNS Server



DNS Server

Customize DNS server

DNS Server 1

DNS Server 2 - optional

Domain Name System (DNS) is responsible for translating internet domain names into IP addresses. A domain name is an alphanumeric name, such as `www.moxa.com`, which is easier to remember than the numerical IP address. A DNS server is a host that translates this kind of text-based domain name into the actual IP address used to establish a TCP/IP connection. When a user wishes to access a specific website, their computer sends the domain name (e.g., `moxa.com`) to a DNS server to obtain the website's IP address. The user's computer connects to the website's web server using the IP address obtained from the DNS server.

The NPort 5600-DT-G2 acts as a DNS client, actively querying the DNS server for domain name IP addresses. The following functions on the NPort 5600-DT-G2 web console support the use of domain names in place of IP addresses: Time Server, Destination IP Address (in TCP Client mode), Mail Server, SNMP Trap Server, Destination Address (in Pair Connection mode), Primary/Secondary Host Address (in Terminal mode), RADIUS Server, TACACS+ Server and SMTP Server.

DNS server 1: Choose Customize DNS server to enter the DNS server's IP address in this field. This allows the NPort 5600-DT-G2 to use domain names instead of IP addresses to access hosts.

DNS server 2: This is an optional field. The IP address of another DNS server can be entered in this field if DNS server 1 is unavailable.

Port Speed

If the switch or router that connects to the Ethernet port of the NPort is a legacy device that only supports 10Mbps or 100Mbps, you may want to modify the port speed that the NPort will support.

Ethernet Port	Type	Speed Mode
LAN1	1000 BASE-T	Auto-negotiation
LAN2	1000 BASE-T	Auto-negotiation

When selecting the pencil icon to modify the settings of the Ethernet port, there are five choices:

1. Auto-negotiation: the NPort and the switch will automatically negotiate at the highest speed that both devices support.
2. 100 Mbps full-duplex: the NPort will set itself to only support 100 Mbps full-duplex to negotiate with the switch for communication.
3. 10 Mbps full-duplex: the NPort will set itself to only support 10 Mbps full-duplex to negotiate with the switch for communication.
4. 100 Mbps half-duplex: the NPort will set itself to only support 100 Mbps half-duplex to negotiate with the switch for communication.
5. 10 Mbps half-duplex: the NPort will set itself to only support 10 Mbps half-duplex to negotiate with the switch for communication.

Routing Table

If the NPort encounters an unknown IP address, it will check the routing table to determine the network interface for sending the Ethernet packets. This is how network devices collaborate to ensure all Ethernet packets reach the target device. The routing table in the NPort contains information about network routes and their associated metrics, for example, distances. The **routing table** also provides information about the immediate network topology. You can configure the network connection for the NPort 5600-DT-G2 to an external network. Edit the route settings and view the current routing status on this page.

Destination	Subnet Mask	Gateway	Source Protocol	Flags	Metrics	Use	Interface
Refresh every 10 seconds ...							

To edit route settings, select the **EDIT** button.

Route Settings-Static



Home > Network Settings > Routing Table > Route Settings


← Route Settings

CREATE

No	Destination	Subnet Mask	Gateway	Metric	Interface
No data to display.					

On the static page, select the **CREAT** button to create a routing entry. You must provide information on the Destination, Subnet Mask, Gateway, Metric, and Interface.

Create Routing Entry



Create Routing Entry

Destination

Subnet Mask

Gateway

Metric
10

Interface
-- Select One --

CANCEL SAVE

Destination: This is the target device's IP address of the route's destination.

Subnet Mask: This is the destination network's netmask.

Gateway: This is the IP address of the next-hop router.

Metric: You may use this optional field to enter the number of hops from the source to the destination. This allows the NPort 5600-DT-G2 to prioritize the routing of data packets if more than one router is available.

Interface: This is the network interface to which the packet must be sent. Select Ethernet.


Serial Port Settings

The third section of the Navigation Panel is Serial Port Settings, which is grouped into three categories: Operation Modes, Serial Parameters, and Secure Connection. To configure the operation mode and settings for a port, expand Serial Port Configurations in the navigation panel; then, expand the category to configure.


Operation Modes

NPort 5600-DT-G2 Series provides the capability to transfer data from serial-to-Ethernet and vice versa. The setting of the Operation Modes sets the way the data was packaged or how it is delivered on the Ethernet network. There are five popular applications: COM-based Control, Socket, Pair Connection, Connect Console, and Connect Modem Application. They will be introduced one-by-one in the following sections.

- **COM-based Control:** For software using a COM port (Windows) or TTY port (Linux) to communicate with the serial device.
- **Socket:** For socket programs that communicate with NPort with an IP address and TCP/UDP port.
- **Pair Connection:** To extend communication distance without changes to the host PC/HMI and serial device. This requires two NPort devices.



Select **Operation Modes** in the navigation panel to configure the mode for each serial port. For NPort 5600-DT-G2 models with two or more serial ports, use the checkboxes of the port to apply the settings to one or more ports. Then, select the **CONFIGURE** button.



An Operation Mode Wizard guides settings completion. Select the application and operation mode as the first step. The next step involves configuring the basic settings for various scenarios. Set the advanced settings for a few scenarios during the third step. During the last step, go over the settings mentioned earlier. If they're okay, confirm them, and these settings will be activated immediately.

Application: Select an application for the serial port from among the choices. Your application will determine the modes that are available.


Operation Mode: Once you have chosen an application, select the operation mode. The configuration settings will vary depending on the mode that you have selected.

Application	Operation Mode	Description
No Operation	N/A	To decrease the risk of cyberattacks, select "No Operation" to disable the relative service if there are no serial devices connected to a specific port.
COM-based Control	Real COM mode	Installs the Moxa driver to simulate a real COM port over the network.
	RFC2217 mode	Installs a third-party driver to simulate a real COM port over the network.
Socket	TCP Server mode	Your application establishes a TCP connection to the NPort, providing access to connected serial devices.
	TCP Client mode	Your application listens to TCP connections from the NPort, providing access to connected serial devices.
	UDP mode	Your application sends and receives UDP packets to establish communication with connected serial devices.
Pair Connection	Pair Connection Client mode	Connects to another NPort to enable two serial devices to communicate with each other.
	Pair Connection Server mode	Accepts a connected NPort to enable two serial devices to communicate with each other.

COM-based Control Applications


The COM-based control application requires the installation of a Moxa or third-party driver to open a COM port (on Windows platform) or a TTY port (on a Linux/UNIX-like platform) to start communication with the remote serial devices. To keep the legacy software on Windows or Linux/UNIX-like platforms the same, Moxa provides the drivers on different operating systems. Download them from Moxa website and refer to [Chapter 4, Mapping COM Ports](#), on how to use them.

Real COM Mode



Step 1: Mode Selection

Based on the scenario, select the application COM-based Control and Operation Mode Real COM. Then, select the **NEXT** button to proceed to the next step.




Step 2: Basic Settings


In most scenarios, when configuring the operation mode to Real COM mode, you have already completed the setup. Real COM mode does not have any basic settings. Select the **NEXT** button to go to Step 3.

Step 3: Advanced Settings—Connection Settings

In some scenarios, you may need to change the advanced settings to fulfill these special cases.



To communicate with multiple hosts on the NPort, enable **Max. Connection** and set the number to match the number of hosts. The NPort will now allow multiple hosts to connect concurrently. For example, let's suppose Host 1 is the primary computer, responsible for sending requests and receiving responses, while Host 2 is the backup computer, designated solely for receiving responses. Then, you should set the number to 2.



Max. connection (default=1): This field is used if you need to receive data from different hosts simultaneously. When set to 1, only one specific host can access this port of the NPort 5600-DT-G2, and the Real COM driver on that host will have full control over the port.

When the value is set to 2 or higher, multiple hosts' Real COM drivers can simultaneously open this port, up to the specified number. When several hosts' Real COM drivers open the port simultaneously, the COM driver only acts as a pure data tunnel and lacks control functionality. The serial port parameters will use firmware settings instead of depending on your application program (AP).

The firmware will send data back only to the driver on the host. When the data is received on the serial port and passed to the Ethernet side of the NPort, all the hosts will receive the same data. When the data is received on the Ethernet port and passed to the serial side of the NPort, the data will be sent first-in, first-out.

If the situation described above doesn't match your site, there are several advanced functions at **Multiple Connection Settings** to make some modifications.

Allow driver control: As mentioned above, when **Max. connection** is set to 2 or higher, the serial port parameters will use firmware settings. If you want the serial parameters to still use the settings of your application program, enable the **Allow driver control** function. When you enable it, the serial port settings of your AP will overwrite the firmware settings while opening the COM port. Usually, you should only enable this function on one of the hosts. If you enable it on two or more hosts, then the serial parameters will be overwritten every time these hosts open the COM port.

To handle the unexpected data communication of multiple connections, there are different combinations for different scenarios.

Connection Control	Congestion Handling	Description
Send serial data to all hosts	-	This is the default data communication behavior for multiple connections. The serial data will be transmitted to the host. What happens if one host cannot receive the data?
	Wait until transmission succeeds	Wait until the host can receive data again. If the host cannot return, this option will store the serial data in the NPort's serial buffer as a side-effect. Once the serial data reaches 1,024 bytes, the buffer becomes full and can no longer receive data. Any new incoming data will be discarded.
	Keep sending data to other hosts	Ignore the abnormal host; keep sending data to other online hosts. The downside of this option is that communication seems OK when the user only checks the status on the succeeding host(s). A mechanism might be necessary to alert the user when a host is unable to receive data.
Send serial data to the requested host	-	At times, the other hosts are unable to handle unrequested responses. In this scenario, choose to Send serial data to the requested host , ensuring that each host only receives the response specific to their request. What happens if the serial device fails to respond or responds too slowly in this situation?

Connection Control	Congestion Handling	Description
	Discard	If the serial response times out, then the NPort will discard all the new incoming serial data before the NPort receives an Ethernet request.
	Send to the most recent successful recipient	If the serial response times out and new serial data arrives, the NPort will forward the data to the host that most recently received the response successfully from the NPort.
	Send to all open connections	If the serial response times out and the system receives new serial data, the NPort distributes the data to all hosts still connected.
	Enable response timeout	To ensure smooth operation in this one-request-one-response application, you should specify the waiting time for the NPort to receive the serial response. The default timeout time is 10,000 ms. This value shall be less than the timeout time on the user's AP. Make sure this value is smaller than the AP's timeout time. If not, an unusual situation could occur where AP identifies it as a timeout error, but the NPort is still waiting for a response.

Enable TCP alive check

Allow the NPort to reset the TCP session by checking the receiving of the last TCP packet until the check time timeout.

Check Time (min)

7

Service providers always have limited resources. By enabling Real COM mode, the NPort allows access to connected serial devices. In the event of an accidental TCP connection failure, the resource could be indefinitely occupied until you restart the NPort. To prevent this from happening, the NPort will enable the **Enable TCP alive check time** function by default to verify if the existing connection is alive or not. If the session is not active and the timeout period (default value of 7 minutes) is reached, the NPort will end the session and make it available for other users/devices.

Enable TCP alive check time (default=7 min): The duration for which the NPort 5600-DT-G2 waits for a response to keep-alive packets before closing the TCP connection can be specified in this field. To verify connection status, the NPort 5600-DT-G2 sends keep-alive packets at regular intervals. If the packet goes unanswered by the remote host within the specified time, the NPort 5600-DT-G2 will terminate the TCP connection.


Connection Settings Data Transmission Settings

Enable port buffering

To prevent loss of serial data during an Ethernet disconnection, enable this function. Enabling port buffering means that RTS/DTR will always be set to on.

Poor cable contact or a damaged switch/router could cause it to be disconnected or broken. When this happens, serial data cannot transmit over Ethernet because no receiver is present. As time passes, the serial data could be discarded and lost. If the serial data is important, you may enable the Enable port buffering function. The NPort can store serial data in its internal memory, which is 64 Kbytes.

Enable port buffering (default=No): To prevent serial data loss when the Ethernet connection is down, check the checkbox to enable port buffering. If you enable port buffering, RTS/DTR will remain on.




In a serial bus, the host and the serial device can use RTS/DTR signals to show their status to each other. Using the RTS/DTR Behavior function, the NPort can simulate the RTS/DTR behavior on Ethernet connections. When using legacy software, enable the RTS/DTR signal and keep it constantly on to prevent the host from entering sleep mode or shutting down. This will ensure the host is always ready for communication.

RTS/DTR Behavior (default=always on): Configures what happens to the RTS and DTR signals when the TCP session is disconnected. For some applications, serial devices need to know the Ethernet link status through RTS or DTR signals sent via the serial port. If the serial devices detect that the RTS or DTR is off, they may jump into sleeping mode or low-power mode. Then, it may take a while to come back from the sleeping/low-power mode, which will cause issues because the host PC will come back quicker. Here, set the signal to always on.

When the Enable port buffering function is enabled, the RTS and DTS signals will always be set to ON to keep the serial device sending data. This function may be disabled at the same time.

Step 4: Advanced Settings—Data Transmission Settings

When serial data is transmitted on the serial bus, its continuous data. A "Read" command allows the software to receive all of the data. When everything switches to Ethernet, it's a different story. Ethernet data can be divided into packets, which are then assembled by the receiver into a complete frame to interpret the transmission request from the other device. However, a legacy serial software might lack support for the fundamental "assemble" function found in socket programs. Here, the NPort enables the Data Transmission function to deliver the correct frame at the beginning, requiring no changes to the legacy serial software for reading accurate data.



Like a barcode reader, serial data has a fixed length, and the fixed length data is read at once. A second common application is a serial protocol with specific ending character(s), which makes it easier for the engineer to read the data. In these two scenarios, enable the **Enable data packing** function.

Enable data packing: With the drop-down menu Packing Method, select **Packet length** or **Delimiter (hex)**.

Packet length (Byte): The packet length setting refers to the maximum amount of data that is allowed to accumulate in the serial port buffer before sending. When you specify a packet length between 1 and 1024 bytes, the data in the buffer will be sent as soon as it reaches the specified length.

Connection Settings **Data Transmission Settings**

Enable data packing
Specify the packing and sending of serial data to the host.

Packing Method
Delimiter (hex) ▼

Delimiter 1
0x 0

Delimiter 2 - Optional
0x

Data Transmit Process

Default process
Send data with delimiter characters.

Delimiter + 1 byte
Send data with delimiter characters and following 1 byte.

Delimiter + 2 bytes
Send data with delimiter characters and following 2 bytes.

Strip delimiter
Send data without delimiter characters.

Delimiter (hex): The delimiter refers to the ending character(s) of the data. When the specific character(s) is received, the NPort will execute the Data Transmit Process to handle the serial data. Then, send it out on the Ethernet side.

Delimiter 1 and Delimiter 2: If Delimiter 1 is configured in hex format, the NPort will treat the designated character as the end character. If there are two ending characters, use Delimiter 2 and ensure they are received in the correct order (Delimiter 1 first, then Delimiter 2). The NPort will pack all the data in the serial buffer and follow the Data Transmit Process to handle the delimiter(s) before transmitting the data to the Ethernet port.

Data Transmit Process: This field determines how to handle the serial data and the delimiter(s) when receiving the delimiter(s). If both Delimiters 1 and 2 are set up, the process will only occur when both characters are received in the correct order.

- **Default process:** Data in the buffer and the delimiter(s) will be transmitted.
- **Delimiter+1 byte:** Data in the buffer and the delimiter(s) plus one byte will be transmitted after one additional byte is received following the delimiter(s).
- **Delimiter+2 bytes:** Data in the buffer and the delimiter(s) plus two bytes will be transmitted after two additional bytes are received following the delimiter.
- **Strip delimiter:** Data in the buffer will be transmitted and the delimiter(s) will be dropped.

Some protocols, like Modbus, may separate different messages from the idle time between two messages. For this case, enable the **Enable force transmit** function and input the idle time in the **Force Transmit Time (ms)** field.


Enable force transmit
Allow the packaging and transmission of serial data until the specified force transmit time is met.

Force Transmit Time (ms)

Enable force transmission: The NPort will monitor the idle time between two characters. If the time is reached and there are no new characters are being received, the NPort will package all the data in the serial buffer and then send it on the Ethernet side. The number of this field is between 1 and 65535.

Step 5: Confirmation

Review and **SAVE** the above settings to make them effective.




RFC2217 Mode

If you prefer a virtual COM driver or have different brands of serial device servers, install a third-party driver to communicate with the NPort and with all the other brands of device servers. Here, select the RFC2217 mode.

Step 1: Mode Selection

Select the COM-based control and select RFC2217 mode.



Step 2: Basic Settings

Home > Serial Port Settings > Operation Modes > Configure Port(s)

← Configure Port(s)

1 Mode Selection — 2 Basic Settings — 3 Advanced Settings

RFC2217 Server Settings

Assign TCP port starting from 4001 to selected port(s).

Assign TCP port starting from: This is the TCP port number assignment for the serial port on the NPort 5600-DT-G2. It is the port number that the serial port uses to listen. If over two serial ports are configured in RFC2217 mode, the listen port will start from this assigned number (the first port will listen on TCP port 4001 and the second port will listen on TCP port 4002). For the host (or other network devices), this TCP port number is also the target TCP port used to establish the TCP connection. To avoid conflicts with well-known TCP ports, set the default to 4001.

Home > Serial Port Settings > Operation Modes > Configure Port(s)

← Configure Port(s)

1 Mode Selection — 2 Basic Settings — 3 Advanced Settings — 4 Confirmation

Advanced settings can generally be used with default values. Customize the settings if needed.

Connection Settings | Data Transmission Settings

Enable TCP alive check
Allow the NPort to reset the TCP session by checking the receiving of the last TCP packet until the check time timeout.

Check Time (min)
7

← BACK CANCEL NEXT >

Step 3: Advanced Settings—Connection Settings

Enable TCP alive check

Allow the NPort to reset the TCP session by checking the receiving of the last TCP packet until the check time timeout.


Check Time (min)
7

Service providers always have limited resources. By enabling Real COM mode, the NPort allows access to connected serial devices. In the event of an accidental TCP connection failure, the resource could be indefinitely occupied until you restart the NPort. To prevent this from happening, the NPort will enable the Enable TCP alive check time function by default to verify if the existing connection is alive or not. If the session is not active and the timeout period (default value of 7 minutes) is reached, the NPort will end the session and make it available for other users/devices.

Enable TCP alive check time (default=7 min): The duration for which the NPort 5600-DT-G2 waits for a response to keep-alive packets before closing the TCP connection can be specified in this field. To verify connection status, the NPort 5600-DT-G2 sends keep-alive packets at regular intervals. If the packet goes unanswered by the remote host within the specified time, the NPort 5600-DT-G2 will terminate the TCP connection.

Step 4: Advanced Settings—Data Transmission Settings

When serial data is transmitted on the serial bus, it's continuous data. A "Read" command allows the software to receive all of the data. When everything switches to Ethernet, it's a different story. Ethernet data can be divided into packets, which are then assembled by the receiver into a complete frame to interpret the transmission request from the other device. However, a legacy serial software might lack support for the fundamental "assemble" function found in socket programs. Here, the NPort enables the Data Transmission function to deliver the correct frame at the beginning, requiring no changes to the legacy serial software for reading accurate data.




The screenshot shows the 'Data Transmission Settings' tab in a configuration window. At the top, there are three progress indicators: 'Mode Selection' (checked), 'Basic Settings' (checked), and 'Advanced Settings' (active, indicated by a red dot). Below the indicators, a note states: 'Advanced settings can generally be used with default values. Customize the settings if needed.' The 'Data Transmission Settings' section is active, showing a checked checkbox for 'Enable data packing' with the subtext 'Specify the packing and sending of serial data to the host.' Below this is a 'Packing Method' dropdown menu with the text '-- Select One --' and a list of options: 'Packet length' (highlighted) and 'Delimiter (hex)'. There is also an unchecked checkbox for 'Delimiter (hex)' with the subtext 'Allow the packaging and transmission of serial data until the specified force transmit time is met.'

Like a barcode reader, serial data has a fixed length, and the fixed length data is read at once. A second common application is a serial protocol with specific ending character(s), which makes it easier for the engineer to read the data. In these two scenarios, enable the **Enable data packing** function.

Enable data packing: With the drop-down menu Packing Method, select **Packet length** or **Delimiter (hex)**.

Packet length (Byte): The packet length setting refers to the maximum amount of data that is allowed to accumulate in the serial port buffer before sending. When you specify a packet length between 1 and 1024 bytes, the data in the buffer will be sent as soon as it reaches the specified length.



The screenshot shows the 'Data Transmission Settings' tab. The 'Enable data packing' checkbox is checked. The 'Packing Method' dropdown menu is set to 'Delimiter (hex)'. Below this, there are two input fields: 'Delimiter 1' with the value '0x 0' and 'Delimiter 2 - Optional' with the value '0x'. At the bottom, the 'Data Transmit Process' section has four radio button options: 'Default process' (selected), 'Delimiter + 1 byte', 'Delimiter + 2 bytes', and 'Strip delimiter'.

Delimiter (hex): The delimiter refers to the ending character(s) of the data. When the specific character(s) is received, the NPort will execute the Data Transmit Process to handle the serial data. Then, send it out on the Ethernet side.


Delimiter 1 and Delimiter 2: This field determines how to handle the serial data and the delimiter(s) when receiving the delimiter(s). If both Delimiters 1 and 2 are set up, the process will only occur when both characters are received in the correct order.

Data Transmit Process: This field determines how to handle the serial data and the delimiter(s) when receiving the delimiter(s). If both Delimiters 1 and 2 are set up, the process will only occur when both characters are received in the correct order.

Default process: Data in the buffer and the delimiter(s) will be transmitted.

- **Delimiter+1 byte:** Data in the buffer and the delimiter(s) plus one byte will be transmitted after one additional byte is received following the delimiter(s).
- **Delimiter+2 bytes:** Data in the buffer and the delimiter(s) plus two bytes will be transmitted after two additional bytes are received following the delimiter.
- **Strip delimiter:** Data in the buffer will be transmitted and the delimiter(s) will be dropped.


Some protocols, like Modbus, may separate different messages from the idle time between two messages. For this case, enable the **Enable force transmit** function and input the idle time in the **Force Transmit Time (ms.)** field.



Enable force transmit: The NPort will monitor the idle time between two characters. If the time is reached and there are no new characters are being received, the NPort will package all the data in the serial buffer and then send it on the Ethernet side. The number of this field is between 1 and 65535.

Step 4. Confirmation

Review and **SAVE** the above settings to make them effective.




Socket Applications

The Socket application requires the user to have or create a socket program to establish the TCP session or send UDP packets to the destination NPort. Usually when you want to manage multiple brands of network devices, you may have the resources to create or integrate a socket program to fulfill this need.


TCP Server Mode

If the user's program starts the TCP session actively, the NPort shall be a TCP Server to listen to a specific TCP port and wait for the user's program to establish the TCP session. Select **TCP Server** mode on the NPort.



Step 1: Mode Selection

Select the **Socket** and **TCP Server** mode.



Step 2: Basic Settings


Assign data port: This is the TCP port number assignment for the serial port on the NPort 5600-DT-G2. It is the port number that the serial port uses to listen for connections, and that other devices must use to contact the serial port. To avoid conflicts with well-known TCP ports, the default is set to 4001.

Assign command port: The command port is the TCP port for listening to Moxa commands from the host. To prevent a TCP port conflict with other applications, the user can set the command port to another port if needed.

Step 3: Advanced Settings—Connection Settings

In some scenarios, you may need to modify the advanced settings to fulfill his special cases.

For those users who have more than one host to communicate with the NPort, you will need to enable the Max. Connection by changing the number to the number of the hosts. With this, the NPort will allow all these hosts to connect simultaneously. For example, Host 1 is the primary computer that will send requests and receive the responses, and Host 2 is the backup computer to receive the responses. Set the number to 2.



Max. connection (default=1): This field is used if you need to receive data from different hosts simultaneously. When set to 1, only one specific host can access this port of the NPort 5600-DT-G2, and the Real COM driver on that host will have full control over the port.

When set to 2 or greater, up to the specified number of hosts' Real COM drivers may open this port at the same time. When multiple hosts' Real COM drivers open the port at the same time, the COM driver only provides a pure data tunnel—no control ability. The serial port parameters will use firmware settings instead of depending on your application program (AP).

The firmware will send data back only to the driver on the host. When the data is received on the serial port and passed to the Ethernet side of the NPort, all the hosts will receive the same data. When the data is received on the Ethernet port and passed to the serial side of the NPort, the data will be sent first-in, first-out.

If the above scenario is not the case on your site, there are several advanced functions in **Multiple Connection Settings** to make some modifications.

Allow driver control: as mentioned above, when set **Max. connection** to 2 or more, the serial port parameters will use firmware settings. If you want the serial parameters to use the settings of your application program, enable the **Allow driver control** function. When you enable it, the serial port settings of your AP will overwrite the firmware settings while opening the COM port. Usually, you should only enable this function on one host. If you enable it on 2 or more hosts, then the serial parameters will be overwritten every time these hosts open the COM port.

To handle the unexpected data communication of multiple connections, there are different combinations for different scenarios.

Connection Control	Congestion Handling	Description
Send serial data to all hosts	–	This is the default data communication behavior for multiple connections; the serial data will be transmitted to all the hosts. What if there is one host that cannot receive the data successfully?
	Wait until transmission succeeds	Just wait until the host can receive data again. There is a side-effect on this option: if the host just cannot be back, the serial data will be stored on the serial buffer of the NPort. When the serial data is accumulated to 1,024 bytes, the serial buffer will be full and cannot receive any data. If there are new incoming data, all of it will be dropped.
	Keep sending data to other hosts	Just ignored the abnormal host, kept sending data to other online hosts. The side-effect of this option is that the communication seems OK when the user only checks the status on the succeed host(s). A mechanism could notify the user of an abnormal host, preventing data reception.

Connection Control	Congestion Handling	Description
Send serial data to the requested host	-	Sometimes, the other hosts cannot handle the responses they don't request. Here, select Send serial data to the requested host ; then, all the hosts will only receive the response based on their own request. For this scenario, what if the serial device doesn't respond to the request or responds too late?
	Discard	If the serial response is timeout, then the NPort will discard all the new incoming serial data before the NPort receives an Ethernet request.
	Send to the most recent successful recipient	If the serial response times out and the NPort receives new incoming serial data, it will send the data to the host that most recently received the response successfully from the NPort.
	Send to all open connections	If the serial response is timeout and the NPort receives new incoming serial data, it will send the data to all the hosts that are still connected to the NPort.
	Enable response timeout	For this kind of one-request-one-response application, you may need to define how long the NPort shall wait for the serial response? The default timeout time is 10,000 ms. This value shall be less than the timeout time on the user's AP. Otherwise, this abnormal scenario might happen: the AP considers it a timeout error but the NPort stis stillaiting for a response.

Enable TCP alive check
 Allow the NPort to reset the TCP session by checking the receiving of the last TCP packet until the check time timeout.

Check Time (min)

Service providers always have limited resources. By enabling Real COM mode, the NPort allows access to connected serial devices. In the event of an accidental TCP connection failure, the resource could be indefinitely occupied until you restart the NPort. To prevent this from happening, the NPort will enable the **Enable TCP alive check time** function by default to verify if the existing connection is alive or not. If the session is not active and the timeout period (default value of 7 minutes) is reached, the NPort will end the session and make it available for other users/devices.


Enable TCP alive check time (default=7 min): The duration for which the NPort 5600-DT-G2 waits for a response to keep-alive packets before closing the TCP connection can be specified in this field. To verify connection status, the NPort 5600-DT-G2 sends keep-alive packets at regular intervals. If the packet goes unanswered by the remote host within the specified time, the NPort 5600-DT-G2 will terminate the TCP connection.

Enable inactivity timeout
 If there is no data from or to the serial device within the specified timeout time, allow the termination of both data and command connections.

Timeout Time (ms)


Enable inactivity timeout, this setting is used for applications that may incur high costs for the connection between the remote host and the NPort, such as when it is connected with a cellular/satellite line.

When the TCP session is established, the NPort will terminate the session actively if there is no new data for a while on the serial port. For the timing to terminate the TCP session, the user will need to set the Timeout time (ms.) for this option.



Compared with the serial bus, the Ethernet network is not stable. Poor cable contact or a damaged switch/router could cause it to be disconnected or broken. When this happens, the serial data cannot be transmitted over Ethernet because the receiver does not exist. As time passes, the serial data could be discarded and lost. If the serial data is important, you may enable the **Enable port buffering** function. The NPort can store serial data in its internal memory, which is 64 Kbytes.

Enable port buffering (default=No): To prevent serial data loss when the Ethernet connection is down, check the checkbox to enable port buffering. If you enable port buffering, RTS/DTR will remain on.




In a serial bus, the host and the serial device can use RTS/DTR signals to indicate their status to each other. Using the RTS/DTR Behavior function, the NPort can simulate the RTS/DTR behavior on Ethernet connections. When using legacy software, enable the RTS/DTR signal and keep it constantly on to prevent the host from entering sleep mode or shutting down. This will ensure the host is always ready for communication.

RTS/DTR Behavior (default=always on): Configures what happens to the RTS and DTR signals when the TCP session is disconnected. For some applications, serial devices need to know the Ethernet link status through RTS or DTR signals sent via the serial port. This function may be disabled by enabling the Enable port buffering function.

Step 3: Advanced Settings—Data Transmission Settings

When serial data is transmitted on the serial bus, it's continuous data. The software can receive the whole data with a simple "Read" command. When everything moves to Ethernet, it's another story. The Ethernet data might be separated into packets, and the receiver will assemble these packets into one complete frame to understand what the other device wants to transmit. But if it's a legacy serial software, it may not support the "assemble" function, which is a basic function of a socket program. Here, the NPort provides the Data Transmission function to deliver the correct frame at the beginning, so the legacy serial software needs nothing changed to read the correct data.



Like a barcode reader, serial data has a fixed length, and the fixed length data is read at once. A second common application is a serial protocol with specific ending character(s), which makes it easier for the engineer to read the data. In these two scenarios, enable the **Enable data packing** function.

Enable data packing: With the drop-down menu Packing Method, select **Packet length** or **Delimiter (hex)**.

Packet length (Byte): The packet length setting refers to the maximum amount of data that is allowed to accumulate in the serial port buffer before sending. When a packet length between 1 and 1024 bytes is specified, data in the buffer will be sent as soon as it reaches the specified length.

Connection Settings Data Transmission Settings

Enable data packing
Specify the packing and sending of serial data to the host.

Packing Method
Delimiter (hex) ▼

Delimiter 1
0x 0

Delimiter 2 - Optional
0x

Data Transmit Process

Default process
Send data with delimiter characters.

Delimiter + 1 byte
Send data with delimiter characters and following 1 byte.

Delimiter + 2 bytes
Send data with delimiter characters and following 2 bytes.

Strip delimiter
Send data without delimiter characters.

Delimiter (hex): The delimiter refers to the ending character(s) of the data. When the specific character(s) is received, the NPort will execute the Data Transmit Process to handle the serial data and then send it out on the Ethernet side.

Delimiter 1 and Delimiter 2: If Delimiter 1 is configured in hex format, the NPort will treat the designated character as the end character. If there are two ending characters, use Delimiter 2 and ensure they are received in the correct order (Delimiter 1 first, then Delimiter 2). The NPort will pack all the data in the serial buffer and follow the Data Transmit Process to handle the delimiter(s) before transmitting the data to the Ethernet port.

Data Transmit Process: This field determines how to handle the serial data and the delimiter(s) when receiving the delimiter(s). If both Delimiters 1 and 2 are set up, the process will only occur when both characters are received in the correct order.

- **Default process:** Data in the buffer and the delimiter(s) will be transmitted.
- **Delimiter+1 byte:** Data in the buffer and the delimiter(s) plus one byte will be transmitted after one additional byte is received following the delimiter(s).
- **Delimiter+2 bytes:** Data in the buffer and the delimiter(s) plus two bytes will be transmitted after two additional bytes are received following the delimiter.
- **Strip delimiter:** Data in the buffer will be transmitted and the delimiter(s) will be dropped.

Some protocols, like Modbus, may separate different messages from the idle time between two messages. For this case, enable the **Enable force transmit** function and input the idle time in the **Force Transmit Time (ms)** field.

Enable force transmit
 Allow the packaging and transmission of serial data until the specified force transmit time is met.

Force Transmit Time (ms)

Enable force transmit: The NPort will monitor the idle time between two characters. If the time is reached and there are no new characters are being received, the NPort will package all the data in the serial buffer and then send it on the Ethernet side. The number of this field is between 1 and 65535.

Step 4: Confirmation

Review and **SAVE** the above settings to make them effective.

Home > Serial Port Settings > Operation Modes > Configure Port(s)

← Configure Port(s)

1 Mode Selection 2 Basic Settings 3 Advanced Settings 4 Confirmation

Selected Port: 1

Application: Socket
 Operation Mode: TCPServer

TCP Server Settings
 Data Port: Start from 4001
 Command Port: Start from 966


Connection Settings
 Max. Connection: 1
 TCP Alive Check: Enabled
 Check Time: 7 mins
 Inactivity Timeout: Disabled
 Port Buffering: Enabled
 Buffering Location: Memory (84K)
 RTS Always On: Enabled
 DTR Always On: Enabled

Data Transmission Settings
 Data Packing: Disabled
 Force Transmit: Disabled

← BACK CANCEL SAVE

TCP Client Mode

When your program listens on a specific TCP port and waits for the NPort to establish the TCP session. Select **TCP Client** mode on the NPort.



Step 1: Mode Selection

Select the **Socket** and then **TCP Client** mode.

The screenshot shows the 'Configure Port(s)' interface with a progress bar at the top indicating four steps: 1. Mode Selection (active), 2. Basic Settings, 3. Advanced Settings, and 4. Confirmation. Below the progress bar, the 'Remote Server Settings' section is visible. It includes a 'Connect Method' section with two radio button options: 'Connect to all servers' (selected) and 'Connect to the first available server'. Below this is a 'Server 1' section with a 'Destination Address' input field, a note 'Assign the address port starting from 4001 to selected port(s)', and another note 'Assign local port starting from 5010 incrementing by 10 to selected port(s)'. At the bottom of the server section is a '+ ADD SERVER' button. The bottom navigation bar contains '< BACK', 'CANCEL', and 'NEXT >' buttons.

Step 2: Basic Settings

There are two types of TCP Client applications. If the serial device needs to connect to all the hosts (the TCP Servers) simultaneously, select **Connect to all servers**. Or, if the serial device will try to connect to all hosts but only needs to establish a connection with the first one, select **Connect to the first available server**. With this setting, the NPort will connect the servers in the order they were entered.

Connect Method: Choose whether you want to **Connect to all servers** or **Connect to the first available server**.

Several parameters need to be set for each server:

Destination Address: Specifying an IP address allows the NPort 5600-DT-G2 to connect actively to the remote host. Provide the destination address for each server.

Assign the address port starting from: This is the TCP port number assignment on the remote host to listen to NPort's request. Confirm that the port on the remote host matches the AP setting. The default port is set to 4001 to avoid conflicts with well-known TCP ports.

Assign local port starting from: Use these fields to specify the designated local port on the NPort.

ADD Server: Select **ADD Server** to add more remote servers for NPort to connect.

The screenshot shows the 'Configure Port(s)' interface with the progress bar now at Step 2: Basic Settings (active). Below the progress bar, a note states: 'Advanced settings can generally be used with default values. Customize the settings if needed.' There are two tabs: 'Connection Settings' (active) and 'Data Transmission Settings'. Under 'Connection Settings', there are two dropdown menus: 'When to Connect' set to 'Device starts up' and 'When to Disconnect' set to 'Never'. Below these are two checked checkboxes: 'Enable TCP alive check' and 'Enable port buffering'. The 'Enable TCP alive check' section includes a 'Check Time (min)' input field with the value '7'. The 'Enable port buffering' section includes a 'Buffering Location' dropdown menu set to 'Memory (64K)'. The bottom navigation bar contains '< BACK', 'CANCEL', and 'NEXT >' buttons.

Step 3: Advanced Settings—Connection Settings

In TCP Client mode, the NPort will start the TCP session. It's important to determine when the NPort shall start or end the session. Based on different scenarios, set the behavior of the **When to Connect/ When to Disconnect** function.

When to Connect/Disconnect: This setting determines the parameters under which a TCP connection is established or disconnected. The following table provides the different options. We provide both the connect and disconnect conditions.

When to Connect	When to Disconnect	Description
Device starts up	Never	This setting is used for serial devices that may proactively update data and always remain powered on, so the NPort needs to start updating data as quickly as possible. The NPort will try to establish the TCP session when the firmware is ready. The NPort will not actively terminate the session once the TCP session is established. If the remote host disconnects the TCP session or it gets disconnected accidentally, the NPort will try to reestablish it automatically.
Receive any characters from serial	Never	This setting is used for serial devices that may proactively update data, but they may not be powered all the time, or they may update data very frequently. Therefore, the NPort can wait until it receives new serial data, and then it starts to establish the TCP session. The NPort will try to establish a TCP session when it receives data on the serial port. The NPort will not actively terminate the session once it has established the TCP session. If the TCP session is disconnected by the remote host or by accident, the NPort will try to reestablish it automatically.
	Reach the inactivity timeout time	This setting is for applications that may incur high costs for the connection between the remote host and the NPort, such as when it is connected with a cellular/satellite line. The NPort will try to establish a TCP session when it receives data on the serial port. When the TCP session is established, the NPort will end the session actively if there is no new data for a while on the serial port. Set the timeout time to determine when to end the TCP session.
DSR on	Never	This setting is used for serial devices that can notify the host of their readiness to update data by turning on the DTR signal. Once the NPort detects the DSR signal is on, it will establish the connection and be ready for serial data updates. The NPort will try to establish the TCP session when it detects the DCD signal is on. When the TCP session is established, the NPort will not terminate the session actively. If the TCP session is disconnected by the remote host or by accident, the NPort will try to reestablish it automatically.
	DSR off	This setting is used for serial devices that can notify the host by changing the DTR signal to on when they are ready to update data. When the serial device finishes data updates, it will also notify the host by changing the DTR signal to off. The NPort will try to establish the TCP session when it detects that the DSR signal is on. When the TCP session is established, the NPort will only terminate the session actively when detecting the DSR signal is off.
DCD on	Never	This setting is used for serial devices that can notify the host of their readiness to update data by turning on the DCD signal. So, when the NPort detects the DCD signal is on, it should establish the connection and be ready for serial data updates. The NPort will try to establish the TCP session when it detects the DCD signal is on. When the TCP session is established, the NPort will not terminate the session actively. If the TCP session is disconnected by the remote host or by accident, the NPort will try to reestablish it automatically.

When to Connect	When to Disconnect	Description
	DCD off	<p>This setting is used for serial devices that can notify the host by changing the DCD signal to on when they are ready to update data. When the serial device finishes the data update, it will also notify the host by changing the DCD signal to off.</p> <p>The NPort will try to establish the TCP session when it detects the DCD signal is on. When the TCP session is established, the NPort will only terminate the session actively when detecting the DCD signal is off.</p>

Enable TCP alive check

Allow the NPort to reset the TCP session by checking the receiving of the last TCP packet until the check time timeout.

Check Time (min)

7

Service providers always have limited resources. By enabling Real COM mode, the NPort allows access to connected serial devices. In the event of an accidental TCP connection failure, the resource could be indefinitely occupied until you restart the NPort. To prevent this from happening, the NPort will enable the **Enable TCP alive check time** function by default to verify if the existing connection is alive or not. If the session is not active and the timeout period (default value of 7 minutes) is reached, the NPort will end the session and make it available for other users/devices.

Enable TCP alive check time (default=7 min): The duration for which the NPort 5600-DT-G2 waits for a response to keep-alive packets before closing the TCP connection can be specified in this field. To verify connection status, the NPort 5600-DT-G2 sends keep-alive packets at regular intervals. If the packet goes unanswered by the remote host within the specified time, the NPort 5600-DT-G2 will terminate the TCP connection.

Connection Settings Data Transmission Settings

Enable port buffering

To prevent loss of serial data during an Ethernet disconnection, enable this function. Enabling port buffering means that RTS/DTR will always be set to on.

Compared with the serial bus, the Ethernet network is not stable. It could be disconnected/broken by a cable, poor contact, or switch/router damage. When this happened, the serial data cannot be transmitted on the Ethernet because the receiver did not exist. As time goes by, serial data may be dropped and lost. If the serial data is important, you can enable the **Enable port buffering** function. The NPort will save the serial data to the internal memory, 64 Kbytes.

Enable port buffering (default=No): To prevent serial data loss when the Ethernet connection is down, check the checkbox to enable port buffering. If you enable port buffering, RTS/DTR will remain on.

RTS/DTR Behavior

If the port buffering is disabled, you may customize the RTS/DTR behaviors when TCP session is disconnected.

RTS always on

DTR always on

On a serial bus, the host and the serial device may be set to turn on/off the RTS/DTR signals to notify the serial device that the host is alive or not, and vice versa. The NPort supports the RTS/DTR Behavior function to simulate the above behavior on the Ethernet connections. Some legacy software on the host may switch to sleep mode or shutdown itself based on the RTS/DTR signal. When enabling this function and keeping these two signals always on, it can prevent this from happening and keep the host ready for communication.

RTS/DTR Behavior (default=always on): You can configure what happens to the RTS and DTR signals when a TCP session is disconnected. For some applications, serial devices need to know the Ethernet link status through RTS or DTR signals sent via the serial port. This function may be disabled by enabling the Enable port buffering function.

Step 3: Advanced Settings—Data Transmission Settings

When serial data is transmitted on the serial bus, it's continuous data. A "Read" command allows the software to receive all of the data. When everything switches to Ethernet, it's a different story. Ethernet data can be divided into packets, which are then assembled by the receiver into a complete frame to interpret the transmission request from the other device. However, legacy serial software might lack support for the fundamental "assemble" function found in socket programs. Here, the NPort enables the Data Transmission function to deliver the correct frame at the beginning, requiring no changes to the legacy serial software for reading accurate data.

The screenshot shows a configuration window with three tabs: 'Mode Selection', 'Basic Settings', and 'Advanced Settings'. The 'Advanced Settings' tab is active. Below the tabs, there is a note: 'Advanced settings can generally be used with default values. Customize the settings if needed.' Underneath, there are two sub-tabs: 'Connection Settings' and 'Data Transmission Settings'. The 'Data Transmission Settings' sub-tab is selected. It contains the following options:

- Enable data packing**
Specify the packing and sending of serial data to the host.
- Packing Method**
-- Select One --
A dropdown menu with 'Packet length' selected.
- Delimiter (hex)**
Allow the packaging and transmission of serial data until the specified force transmit time is met.

Like a barcode reader, serial data has a fixed length, and the fixed length data is read at once. A second common application is a serial protocol with specific ending character(s), which makes it easier for the engineer to read the data. In these two scenarios, enable the Enable data packing function.

Enable data packing: With the drop-down menu Packing Method, select **Packet length** or **Delimiter (hex)**.

Packet length (Byte): The packet length setting refers to the maximum amount of data that is allowed to accumulate in the serial port buffer before sending. When you specify a packet length between 1 and 1024 bytes, the data in the buffer will be sent as soon as it reaches the specified length.

Connection Settings **Data Transmission Settings**

Enable data packing
Specify the packing and sending of serial data to the host.

Packing Method
Delimiter (hex) ▼

Delimiter 1
0x 0

Delimiter 2 - Optional
0x

Data Transmit Process

Default process
Send data with delimiter characters.

Delimiter + 1 byte
Send data with delimiter characters and following 1 byte.

Delimiter + 2 bytes
Send data with delimiter characters and following 2 bytes.

Strip delimiter
Send data without delimiter characters.

Delimiter (hex): The delimiter refers to the ending character(s) of the data. When the specific character(s) is received, the NPort will execute the Data Transmit Process to handle the serial data. Then, send it out on the Ethernet side.

Delimiter 1 and Delimiter 2: If Delimiter 1 is configured in hex format, the NPort will treat the designated character as the end character. If there are two ending characters, use Delimiter 2 and ensure they are received in the correct order (Delimiter 1 first, then Delimiter 2). The NPort will pack all the data in the serial buffer and follow the Data Transmit Process to handle the delimiter(s) before transmitting the data to the Ethernet port.

Data Transmit Process: This field determines how to handle the serial data and the delimiter(s) when receiving the delimiter(s). If both Delimiters 1 and 2 are set up, the process will only occur when both characters are received in the correct order.

Default process: Data in the buffer and the delimiter(s) will be transmitted.

- **Delimiter+1 byte:** Data in the buffer and the delimiter(s) plus one byte will be transmitted after one additional byte is received following the delimiter(s).
- **Delimiter+2 bytes:** Data in the buffer and the delimiter(s) plus two bytes will be transmitted after two additional bytes are received following the delimiter.
- **Strip delimiter:** Data in the buffer will be transmitted and the delimiter(s) will be dropped.

Some protocols, like Modbus, may separate different messages from the idle time between two messages. For this case, enable the **Enable force transmit** function and input the idle time in the **Force Transmit Time (ms.)** field.

Enable force transmit
Allow the packaging and transmission of serial data until the specified force transmit time is met.

Force Transmit Time (ms)

Enable force transmit: The NPort will monitor the idle time between two characters. If the time is reached and there are no new characters are being received, the NPort will package all the data in the serial buffer and then send it on the Ethernet side. The number of this field is between 1 and 65535.

Step 4: Confirmation

Review and **SAVE** the above settings to make them effective.


The screenshot shows the 'Configure Port(s)' interface with four steps: 1. Mode Selection, 2. Basic Settings, 3. Advanced Settings, and 4. Confirmation. The Confirmation step is active. The settings displayed are:

- Selected Port: 1
- Application: Socket
- Operation Mode: TCPClient
- Remote Server Settings
 - Connect Method: Connect to all servers
 - Server 1
 - Destination Address: 10.0.0.10
 - Address Port: Start from 4001
 - Designated Port: Start from 5010
- Connection Settings
 - When to Connect: Device starts up
 - When to Disconnect: Never
 - TCP Alive Check: Enabled
 - Check Time: 7 mins
 - Port Buffering: Enabled
 - Buffering Location: Memory (64K)
- Data Transmission Settings
 - Data Packing: Disabled
 - Force Transmit: Disabled

At the bottom, there are 'BACK', 'CANCEL', and 'SAVE' buttons.

UDP Mode

If your application requires faster data arrival at the device with no need for guaranteed data reception, then you may choose to use UDP packets for the application. For example, at the train station, the message displayed on the LCM could be missed because there are so many displays. If the passenger misses the message on one display, they can find it on the others. The train arrival message may be useless if it arrives on display one minute after the train has already arrived. This is a typical application of the UDP mode.



Step 1: Mode Selection

Select the **Socket** and then **UDP** mode.

The screenshot shows the 'Configure Port(s)' interface with four steps: 1. Mode Selection, 2. Basic Settings, 3. Advanced Settings, and 4. Confirmation. The Basic Settings step is active, showing 'Destination Address Settings' and 'Listen Port Settings'.

Destination Address Settings

- Destination Mode: Static destination
- Specify the destination address to transmit data, and up to 4 sets of destination can be added.
- Destination 1
 - Address Type: Single address
 - Destination Address: [Input field]
 - Assign the address port starting from 4001 to selected port(s).
- + ADD DESTINATION

At the bottom, there are 'BACK', 'CANCEL', and 'NEXT' buttons.

Step 2: Basic Settings

There are two types of UDP applications. The data may be sent to static destinations, or it may depend on different serial data going to different destinations.

Destination Mode	Address Type	Description
Static destination	Single address	This setting allows serial devices to proactively update data to specific remote hosts. Input the target IP address and listen to the UDP port with this option.
	Address range (up to 16 addresses)	This setting allows users to proactively update data from serial devices to specific remote hosts. You can input a range of IP addresses and listen to the UDP port with this option.
Dynamic learning	Learning by packet	This setting is used for a one-request, one-response scenario. The NPort will record the source IP address and UDP port as the destination IP address and UDP port when the NPort receives serial data. Whenever the NPort receives an Ethernet request, it will update the destination IP address and UDP port.
	Learning when reaching the timeout	Until the timeout time is reached, the NPort will remove the old destination IP address and UDP port and update the information of the next UDP request to the table.

Destination Address Settings Listen Port Settings

Destination Mode
Static destination

Specify the destination address to transmit data, and up to 4 sets of destination can be added.

Destination 1

Address Type
Single address

Destination Address

Assign the address port starting from 4001 to selected port(s).

+ ADD DESTINATION

Destination Mode: Specify the way to determine the destination address to transmit data. There are two options: the **Static destination** or **Dynamic learning**. This snapshot shows the parameters for the Static destination.



The parameters for Destination 1 are:

Address Type: Specify **Single address** or **Address range (up to 16 addresses)** as the destination for communication.

Destination Address: Input unicast, multicast IP addresses or domain names as the destination address. At least one destination range must be provided.

Assign the address port starting from: This is the UDP port number assignment for the serial port on the NPort.

ADD DESTINATION: Select the button to add more destinations.




Destination Mode: Specify how to determine the destination address to transmit data. There are two options: the **Static destination** or **Dynamic learning**. This snapshot shows the parameters for Dynamic learning.

Learning Method: Under **Dynamic learning** mode, the NPort will record the source IP address and UDP port from the UDP packet. Depends on different user scenarios:


- The different UDP hosts may send the requests frequently, and the NPort (also the serial device) needs to reply to every request. Select **Learning by packet**. With this setting, the NPort will update the Destination IP address and UDP port for each UDP packet, so all the UDP hosts can receive the expected results.
- The different UDP hosts may take turns sending requests and getting responses. Only when one host has finished its turn for updating will the token pass to the second host to start another turn for requesting/responding. Here, set **Learning when reaching the timeout** and a specific timeout time (ms) for the hosts to exchange the token. The NPort can learn the new host's IP address and UDP port.

Regardless of the selected Destination Mode, assign the local listen port in the Listen Port Settings tab.



Assign the local listen port from (default=4001): This is the UDP port that the NPort 5600-DT-G2 listens to and that other devices must use. To avoid conflicts with well-known UDP ports, the default is set to 4001.

Step 3: Advanced Settings



When serial data is transmitted on the serial bus, it's continuous data. A "Read" command allows the software to receive all of the data. When everything switches to Ethernet, it's a different story. Ethernet data can be divided into packets, which are then assembled by the receiver into a complete frame to interpret the transmission request from the other device. However, legacy serial software might lack support for the fundamental "assemble" function found in socket programs. Here, the NPort enables the Data Transmission function to deliver the correct frame at the beginning, requiring no changes to the legacy serial software for reading accurate data.

Like a barcode reader, serial data has a fixed length, and the fixed length data is read at once. A second common application is a serial protocol with specific ending character(s), which makes it easier for the engineer to read the data. In these two scenarios, enable the **Enable data packing** function.

Enable data packing: With the drop-down menu Packing Method, select **Packet length** or **Delimiter (hex)**.

Packet length (Byte): The packet length setting refers to the maximum amount of data that is allowed to accumulate in the serial port buffer before sending. When a packet length between 1 and 1024 bytes is specified, data in the buffer will be sent as soon as it reaches the specified length.

The screenshot shows the 'Data Transmission Settings' tab. At the top, there are two tabs: 'Connection Settings' and 'Data Transmission Settings'. Below the tabs, there is a section for 'Enable data packing' which is checked. A sub-section 'Specify the packing and sending of serial data to the host.' contains a 'Packing Method' dropdown menu currently set to 'Delimiter (hex)'. Below this, there are two input fields: 'Delimiter 1' with the value '0x 0' and 'Delimiter 2 - Optional' with the value '0x'. At the bottom, there is a 'Data Transmit Process' section with four radio button options: 'Default process' (selected), 'Delimiter + 1 byte', 'Delimiter + 2 bytes', and 'Strip delimiter'.

Delimiter (hex): The delimiter refers to the ending character(s) of data. When the specific character(s) is received, the NPort will execute the Data Transmit Process to handle the serial data and then send it out on the Ethernet side.

Delimiter 1 and Delimiter 2: If Delimiter 1 is configured in hex format, the NPort will treat the designated character as the end character. If there are two ending characters, use Delimiter 2 and ensure they are received in the correct order (Delimiter 1 first, then Delimiter 2). The NPort will pack all the data in the serial buffer and follow the Data Transmit Process to handle the delimiter(s) before transmitting the data to the Ethernet port.

Data Transmit Process: This field determines how to handle the serial data and the delimiter(s) when receiving the delimiter(s). If both Delimiters 1 and 2 are set up, the process will only occur when both characters are received in the correct order.

Default process: Data in the buffer and the delimiter(s) will be transmitted.

- **Delimiter+1 byte:** Data in the buffer and the delimiter(s) plus one byte will be transmitted after one additional byte is received following the delimiter(s).
- **Delimiter+2 bytes:** Data in the buffer and the delimiter(s) plus two bytes will be transmitted after two additional bytes are received following the delimiter.
- **Strip delimiter:** Data in the buffer will be transmitted and the delimiter(s) will be dropped.

Some protocols, like Modbus, may separate different messages from the idle time between two messages. For this case, enable the **Enable force transmit** function and input the idle time in the **Force Transmit Time (ms.)** field.

Enable force transmit
 Allow the packaging and transmission of serial data until the specified force transmit time is met.

Force Transmit Time (ms)

Enable force transmit: The NPort will monitor the idle time between two characters. If the time is reached and there are no new characters are being received, the NPort will package all the data in the serial buffer and then send it on the Ethernet side. The number of this field is between 1 and 65535.

Step 4: Confirmation

Review and **SAVE** above settings to make them effective.

Home > Serial Port Settings > Operation Modes > Configure Port(s)

← Configure Port(s)

1 Mode Selection 2 Basic Settings 3 Advanced Settings 4 Confirmation

Selected Port: 1

Application: Socket
 Operation Mode: UDP

Destination Address Settings
 Destination Mode: Static destination

Destination 1
 Address Type: Single address
 Destination Address: 10.0.0.5
 Address Port: Start from 4001

Listen Port Settings
 Listen Port: 4001

Data Transmission Settings
 Data Packing: Disabled
 Force Transmit: Disabled


< BACK CANCEL SAVE

Pair Connection Applications

The Pair Connection application is designed for serial applications that keep the serial host and serial device connected. Here, the serial host cannot install any driver or socket program since it might not have Ethernet ports. But let's say the factory refurbishes, and the distance between the serial host and serial device increases significantly or maybe the network transitions to an Ethernet-based network. In this scenario, buying two NPorts with the Pair Connection application is a good fit.

Pair Connection Client Mode

With Pair Connection Application, set one NPort to Pair Connection Client mode to establish the connection and set the other NPort to Pair Connection Server mode to receive the request.



Step 1: Mode Selection

Select **Pair Connection** and **Pair Connection Client** modes.

The screenshot shows the 'Mode Selection' step of the configuration process. At the top, there are three tabs: '1 Mode Selection' (active), '2 Basic Settings', and '3 Advanced Settings'. Below the tabs, the text reads 'NPort Server Settings' and 'Assign the server address and port of the connected NPort to the serial port(s)'. There is a text input field for 'Server Address'. At the bottom, there is a label 'Assign server port(s) starting from' followed by a text input field containing '4001', and then 'to selected port(s)'.

Step 2: Basic Settings

Server Address: The Pair Connection Client will try to establish the TCP session with this IP address. Input an IP address or a domain name.

Assign server port(s) starting from: This is the TCP port number assignment for the serial port on the NPort. It is the TCP port number on the remote NPort to listen to requests from the Pair Connection Client. To avoid conflicts with well-known TCP ports, set the default to 4001.

Step 3: Advanced Settings

The screenshot shows the 'Advanced Settings' step of the configuration process. At the top, there are three tabs: '1 Mode Selection', '2 Basic Settings', and '3 Advanced Settings' (active). Below the tabs, the text reads 'Advanced settings can generally be used with default values. Customize the settings if needed.' Under the heading 'Connection Settings', there are two options: 'Enable TCP alive check' (checked) and 'Enable port buffering' (unchecked). The 'Enable TCP alive check' option has a sub-description: 'Allow the NPort to reset the TCP session by checking the receiving of the last TCP packet until the check time timeout.' Below this is a 'Check Time (min)' input field with the value '7'. The 'Enable port buffering' option has a sub-description: 'To prevent loss of serial data during an Ethernet disconnection, enable this function. Enabling port buffering means that RTS/DTR will always be set to on.'

Service providers always have limited resources. By enabling Real COM mode, the NPort allows access to connected serial devices. In the event of an accidental TCP connection failure, the resource could be indefinitely occupied until you restart the NPort. To prevent this from happening, the NPort will enable the **Enable TCP alive check time** function by default to verify if the existing connection is alive or not. If the session is not active and the timeout period (default value of 7 minutes) is reached, the NPort will end the session and make it available for other users/devices.

Enable TCP alive check time (default=7 min): The duration for which the NPort 5600-DT-G2 waits for a response to keep-alive packets before closing the TCP connection can be specified in this field. To verify connection status, the NPort 5600-DT-G2 sends keep-alive packets at regular intervals. If the packet goes unanswered by the remote host within the specified time, the NPort 5600-DT-G2 will terminate the TCP connection.


The screenshot shows the 'Data Transmission Settings' step of the configuration process. At the top, there are two tabs: 'Connection Settings' and 'Data Transmission Settings' (active). Below the tabs, there is a single option: 'Enable port buffering' (checked). The sub-description reads: 'To prevent loss of serial data during an Ethernet disconnection, enable this function. Enabling port buffering means that RTS/DTR will always be set to on.'

Compared with the serial bus, the Ethernet network is not stable. Poor cable contact or a damaged switch/router could cause it to be disconnected or broken. When this happens, the serial data cannot be transmitted over Ethernet because the receiver does not exist. As time passes, the serial data could be discarded and lost. If the serial data is important, you may enable the **Enable port buffering** function. The NPort can store serial data in its internal memory, which is 64 Kbytes.

Enable port buffering (default=No): To prevent serial data loss when the Ethernet connection is down, check the checkbox to enable port buffering. If you enable port buffering, RTS/DTR will remain on.


Step 4: Confirmation

Review and **SAVE** the above settings to make them effective.




Pair Connection Server Mode

With Pair Connection Application, set one NPort to Pair Connection Client mode to establish the connection and set the other NPort to Pair Connection Server mode to receive the request.




Step 1: Mode Selection

Select the **Pair Connection** and **Pair Connection Server** modes.



Step 2: Basic Settings

Assign TCP listen port starting from (default=4001): This is the TCP port the NPort listens to, which shall match the Pair Connection Client's setting. To avoid conflicts with well-known UDP ports, set the default to 4001.



✓ Mode Selection — ✓ Basic Settings — 3 Advanced Settings

Advanced settings can generally be used with default values. Customize the settings if needed.

Connection Settings

Enable TCP alive check
Allow the NPort to reset the TCP session by checking the receiving of the last TCP packet until the check time timeout.


Check Time (min)
7

Enable port buffering
To prevent loss of serial data during an Ethernet disconnection, enable this function. Enabling port buffering means that RTS/DTR will always be set to on.

Step 3: Advanced Settings

Service providers always have limited resources. By enabling Real COM mode, the NPort allows access to connected serial devices. In the event of an accidental TCP connection failure, the resource could be indefinitely occupied until you restart the NPort. To prevent this from happening, the NPort will enable the **Enable TCP alive check** time function by default to verify if the existing connection is alive or not. If the session is not active and the timeout period (default value of 7 minutes) is reached, the NPort will end the session and make it available for other users/devices.

Enable TCP alive check time (default=7 min): The duration for which the NPort 5600-DT-G2 waits for a response to keep-alive packets before closing the TCP connection can be specified in this field. To verify connection status, the NPort 5600-DT-G2 sends keep-alive packets at regular intervals. If the packet goes unanswered by the remote host within the specified time, the NPort 5600-DT-G2 will terminate the TCP connection.



Connection Settings Data Transmission Settings


Enable port buffering
To prevent loss of serial data during an Ethernet disconnection, enable this function. Enabling port buffering means that RTS/DTR will always be set to on.

Compared with the serial bus, the Ethernet network is not stable. Poor cable contact or a damaged switch/router could cause it to be disconnected or broken. When this happens, the serial data cannot be transmitted over Ethernet because the receiver does not exist. As time passes, the serial data could be discarded and lost. If the serial data is important, you may enable the Enable port buffering function. The NPort can store serial data in its internal memory, which is 64 Kbytes.

Enable port buffering (default=No): To prevent serial data loss when the Ethernet connection is down, check the checkbox to enable port buffering. If you enable port buffering, RTS/DTR will remain on.

Step 4: Confirmation

Review and **SAVE** the above settings to make them effective.




No Operation


To address cybersecurity concerns, users can set a serial port to No Operation if it is not connected to any serial devices. Disabling unused services can decrease cybersecurity risks.


Serial Parameters

Matching serial parameters between the serial device and the NPort device server is an essential factor for communication. Refer to the device manual to obtain its serial parameters. Then, navigate **Serial Port Settings > Serial Parameters** to modify the serial parameters.

Only if the NPort is configured as a **COM-based Control** application can you skip this step/section. The COM port software or TTY software will overwrite the serial parameters while it opens a COM port/TTY port.



Select Serial Port Settings > Serial Parameters in the navigation panel to configure the parameters for each serial port. Select the  button and then select **EDIT** to change the serial parameters on a specific serial port. The Edit Port window will open to change the existing parameters.



Edit Port 1

Interface
RS-232

Basic Settings

Baudrate (bps)
115200

Parity
None

Data Bits
8

Stop Bit(s)
1

Flow Control
None

Advanced Settings

Enable FIFO
Enabling FIFO results in increased throughput for serial communication.

CANCEL SAVE

If you want to change multiple serial ports simultaneously, select the checkboxes of the target ports and then click the **CONFIGURE** button. The Configure Port window allows you to set new values for all selected ports by displaying empty parameter fields.

<input checked="" type="checkbox"/> Port	Interface	Baudrate	Parity	Data Bits	Stop Bit(s)	Flow Control	
<input checked="" type="checkbox"/> 1	RS-232	115200	None	8	1	None	⋮
<input checked="" type="checkbox"/> 2	RS-232	115200	None	8	1	None	⋮

CONFIGURE

Configure Port(S)

Selected Port: 1, 2

Interface
-- Select One --

Basic Settings

Baudrate (bps)
-- Select One --

Parity
-- Select One --

Data Bits
-- Select One --

Stop Bit(s)
-- Select One --

Flow Control
-- Select One --

CANCEL SAVE

Basic Settings

Interface (default=RS-232): You may configure the serial interface to RS-232, RS-422, RS-485 2-wire, or RS-485 4-wire

Baudrate (bps) (default=115200): This field configures the port's baudrate. Select one of the standard baudrates from the drop-down box or select Other and input the specific baudrate of the serial device in the Value box.


Parity (default=None): This field configures the parity parameter.

Data Bits (default=8): This field configures the data bits parameter; 5, 6, 7, or 8 are supported.

Stop Bits (default=1): This field configures the stop bits parameter; 1 or 2 are supported.

Flow control (default=None): This field configures the flow control type, including RTS/CTS, DTR/DSR, Xon/Xoff, RTS Toggle and None. When setting the interface to RS-232, it supports all the above flow-control mechanisms. When setting the interface to RS-422, RS-485 2-wire or RS-485 4-wire, it only supports None and Xon/Xoff.

Advanced Settings



Enable FIFO:

The Enable FIFO function is enabled by default for improved data throughput. There are two situations where the user may choose to disable the Enable FIFO function by unchecking the checkbox.


- If the serial device does not have FIFO/buffer or does not support the flow control function. In this case, the serial device may not receive the serial data from the NPort on time, so some data might be dropped.
- If data latency is more important than data throughput. To achieve higher data throughput, data can be temporarily stored in the buffer, allowing for larger amounts of data to be sent at once. The downside is that the latency of a single data may be slower. If latency is important for the serial device to read data correctly, then you should consider disabling the Enable FIFO function.

This field enables or disables the 512-byte FIFO buffer. The NPort 5600-DT-G2 provides FIFO buffers for each serial port, for both the Tx and Rx signals.


Secure Connection

To face the increasing cybersecurity threats, you may want to consider how you can protect important data on the serial device. The communication distance on the serial bus is short and hard to steal (usually in a factory with a security guard). When using a device server to pass serial data to an Ethernet network, it is another story. An Ethernet network is more vulnerable than a serial bus. The NPort device server provides the ability to communicate on the Ethernet network.

Select **Serial Port Settings > Secure Connection** in the navigation panel to configure the **TCP Connection Type** for each serial port. You can also select multiple serial ports and select the **CONFIGURE** button to change them simultaneously.




TCP Connection Type



Option	Description
Unencrypted connection	Data sent through Ethernet will not be encrypted. This is the default value.
Encrypted connection	Data sent through Ethernet will be encrypted with TLS v1.2.
Encrypted and authenticated connection	Data sent through Ethernet will be encrypted with TLS v1.2, and the connection will be authenticated by certificate before the connection is established. Upload the certificate on the Remote Device Certificate tab for authentication if you choose this type.

Remote Device Certificate



Dashboard > Serial Port Settings > Secure Connection

Secure Connection

Secure connection supports Real COM, Reverse Real COM, TCP Server, TCP Client, and Pair Connection modes in TCP connection. Configure the TCP connection type as needed.
[Refer to the cipher suites for an encrypted connection.](#)


TCP Connection Type: **Remote Device Certificate**

The port(s) with encrypted and authenticated connections will verify the uploaded certificates.

File Name	Issued to	Issued by	Status
No certificate to display. Click <input type="button" value="UPLOAD"/> button to upload the certificate.			

Encrypting the TCP session safeguards the confidentiality of the serial data, but how can we ensure the authenticity of the network device being communicated with? It's possible that the server is fake and attempting to extract valuable data from the serial device. To avoid this, it is recommended to enable certificate-based authentication. The NPort will verify the user-uploaded certificate and request verification of the remote server's certificate before establishing a secure connection. Once both devices are confirmed as correct, they will establish an encrypted TCP session to safeguard the crucial serial data. To enable it, remember to select **TCP Connection Type** to **Encrypted and authenticated connection** and upload the certificate at **Remote Device Certificate** tab.

When switching to the **Remote Device Certificate** tab, select the **UPLOAD** button to upload your certificate for authentication.



Upload Certificate

Choose one or multiple certificates to upload. The number of certificates that can be uploaded is limited to 10.

No file chosen

Security

With cyberattacks growing in number and sophistication, device server vendors are adding functions geared towards protecting sensitive business and personal information. All the related functions are listed under the **Security** category.

Services

Based on different user scenarios, you may need different services to meet these requirements. Select **Security > Services** to enable/disable the services he needs or no need.

Home > Security > Services

Services

Set the software and hardware services by toggling the buttons or editing the options below.

Software Services

Web Console
TCP: Port 443

Serial Console
Command-Line Interface

SNMP Agent ⓘ
UDP: Port 161

MOXA Service ⓘ
RESTful API(TCP: Port 443), mDNS(UDP: Port 5353), LLDP.

Gratuitous ARP
Periodic to send gratuitous ARP

Hardware Services


Beeper

Reset Button on Device Only enable within 60s after booting [EDIT](#)

Software Services	Value	Default Value	Description
Web Console	Enable/Disable	Enable	This setting is to enable/disable the web console. To ensure security, the NPort 5600-DT-G2 device server only supports HTTPS console using TLS v1.2 or later. The web console provides all the settings that the NPort 5600-DT-G2 supports. We don't recommend a user disabling it.
Serial Console	Enable/Disable	Enable	This setting is to enable/disable the serial console on serial port 1 of the NPort 6150-G2/6250-G2. Log in to the serial console while the device server is booting up to configure the network settings, like the IP address. After setting the network settings, it is advisable to disable the serial console. This prevents accidental triggering of the console by the serial device during simultaneous boot-up.
SNMP Agent	Enable/Disable	Disable	This setting is to enable/disable the SNMP Agent service. If you want to use the SNMP protocol to monitor the status or change some configuration settings of the NPort 5600-DT-G2, enable the service. If your site doesn't match this scenario, disable it.
Moxa Service	Enable/Disable	Enable	This setting is to enable/disable Moxa proprietary service. NPort Windows Driver Manager, DSU-G2, and MXStudio are based on this service to work. You cannot use this software when Moxa Service is disabled.

Software Services	Value	Default Value	Description
WINS	Enable/Disable	Disable	This setting is to enable/disable the WINS service. Windows Internet Name Service (WINS) is the Microsoft implementation of NetBIOS Name Service (NBNS), a name server and service for NetBIOS computer names. If the service is not enabled in your network, keep it disabled.
Gratuitous ARP	Enable/Disable	Disable	This setting is to enable/disable the Gratuitous ARP service. In some applications, you may need the NPort 5600-DT-G2 to send broadcast packets to update the ARP table on the server. If you enable this function and set the send period, the NPort 5600-DT-G2 will periodically send broadcast ARP packets at the specified time interval.

Gratuitous ARP
Periodic to send gratuitous ARP

When selecting the edit button  of Gratuitous ARP service, set the time for the ARP packets. The default value is 300 seconds.

Edit Periodic Time

Periodic Time (sec)
300

CANCEL SAVE

Hardware Services	Value	Default Value	Description
Beeper	Enable/Disable	Enable	This setting is to enable/disable the beeper of the device. You will hear the beeper when the device is ready after a power cycle. If you don't want to hear the sound, you may disable the service.
Reset Button on Device	Only enable within 60s after booting up/Always enable	Only enable within 60s after booting up	By default, the device disables the reset button after booting up for 60 seconds to prevent someone from accidentally pushing the button and resetting the device to its default settings.

Reset Button on Device Only enable within 60s after booting

The EDIT button in the **Reset Button On Device** service allows you to specify when the reset button should be enabled. Either the button is enabled for just one minute after the device boots up, or it stays enabled indefinitely.

Reset Button On Device

Considering the possibility of an accidental operation, there are two modes for the reset button on device. You may set it according to your needs.

Mode


Only enable within 60s after booting

Always enable


CANCEL SAVE

Allowlist

An allowlist is a list of IP addresses or domains that are provided privileged access. Enabling this function limits the number of IP addresses that can access the device server, which can prevent unauthorized access from an untrusted network.



Before you enable the allowlist, add at least one rule to the table. And remember to make sure the host PC's IP address is on the list, or you may not access the web console of the device server.




Select the ADD RULE button to add a new rule. You may fill an IP Address or a domain name in the IP Address column and then input the subnet mask to allocate a range of IP addresses. We recommend you enable this function so that the new rules will be enabled while adding a new rule. If you don't want to enable it, remember to uncheck the checkbox **Enable this rule**.

Certificate


The NPort 5600-DT-G2 will automatically generate a self-certification for all the TLS sessions, including the web console (HTTPS), secure operation modes, and syslog-ng service.

If you have a company-generated or a third-party verified certification, select the MANAGE button to import the certification to mitigate the cybersecurity risks to the network.




When accessing the **Security > Certificate** page, it shows the status of the system certificate:

- Is the system certificate still valid? Or has it expired?
- Who requested the system certificate?
- Who issued the system certificate? If it is a self-certification, the IP address will be the NPort's IP address.
- When was the system certificate issued?
- When will the system certificate expire?



When you select the **MANAGE** button, there are three actions:


- **Download system certificate:** The browser or the software on a PC may request the target device to provide a valid certificate before establishing a secure connection. Here, download the system certificate from the NPort. and then upload it to the browser or the software. Then, a secure connection will be established.
- **Regenerate system certificate:** If the system certificate has expired or is no longer secure, regenerate the system certificate for new secure connections.
- **Import user certificate:** If you have a company-generated or a third-party verified certificate, import that certificate to the NPort to establish new secure connections.



When selecting the **MANAGE > Import user certificate**, select **the Choose File** button to find the certificate on the PC. Select the **IMPORT & RESTART** button to ensure the NPort will restart itself to use the imported certificate.


DoS Defense

As an edge device, the NPort may not be directly exposed to cyberattacks. The NPort 5600-DT-G2 Series includes basic defense mechanisms to safeguard itself against localized or limited cyber threats. For this reason, the DoS Defense function has been implemented and is enabled by default.



Login Settings

The NPort device server administrator may need to send messages to a user upon successful or failed login attempts. The administrator can edit related messages or functions here.



When you successfully log in to an NPort 5600-DT-G2 device server, the **Login Message** column will be shown. The message input by the administrator can be up to 256 characters long.

To communicate with users who couldn't log in, the administrator can opt for customized message mode and enter the message in the Message Text column. When the mode is set to default message, the NPort 5600-DT-G2 also offers a recommended message for the administrator to refer to.

Home > Security > Login Settings

Login Settings

Login Message Login Lockout Session Control

To prevent hackers from repeatedly attempting to log in and crack passwords, you can enable login failure lockout and adjust the necessary settings.

Enable login failure lockout

Max. Failure Retry (times)
5

Enable reset login failure counter
The login failure counter will reset and recalculate based on the period you have set.

Lockout Time (min)
5

SAVE

To prevent hackers from repeatedly attempting to log in and crack passwords, we recommend that you enable the Login Lockout function. It will be enabled by default.

Name	Value	Default Value	Description
Enable login failure lockout	Checked / uncheck	Checked	When checked, the Login Lockout function will be enabled.
Max. Failure Retry (times)	1 to 10	5	If the Login Lockout function is enabled, it sets the number of attempts a user has before being locked out. Let's say the value is 5; then, five password attempts are allowed. Regardless of whether the password is right or wrong on the sixth attempt, access to the device will be denied.
Enable reset login failure counter	Checked / uncheck	Unchecked	If this function is enabled, the user can wait a bit and then retry logging in. If this feature is turned off, the only option is to contact the administrator and request an account unlock.
Lockout Time (min.)	1 to 60	5	If the option to reset the login failure counter is turned on, it sets the waiting time for the user before another login attempt.

Home > Security > Login Settings

Login Settings

Login Message Login Lockout Session Control

Max. Login User for HTTPS (count)
3

Session Timeout (min)
60

SAVE

For security and resource arrangement reasons, the NPort will limit the usage of HTTPS sessions.

Name	Value	Default Value	Description
Max. Login User for HTTPS (count)	1 - 10	5	The number of users with different user accounts who can establish an HTTPS connection to the NPort.
Session Timeout (min)	1 - 1440	60	The time the NPort allows for inactivity when a user logs in before ending the HTTPS session


Account Management

For security reasons, different users need different accounts and privileges on one device. With the Account Management function of the NPort 5600-DT-G2 Series, administrators can easily add, delete, or change user account names. They can also assign access to specific function categories based on different user groups. Administrators can effectively manage passwords and login policies to ensure that only authorized users can use the device.

Accounts

In the NPort 5600-DT-G2 Series, the categories that you can access have a strong correlation with the user groups defined by the administrator(s) (for managing the groups, refer to the next section, Groups). Administrators are allowed to add user accounts to the NPort 5600-DT-G2 device by selecting the Create button on the **Accounts** page.

The **Create New Account** window will pop up for you to input account information and assign a password to the user. Also, the Administrator(s) shall assign a proper **Group** to users to limit their privileges of using the NPort 5600-DT-G2. To add/delete/edit the **Group**, go to the **Groups** section in the menu. The **password** rules can be set up in the **Password Policy** section.



Create New Account

Account Name
Moxa

Group
Administrator

Password

✖ Contains at least 8 characters

Confirm New Password

CANCEL SAVE

You may also select the More menu button on an existed user to edit the account's above information/settings.)

admin	Administrator	Active	2024-08-06	⋮
Users	Viewer	Active	2024-08-26	⋮

Change password

Change group

Deactivate


Delete

Change password

As an administrator, you can change every user's password. The Change Password window will appear. Input the new password twice and **SAVE** the new password. The password will be changed.

As a general user, you can only change your password. Select the More menu button in your account name and select **Change password** so that the Change password window opens. Input the new password twice and **SAVE** the new password. You will change the password.

Change group



Change Group


Account Name: Users
Date of Creation: 2024-08-26

Group
Viewer

CANCEL SAVE

Only the administrator can change the group of a user account. Select the More menu button in the target account name and select **Change group** to open the Change Group window. On the drop-down menu, select the group you want to move and select the **SAVE** button. The user account will move to a new group.

Deactivate



Deactivate Account


Deactivating the account will result in the account being blocked from accessing the system.

Are you sure you want to deactivate the account "Users" ?

CANCEL DEACTIVATE

Only the administrator deactivates a user account. When deactivating a user, it still exists on the NPort, but the user cannot log in to the device. Only when the administrator activates the user account can the user log in. Select the More menu button on the target account name and then **Deactivate** to open the Deactivate Account window. Select the **DEACTIVATE** button to deactivate the user account.

Delete



Delete Account

Deleting the account will remove the account permanently from the system and revoke all access.

Are you sure you want to delete the account "Users" ?

CANCEL DELETE

Only the administrator can delete a user account. When deleting a user account, it will be removed from the NPort. Select the More menu button on the target account name and select **Delete** to open the Delete Account window. Select the **DELETE** button to delete the user account.

Groups

Access different function categories with the NPort 5600-DT-G2 based on their group affiliation. Customizing access permissions for different groups is restricted to the group administrator by default, or any group that is granted Read/Write permission on the Account Management category.

A maximum of four user groups can be created, with up to four user accounts per group. By default, the NPort 5600-DT-G2 has the Administrator, Operator, and Viewer user groups built in.

- The Administrator group cannot be removed, and the name cannot be changed.
- The Operator group can be removed, and the name can be changed.
- The Viewer group cannot be removed, but the name can be changed.

Selecting the Create button on the Groups page creates a new group.

Group	Number of Accounts	TACACS+ Privilege Level
Administrator This group is designed for the supervisor of the device. The accounts of this group will have full privileges. This is a built-in group and cannot be modified or deleted.	1 account(s)	15
Operator This group is designed for the maintainer of the device. The accounts of this group can modify and monitor most of the settings and troubleshooting functions.	0 account(s)	1
Viewer	1 account(s)	--
Sample	0 account(s)	--

Create New Group

Basic Information

Group Name

Group Description - Optional

0/300

Console Permissions

System Settings
-- Select One --

Network Settings
-- Select One --

Serial Port Settings
-- Select One --

Security
-- Select One --

Account Management
-- Select One --

Maintenance
-- Select One --

Diagnostics
-- Select One --

CANCEL SAVE

Group Name: The name of the group the user is going to create. You may need to give the group name. When the NPort enables a central account management mechanism with RADIUS, the group name shall match the Filter-ID parameter on the RADIUS server.

Group Description—Optional: Describe the group to understand the purpose for creating this group. For example, creating a group named "Operator" with the description: "This group is designed for the maintenance of the device. The accounts of this group can change and monitor most of the settings and troubleshooting functions." This is an optional column.


Console Permissions: Assign privileges for different categories using the drop-down menu. There are three types of permissions:

- **No Display:** The user in this user group will not see this function group when accessing the NPort 5600-DT-G2.
- **Read Only:** The user in this user group can only view the function/setting in this function group but cannot make modifications.
- **Read Write:** The user in this user group can view the function/setting in this function group and make modifications.

There are seven categories:


- System Settings: Includes all the settings for the NPort itself, like the server's name and notification.
- Network Settings: Includes all the settings related to the Ethernet port, like the IP address and subnet mask.
- Serial Port Settings: Includes all the settings related to the serial port, like the operation mode and serial parameters.
- Security: Includes all the settings related to cybersecurity, like the allowlist and login settings.
- Account Management: Includes all the settings related to accounts and groups, like create/modify/delete an account or group.
- Maintenance: Includes all the settings related to routine maintenance jobs, like firmware upgrades and configuration import/export.
- Diagnostics: Includes all the functions that help the user troubleshoot, like device status and traffic monitoring.

Select the **More menu** button on an existing group to edit its access privileges or delete the group.



Password Policy

With the PC platform becoming increasingly powerful, users worry about the risk of password brute-force attacks. The administrator can mitigate cybersecurity risk by enabling the Password Policy function to boost password complexity.



Parameter	Setting	Default	Description
Password minimum length	8 to 256 characters	8	Define the minimum length of the login password for NPort 5600-DT-G2.
At least one digit (0-9)	Enable/Disable	Disable	The password must contain at least one number (0 to 9) when enabling this parameter.
Mixed upper- and lowercase letters (A to Z, a to z)	Enable/Disable	Disable	The password must contain an upper- and a lowercase letter when enabling this parameter.
At least one special character (~!@#\$%^&*-_!;:;,.<>[]{}())	Enable/Disable	Disable	The password must contain at least one special character when enabling this parameter.
Enable password lifetime	Enable/Disable	Enable	Enhancing account security by setting a password lifetime.
Password Lifetime (day)	1 to 180 days	90 days	Users can set a specific lifetime for their passwords and receive system notifications to change them if the option is enabled.

On completion of the settings, select the **SAVE** button to save the changes and make them effective.

For setting related to failure logins, for example, to lock out an IP address after five failure password inputs, find the **Security > Login Settings > Login Lockout** section.

Maintenance

Operators may have to perform routine tasks every month or quarter to maintain the system when it is online. NPort categorizes these actions as maintenance to simplify their completion for the user.

Config. Import/Export

You may want to back up the configuration settings of the NPort to access the **Maintenance > Config. Import/Export** to accomplish it.


File Authentication

Because of security concerns, the NPort 5600-DT-G2 can no longer export a configuration file without a password. Select the **MANAGE** button to set a password for the exported configuration file.

When selecting the **Set custom password**, give a customized password for the exported configuration file. The NPort 5600-DT-G2 will use this password to decode the imported configuration file. The password policy for the configuration file allows for 8 to 64 characters and does not have any complex requirements.


When selecting the **Reset to default password**, the NPort 5600-DT-G2 will use the default password to encode or decode a configuration file.

Import/Export the Configuration File



The screenshot shows the 'Import' tab selected. At the top, there are two tabs: 'Import' (active) and 'Export'. Below the tabs, there is a 'Choose File' button and the text 'No file chosen'. At the bottom, there is a teal 'IMPORT' button.

On the **Import** tab, select the **Choose File** button to choose the configuration file you want to import.




The screenshot shows the 'Export' tab selected. At the top, there are two tabs: 'Import' and 'Export' (active). Below the tabs, there is a message: 'The exported configuration file is not included:' followed by a bulleted list: 'System log', 'Certificate on the system', 'Custom password of the file authentication', and 'Custom profile of the default setting'. At the bottom, there is a teal 'EXPORT' button.

At the **Export** tab, select the **EXPORT** button to choose where you want to save the configuration file.

Firmware Upgrade


It's highly advisable to always upgrade to the latest firmware version because of the increasing number of cybersecurity threats. Consistently using the latest firmware helps reduce cybersecurity risks.

When you want to upgrade the firmware, select **Maintenance > Firmware Upgrade**, and then the **Choose File** button to find the firmware file. Select the **UPLOAD** button to proceed.




The screenshot shows the 'Firmware Upgrade' page. At the top, there is a breadcrumb trail: 'Home > Maintenance > Firmware Upgrade'. Below that is the title 'Firmware Upgrade'. Underneath, it says 'Current Firmware Version: v1.0.0 Build 24080808'. A paragraph follows: 'Choose the firmware file and upload it to the device. You can download the firmware file from the product page of [Moxa official website](#).' Below this is a 'Choose File' button and the text 'No file chosen'. At the bottom, there is a teal 'UPLOAD' button.

Ensure the device remains powered on and select the **UPLOAD & RESTART** button. The device will upgrade to the new firmware version and restart itself.



The screenshot shows a web interface for a 'Firmware Upgrade'. At the top, there is a breadcrumb trail: 'Home > Maintenance > Firmware Upgrade'. The main heading is 'Firmware Upgrade'. Below this, it states 'Current Firmware Version: v1.0.0 Build 24081513'. A paragraph of text reads: 'Choose the firmware file and upload it to the device. You can download the firmware file from the product page of Moxa official website.' There is a file input field with the text 'Choose File' and the filename 'nport6000g2_r...ld_24081513.bin'. Below the input field is a teal 'UPLOAD' button. A modal dialog box titled 'Upload File' is open in the foreground. It contains the text: 'Please ensure that the device remains powered on during the process. The new firmware version will come into effect after restarting.' At the bottom of the dialog are two buttons: 'CANCEL' and 'UPLOAD & RESTART'.


When the login page appears, it signifies the completion of the firmware upgrade process.



The diagram illustrates the transition from a system restarting screen to a login page. On the left, a box represents the 'System restarting...' screen. It features the MOXA logo at the top, followed by the text 'System restarting...'. Below this is a yellow warning box with the text: 'Warning Do not leave the page during the process. The system will redirect to the login page later.' At the bottom right of this box is a power button icon with three dots below it. A large black arrow points from this box to the right, where a second box represents the login page. This page also features the MOXA logo at the top. Below it is the text 'Log in to NPort-5650-16-DT-J-G2_0029'. There are two input fields: 'Account Name' and 'Password'. The 'Password' field has a toggle icon for visibility. Below the input fields is a link for 'Forgot password?'. At the bottom right is a teal 'LOG IN' button.

Reset to Default

This function will reset all the NPort 5600-DT-G2's settings to the factory default values. All previous settings, including the console password, will be lost. If you wish to keep the NPort 5600-DT-G2 IP address, netmask, and other network settings, make sure **Keep current device network settings** is checked before loading the factory defaults.



Home > Maintenance > Reset to Default

Reset To Default


The initial default setting is the factory default, and it can also be set as a custom profile using the current device configuration. Click "RESET" to restore the device to its default setting.

Default Setting	MANAGE
Factory default	MANAGE

Keep current device network settings
Preserved items include mode, IP address, netmask (IPv4), prefix (IPv6), gateway, and DNS.


RESET

Machine builders and system integrators may have their preferred default values on the NPort. The NPort 5600-DT-G2 provides **Set as custom profile** function to allow users to set the settings as the default setting. In this case, when the customer triggers the Reset to Default function, the device will restore the custom default settings. The hardware reset button is the only way to reset it to the Moxa factory default. Selecting the **MANAGE** button and selecting **Set as custom profile** will enable this function. The configuration file will be saved as default when the customer starts a reset using the web console, DSU-G2, or MCC Tool.



Restart

If you want to restart the device, access **Maintenance > Restart** and select the **RESTART** button. The device will restart itself.



Home > Maintenance > Restart

Restart

Click "RESTART" button to restart the system.


RESTART

Diagnostics

System integrators and technical engineers may encounter issues when configuring a new application or receiving error reports during system operation. When that happens, you might find it helpful to have some diagnostic tools for troubleshooting.


In the Navigation Panel, the Diagnostics section brings together all the necessary functions for quick troubleshooting.

Quick System Check




When system integrators or technical engineers encounter issues while configuring a new application or receiving error reports during system operation, the first step is often to verify whether the device itself is functioning properly.

To facilitate this, the NPort 5600-DT-G2 Series includes a **Physical Serial Test** function that helps determine if the device is operating correctly. Before starting the test, refer to [Appendix A](#) for instructions on creating your own loopback connectors to connect the serial ports, or [Appendix B](#) for information on purchasing ready-made loopback connectors - LB-DB9F-G-01 for DB9 serial ports, LBRJ45-G-01 for RJ45 serial ports and LB-RJ5010P-G-01 for 10-pin RJ50 serial ports.



After connecting the loopback connectors, select **START TEST**, then select the serial port you want the device to check. Alternatively, choose **All ports** to test all available serial interfaces. Next, select the **TEST** button to begin the procedure. Once the test is complete, the system will display the results, which can be exported or captured as a snapshot for reference or for discussion with Moxa Technical Support.


The Application Analysis function helps diagnose communication issues by analyzing both serial and network traffic in the operational environment. Before starting the test, ensure that the application, which connects and communicates with the NPort, is running, and that all serial devices connected to the NPort's ports are powered on. The system will then monitor data received from both the host PC and the serial devices to determine which side may be causing the communication issue.



Select **START ANALYSIS**. Next, select the serial port you wish to test and then **ANALYZE** to begin the procedure. Once the test is complete, the system will display the results, which can be exported or captured as a snapshot for reference or for further discussion with Moxa Technical Support.


Support

If you need direct support from Moxa, you can find it on the Diagnostics and Support page. There, we provide a list of recommended information to collect before contacting Moxa, as well as contact information for seeking assistance.



Product Information

Find here the basic information of the NPort device server, including the model name, serial number, and firmware version of the NPort 5600-DT-G2 device.



Diagnostic Information

Previously, users would typically reached out to Moxa customer service initially, and the engineer would then request additional information for problem analysis. For the NPort 5600-DT-G2 Series, we advise users to gather diagnostic information and send it along with their inquiry to Moxa customer service. This can make it simpler for the customer service engineer to pinpoint the root cause of the problem.

Download Diagnostic Information

Info
To maintain security, please delete the file after it has been sent to avoid any potential leaks of information.

By accepting this privacy announcement, you consent to the automatic collection of the following information:

- Model name
- Firmware version
- Serial number
- System uptime
- RTC time
- Log file
- Configuration file
- Monitor data (serial-to-network connection, serial port statistics, network connections, and network statistics)

If you agree, the data will be collected and made available in a file for download. The file is intended solely for troubleshooting assistance. For your security, please be aware that the file will be encrypted, and the device won't keep a copy after downloading.

I consent to the collection of the data and understand its purpose.

CANCEL **DOWNLOAD**

The Download Diagnostic Information window will open and list what information on the NPort device server will be collected/downloaded. Select **DOWNLOAD** to save the data after providing your consent for collection. The diagnostic information is encrypted to ensure it is secure when delivered over the Internet and can only be unzipped by Moxa engineers for troubleshooting purposes. Access will not be granted without a password.

To verify this information, use the NPort device server's web console.

Contact Support

Contact Support


For any assistance, please contact your distributor or Moxa technical support:

- [Distributor finder](#)
- [Moxa technical support](#)


After downloading the diagnostic information, you can find the contact window by selecting the **Distributor finder** or **Moxa technical support**, which will guide you to the corresponding resources on the official website.

System Log

It is very important to record the activities of a device. At the System Settings > Notification page, configure which events will be recorded. Under the **Diagnostics > System Log > Log View** tab, find the recorded events on the NPort device server. Under the **Log Settings** tab, set the advanced settings for the local system log.




The system will record an event under these columns: Severity, Category, Event Name, and Timestamp. You may find more information in the **System Settings > Notification** section. The event list is in the appendix.




Select the arrow icon  to read more details about the event.

The NPort device server provides some management functions for you to easily read the events.




FILTER: Filters the event by Severity, Category, Event Name, or Timestamp.



A filter dropdown menu with a search bar and an 'APPLY' button. The dropdown is open, showing a list of filter options: Severity, Category, Event Name, and Timestamp (Date). The 'Severity' option is currently selected and highlighted.

CLEAR: Deletes all system logs on the device.




A dialog box titled 'Clear System Log'. It contains the text: 'This action is irreversible and will result in the deletion of all system logs on the device. Are you sure that you want to proceed?'. At the bottom right, there are two buttons: 'CANCEL' and 'CLEAR'.

EXPORT: Exports the system log for troubleshooting.

REFRESH: Refreshes the logs on the panel.

Under the Log Settings tab, you will see the **Current Log Capacity** displayed as a percentage for reference. Because the system stores events on local flash memory, it limits the number of events that can be saved. Select the **EDIT** button to manage the settings.



The 'System Log' interface showing the 'Log Settings' tab. It displays 'Log Settings' with a green checkmark and '50 enabled event(s)'. Below this, it shows 'Current Log Capacity: 3%' and 'Log Capacity Policy: Overwrite the oldest log'. An 'EDIT' button is visible in the top right corner, which has opened a dropdown menu with options for 'Events Settings' and 'Log Capacity Settings'.

Events Settings

Select the events you would like to save on the local system log.

Home > Diagnostics > System Log > Events Settings

← Events Settings

Select the events you would like to save in the system log. The events can be sorted by severity.
[Refer to the details of the severity](#)

Severity: Error Warning Notice Informational SEARCH

System (11) Network (7) Security (17) Maintenance (8) Serial (7)

<input type="checkbox"/>	Event Name	Severity
<input checked="" type="checkbox"/>	Firmware ready	Notice
<input checked="" type="checkbox"/>	User trigger reboot	Notice
<input type="checkbox"/>	Configuration changed	Informational
<input checked="" type="checkbox"/>	Configuration changed failed	Notice
<input type="checkbox"/>	NTP success	Informational
<input checked="" type="checkbox"/>	NTP fail	Warning
<input type="checkbox"/>	Manual setting time success	Informational
<input checked="" type="checkbox"/>	Email fail	Notice
<input checked="" type="checkbox"/>	SNMP inform fail	Notice
<input checked="" type="checkbox"/>	Email service is back	Notice

SAVE

Find more information in the **System Settings > Notification** section. Also, the event list is in the appendix.

Log Capacity Settings

Home > Diagnostics > System Log > Log Capacity Settings

← Log Capacity Settings

Capacity Management

Current Log Capacity: 3%

The maximum number of system logs that can be stored on the device is 10,000. You may manage the log capacity by clearing all system logs.

CLEAR

Policy Settings

Please select the overwrite policy when the log capacity reaches its limit.

Overwrite Policy

Overwrite the oldest log

Stop recording the log

The system will notify or log the "log threshold reached" event according to the value set below.

Capacity Threshold (%)

80

SAVE

Capacity Management: The NPort 5600-DT-G2 provides 10,000 audit records. Select the **CLEAR** button to clear the local system log when it's getting full.

Policy Settings: When the log capacity reaches its limit, decide what action the NPort should take because of the limited recording system log capacity.

- Overwrite the oldest event log
- Stop recording events

Capacity Threshold (%): The system will notify you or record an event "log threshold reached" when the log capacity reaches the value set here. The default value is 80.

Operation Mode Statistics

The key feature of an NPort device server is transmitting serial data to the Ethernet network and vice versa. Everything that happens on the serial interface will be recorded here, **Diagnostics > Operation Mode Statistics**, to help the user understand the serial data transmitted/received or the modem status changes.

Home > Diagnostics > Operation Mode Statistics


Operation Mode Statistics

The information below provides an overview of the operation mode status. For detailed information on each port, please access the "Port" link within the list.

Real-time data displaying ... [RESET COUNTERS](#)

Port	Operation Mode	Connection Status	Ethernet Tx / Serial Rx (Byte)	Serial Tx / Ethernet Rx (Byte)	Serial Errors (Count)
> Port 1	Real COM	Disconnected	0 / 0	0 / 0	0
> Port 2	Real COM	Disconnected	0 / 0	0 / 0	0


- The Operation Mode statistics contain the operation mode, connection status, the transmitted/received packets on Ethernet and serial connections, and serial errors. The status or numbers for each port and column are shown here.
- Port: The serial port number of this NPort. When selecting the port, there are more details.
- Operation Mode: The operation mode that is set at the specific serial port.
- Connection Status: Whether the Ethernet session is connected
- Ethernet Tx / Serial Rx (Byte): The Ethernet port and the serial port recorded a total of transmitted bytes and received bytes, respectively. Normally, these two numbers ought to match. If the Ethernet session disconnects, the number will reset.
- Serial Tx / Ethernet Rx (Byte): The serial port and the Ethernet port recorded a total of transmitted bytes and received bytes, respectively. Normally, these two numbers ought to match. If the Ethernet session disconnects, the number will reset.
- Serial Errors (Count): If the NPort detects an error in the received serial data (1 byte), for example, a frame error or parity error, it increments this counter by 1.



When selecting a specific port number, the Port window will open with the information below.

Serial Parameters tab:

This tab displays the current settings of the serial parameters, such as the interface, baudrate, and so on.



Serial Connections tab:

This tab displays the current statistics of the serial port:

- **Serial Total Tx:** The amount of data transmitted on the serial port since the device was powered up. The number resets when performing a power cycle.
- **Serial Total Rx:** The amount of data received on the serial port since the device was powered up.. The number resets when performing a power cycle.
- **Serial Tx (Byte):** The amount of data transmitted on the serial port since the TCP session is connected. The number resets when the TCP session disconnects.
- **Serial Rx (Byte):** The amount of data received on the serial port since the TCP session is connected.. The number resets when the TCP session disconnects.
- **Frame Error (Count):** When NPort receives a byte of serial data, it will check if the frame format matches the serial parameters. If not, it will count as one frame error.
- **Parity Error (Count):** When NPort receives a byte of serial data, it will check if the parity value is correct. If not, it will count as one parity error.
- **Overrun Error (Count):** If the serial device sends data too quickly for the NPort to read, resulting in dropped data bytes, it will be considered an overrun error.

- **Break (Count):** When the NPort receives a break signal, it will count it as one break.
- **Serial Signal:** Displays the status of all modem signals, including DSR, DTR, RTS, CTS and DCD.

Home > Diagnostics > Operation Mode Statistics > Port 1

← Port 1

Operation Mode: Real COM (Secure)

Serial Parameters Serial Connections **Ethernet Connections**

Real-time data displaying ...

Overview

Connections	Ethernet Tx (Byte) ⓘ	Ethernet Rx (Byte) ⓘ	Buffering (Byte) ⓘ	Strip Delimiter (Byte) ⓘ
0	0	0	0	0

Connections

IP Address	Connection Tx (Byte)	Connection Rx (Byte)	TCP State	Cipher Suite
No data to display.				

Ethernet Connections tab:

This tab displays the current statistics of the Ethernet port related to serial communications:

- **Connections:** The number of TCP sessions established on this serial port.
- **Ethernet Tx (Byte):** The amount of data transmitted on the Ethernet port since the TCP session was established. The number will reset when the TCP session disconnects. The number needs to match the Serial Rx (Byte). It is easy to check this on the **Diagnostics > Operation Mode Statistics** page.
- **Ethernet Rx (Byte):** The amount of data received on the Ethernet port since the TCP session was established. The number will reset when the TCP session disconnects. The number needs to match the Serial Tx (Byte). It is easy to check this on the **Diagnostics > Operation Mode Statistics** page.
- **Buffering (Byte):** Byte numbers are still stored in the NPort buffer. If the numbers above don't match (Ethernet Tx and Serial Rx or Ethernet Rx and Serial Tx), it could be because there are still some data bytes in the buffer.
- **Strip Delimiter (Byte):** If you enable the Delimiter function with the Strip delimiter process, the total dropped delimiters will be recorded here.

The Connections sheet displays more detailed information about the TCP sessions:

- **IP Address:** This column displays the IP address connected to the NPort.
- **Connection Tx (Byte):** The amount of data transmitted on the Ethernet port since the TCP session was established. The number resets when the TCP session disconnects. The number needs to match the Serial Rx (Byte). It is easy to check this on the **Diagnostics > Operation Mode Statistics** page.
- **Connection Rx (Byte):** The amount of data received on the Ethernet port when the TCP session was established. The number resets when the TCP session disconnects. The number needs to match the Serial Tx (Byte). It is easy to check this on the **Diagnostics > Operation Mode Statistics** page.
- **TCP State:** Displays the status of this TCP session, which may be CLOSED, LISTEN, ESTABLISHED, CLOSING and TIME-WAIT.
- **Cipher Suite:** If the TCP session has the encrypted connection feature enabled (Serial Port Settings → Secure Connection), this column will show the cipher suite used for the TCP session.

Network Monitor

The key feature of an NPort device server is transmitting serial data to the Ethernet network and vice versa. Everything that happens on the Ethernet interface will be recorded here, **Diagnostics > Network Monitor**, to help you understand the Ethernet data transmitted/received.

Home > Diagnostics > Network Monitor

Network Monitor

Network Statistics Network Connections

Real-time data displaying ..

Ethernet Packet Count

Direction	Unicast	Broadcast	Multicast	Error
Sent	2437737 (+2/s)	5 (+0/s)	9 (+0/s)	0 (+0/s)
Received	8603682 (+12/s)	5431646 (+10/s)	1159879 (+0/s)	635742 (+0/s)

Protocol Packet Count

TCP
 UDP
 ICMP
 IPv4
 IPv6
 PPP

Sent	Received	Drop	Retransmitted	Receive RST
1583934 (+2/s)	4252706 (+4/s)	11941 (+0/s)	8 (+0/s)	9986 (+0/s)

Network Statistics tab:

The Ethernet Packet Count sheet separates the Ethernet data in two directions, Send and Received, to count the number of unicasts, broadcasts, and multicasts. If there are any error bytes, the Error column will count them.

The Protocol Packet Count sheet separates the Ethernet data by different protocols to count the numbers of TCP, UDP, ICMP, IPv4, IPv6 and PPP.

Network Connections tab:

This tab displays the status of all TCP sessions.

Home > Diagnostics > Network Monitor

Network Monitor

Network Statistics **Network Connections**

Real-time data displaying ..

Protocol	Recv-Q	Send-Q	Local Address	Foreign Address	State
TCP	0	0	0.0.0.0:950	0.0.0.0:0	LISTEN
	0	0	AF_PACKET		
TCP	0	0	:::63512	:::0	LISTEN
TCP	0	0	:::36418	:::0	LISTEN
TCP	0	0	:::56438	:::0	LISTEN
TCP	0	0	0.0.0.0:443	0.0.0.0:0	LISTEN
TCP	0	0	:::443	:::0	LISTEN

Ping

The Ping function is a good tool for troubleshooting. Engineers can use the NPort device server in this tool to verify the status of network nodes.

Directly input the IP address and select the PING button. The NPort will check whether the target node can respond to the ping request and display the result.

Dashboard

Home > Diagnostics > Ping

Ping

Enter the IP address or domain name for testing. Click the "PING" button and wait for the results.

Remote Host Destination Address

10.160.122.41

PING

Results

```
Reply from 10.160.122.41: bytes=32 icmp_seq=0 ttl=124
time=7 ms
Reply from 10.160.122.41: bytes=32 icmp_seq=1 ttl=124
time=9 ms
Reply from 10.160.122.41: bytes=32 icmp_seq=2 ttl=124
time=12 ms
Reply from 10.160.122.41: bytes=32 icmp_seq=3 ttl=124
time=8 ms
```

System Settings
Network Settings
Serial Port Settings
Security
Account Management
Maintenance
Diagnostics
Support
System Log
Operation Mode Statistics
Network Monitor
Ping
Traffic Monitor

Traffic Monitor

The key feature of an NPort device server is transmitting serial data to the Ethernet network and vice versa. To troubleshoot, you must check if the Ethernet side correctly transfers the serial data. Previously, the customer service engineer had the option of using a third-party tool to indirectly check the data and provide an answer. Engineers can now use the **Traffic Monitor** function to compare recorded serial and Ethernet data.

Dashboard

Home > Diagnostics > Traffic Monitor

Traffic Monitor

Select the port(s) to be monitored for real-time traffic data, enabling the detection of connection problems. The existing traffic data will be cleared automatically when leaving or restarting the page.

Port(s)
-- Select Port(s) --

START

Hex ASCII

Auto scroll

FILTER CLEAR EXPORT

Time	Port	Direction	Remote Device	Length (Byte)	Data
No data to display. Select port(s) and click "START" to monitor the traffic.					

System Settings
Network Settings
Serial Port Settings
Security
Account Management
Maintenance
Diagnostics
Support
System Log
Operation Mode Statistics
Network Monitor
Ping
Traffic Monitor

As a troubleshooting tool, it may not be proper to monitor normal communication for a very long time because of the limited local memory size. Moxa recommends that the engineer use this tool to capture both abnormal and normal communication for a few minutes, allowing them to compare and analyze it.

To initiate capturing, choose the target port and select the START button. The transactions captured will be shown below. Decide whether to view the data as HEX or ASCII.

After finishing the capture, you have the option to select the FILTER button to narrow down the data for analysis or select the EXPORT button to save the transactions for further analysis by Moxa customer service.

8. Mass Deployment/Maintenance

Once you complete the settings on a device server, you may need to deploy those settings to multiple devices or sites. Moxa provides the GUI tool Device Search Utility v3.0 or the CLI tool Moxa CLI Command Tool, MCC Tool, to meet this requirement.

After setting up the devices at the locations, the maintainer might need to perform routine tasks regularly to run the system. This includes tasks such as firmware upgrades or password updates. The Device Search Utility v3.0 and MCC Tool can assist the maintainer in carrying out these tasks effortlessly.

Mass Configuration With GUI Tool: Device Search Utility v3.0 or Later


The Device Search Utility v3.0 is a web-based utility. Make sure the operating system and browser versions are compliant with the following versions before using the tool:


- Chrome:
 - For Windows 7, 8/8.1, Server 2012 and Server 2012 R2: Chrome 109 and later
 - For Windows 10 and later, Server 2016 and later: All Chrome versions
- Firefox:
 - For Windows 7 and later versions, Server 2012 and later versions: All Firefox ESR versions
- Edge:
 - For Windows 7 and later versions, Server 2012 and later versions: All Firefox ESR versions



Execute the Device Search Utility and select the Search Device button to find the target NPort(s). Remember to unlock them before any further action.

Import/Export Configuration

Select the NPort device server(s) to import/export configuration and then move the mouse to More functions to choose the  Import Configuration function.



Import Configuration is to import one configuration file to one or more devices of the same model. Select the BROWSER... button to find out where the configuration file is saved.

Import Configuration

Choose the configuration file to upload and import.

Configuration File

Keep current device network settings
Preserved items include mode, IP address, netmask (IPv4), prefix (IPv6), gateway, and DNS.

Keep the Current Device Network Settings

If the target NPort device server(s) already has the proper IP address(es) configured, you may choose to retain the existing network settings for the device(s). Select the option.

After importing the configuration, Device Search Utility will display success or failure in the Status and Message columns for each device.

Info: It may take a while to execute this process, please wait for it to end before performing other actions.

Execution is completed !

Device Name	Model Name	Status	Message	Last Updated Time
NP5210A_8205	NPort 5210A	Failed	File format incorrect.	Feb 06, 2024 10:08:59
NP5210A_8295	NPort 5210A	Success	Success.	Feb 06, 2024 10:08:59


Items per page: 10 1 - 2 of 2

Your device may restart again to make the configuration effective, and it will stop your work in progress.



NOTE

For the cause of failure, refer to the **DSU** User Manual Appendix: Error Messages.

For exporting the configuration file(s), you can also find the  Export Configuration function under the More functions button.

Export Configuration is used to export the configuration file from one or more devices with the same model. When exporting only one device, the file format may be *.ini, *.dat, *.txt, *.cfg, *.dec. The filename will be [ModelName] - [IP] _ [Date] .xxx, e.g., NPort6150-10.123.10.1_220724.ini.

When exporting multiple devices, the system will zip the configuration files.

Import Certificate

To build a more secure or a zero-trust network environment, you may want to set up a public key infrastructure (PKI). The certificate needs to be imported onto all network devices for this scenario. To simplify the loading process, the Device Search Utility supports importing certificates to multiple NPort device servers.


Find the  Import Certificate function under the More functions button.

Import Certificate is to exchange certificate files to one or more devices to establish secure command/data transferring.

Step 1: Select NPort G2 models


Step 2: Import certificate file

Step 3: Import and restart



Firmware Upgrade

The increasing convergence of IT and OT poses a cybersecurity risk as more OT network devices connect to office networks. Upgrading the firmware version to the latest one is crucial for all network devices. To meet this requirement, the Device Search Utility supports firmware updates on multiple NPort device servers.

Find the  **Firmware Upgrade** function under the **More functions** button. **Firmware Upgrade** is to send one firmware file to one or more devices of the same model. The firmware file extension normally comes with .ROM.

Step 1: Select NPort G2 models

Step 2: Import firmware file

Step 3: Imported, and the device will restart.

Mass Configuration with CLI tool: MCC Tool

The MCC Tool is a command-line utility based on the Windows and Linux platforms. Make sure you have downloaded the correct file for your operating system.

Unzip the file and install the MCC Tool. Execute the MCC Tool from the command line to manage the NPort device servers in the network.

Import/Export Configuration

Import/export the device configuration for a specific device or a range of devices through the device list file. The password must be specified by the parameter or by the device list file. Device configurations are stored in individual files, using device type, IP address, and file creation date as the filename. The result log is directly printed on the screen, or you can specify a result_log file for it.

```
MCC_Tool -cfg -ex -i [ip_address] -u [user] -p [password] -dk [key] -l [result_log]
```

```
MCC_Tool -cfg -ex -d [Device_list] -l [result_log]
```

```
MCC_Tool -cfg -ex -d [Device_list] -l [result_log] -t [timeout_value]
```

```
MCC_Tool -cfg -im -i [ip_address] -u [user] -p [password] -dk [key] -f [cfg_file] -l [result_log] -n -nr
```

```
MCC_Tool -cfg -im -d [Device_list] -l [result_log] -n -nr
```

```
MCC_Tool -cfg -im -d [Device_list] -l [result_log] -t [timeout_value]
```

Parameters Description:

Command	Function	Remark
-cfg	Execute actions related to configuration	
-ex	Export the configuration file	
-im	Import the configuration file	
-i	Device IP address (ex. 192.168.1.1)	
-d	Device list	
-u	Device's user account for login	
-p	Device's password for login	
-dk	<p>When Exporting configuration: The command decrypts the exported file with the pre-shared key.</p> <ul style="list-style-type: none"> If this parameter is not used, the exported file will be encrypted by the pre-shared key set on the firmware of the device. If this parameter is used, the exported file will be decrypted to a clear-txt file for editing. <p>When Importing configuration: If the configuration file that needs to be imported is encrypted, the command is needed with pre-shared key.</p> <ul style="list-style-type: none"> If the import configuration file is without -n, the MCC tool will ignore -dk (won't return -11). If the import configuration file is with -n, the MCC tool will use pre-shared key to decrypt the encrypted file. Therefore, if the key is wrong for decrypting the file, the MCC tool will return -10. However, if the file is in plain text, and you input the pre-shared key, it will ignore the key (won't return -10). * <p>(by parameter -dk or the key column in the device list file)</p>	
-f	The configuration file to be imported	Only for the import configuration function
-n	Keep original network parameters (including IP, subnet mask, gateway, and DNS)	Only for the import configuration function
-nr	Do not reboot the device after importing the configuration file	Only for the import configuration function.
-l	Export result log file	
-t	Timeout (1 to 120 seconds) Export function Default value: 30 seconds Import function Default value: 60 seconds	

Example: Export the configuration using a device list and export the results to a result log

MCC_Tool -cfg -ex -d [DeviceList] -l [result_log]

The result_log will include the following items:

Model	ServerName	IP	MAC	FwVer	ExportCfgFile	Key	ErrCode
NPort6650;	NPort6650_123;	192.168.1.1;	00:90:e8:01:02:03;	1.3;	NP6650_192_168_1_1_20170622.ini;	moxa;	0;
NPort6150;	NPort6150_456;	192.168.1.2;	00:90:e8:04:05:06;	1.3;	NP6650_192_168_1_2_20170622.ini;	moxa;	0;

Example: Import the configuration to a device list (with restarting the units) and export the results to a result log.

MCC_Tool -cfg -im -d [DeviceList] -l [result_log]

The result_log will include the items below:

Model	ServerName	IP	MAC	FwVer	CfgFile	Key	ErrCode
NPort6650;	NPort6650_123;	192.168.1.1;	00:90:e8:01:02:03;	1.3;	NP6650_192_168_1_1_20170622.ini	moxa;	0;
NPort6150;	NPort6150_456;	192.168.1.2;	00:90:e8:04:05:06;	1.3;	NP6650_192_168_1_2_20170622.ini	moxa;	0;

Example: Import the configuration to a device list without restarting the units and export the results to a result log.

MCC_Tool -cfg -im -d [DeviceList] -nr -l [result_log]

Firmware Upgrade

With the IT/ OT convergence trend, office networks may see an increase in OT network devices, posing cybersecurity risks. Upgrading the firmware version is crucial for all network devices. The MCC Tool allows users familiar with the command-line interface to update the firmware on multiple NPort device servers to fulfill this need.

The NPort 5600-DT-G2 Series supports password protection by default and cannot be disabled. The password(s) must be specified by a command parameter or by the DeviceList file before upgrading the firmware and restarting a specific device (or multiple devices simultaneously).

MCC_Tool -fw -up -i [ip_address] -u [user] -p [password] -f [firmware_file] -l [result_log]

MCC_Tool -fw -up -d [Device_list] -l [result_log]

MCC_Tool -fw -up -d [Device_list] -l [result_log] -t [timeout_value]

Parameters Description:

Command	Function	Remark
-fw	Execute actions for firmware related	
-up	Upgrade firmware version	
-i	Device's IP address (192.168.1.1)	
-u	Device's user account for login	
-p	Device's password for login	
-d	Device list	
-f	Firmware file to be upgraded	
-l	Export result log file	
-t	Timeout (1~1200 seconds) Default value: 800 seconds	
-print	Print upgrade process status message	

Example: Upgrade firmware using a device list and capture the results in an import log.

MCC_Tool -fw -u -d [DeviceList] -l [result_log]

The result_log will include the items below:

Model	ServerName	IP	MAC	FwFile	ErrCode
NPort6650;	NPort6650_123;	192.168.1.1;	00:90:e8:01:02:03;	NP6000_V1.3.rom;	0;
NPort6150;	NPort6150_456;	192.168.1.2;	00:90:e8:04:05:06;	NP6000_V1.3.rom;	0;

Change Password

Because of the IT/OT convergence trend, an increasing number of companies require their employees to update their login passwords regularly, as do the network devices. The owner/maintainer of the network devices may need to update the password regularly. The MCC Tool helps you to ease this routine job by generating a small script to update the password.

Set the password of the target device specified by an IP address. The current password must be specified by a parameter or by the Device List file.

MCC_Tool -pw -ch -i [ip_address] -u [user] -p [old_password] -npw [new_password]

MCC_Tool -pw -ch -d [Device_list] -nd [device_list_new_password] -l [result_log]

MCC_Tool -pw -ch -d [Device_list] -nd [device_list_new_password] -l [result_log] -t [timeout_value]

Parameters Description:

Command	Function	Remark
-pw	Execute actions for password	
-ch	Change password	
-npw	The new password for a specific user	
-i	Device's IP address (192.168.1.1)	
-u	Device's user account for login	
-p	Device's password for login (old password)	
-d	Device list	
-nd	The list of devices with new password settings	You will need to assign a new password in the Device List when using the -nd command.
-l	Export result log file	
-nr	Don't reboot the device after changing the password	
-t	Timeout (1to120 seconds) Default value: 60 seconds	

Example: Set the new password as "5678" and restart the device to make it effective. Print the result on the screen.

MCC_Tool -pw 5678 -i 192.168.1.1 -u admin -p moxa

Example: Set the new password from a device list and then restart the device to make it effective. Export the results to a results log

MCC_Tool -pw DeviceList_New -d [DeviceList] -l [result_log]

The result_log will include the items below:

Model	ServerName	IP	MAC	FwVer	User	PWD	ErrCode
NPort6650;	NPort6650_123;	192.168.1.1;	00:90:e8:01:02:03;	1.3;	admin;	5678;	0;
NPort6150;	NPort6150_456;	192.168.1.2;	00:90:e8:04:05:06;	1.3;	admin;	moxa;	0;


9. Advanced Settings of NPort Windows Driver Manager

The NPort Windows Driver Manager has additional capabilities apart from being a driver for the virtual COM application. There are many advanced settings to help you face different user scenarios. In this chapter, we will explain which functions/settings are useful in different scenarios.

Configure the mapped COM ports

After mapping the COM ports, refer to Chapter 4 for instructions. Many times, the legacy COM port software can establish communication with serial devices by opening either the COM port or the TTY port. In specific cases, the user may need to change the advanced settings of the NPort Windows Driver Manager for certain applications.


To reconfigure settings for a specific serial port on the NPort device server, select the corresponding row and select the **Setting** icon in Real COM Mode/Reverse Real COM Mode.



No	COM Port	Address 1	Address 2
1	COM1	192.168.127.254 950:966 (Port1)	
2	COM5	192.168.127.254 951:967 (Port2)	
3	COM6	192.168.127.254 952:968 (Port3)	
4	COM8	192.168.127.254 953:969 (Port4)	

Change the Number of a Mapped COM Port

Some legacy COM port software is restricted to using specific COM ports like COM1 or COM2. Nevertheless, the NPort Windows Driver Manager has the capability to automatically assign COM ports starting from COM3. To modify the COM port number, select the **Setting** button and locate the **COM Number** drop-down menu in the Basic Settings. Select the COM port requested by the legacy COM port software.



To assign the serial ports of the NPort device server to COM port numbers in sequence, choose **Auto Enumerating COM Number** option for selected ports.

COM Splitting


When you activate COM Splitting, you can use multiple COM port software to communicate with the same serial device. Only one piece of software can open/occupy a COM port, causing others to wait until it is closed. The **COM Splitting** function allows multiple COM port numbers to be assigned to the same serial port on the NPort device server. The first software accesses COM1, while the second software uses COM2, but both communicate with the same serial device.

Since both software will be using the same serial port and device, they must coordinate when the first software sends a command and when the second one does. Or there may be a data collision. Using this feature could be a better option for enabling one-way communication from the serial device to multiple host PCs on the Ethernet network. Let's say there's a serial temperature sensor that constantly updates temperature data to the control servers. If the temperature gets too high or too low, one server will send a request to activate the fan or heater. The purpose of the second server might be to serve as the database for recording temperature readings.


The **COM Splitting** function will group all the selected COM ports into one COM port. Even if you use varying software to communicate via different COM port numbers, all the software will receive identical data from the serial device.


To handle various host PCs connecting to the same serial port, it is necessary to modify the **Max. Connection** setting according to the number of ports grouped in your NPort. For example, if you split to two COM ports, **Max. Connection** needs to be adjusted to 2. The grouped serial ports must be directed to the same NPort device server; they cannot be combined from different NPorts.

Enabled COM Splitting




1. Select the target COM port number and then the **Setting** button.
2. Select to enable the **COM Splitting** function.
3. **Add COM** to select target COM ports for splitting; the COM port must be available.






4. After selecting **OK**, check if the COM ports you just selected are grouped together. Select **Apply** to save the changes.



5. Once the COM port number changes to black text, the software can open multiple COM Splitting ports to receive serial data.

Advanced Setting

Transferring serial data to an Ethernet network can result in timing differences and variations in behavior compared to TCP socket behavior. The NPort Windows Driver Manager offers various advanced settings to accommodate these differences, ensuring that your original software remains unchanged and communication functions properly.



Tx Mode

Because Ethernet and serial technology have significantly different speeds, the serial line's maximum baudrate is only 921,600bps, while Ethernet's minimum speed is 10Mbps. The Tx Mode offers two options for the driver to mimic either Ethernet or serial bus behavior more closely.

The default setting for the Tx Mode is **Hi-Performance** mode, which sends as much data as possible to the serial side. This behavior will be closer to Ethernet. The driver buffer will temporarily store the data before sending it all at once over Ethernet, resulting in higher data delivery throughput.

This might pose issues for older serial applications or devices that lack sufficient buffer or performance to handle large amounts of data quickly. To handle these situations, switch the Tx Mode to **Classical** mode. In Classical mode, the NPort sends the serial data one byte at a time, eliminating the need for a large buffer size in the serial device. This is designed to work with serial devices like these. The **Classical** mode allows for quicker data delivery by minimizing latency. The serial data can bypass the driver buffer's waiting time.

FIFO

This FIFO setting is the same setting on the NPort device server. If they're not the same, the value in the NPort Windows Driver Manager will overwrite the setting on the firmware and apply either Real COM mode or Reverse Real COM mode.

The Enable FIFO function is enabled by default for improved data throughput. There are two scenarios you may consider disabling the Enable FIFO function (uncheck the checkbox).

- The serial device does not have FIFO/buffer or does not support flow control functions. In this case, the serial device may not be able to receive the serial data from NPort on time, which means that some data might be dropped.
- Data latency is more important than data throughput. Higher data throughput involves temporarily storing data in a buffer to enable sending larger amounts of data at once. This behavior may result in slower latency for individual data points. If maintaining low latency is a priority for reading data correctly on the serial device, it is recommended to disable the Enable FIFO function.

This field enables or disables the 512-byte FIFO buffer. The NPort 5600-DT-G2 provides FIFO buffers for each serial port, for both the Tx and Rx signals.

Network Timeout

This function shares similarities with the **TCP alive check time** function on the NPort device server. The only difference is in the source of each function. The source of the **TCP alive check time** is the NPort device server; it will check if the remote host PC is alive or not. The source of the **Network Timeout** function is the host PC (which installed the NPort Windows Driver Manager); it will check if the remote NPort is alive or not. Use this option to prevent blocking when the target NPort is unavailable.

Fast Flush (only flushes the local buffer)

For some applications, the user's program will use the Win32 "PurgeComm()" function before it reads or writes data. Following the execution of the PurgeComm() function, the NPort driver persists in querying the firmware of the NPort multiple times to ensure the absence of queued data in the firmware buffer, instead of solely flushing the local buffer on the host PC. The purpose of this design is to meet specific requirements. The additional time required for Ethernet communication means it may take longer (about several hundred milliseconds) than a native COM1. PurgeComm() is noticeably faster on native COM ports than on mapped COM ports on the NPort 5600-DT-G2. To support applications with faster response requirements, the new NPort driver incorporates a Fast Flush option. This function is enabled by default.

If you disable Fast Flush and notice a significant decrease in performance for COM ports mapped to the NPort 5600-DT-G2, check if your application uses "PurgeComm()" functions. If so, try enabling the Fast Flush function and see if there is a significant improvement in performance.


Auto Network Reconnection

While serial communication is always connected, Ethernet communication is not. The NPort Windows Driver Manager offers Auto Network Reconnection for automatic re-establishment of connections, ensuring the serial device is always considered connected and capable of sending data.

If this option is enabled, the driver will continuously attempt to re-establish the TCP connection when the NPort 5600-DT-G2 fails to reply to the background "check-alive" packets. The Network Timeout function, which cannot be disabled, determines the timing of these packets.

Always Accept Open Requests

When the driver cannot establish a connection with the NPort, your software can still open the mapped COM port, like an onboard COM port.



Return Error If Network Is Unavailable

We discovered that some legacy COM port software always opens a fixed range of COM ports, from COM1 to COM10, when executed by the user. For the real application, only COM3, COM5, and COM7 are available, so the software will always return failure since it cannot open COM1 to COM10 successfully. To temporarily resolve this issue with the outdated software, you can deactivate the **Return error if network is unavailable** option.

Disabling this option will prevent the driver from reporting errors for failed connections to the NPort 5600-DT-G2. Enabling this option will result in the Win32 Comm function returning the error code "STATUS_NETWORK_UNREACHABLE" if a connection to the NPort 5600-DT-G2 cannot be established. Typically, this indicates that your host's network connection is offline, possibly due to a disconnected cable. But if you're able to access other network devices, it's likely that the NPort 5600-DT-G2 is either disconnected or not powered on. To use this feature, make sure **Auto Network Re-Connection** is turned on.

Ignore TX Purge


When programming for legacy COM port software, it is common practice to clear the buffer before and after writing data to prevent any unwanted data from being present. In the past, there were no troubles, making it an effective method to avoid sending incorrect data to the serial device.

Because of advancements in technology, PCs now have significantly improved performance compared to the past. The clear buffer command might prematurely send to the NPort device server after the write command. The NPort might still hold correct data in its buffer, but the Win32 API PurgeComm command will lose it when it receives the clear buffer command. You might notice that the received serial data is missing in the last few bytes. Enabling the **Ignore TX Purge** function might be the solution when this occurs.

Security

When addressing the growing cybersecurity threats, it is crucial to devise ways to protect vital data on serial devices. The serial bus has a short communication distance and is difficult to steal, especially in secure manufacturing facilities with guards. However, it's a different situation when it comes to using a device server to transmit serial data over an Ethernet network. The Ethernet network is much more vulnerable than the serial bus. The NPort device server enables encryption of Ethernet network communications. With the NPort Windows Driver Manager, you can encrypt communications on the host PC.

Select the target serial port, then the **Setting** button, and switch to the **Security** tab:



Enable Encryption

Enable SSL encryption for data and command transmission of the selected COM port.

Data Only

The NPort 6000 Series supports data encryption only. Select this option if you are using the NPort 6000 Series.

Data and Command

The NPort 5600-DT-G2 Series supports both data and command encryption. Select this option if you are using NPort G2 models.

Certification Authentication


This security enhancement allows you to verify the server and client using an imported certificate from a trusted Certificate Authority (CA). Select the **Import** button above to import your own.

Keep Connection

For quicker operations, it is recommended to enable this option if the COM port software frequently opens and closes the COM port with data encryption and the NPort is dedicated to one host. The opening time of a COM port with encryption enabled will be brief (300 to 500ms) because of the SSL protocol. By enabling these options, you can ensure a continuous SSL connection for the COM port. The opening and closing of the COM port will be faster here. The Keep Connection feature is not supported in Reverse Real COM mode.

Importing/Exporting COM mapping

To load/save the configuration to a text file, select Import/Export from the **COM Mapping** menu. You will then be able to use this configuration file on another host and use the same COM Mapping settings on the host.




Port Sniffer Wizard

Engineers may require an analyzer to track the commands and responses exchanged between the Windows platform and the NPort Windows Driver Manager to diagnose communication issues. The Port Sniffer Wizard is a tool that tracks and records activity on all serial ports of a system. Its advanced filtering and search capabilities make it a powerful tool for exploring Windows functionality, monitoring port usage, and troubleshooting systems or application configurations.

How to Use the Port Sniffer


Select **Port Sniffer Wizard** from the drop-down menu under Help.



Task Page

Select the task you need and choose **Next**:

- Capture serial data logs
- Monitor runtime serial data (for developers)
- Display existing settings
- Delete existing settings



Capture Serial Data Logs

If errors occur, you can capture serial data logs from specific ports and send the logs back to Moxa. We can help you check the problem. Select this function to export log files.



NOTE

Enabling the serial data logging function may cause slight latency.

Step 1: COM port setting

- Select one or more COM ports to capture.
- Turn on the function that you need.
 - Display IRP direction
IRP will inform users whether an error occurs when issuing a command or returning a response.
 - Hide sensitive data
The system will hide the data, so you don't need to worry about data leakage. Used specifically for sensitive data.

The screenshot shows a dialog box titled "Port Sniffer" with a close button (X) in the top right corner. The main area is titled "Select COM ports to capture" and contains a list of COM ports with checkboxes: COM5, COM6, COM7, COM8, COM11, and COM12. The checkbox for COM12 is checked. To the right of the list are three checked options: "Display IRP direction", "Log to file", and "Hide sensitive data". Below these options is a "Refresh" button. At the bottom of the dialog, there are three buttons: "< Back", "Next >" (which is highlighted with a blue border), and "Cancel".

Step 2: Set the parameters of the log files.

- Enable log service.



NOTE

Disabling the log service will not capture the serial data.

- Choose the location of the log files.
- Set the max. number of log files and max. file size (MB).

Port Sniffer

Set the attribute of logging file

Log Service : ENABLED

Location of log files : C:\mxportsf

Max. number of log files : 10

Max. file size (MB) : 30

Click Finish, Sniffer will start/stop to log serial data in the background.

Click Back, return to check the COM port settings.

< Back Finish Cancel

- Select finish and check the log files at the locations you set.

Monitor Runtime Serial Data (for developers)

The difference between the "Capture serial data logs" and "Monitor runtime serial data" functions is that the latter presents the status in real time.

Step 1: COM port setting

- Select one or more COM ports to monitor the serial log in the runtime.
- Turn on the function that you need.
 - Display IRP direction
IRP will inform users whether an error occurs when issuing a command or returning a response.
 - Log to file
 - Export log files simultaneously. (Exporting log files simultaneously will cause latency)



NOTE

Monitor runtime is usually used by developers or serial driver programmers to troubleshoot. Download debug tools like "DebugView" from a third party to view the real-time status.

- Hide sensitive data
The system will hide the data. Used specifically for sensitive data.

Port Sniffer

Select COM ports to capture

COM Number	
<input type="checkbox"/> COM5	<input checked="" type="checkbox"/> Display IRP direction
<input type="checkbox"/> COM6	<input checked="" type="checkbox"/> Log to file
<input type="checkbox"/> COM7	<input checked="" type="checkbox"/> Hide sensitive data
<input type="checkbox"/> COM8	
<input type="checkbox"/> COM11	
<input checked="" type="checkbox"/> COM12	


Refresh

Click Next, set the parameters of logging files.
Click Back, return to the task page.

< Back Next > Cancel

Step 2: Set the parameters of the log files. Skip this step if you disabled **Log to file** function.

- Enable log service.
- Choose the location of the log files.
- Set the max. number of log files and max. file size (MB).




Step 3: Set the environment settings.

- Enable the **Debug Print Filter** to dump messages from the kernel. The setting will take effect after the system restarts.




NOTE

1. Disabling the **Debug Print Filter** will not output the serial data to the monitor.
2. See the runtime serial data from the debug output monitor.




- Select **Finish** and open "DebugView" to monitor runtime serial data.



Display existing settings

- Step 1:** Select **Display existing settings** to view the current settings.




Step 2: Check the COM port settings.

The screenshot shows the 'Port Sniffer' dialog box. The title bar reads 'Port Sniffer' with a close button (X) on the right. The main area is titled 'Select COM ports to capture'. On the left, there is a list box labeled 'COM Number' containing 'COM12' with a checked checkbox. To the right of the list box are three checkboxes: 'Display IRP direction' (checked), 'Log to file' (unchecked), and 'Hide sensitive data' (checked). Below these checkboxes is a 'Refresh' button. At the bottom of the dialog, there are three buttons: '< Back', 'Next >' (highlighted with a blue border), and 'Cancel'. Below the main area, there is instructional text: 'Click Next, check the parameters of logging files.' and 'Click Back, return to the task page.'

Step 3: Check the parameters of the logging files.

The screenshot shows the 'Port Sniffer' dialog box. The title bar reads 'Port Sniffer' with a close button (X) on the right. The main area is titled 'Set the attribute of logging file'. It contains four settings: 'Log Service' is a dropdown menu set to 'ENABLED'; 'Location of log files' is a dropdown menu set to 'C:\mxportsf'; 'Max. number of log files' is a text input field containing '10'; and 'Max. file size (MB)' is a text input field containing '30'. At the bottom of the dialog, there are three buttons: '< Back', 'Next >' (highlighted with a blue border), and 'Cancel'. Below the main area, there is instructional text: 'Click Next, check the environment settings.' and 'Click Back, return to check the COM port settings.'


Step 4: Check the environment settings.



Step 5: Select **Finish** to finish the Port Sniffer settings.

Delete existing settings

Step 1: Select **Delete existing settings**.



Step 2: Select **Finish** to delete existing settings.

10. Frequently Asked Questions

We have designed this section to list the Frequently Asked Questions so that users can solve their own questions.

Q1. If I disable the Web console, how can I change the settings?

The web console is the main management console of the NPort 5600-DT-G2. It configures all the functions of the NPort 5600-DT-G2 and monitors the status of the device server. We don't recommend that you disable the web console service.

When operating in an extremely high-risk cybersecurity environment, you may opt to disable the web console service after completing the configuration and confirming that no further adjustments are needed. The web console service can be enabled through SNMP private MIB in this scenario.

If all the remote services are turned off, for example, the web and SNMP services, you can consider a local way to enable the web service again to modify the settings or troubleshoot a problem. The serial port 1 of NPort 5600-GT-G2 models can be accessed as a serial console locally. For more details, see Chapter 6.

If all of the above services are disabled, the only way to reset the device to factory settings and re-enable the web console service is to use the hardware reset button.

Q2. Can different users use the same account to log in to the device server?

Different connections are not allowed for one user account on the device server because of cybersecurity measures.

For example, the administrator is already logged into the NPort as account "admin". And now a second user uses "admin" to log in to the same device server:

- If the password is wrong, the device server will record a login failed event in the syslog. The administrator can check the syslog to notice this failure.
- If the password is correct, the user will log in to the device, and the former connection will be terminated. The administrator will be notified by this unexpected behavior. By logging in again, the administrator can find the IP address from the syslog to prevent the user from trying again.

Q3. Why Device Search Utility v3.0 and later cannot be executed on my Windows 7 or Windows 2008 R2?

Since the Device Search Utility v3.0 is a web-based application, it has minimum requirements for the browser version and operating system:

- Chrome:
 - For Windows 7, 8/8.1, Server 2012 and Server 2012 R2: Chrome 109 and later
 - For Windows 10 and later, Server 2016 and later: All Chrome versions
- Firefox:
 - For Windows 7 and later versions, Server 2012 and later versions: All Firefox ESR versions
- Edge:

- For Windows 7 and later versions, Server 2012 and later versions: All Firefox ESR versions

Q4. How can I check the CRC value of the runtime settings?

The NPort 5600-DT-G2 provides a private MIB for the CRC value of the runtime settings; the OID is configCRC32. Use a MIB browser or send an SNMP command to get the CRC value.

Q5. Is there an easier way to copy the settings of an NPort 5600-DT device server to an NPort 5600-DT-G2?

If you have NPort 5600-DT device servers on site, you may wonder how to transfer the same settings to the NPort 5600-DT-G2 device servers. Is it possible to configure each setting individually, one page at a time, even if it takes a lot of time?


The NPort 5600-DT-G2 device servers have the capability to import the configuration file directly from an NPort 5600-DT. Export the NPort 5600-DT settings and import them into the NPort 5600-DT-G2. The NPort 5600-DT-G2 can then replace the device server on-site.

Q6. If there is a power outage during a firmware upgrade, how can I recover the device?

The NPort 5600-DT-G2 supports a fail-safe mechanism during firmware upgrades. If there is a power outage, just power up the device. The device will be ready with the previous version of the firmware. Try again or arrange another proper time to upgrade the firmware.

Q7. Before calling Moxa customer service, is there anything I can prepare to save both of us time?

Find the **Support > Diagnostic Information** and select the **DOWNLOAD** button to collect all the settings and logs for troubleshooting. This will help Moxa customer service understand the case background and replicate the issue you are experiencing.




A. Pinouts and Cable Wiring

As mentioned in Chapter 2, the pin assignment of NPort 5600-DT-G2 Series is as below:


The serial port RS-232/422/485 pin assignment of NPort 5600-8-DT-G2 models (DB9 male):

Pin	RS-232	RS-422/4-wire RS-485	2-wire RS-485
1	DCD	TxD-(A)	-
2	RxD	TxD+(B)	-
3	TxD	RxD+(B)	Data+(B)
4	DTR	RxD-(A)	Data-(A)
5	GND	GND	GND
6	DSR	-	-
7	RTS	-	-
8	CTS	-	-
9	-	-	-




The serial port RS-232/422/485 pin assignment of NPort 5600-16-DT-J-G2 models (8-pin RJ45):

Pin	RS-232	RS-422/4-wire RS-485	2-wire RS-485
1	DSR	-	-
2	RTS	TxD+(B)	-
3	GND	GND	GND
4	TxD	TxD-(A)	-
5	RxD	RxD+(B)	Data+(B)
6	DCD	RxD-(A)	Data-(A)
7	CTS	-	-
8	DTR	-	-




The serial port RS-232/422/485 pin assignment of NPort 5600-8-DTS-J-G2 models (10-pin RJ50):

Pin	RS-232	RS-422/4-wire RS-485	2-wire RS-485
1	-	TxD-(A)	-
2	DSR	RxD-(B)	Data-(A)
3	RTS	-	-
4	CGND	CGND	CGND
5	TxD	TxD+(A)	-
6	RxD	RxD+(B)	Data+(B)
7	SGND	SGND	SGND
8	CTS	-	-
9	DTR	-	-
10	DCD	-	-



The Ethernet port pin assignment (RJ45):

Pin	RJ45
1	Tx+
2	Tx-
3	Rx+
4	-
5	-
6	Rx-
7	-
8	-






Cable Wiring Diagrams

To connect serial devices/Ethernet devices, customize the connecting cable to connect the NPort and the serial/Ethernet devices. Here are some of the most popular cable wirings for your reference.

Ethernet Cables

There are two major types of RJ45 Ethernet cables: straight-through and crossover cables.



Serial Cables

Depending on different connectors on the serial devices, we provide several serial cables to connect easily to the NPort and the device.

CBL-RJ45F9-150

The CBL-RJ45F9-150 is a 150-cm long cable to connect the NPort's DB9 male connector to a serial device with RJ45 serial connector. The pin assignment of this cable is as below:

Pin on DB9 male	RS-232 signal	Pin on RJ45	RS-232 signal
1	DCD	6	DCD
2	RxD	4	RxD
3	TxD	5	TxD
4	DTR	1	DTR
5	GND	3	GND
6	DSR	8	DSR
7	RTS	7	RTS
8	CTS	2	CTS
9	-	-	-



CBL-RJ45SF9-150

Industrial applications, such as the factory floor, are typically electrically noisy environments. The CBL-RJ45SF9-150 is a 150-cm long cable, shielded to protect the signals from noise and connect the NPort's DB9 male connector to a serial device with an RJ45 serial connector. The pin assignment of this cable is as below:

Pin on DB9 male	RS-232 signal
1	DCD
2	RxD
3	TxD
4	DTR
5	GND
6	DSR
7	RTS
8	CTS
9	-

Pin on RJ45	RS-232 signal
6	DCD
4	RxD
5	TxD
1	DTR
3	GND
8	DSR
7	RTS
2	CTS
-	-



CN-20070

The CN-20070 is a 150-cm long cable used to connect the NPort's DB9 male connector to a serial device with a 10-pin RJ45 serial connector. The pin assignment of this cable is as below:

Pin on DB9 male	RS-232 signal
1	DCD
2	RxD
3	TxD
4	DTR
5	GND
6	DSR
7	RTS
8	CTS
9	-
10	-

Pin on 10-pin RJ45	RS-232 signal
1	DCD
5	RxD
6	TxD
2	DTR
7	GND
9	DSR
8	RTS
3	CTS
-	-
-	-



B. Accessory Introduction

Moxa provides different accessories for different user scenarios. The scenarios will be introduced with the appropriate accessory in this appendix.

Convert the DB9 Connector to Other Connectors

The DB9, RJ45 and terminal block are the most popular interfaces on serial communications. The NPort device server has a built-in DB9 connector as the default. Moxa provides a connector to convert the DB9 interface to other connectors.

ADP-RJ458P-DB9F

The ADP-RJ458P-DB9F is a connector that transforms the NPort's DB9 male connector to an 8-pin RJ45 serial connector. The pin assignment of this connector is as below:

Pin on DB9 male	RS-232 signal	Pin on RJ45	RS-232 signal
1	DCD	6	DCD
2	RxD	4	RxD
3	TxD	5	TxD
4	DTR	1	DTR
5	GND	3	GND
6	DSR	8	DSR
7	RTS	7	RTS
8	CTS	2	CTS
9	-	-	-



Mini DB9F-to-TB

The Mini DB9F-to-TB is a connector that transforms the NPort's DB9 male connector to a 5-pin terminal block serial connector. This connector usually is used in an RS-422/RS-485 application. The pin assignment of this connector is as below:

Pin on DB9 male	RS-422 signal/ 4-wire RS-485 signal	2-wire RS-485 signal
1	TxD-(A)	-
2	TxD+(B)	-
3	RxD+(B)	Data+(B)
4	RxD-(A)	Data-(A)
5	GND	GND
6	-	-
7	-	-
8	-	-
9	-	-



LB-DB9F-G-01

The LB-DB9F-G-01 is a loop-back connector for the NPort's DB9 male connector. It shortens Pin2 and Pin3; Pin4 and Pin6; and Pin1, Pin7, and Pin8; so the serial port can have a self-test to verify if the serial communication works properly. The pin assignment of this connector is as below:

Pin on DB9 male	RS-232 signal	Notes
1	DCD	Shorted with Pin7, Pin8
2	RxD	Shorted
3	TxD	
4	DTR	Shorted with Pin6
5	GND	-
6	DSR	Shorted with Pin4
7	RTS	Shorted
8	CTS	
9	-	-



Convert the 8-pin RJ45/10-pin RJ50 Connector to Other Connectors

The NPort 6600-G2 device server has built-in 8-pin DB9 connectors as the default. Moxa provides a connector to convert the 8-pin RJ45 interface to other connectors.

LB-RJ458P-G-01

The LB-RJ45-G-01 is a loop-back connector for the NPort's RJ45 connector. It shortens Pin2, Pin6, and Pin7; Pin4 and Pin5; Pin 1 and Pin 8, so the serial port can have a self-test to verify if the serial communication works properly. The pin assignment of this connector is as below:

Pin on RJ45	RS-232	Notes
1	DSR	Shorted with Pin8
2	RTS	Shorted with Pin6, Pin7
3	GND	
4	TxD	Shorted
5	RxD	
6	DCD	Shorted with Pin1, Pin7
7	CTS	Shorted with Pin1, Pin6
8	DTR	Shorted with Pin1



LB-RJ5010P-G-01


The LB-RJ5010P-G-01 is a loop-back connector for the NPort's 10-pin RJ50 connector. It shortens Pin2, Pin9, and Pin10; Pin5 and Pin6; Pin 3 and Pin 8, so the serial port can have a self-test to verify if the serial communication works properly. The pin assignment of this connector is as below:

Pin on RJ45	RS-232	Notes
1	-	-
2	DSR	Shorted with Pin9, Pin10
3	RTS	
4	CGND	-
5	TxD	Shorted
6	RxD	
7	SGND	-
8	CTS	Shorted with Pin3
9	DTR	Shorted with Pin1, Pin10
10	DCD	Shorted with Pin1, Pin9



CBL-RJ458P-Cisco-BK-180

The Cisco Ethernet devices are very popular on the market, and most of them provide an 8-pin RJ45 serial console port for emergency usage. The NPort 6600-G2 provides Reverse Terminal mode for this kind of emergency usage. To help you with the NPort 6600-G2 and the Cisco devices, we provide the CBL-RJ458P-Cisco-BK-180 with a 1.8 m-long cable with the pin assignment of the Cisco serial console port.



CBL-RJ45F25-150

The CBL-RJ45F25-150 is a cable that converts an 8-pin RJ45 to a DB25 female serial connector, and the cable is 1.5 m long.



CBL-RJ45F9-150

The CBL-RJ45F25-150 is a cable that converts an 8-pin RJ45 to a DB9 female serial connector, and the cable is 1.5 m long.




CBL-RJ45M25-150

The CBL-RJ45M25-150 is a cable that converts an 8-pin RJ45 to a DB25 male serial connector, and the cable is 1.5 m long.




CBL-RJ45M9-150

The CBL-RJ45M9-150 is a cable that converts an 8-pin RJ45 to a DB9 male serial connector, and the cable is 1.5 m long.




CBL-RJ45SF25-150

The CBL-RJ45SF25-150 is a cable that converts an 8-pin RJ45 to a DB25 female serial connector, and the cable is 1.5 m long with shielding.




CBL-RJ45SF9-150

The CBL-RJ45SF9-150 is a cable that converts an 8-pin RJ45 to a DB9 female serial connector, and the cable is 1.5 m long with shielding.




CBL-RJ45SM25-150

The CBL-RJ45SM25-150 is a cable that converts an 8-pin RJ45 to a DB25 male serial connector, and the cable is 1.5 m long with shielding.



CBL-RJ45SM9-150

The CBL-RJ45SM9-150 is a cable that converts an 8-pin RJ45 to a DB9 male serial connector, and the cable is 1.5 m long with shielding.



Selecting Suitable Power Adapter Depends on the Environment

The standard NPort 5600-DT-G2 models will NOT be shipped with a power adapter. As the product provides a terminal block power input, we assume most of the customers will use a DIN-rail type power supply and directly connect the wire cables by their own.

In case you prefer to use power adapters, here is the list of the power adapters we provide. Select one suitable for your region.

- PWR-12150-WPAU-S4: with the Australia power plug
- PWR-12150-WPCN-S4: with the China power plug
- PWR-12150-WPEU-S4: with the European power plug
- PWR-12150-WPKR-S4: with the Korea power plug and certificate
- PWR-12150-WPUK-S4: with the United Kingdom power plug and certificate
- PWR-12150-WPUSJP-S4: with the United States and Japan power plug

With these power adapters, the operating temperature ranges from 0 to 40 degrees Celsius. The NPort device server may be set up in an indoor environment, like a control room. If the NPort device server may be set in an outdoor area or a cabinet without air conditioning, the temperature change might be too big.

Consider buying the wide-temperature models and also the power adapters.

- PWR-12150-AU-SA-T: with the Australia power plug
- PWR-12150-CN-SA-T: with the China power plug
- PWR-12150-EU-SA-T: with the European power plug
- PWR-12150-UK-SA-T: with the United Kingdom power plug and certificate
- PWR-12150-USJP-SA-T: with the United States and Japan power plug

With these wide temperature models and power adapters, the operating temperature is from -40 to 75 degrees Celsius. Generally, the NPort device server may be set up in an outdoor environment, like a cabinet at the remote site, where it may be extremely hot in summer and extremely cold in winter.

For easy connections with a power adapter, Moxa provides a power cable: CBL-PJTB-10, which is a DC barrel jack at one side and with two bare wire V+ and V- at the other side to connect to the NPort 5600-DT-G2.



NPort 5600-DT-G2 Series is designed as a default DIN-rail mounting device with a terminal block power input connector. You can also select a DIN-rail power supply to provide the electricity. This product is intended to be supplied by an external power source (UL Listed/IEC 62368-1/EN 62368-1), of which the output complies with ES1/SDLV. The output rating is rated at 12 to 48 VDC and a minimum current of 800 mA. When using a Class I external power source, the power cord should be connected to an outlet with an earthing connection. Moxa has three DIN-rail power supplies. You can select a proper one for field usage:

- HDR Power Supply Series: 60 W slim form-factor power supplies for DIN-rail mounted products.



- MDR Power Supply Series: 40/60 W slim form-factor power supplies for DIN-rail mounted products.



- NDR Power Supply Series: 120/240 W slim form-factor power supplies for DIN-rail mounted products.



C. Well-known Port Numbers

In this appendix, we provide a list of well-known port numbers that may cause network problems if you set the NPort 5600-DT-G2 to one of these ports. Refer to RFC 1700 for well-known port numbers or to the following introduction from the IANA:

The port numbers are divided into three ranges: the Well-Known Ports, the Registered Ports, and the Dynamic and/or Private Ports.

The well-known ports range from 0 to 1023. The Registered Ports range from 1024 through 49151.

The dynamic and/or private ports range from 49152 through 65535.

The well-known ports are assigned by the IANA, and on most systems, they can only be used by system processes or by programs executed by privileged users. The following table shows famous port numbers among the listed well-known port numbers. For more details, visit the IANA website at <http://www.iana.org/assignments/port-numbers>.

TCP Socket	Application Service
0	Reserved
1	TCP Port Service Multiplexer
2	Management Utility
7	Echo
9	Discard
11	Active Users (sysstat)
13	Daytime
15	Netstat
20	FTP data port
21	FTP control port
23	Telnet
25	SMTP (Simple Mail Transfer Protocol)
37	Time (Time Server)
42	Host name server (names server)
43	Whois (nickname)
49	Login Host Protocol (login)
53	Domain Name Server (domain)
79	Finger protocol (finger)
80	World Wide Web (HTTP)
119	Network News Transfer Protocol (NNTP)
123	Network Time Protocol
213	IPX
160 to 223	Reserved for future use

UDP Socket	Application Service
0	Reserved
2	Management Utility
7	Echo
9	Discard
11	Active Users (sysstat)
13	Daytime
35	Any private printer server
39	Resource Location Protocol
42	Host name server (names server)
43	Whois (nickname)
49	Login Host Protocol (login)
53	Domain Name Server (domain)
69	Trivial Transfer Protocol (TFTP)
70	Gopher Protocol
79	Finger Protocol
80	World Wide Web (HTTP)
107	Remote Telnet Service
111	Sun Remote Procedure Call (Sunrpc)
119	Network News Transfer Protocol (NNTP)
123	Network Time Protocol (NTP)
161	SNMP (Simple Network Management Protocol)
162	SNMP Traps
213	IPX (used for IP Tunneling)

D. SNMP MIB List

The NPort 5600-DT-G2 has built-in SNMP (Simple Network Management Protocol) agent software that supports SNMP Trap, RFC1317 and RS-232-like groups, and RFC 1213 MIB-II. The following table lists the standard MIB-II groups and the variable implementation for the NPort 5600-DT-G2.

RFC1213 MIB-II Supported SNMP Variables

System MIB	Interfaces MIB	IP MIB	ICMP MIB
sysDescr	ifNumber	ipForwarding	icmpInMsgs
sysObjectID	ifIndex	ipDefaultTTL	icmpInErrors
sysUpTime	ifDescr	ipInReceives	icmpInDestUnreachs
sysContact	ifType	ipInHdrErrors	icmpInTimeExcds
sysName	ifMtu	ipInAddrErrors	icmpInParmProbs
sysLocation	ifSpeed	ipForwDatagrams	icmpInSrcQuenchs
sysServices	ifPhysAddress	ipInUnknownProtos	icmpInRedirects
	ifAdminStatus	ipInDiscards	icmpInEchos
	ifOperStatus	ipInDelivers	icmpInEchoReps
	ifLastChange	ipOutRequests	icmpInTimestamps
	ifInOctets	ipOutDiscards	icmpTimestampReps
	ifInUcastPkts	ipOutNoRoutes	icmpInAddrMasks
	ifInNUcastPkts	ipReasmTimeout	icmpInAddrMaskReps
	ifInDiscards	ipReasmReqds	icmpOutMsgs
	ifInErrors	ipReasmOKs	icmpOutErrors
	ifInUnknownProtos	ipReasmFails	icmpOutDestUnreachs
	ifOutOctets	ipFragOKs	icmpOutTimeExcds
	ifOutUcastPkts	ipFragFails	icmpOutParmProbs
	ifOutNUcastPkts	ipFragCreates	icmpOutSrcQuenchs
	ifOutDiscards	ipAdEntAddr	icmpOutRedirects
	ifOutErrors	ipAdEntIfIndex	icmpOutEchos
	ifOutQLen	ipAdEntNetMask	icmpOutEchoReps
	ifSpecific	ipAdEntBcastAddr	icmpOutTimestamps
		ipAdEntReasmMaxSize	icmpOutTimestampReps
		ipRouteDest	icmpOutAddrMasks
		ipRouteIfIndex	icmpOutAddrMaskReps
		ipRouteMetric1	
		ipRouteMetric2	
		ipRouteMetric3	
		ipRouteMetric4	
		ipRouteNextHop	
		ipRouteType	
		ipRouteProto	
		ipRouteAge	
		ipRouteMask	
		ipRouteMetric5	
		ipRouteInfo	
		ipNetToMediaIfIndex	
		ipNetToMediaPhysAddress	
		ipNetToMediaNetAddress	
		ipNetToMediaType	
		ipRoutingDiscards	

Address Translation MIB	TCP MIB	UDP MIB	SNMP MIB
atIfIndex	tcpRtoAlgorithm	udpInDatagrams	snmpInPkts
atPhysAddress	tcpRtoMin	udpNoPorts	snmpOutPkts
atNetAddress	tcpRtoMax	udpInErrors	snmpInBadVersions
	tcpMaxConn	udpOutDatagrams	snmpInBadCommunityNames
	tcpActiveOpens	udpLocalAddress	snmpInBadCommunityUses
	tcpPassiveOpens	udpLocalPort	snmpInASNParseErrs
	tcpAttemptFails		snmpInTooBigs
	tcpEstabResets		snmpInNoSuchNames
	tcpCurrEstab		snmpInBadValues
	tcpInSegs		snmpInReadOnlys
	tcpOutSegs		snmpInGenErrs
	tcpRetransSegs		snmpInTotalReqVars
	tcpConnState		snmpInTotalSetVars
	tcpConnLocalAddress		snmpInGetRequests
	tcpConnLocalPort		snmpInGetNexts
	tcpConnRemAddress		snmpInSetRequests
	tcpConnRemPort		snmpInGetResponses
	tcpInErrs		snmpInTraps
	tcpOutRsts		snmpOutTooBigs
			snmpOutNoSuchNames
			snmpOutBadValues
			snmpOutGenErrs
			snmpOutGetRequests
			snmpOutGetNexts
			snmpOutSetRequests
			snmpOutGetResponses
			snmpOutTraps
			snmpEnableAuthenTraps
			snmpSilentDrops
			snmpProxyDrops

RFC1317 RS-232-like Groups

RS-232 MIB	Async Port MIB
rs232Number	rs232AsyncPortIndex
rs232PortIndex	rs232AsyncPortBits
rs232PortType	rs232AsyncPortStopBits
rs232PortInSigNumber	rs232AsyncPortParity
rs232PortOutSigNumber	
rs232PortInSpeed	
rs232PortOutSpeed	

Input Signal MIB	Output Signal MIB
rs232InSigPortIndex	rs232OutSigPortIndex
rs232InSigName	rs232OutSigName
rs232InSigState	rs232OutSigState

Moxa-NP5600-DT-G2-MIB

overview	basicSetting	networkSetting	opModeSetting
modelName	serverName	ipConfiguration	portIndex
serialNumber	serverLocation	sysIpAddress	portApplication
firmwareVersion	timeZone	netMask	portMode
macAddress	localTime	defaultGateway	
viewLanSpeed	timeserver	dnsServer1IpAddr	
viewLanModuleSpeed		dnsServer2IpAddr	
upTime		pppoeUserAccount	
moduleType		pppoePassword	
configCRC32		winsFunction	
		winsServer	
		lan1Speed	
		routingProtocol	
		gratuitousArp	
		gratuitousArpSendPerios	

deviceControl Mode	socket Mode
deviceControlTcpAliveCheck	socketTcpAliveCheck
deviceControlMaxConnection	socketInactivityTime
deviceControlIgnoreJammedIp	socketMaxConnection
deviceControlAllowDriverControl	socketIgnoreJammedIp
deviceControlSecure	socketAllowDriverControl
deviceControlLocalTcpPort	socketSecure
deviceControlConnectionDownRTS	socketLocalTcpPort
deviceControlConnectionDownDTR	socketCmdPort
	socketTcpServerConnectionDownRTS
	socketTcpServerConnectionDownDTR
	socketTcpClientDestinationAddress1
	socketTcpClientDestinationPort1
	socketTcpClientDestinationAddress2
	socketTcpClientDestinationPort2
	socketTcpClientDestinationAddress3
	socketTcpClientDestinationPort3
	socketTcpClientDestinationAddress4
	socketTcpClientDestinationPort4
	socketTcpClientDesignatedLocalPort1
	socketTcpClientDesignatedLocalPort2
	socketTcpClientDesignatedLocalPort3
	socketTcpClientDesignatedLocalPort4
	socketTcpClientConnectionControl
	socketUdpDestinationAddress1Begin
	socketUdpDestinationAddress1End
	socketUdpDestinationPort1
	socketUdpDestinationAddress2Begin
	socketUdpDestinationAddress2End
	socketUdpDestinationPort2
	socketUdpDestinationAddress3Begin
	socketUdpDestinationAddress3End
	socketUdpDestinationPort3
	socketUdpDestinationAddress4Begin
	socketUdpDestinationAddress4End
	socketUdpDestinationPort4
	socketUdpLocalListenPort

pairConnection Mode	ethernetModem Mode
pairConnectionTcpAliveCheck	ethernetModemTcpAliveCheck
pairConnectionSecure	ethernetModemTcpPort
pairConnectionDestinationAddress	
pairConnectionDestinationPort	
pairConnectionTcpPort	

terminal Mode	reverseTerminal Mode
terminalTcpAliveCheck	reverseTerminalTcpAliveCheck
terminalInactivityTime	reverseTerminalInactivityTime
terminalAutoLinkProtocol	reverseTerminalTcpPort
terminalPrimaryHostAddress	reverseTerminalAuthenticationType
terminalSecondHostAddress	reverseTerminalMapKeys
terminalTelnetTcpPort	
terminalSshTcpPort	
terminalType	
terminalMaxSessions	
terminalChangeSession	
terminalQuit	
terminalBreak	
terminalInterrupt	
terminalAuthenticationType	
terminalAutoLoginPrompt	
terminalPasswordPrompt	
terminalLoginUserName	
terminalLoginPassword	

printer Mode	dial Mode	dataPacking
printerTcpAliveCheck	dialTERMBINMode	portPacketLength
printerTcpPort	dialPPPDMode	portDelimiter1Enable
printerGroup	dialSLIPDMode	portDelimiter1
printerQueueNameRaw	dialAuthType	portDelimiter2Enable
printerQueueNameASCII	dialDisconnectBy	portDelimiter2
printerAppendFromFeed	dialDestinationIpAddress	portDelimiterProcess
	dialSourceIpAddress	portForceTransmit
	dialIpNetmask	
	dialTcpIpCompression	
	dialInactivityTime	
	dialLinkQualityReport	
	dialOutgoingPAPID	
	dialPAPPassword	
	dialIncomingPAPCheck	

comParamSetting	dataBuffering	modemSetting
portAlias	portBufferingEnable	portEnableModem
portInterface	portBufferingLocation	portInitialString
portBaudRate	portBufferingSDFileSize	portDialUp
portBaudRateManual	portSerialDataLoggingEnable	portPhoneNumber
portDataBits		
portStopBits		
portParity		
portFlowControl		
portFIFO		
portOnDelay		
portOffDelay		

welcomeMessage	sysManagement
portEnableWelcomeMessage	enableAccessibleIpList
portMessage	accessibleIpListIndex
	activeAccessibleIpList
	accessibleIpListAddress
	accessibleIpListNetmask
	snmpEnable
	snmpContactName
	snmpLocation
	dDNSEnable
	dDNSServerAddress
	dDNSHostName
	dDNSUserName
	dDNSPassword
	hostTableIndex
	hostName
	hostIpAddress
	routeTableIndex
	gatewayRouteTable
	destinationRouteTable
	netmaskRouteTable
	metricRouteTable
	interfaceRouteTable
	userTableIndex
	userNameUserTable
	passwordUserTable
	phoneNumberUserTable
	radiusServerIp
	radiusKey
	udpPortAuthenticationServer
	radiusAccounting
	sysLocalLog
	networkLocalLog
	configLocalLog
	opModeLocalLog
	mailWarningColdStart
	mailWarningWarmStart
	mailWarningAuthFailure
	mailWarningIpChanged
	mailWarningPasswordChanged
	trapServerColdStart
	trapServerWarmStart
	trapServerAuthFailure
	alarmServerEthernet1LinkDown
	alarmServerEthernet2LinkDown
	alarmServerEthernet3LinkDown
	mailDCDchange
	trapDCDchange
	alarmDCDchange
	mailDSRchange
	trapDSRchange
	alarmDSRchange
	emailWarningMailServer
	emailRequiresAuthentication
	emailWarningUserName
	emailWarningPassword
	emailWarningFromEmail
	emailWarningFirstEmailAddr
	emailWarningSecondEmailAddr

welcomeMessage	sysManagement
	emailWarningThirdEmailAddr
	emailWarningFourthEmailAddr
	snmpTrapReceiverIp
	trapVersion
	httpConsole
	httpsConsole
	telnetConsole
	sshConsole
	lcmReadOnlyProtect
	resetButtonFunction
	loadFactoryDefaultSetting
	maxHttpLoginUsers
	autoLogoutSetting
	loginNotificationMessage
	loginFailureMessage
	userAccountIndex
	activeUserAccount
	accountName
	accountGroupName
	groupName
	networkConfig
	serialConfig
	systemConfig
	adminConfig
	monitorLogWarning
	commonSetting
	pwdMinLength
	pwdComplexityCheckEnable
	pwdComplexityCheckDigitEnable
	pwdComplexityCheckAlphabetEnable
	pwdComplexityCheckSpecialCharEnable
	pwdLifetime
	loginFailureLockoutEnable
	loginFailureLockoutRetrys
	loginFailureLockoutTime

sysStatus	saveConfiguration	restart
remoteIpIndex	saveConfig	restartPorts
monitorRemoteIp		restartSystem
monitorTxCount		
monitorRxCount		
monitorTxTotalCount		
monitorRxTotalCount		
monitorDSR		
monitorDTR		
monitorRTS		
monitorCTS		
monitorDCD		
monitorErrorCountFrame		
monitorErrorCountParity		
monitorErrorCountOverrun		
monitorErrorCountBreak		
monitorBaudRate		
monitorDataBits		
monitorParity		
monitorRTSCTSFlowControl		
monitorXONXOFFFlowControl		
monitorFIFO		

sysStatus	saveConfiguration	restart
monitorInterface		
monitorRTSToggleFlowControl		
relayOutputEthernet1LinkDown		
ethernet1LinkDownAcknowledge		
relayOutputEthernet2LinkDown		
ethernet2LinkDownAcknowledge		
relayOutputEthernet3LinkDown		
ethernet3LinkDownAcknowledge		
portDCDChangedStatus		
portDCDChangedAcknowledge		
portDSRChangedStatus		
portDSRChangedAcknowledge		

E. Event List

The NPort 5600-DT-G2 provides event logs to help users troubleshoot. The events that may be recorded are listed below.

Item	Category	Severity	Default Setting	Event Name	Description
1	System	Notice	Disable	Firmware ready	The system is ready for operation.
2		Notice	Disable	User trigger reboot	The device was rebooted by the user.
3		Informational	Disable	Configuration changed	A user changed the configuration setting, and the new settings are activated.
4		Notice	Disable	Configuration changed failed	A user changed the configuration setting, but the new settings activated failed.
5		Informational	Disable	NTP success	The device synchronizes the time with the NTP server successfully.
6		Warning	Disable	NTP fail	The device failed to synchronize the time.
7		Informational	Disable	Manual setting time success	Manual setting time success.
8		Notice	Disable	Email failure	The device failed to deliver the email message.
9		Notice	Disable	SNMP inform fail	The device failed to deliver an SNMP Inform message.
10		Notice	Disable	Email service is back	Email service resumed; the event recorded for successfully sending after a failure.
11		Notice	Disable	SNMP inform service is back	The SNMP information service resumed; the event recorded for successfully sending after a failure.
12		Informational	Disable	LCM display ready	The system detects the LCM display, and it's ready for use.
13		Notice	Disable	LCM display does not work	The system detects the LCM display, but it doesn't work.
14	Network	Informational	Disable	Ethernet link up	The Ethernet port is linked up.
15		Notice	Disable	Ethernet link down	The Ethernet port is linked down.
16		Notice	Disable	IP changed	A user changed the network configuration setting, and the new settings are activated.
17		Error	Disable	IP conflict	The device detects an IP conflict; this may make the device malfunction.
18		Warning	Disable	Not getting IP from DHCP server	The device shall get an IP address from the DHCP server, but it failed.
19		Warning	Disable	Connect DHCP server fail	The device cannot find a DHCP server on the network.
20		Notice	Disable	Using 169.254.x.x IP	The device is using 169.254.x.x IP address, which is abnormal.
21	Informational	Disable	IP renew	IP of the device is renewed (with DHCP enabled).	
22	Security	Warning	Enable	Clear log	Clear all the system logs on the device.
23		Informational	Disable	System log export	The system log is exported.
24		Notice	Enable	Log threshold reached	The number of log events reached the threshold setting.
25		Informational	Disable	Login success	A user with the IP address logged in to the device successfully.
26		Notice	Enable	Login fail	A user from the IP address try to log in to the device but failed.
27		Informational	Disable	Account/group changed	A user changed the configuration setting of username, password or group privilege.
28		Warning	Enable	Account lockout	An account is locked out because he failed to log in too many times.

Item	Category	Severity	Default Setting	Event Name	Description	
29		Informational	Disable	Service enabled	The device enables the service successfully.	
30		Notice	Enable	Service disabled	The device disables the service successfully.	
31		Warning	Enable	Service enabled/disabled failed	The device enables/disables the service unsuccessfully.	
32		Informational	Disable	Syslog certificate export	The Syslog certificate was exported.	
33		Notice	Enable	Syslog certificate import	The Syslog certificate was imported.	
34		Notice	Enable	Syslog certificate deleted	The Syslog certificate was deleted.	
35		Notice	Enable	Syslog certificate expired	The Syslog certificate was expired.	
36		Informational	Disable	Syslog certificate will expire	The Syslog certificate will expire in one month.	
37		Informational	Disable	SSL certificate export	The SSL certificate was exported.	
38		Notice	Enable	SSL certificate import	The SSL certificate was imported.	
39		Notice	Enable	SSL certificate deleted	The SSL certificate was deleted.	
40		Notice	Enable	SSL certificate expired	The SSL certificate was expired.	
41		Notice	Enable	SSL certificate regenerated	The SSL certificate was regenerated.	
42		Warning	Enable	DoS Defense is triggered	The DoS Defense functions were triggered.	
43		Informational	Disable	Password reached lifetime	The account's password reached the lifetime.	
44		Maintenance	Informational	Disable	Firmware upgrade	The firmware was upgraded.
45			Warning	Disable	Firmware upgrade fail	A user tried to upgrade the firmware, but the device rejected it because of the wrong file format/checksum error.
46			Notice	Disable	Configuration import	The config file was imported.
47			Warning	Disable	Configuration import fail	The device failed to import a config file because of the wrong file format or invalid authentication.
48			Informational	Disable	Configuration export	The config file was exported.
49	Notice		Disable	Load factory default	Load factory default.	
50	Notice		Disable	Load customized default	Load customized default.	
51	Notice		Disable	Log collection	When using it, select the One-click data collection function to collect the event logs and relative information for diagnostic purposes, the device will record this event.	
52	Serial	Informational	Disable	Serial port CTS changed	The CTS signal of the serial port is turned ON from OFF or is turned OFF from ON.	
53		Informational	Disable	Serial port DSR changed	The DSR signal of the serial port is turned ON from OFF or is turned OFF from ON.	
54		Informational	Disable	Serial port DCD changed	The DCD signal of the serial port is turned ON from OFF or is turned OFF from ON.	
55		Notice	Disable	Port OP mode disabled	The operation mode of the port is disabled; the port cannot be connected by any network devices.	
56		Informational	Disable	Port connect	The session is connected to the port.	
57		Notice	Disable	Port disconnect	The session is disconnected from the port.	
58		Error	Disable	Port authentication fail	A user failed to log in to the port in terminal, Reverse Terminal, or dial-in/out operation modes.	

Item	Category	Severity	Default Setting	Event Name	Description
59		Notice	Disable	Port restart	The serial port has restarted.
60		Notice	Disable	Serial data error	There is an error that occurred in the received serial data of the port, for example, a framed error, parity error, or overrun error.

F. Command List of the Serial Console

The NPort 5600-DT-G2 provides a serial console as a command-line interface for users who prefer to log in with the serial port. The serial console only supports limited configuration settings. View the basic information and configure the network settings.

When you first enter the serial console, input **?** to view a list of basic commands and the description of each command.

```
#
# ?
show           - Show running system information
configure      - Enter configuration mode
reload         - Halt and perform a cold restart
quit           - Exit command line interface
# _
```

For users with READ privilege on the serial console, execute the **show** command to view relative settings. For users with WRITE privilege, execute the **configure** command to set or modify relative settings.

Input **# configure** to access the subcategory to show or change the network-related settings.

Set static IP address of the network interface:

Syntax Description	ip	Configure IP parameters
	address	Configure IPv4 address parameters
	static	Configure static IPv4 address
	<i>ipv4-address</i>	The IPv4 address
	<i>ipv4-netmask</i>	The IPv4 subnet mask
	dhcp	Assign the IPv4 address by DHCP
Defaults	IPv4 Address: 192.168.127.254 IPv4 Netmask: 255.255.255.0 IPv4 Gateway: 0.0.0.0	
Command Modes	Global Configuration	
Usage Guidelines	N/A	
Examples	# configure (config)# ip address static 192.168.127.254 255.255.255.0	
Related Commands	no ip address	

Set the default gateway:

Syntax Description	ip	Configure IP parameters
	default-gateway	Configure IPv4 default gateway address
	<i>ipv4-address</i>	The IPv4 address
Defaults	N/A	
Command Modes	Global Configuration	
Usage Guidelines	N/A	
Examples	# configure (config)# ip default-gateway 192.168.127.1	
Related Commands	no IP address	

Show the network status:

Syntax Description	show	Display configuration/status information
	ip	Display IP information
	management	Display IP information
Defaults	N/A	
Command Modes	Privileged EXEC	
Usage Guidelines	N/A	
Examples	# show ip management IPv4 IP configuration : DHCP IP address : 192.168.127.254 Subnet mask : 255.255.255.0 Default gateway : 0.0.0.0 DNS server : 0.0.0.0 #	
Related Commands	N/A	

You can input # reload to access the sub-category to show or change the network-related settings.

Restart the device:

Syntax Description	reload	Halt and perform a cold restart.
Defaults	N/A	
Command Modes	Privileged EXEC	
Usage Guidelines	N/A	
Examples	# reload Proceed with reload? [y/n] y Resetting system...	
Related Commands	N/A	

Reset the device to factory default settings:

Syntax Description	reload	Halt and perform a cold restart.
	factory-default	Halt and perform a cold restart with factory default.
Defaults	N/A	
Command Modes	Privileged EXEC	
Usage Guidelines	N/A	
Examples	# reload factory-default Proceed with reload to factory default? [y/n] y Reset to factory default...	
Related Commands	N/A	

Logout the serial console:


Syntax Description	quit	Logout from the command line interface.
Defaults	N/A	
Command Modes	Privileged EXEC	
Usage Guidelines	N/A	
Examples	# quit	
Related Commands	N/A	

G. How to Become a Registered User

By becoming a registered user of Moxa.com, you gain access to all updates for your purchased or interested products, including software and documentation. To become a registered user and receive all updates, you need to do the following:

Register a Moxa Account

1. Go to Moxa.com and select '**Sign in**' at the top-right corner.



2. On the Sign-in page, select "[Create your Moxa member account](#)" as below.'

A screenshot of the Moxa sign-in page. The title is 'Please sign in'. It contains two input fields: 'Email*' and 'Password*'. Below the email field is a red error message: 'Please input your email address'. Below the password field is a red error message: 'Password is required'. There is a 'Forgot your password?' link. A teal 'SIGN IN' button is centered below the fields. At the bottom, there is a link: 'Not a member? [Create your Moxa member account](#)'.

3. Fill the necessary fields.

Create New Account

Work Email*

First Name* Last Name*

Company*

Phone*

Region*

--Select--

Please input a password*


Request for Product Updates

1. Go to the specific product page to receive updates. Select **" + FOLLOW UPDATE "**

Home > Products > Industrial Edge Connectivity > Serial Device Servers > Terminal Servers > NPort 6100/6200 Series

NPort 6100/6200 Series

1/2-port RS-232/422/485 secure terminal servers



Features and Benefits

- Secure operation modes for Real COM, TCP Server, TCP Client, Pair Connection, Terminal, and Reverse Terminal
- Supports nonstandard baudrates with high precision
- NPort 6250: Choice of network medium: 10/100BaseT(X) or 100BaseFX
- Enhanced remote configuration with HTTPS and SSH
- Port buffers for storing serial data when the Ethernet is offline
- Supports IPv6
- Generic serial commands supported in Command-by-Command mode
- Security features based on IEC 62443

Certifications

CE FC UL LIST

GET A QUOTE + FOLLOW UPDATES

2. Once completed, see the FOLLOW UPDATES button change.

