

Product Change Notification—PCN# PCN001250

November 2, 2026

Dear Valued Customer,

We would like to inform you that Moxa is going to make changes to the EJS-04 and EJS-08 Series. These changes will be implemented through a running change starting on April 01, 2027. Please review the details below to determine how these changes will affect your products and/or operations.

What will change?

To improve EtherCAT network diagnostic capability, the EJS Series will be revised to replace the current PHY with a new PHY chip that supports additional nibble packet forwarding.

The current version did not support this function, which could result in abnormal behavior in certain EtherCAT diagnostic features. With this revision, the updated PHY enables support for Extra Nibble Packet Forwarding, thereby improving compatibility and ensuring proper operation of the related EtherCAT diagnostic functions.

This change is implemented at the hardware level only. Product form, fit, and intended functionality remain unchanged, except for the enhancement described below.

The following changes will be implemented in the new versions:

- Adding support for additional nibble packet forwarding
- RUN LED behavior change
- Power input marking change

Which products will be affected?

Product Name	Current Version	New Version
EJS-04	V1.0.0	V1.1.0
EJS-04-T	V1.0.0	V1.1.0
EJS-08	V1.0.0	V1.1.0
EJS-08-T	V1.0.0	V1.1.0

When will the new versions be available?

Product Name	New Version	Available for Order
EJS-04 Series	V1.1.0	April 01, 2027
EJS-08 Series	V1.1.0	April 01, 2027

If you have any questions, please contact your regional sales representative.